

RF75 user manual

1. Bank1 SPI setting

RF75 bank1 setting is same with RF73.

To use RF73 bank 1 setting, RF75 can work properly. In order to achieve better performance, pls use the following setting.

Bank1	250KHz	1MHz	2MHz
Address (Hex)			
00	Reserved	Reserved	Reserved
01	Reserved	Reserved	Reserved
02	Reserved	Reserved	Reserved
03	Reserved	Reserved	Reserved
04	0xDB8A96F9	0x1B8296F9	0xDB8296F9
05	0xB60F0624	0xA60F0624	0xB60F0624
06	Reserved	Reserved	Reserved
07	Reserved	Reserved	Reserved
08	Reserved	Reserved	Reserved
09	Reserved	Reserved	Reserved
0A	Reserved	Reserved	Reserved
0B	Reserved	Reserved	Reserved
0C	0x00127300	0x00127300	0x00127300
0D	0x36B48000	0x36B48000	0x36B48000
0E	0x 412008048120CFF7FEFFFF	0x 412008048120CFF7FEFFFF	0x 412008048120CFF7FEFFFF



2. TX output power setting

RF75 TX output setting is different with RF73, RF75 setting is below:

Bank1.Reg4<29:27>	Bank0.Reg6<2:1>	TX Power(dBm)	
7	3	4	
0	3	-1	
0	2	-7	
2	1	-12	
3	1	-12	
0	1	-18	
3	0	-18	
0	0	-25	
Others	-1		

3. RSSI Threshold

RF75 RSSI threshold couldn't be adjusted.

	250KHz	1MHz	2MHz
RSSI Threshold(dBm)	-84	-80	-67

4. 5V IO operation

In some applications, MCU IO logic level is higher than RF75 voltage. For example, when RF75 voltage is 3.3V, and MCU IO logic level, pls connect 2kohm resistor with each of SCK, CE,CSN, MOSI pin.



5. application schematics




Fig 1 RF75 Application schematic



6. Contact Information

HOPE MICROELECTRONICS CO.,LTD

Add: 2/F, Building 3, Pingshan Private Enterprise Science and Technology Park, Lishan Road, XiLi Town, Nanshan District, Shenzhen, Guangdong, China

Tel: 86-755-82973805
Fax: 86-755-82973550
Email: sales@hoperf.com
Website: http://www.hoperf.com
http://www.hoperf.cn

HOPE MICROELECTRONICS CO.,LTD

Add: 2/F, Building 3, Pingshan Private Enterprise Science and Technology Park, Lishan Road, XiLi Town, Nanshan District, Shenzhen, Guangdong, China

Fax: 86-755-82973550
Email: sales@hoperf.com
Website: http://www.hoperf.com
http://www.hoperf.cn

Tel: 86-755-82973805

This document may contain preliminary information and is subject to change by Hope Microelectronics without notice. Hope Microelectronics assumes no responsibility or liability for any use of the information contained herein. Nothing in this document shall operate as an express or implied license or indemnity under the intellectual property rights of Hope Microelectronics or third parties. The products described in this document are not intended for use in implantation or other direct life support applications where malfunction may result in the direct physical harm or injury to persons. NO WARRANTIES OF ANY KIND, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MECHANTABILITY OR FITNESS FOR A ARTICULAR PURPOSE, ARE OFFERED IN THIS DOCUMENT.

©2006, HOPE MICROELECTRONICS CO.,LTD. All rights reserved.