17 TV Update Check

- 17.1 ULI Update17.2 USB update

17.1 ULI Update

	ULI Update Requirements	Details
1	The TV can receive updates from VIZIO via ULI.	
2	At power down. or shortly thereafter, the TV board wakes up (displays remains off), and checks ULI for an update.	
3	software update.	Platform: Qterics ULI checks for firmware update DLM: checks for app binaires, the update of SmartCast Platform software (including REST), SmartCast servers checking for code too big to add to the build.
4	If an update is available, then the update is downloaded and installed.	
5	At power on, TV displays a notification of the update.	
6	If powered on while installing the update, a message displays indicating an update is in progress, a progress bar displays, and the LED is flashing. A reboot is performed to complete the update installation.	
7	If powered on while downloading, the update is aborted. No message presented.	

17.2 USB update

	USB Update	Details
1	If a USB stick is inserted with an update, the update begins immediately.	
2	• A • T • O • T • A • A	/hile the update downloads and installs, a warning displays progress bar displays as the update downloads. he LED is flashing while the update downloads and installs. ther than power down, no response to IR or IP controls. V powers down and reboots. s the update is installed a progress bar displays. t power on, TV displays a notification of the update the USB update fails, then a message displays.