

START-UP

BATTERIES 1, 2, 3 ON
EXT PWR CONNECT/ON
IF EXT PWR NO AVAIL -> APU
APU LOOP TEST TESTED
INR TK PMP 2 ON
APU MASTER ON
APU START ON
APU BLEED ON
PITCH TRIM ON

FMS CONFIG

INTI ALIGN IRS SET
INIT REQUEST SIMBRIEF OR SET
F-PLN SET DEPARTUR SID
F-PLN ROUTE CHECK
INIT PAGE 2 SET
TAKEOFF PERF SET

CREW CHECK

ENG 1 LOOP TEST TESTED
ENG 2 LOOP TEST TESTED
ANN LT TESTED
FLT RECORDER TESTED
WINDOWS HEAT AS RQRD
PROBES AS RQRD
ELEC IND
EMER & ESS SELECT
BATTERIES DC CHECK

BEFORE PUSH & START

IF NO APU START

APU LOOP TEST TESTED
APU MASTER ON
APU START ON
APU BLEED ON
PITCH TRIM ON
CABIN DOOR LOCKED
EXT PWR OFF
ALL FUEL PUMP ON
FLEX TO TEMP FLX TO & SET
AP HEADING SET
AP SPD/MACH SET V2
AP ALT SEL SET INITIAL CLIMB

COCKPIT PREPARATION

IRS NAV
SEATBELTS SIGN ON
SMOKING SIGN AUTO
EMERG EXT LIGHT ARMED
GND CTL ON
NAV & LOGO ON (1)
STROBE AUTO
WING AS RQRD
ATS ON
YAW DAMPER ON
GALLEY ON
LO PR SUPPLY ON
ALTIMETER SET
LANDING ELEVATION SET
SQUAWK SET

PUSH & START

BEACON ON
WINDOWS HEAT ON
PROBES ON
IGNITION A OR B
ENG 2 START
WAITING N2=20%
FUEL ENG 2 OPEN
REPEAT FOR ENG 1
APU BLEED OFF
IGNITIONS OFF
APU MASTER OFF



CHECKLIST

A310

By chiken

BEFORE TAXI

TRIMSET
FLAPSSET
SPOILERARM
AUTO BRAKESMAX
AP NAVON
CSTRON
NOSE LIGHTTAXI
RUNWAY LIGHTAS RQRD
FLIGHT CONTROLCHECK FREE

CLIMB

CLIMB WITH PROFILE OR VL
ANTI ICE AS RQRD
FLEX TO TEMP CL
AT TRANS ALT FL100
ALTIMETER STD(29.92)
SEATBELT SIGN OFF
LANDING LIGHT OFF
WEATHER RADAR AS RQRD

BEFORE TAKE OFF

SQUAWK TA/RA OF TA
LANDING LIGHT ON
PACKS OFF
NOSE LIGHT TO

TAKE OFF

N1=40% RELEASE BRAKE AND SET A/THR
VR ROTATE

AFTER TAKE OFF

GEAR UP
PACKS ON
SPOILER DISARM
RUNWAY LIGHT OFF
NOSE LIGHT OFF
WING LIGHT OFF
FLAPS RETRACT
AP ACTIVATE

CRUISE

FLEX TO TEMP CR
ECAM CHECK
APPROACH SELECT

DESCENT

MANAGE SPEED
AT TRANS ALT FL100
LANDING LIGHT ON
SEATBELT SIGN ON
FLEX AUTO

BEFORE LANDING

ANTI ICE OFF
FMS FINAL APPROACH ON
FLAPS SET
SPOILER ARM
GEAR DOWN
AUTO BRAKE AS RQRD
NOSE LIGHT ON
AUTO LAND OR MANUAL LANDING



CHECKLIST

A310

By chiken

LANDING

TROTTE.....OFF WHEN 70 GS
AUTOBRAKE.....OFF WHEN 20 GS

AFTER LANDING

FLAPS RETRACT
SPOILER RETRACT
LANDING LIGHT OFF
NOSE LIGHT TAXI
RUNWAY LIGHT AS QRDR
STROBE OFF
APU MASTER START
APU START ON
SQUAWK STANDBY

SHUTDOWN

WINDOWS HEAT OFF
PROBES OFF
ATS OFF
YAW DAMPER OFF
PITCH TRIM OFF
GALLEY OFF
SMOKING SING OFF
LO PR SUPPLY OFF
EMERG EXT LIGHT DISARMED
EXT PWR OR APU OFF
BATTERIES 1, 2, 3 OFF

SECURING AND DEBOARD

PARKING BRAKE ON
FUEL ENG 1 & 2 OFF
BEACON OFF
CABIN DOOR UNLOCK
NOSE LIGHT OFF
RUNWAY LIGHT OFF
STROBE OFF
LOGO & NAV OFF
APU BLEED ON
SEATBELT SIGN OFF
ALL FUEL PUMP OFF

IF EXT PWR IS AVAIL

EXT PWR CONNECT/ON
APU MASTER OFF
APU BLEED OFF