

Quick Start — Load Calculator (Basic)

Version 1.1.2

1. WHAT THIS CALCULATOR DOES

This calculator estimates **generator electrical load** for a field hospital–style site using **kilowatts (kW)** only. You enter how many of each listed equipment items you expect to run, and it totals load, suggests a **rough generator size** using an 80% loading rule, and lets you **check your plan against an available generator**. It also supports optional **fuel tank and runtime** estimates. It is simpler than the Pro version (no separate “power factor” or peak motor-starting math). Use it for **planning conversations**; final electrical design needs a qualified engineer.

2. BEFORE YOU START

- A list or rough count of **major equipment** you expect (the calculator groups items by category).
- Optional: the **available generator size** in kW you want to compare against.
- Optional: **fuel tank size** and planning values for fuel use, if you want a runtime estimate.
- A **scenario name** and any **notes or assumptions** you want stored with a saved plan.

3. HOW TO USE IT — STEP BY STEP

1. Open the Load Basic calculator from the suite.
2. Expand equipment **categories** and enter **quantities** for each item you expect to use. The tool multiplies quantity by each item’s fixed kW to build row and category totals.
3. Use **search** if you need to find equipment quickly; the sidebar can show both **total load for everything** and, while searching, load for **only what is visible**.
4. Review the **load summary** in the sidebar: total connected load, recommended generator size at 80% loading, and — if you entered it — how your load compares to **available generator capacity** (including a simple status such as adequate margin, tight, or insufficient).
5. Optional: enter **fuel** information to see approximate runtime.
6. Use **Reset Quantities** to zero amounts only, or **Reset Worksheet** for a fuller clear including scenario fields and search.
7. When satisfied, **save a scenario**, **export**, or **print** as needed.

4. UNDERSTANDING THE RESULTS

Total connected load is the sum of all equipment you entered — your main planning total. **Filtered view load** appears when you search and shows load for visible rows only, to support focused review. **Recommended generator** applies a standard continuous-load margin (planning at 80% of generator capacity). The **capacity check** compares your total to a generator you specify so you can see percent used and a quick status. **Fuel runtime** is an estimate from your tank size and consumption assumptions. All of this supports **preliminary generator and fuel planning**, not final engineering sign-off.

5. SAVING YOUR WORK

Save a **named scenario** with **Save scenario** when you want a version you can reload later in this browser. Use **Export to file** to keep a backup or send your plan to someone else. If something disappears from the screen, try **Restore Autosave** on the toolbar to recover the last automatically saved worksheet state.

Field Hospital Calculator Suite v1.1.2

For planning use only. Verify all outputs with qualified personnel before deployment.