

Quick Start — Load Calculator (Pro)

Version 1.1.2

1. WHAT THIS CALCULATOR DOES

This calculator estimates **electrical load** for a field hospital–style site in more detail than the Basic version. It uses both **kilowatts** (useful power) and **kilovolt-amperes** (a common way generators are rated), lets you adjust **how each item is modeled electrically** where the form allows, estimates **extra demand when large equipment first starts**, suggests a **generator size** that considers both steady running load and that starting spike, and can estimate **fuel runtime**. You can adjust built-in equipment values and add custom rows. It is for **planning and engineering review support**, not as a substitute for a qualified electrical engineer's final design.

2. BEFORE YOU START

- Rough **equipment list** and quantities, including any items not on the standard lists (you can add custom rows).
- If known, the **actual generator size** you want to check against (in kVA).
- Optional: **fuel tank capacity** and consumption assumptions for runtime.
- A **scenario name** and **notes** if you plan to save versions.

3. HOW TO USE IT — STEP BY STEP

1. Open the Load Pro calculator from the suite.
2. Go through each **category** and enter **quantities**. Where the table allows, adjust **power draw per item** and the **power factor (PF)** for each row if your equipment differs from the defaults.
3. Use **Add custom row** where needed, and remove rows you do not need.
4. Use **search** to focus the list; the sidebar shows **totals for all equipment** and, when searching, **subtotals for visible rows**.
5. Review the **summary**: running load, peak starting demand, recommended generator size, and the **generator capacity check** against the size you enter (including status such as adequate margin, tight, insufficient, or peak-start failure).
6. Optional: enter **fuel** information for approximate runtime.
7. Use category resets or full sheet reset tools if you need to start over.
8. **Save**, **export**, or **print** when the plan is ready.

4. UNDERSTANDING THE RESULTS

Running load describes steady operation. **Peak starting** reflects a conservative estimate of the worst moment when a large motor-type load starts while other equipment is already running — important for picking a generator that will not trip or overload. **Recommended generator size** takes the larger of that peak need and a standard continuous-load margin. The **capacity check** shows how your plan compares to a real generator you specify. **Fuel runtime** is a simple estimate from load and tank data. Together, these support **sizing discussions and engineering review**; they are not a code-compliant study by themselves.

5. SAVING YOUR WORK

Save a **named scenario** with **Save scenario** when you want a version you can reload later in this browser. Use **Export to file** to keep a backup or send your plan to someone else. If something disappears from the screen, try **Restore Autosave** on the toolbar to recover the last automatically saved worksheet state.

Field Hospital Calculator Suite v1.1.2

For planning use only. Verify all outputs with qualified personnel before deployment.