/alu/in_a	111a		0001	0011	1111	Ĭ	I	0100	0010	0000	1111	11xx	1111
/alu/in_b	0001	†	†	†	0011		+	†	†		†	xx11	1111
/alu/in_opcode	1	2	3	4	5	6	7	8	9	а	b	1	f
/alu/out_y	111b	1119	0002	0010	1111	0011	1100	0080	0020	ffff	eeef	XXXX	-
/alu/out_zero		-		+					-		-		-
/alu/out_carry		-		-							+		
	ps I				000 ps				000 ps				

Entity:alu Architecture:fast Date: Fri Apr 26 11:08:42 AM PDT 2013 Row: 1 Page: 1