



Produced by
Psion Teklogix Ltd

Jotter User Guide

Contents

JOTTER	1
Formatting the text	2
Inserting other information	2
Finding a note	2
Deleting entries	3
Customising Jotter	3
Sorting entries	3
Jotter files	3
Printing Jotter entries	3

JOTTER

Use the Jotter program to jot down notes and information quickly, for example, when you are on the phone or in a meeting.

You can keep each item of information as a separate entry, and search for text to find entries easily.

You may want to use a Jotter file as a quick and easy storage location for pieces of information, and then copy text to a more appropriate file or location later. Alternatively, you could have a number of Jotter files for different subjects or types of notes and keep the information for reference.




Displaying on-line help

To display on-line help, select the [Help on Jotter](#) option from the [Tools](#) menu.

Adding a note

- When you first start Jotter, you can start typing a note straight away. You can type as much text as you like or use the [Paste](#) command on the [Edit](#) menu to insert text from other programs.
- If your netpad is connected to your PC, you can use CopyAnywhere in PsiWin to copy text on your PC and paste it straight into a Jotter entry. You can find out more about CopyAnywhere by looking at the PsiWin on-line help.



- To insert special characters or symbols in the text use the [Special character](#) command on the [Insert](#) menu and select the character from the list.

Use the [View](#) button on the Toolbar to change between the Jotter views.

- **Edit view** displays one entry using the full width of the screen.
- **List view** displays a list of text from each entry.
- **Split view** shows the list and the text of the current entry.

You can add entries from any view.



Starting Jotter with a blank entry.

When you open a Jotter file, you will see the entry you were using the last time you opened the file. If you want to add an entry, you have to use the [New entry](#) button on the Toolbar. To save time when you want to quickly type a note, you can set up Jotter so that it always starts with a blank entry. To do this, use [Entry preferences](#) from the [Tools](#) menu.

Formatting the text

- **To insert a bullet:** Move the cursor to the paragraph and select the [Bullet](#) command from the [Text](#) menu. To remove a bullet from a paragraph, move the cursor to the paragraph and select the command again to remove the tick.
- **To format text:** Highlight the text you wish to format and use the commands on the [Text](#) menu to change the font, size of the text, underline the text or make it bold or italic.


Inserting other information

To insert the date:

- Select [Date](#) from the [Insert](#) menu. Note that Jotter can display either the date that you created the entry, or the date it was last changed. See '*Customising Jotter*' for more details.

To insert a sketch:

1. Select [Sketch](#) from the [Insert](#) menu, or tap the [Insert sketch](#) button on the Toolbar.
2. Draw the sketch, then tap the [Done](#) button to return to Jotter and insert the sketch.



To insert other objects, i.e. a graph, table, text or a sound, select [Other object](#) from the [Insert](#) menu and then select the program you want to use. Create the information you want to insert then tap [Done](#) when you've finished.

- You can include Sheet information as a graph or table - display the information as you want it to appear before tapping [Done](#).
- To change the appearance of a Sheet or Sketch object, select [Format Object](#) from the [Object](#) commands on the [Edit](#) menu. You can change the size, crop the edges or just display the object as an icon. Note that Jotter can only display inserted sounds and Word objects as icons so you cannot change any format settings.
- If you wish to make changes to a sketch, graph or other object in a Jotter entry, highlight the object and press Enter. Change the object as required, then tap [Done](#) to return to Jotter and update the object.

Finding a note

If you need to find a particular entry, you can:

- **browse for the entry in the List or Split view.** To display text from the entries in a list, tap the [View](#) button on the Toolbar and select either [List](#) or [Split](#). The List view may be useful if you can identify the entry from the first few words. The Split view shows the text in the current entry as well as the list.

- **search for text in the entry.** To do this, tap on the [Find](#) button on the Toolbar, or select the command from the [Edit](#) menu. Type the text you want to find, then press Enter to search all the entries and display the first entry that includes the text. Use [Next](#) and [Prev](#) to move between the entries in the search results. Tap [Done](#) to end the search and display all the entries again.

Deleting entries

If you don't want to keep a Jotter entry, select the entry and use [Delete entry](#) from the [Edit](#) menu to delete it. If you accidentally delete an entry, you can restore it by using [Undo delete entry](#) on the [Edit](#) menu.

Customising Jotter

You can change some aspects of how Jotter looks and works using the commands on the [Tools](#) menu.

- To display either the date you created an entry, or the date you last updated it, use [View preferences](#) in the Split view.
- You can display the list of entries in the Split view on the left or right, or change the proportion of the screen taken up by the entry and title list. To change these settings, move to the Split view and select [View preferences](#).
- You can change the amount of information included in the list of entries in the List and Split view using the [Entry preferences](#) command. You can display as much of the text as will fit (with a comma marking different paragraphs) or just the first line of the entry. You may want to do this if you want to use the first line of the entry as a title.

Sorting entries

Jotter lists entries in the order in which you add them, with the newest entries at the end of the list.

To sort entries into alphabetical or date order:

1. Select the [Sort](#) command from the [Tools](#) menu.
2. Specify how you wish to sort the entries, e.g. alphabetically or by date.
3. Specify whether to sort the entries in ascending or descending order. For date ordering, ascending order means that Jotter lists the most recently added or updated entries last.

Jotter files

If you wish to start a new Jotter file, select [Create new file](#) on the [File](#) menu.

To combine the entries of two Jotter files, first open one of the files in Jotter. Select [Merge in](#) from the [More](#) commands on the [File](#) menu, then select the name of the file you want to merge.

Printing Jotter entries

You can print the current entry or all the entries in the current view using the [Printing](#) commands on the [File](#) menu or by tapping the [Print](#) button on the Toolbar.

- To check the printer model: select [Print setup](#). If the printer model displayed is not the printer that you're using, use the [Printer](#) button to select the correct printer.
- To set up the page for printing: select [Page setup](#).
- To see how the information will look: select [Print preview](#).
- To print: select [Print](#), then choose whether to print just the current entry or all the entries in the current view and tap [Print](#).

Note: Refer to the instructions in the '[Printing](#)' document to select a printer.