

action Execute Fuel Transfer



<<action>>

Validate Fuel Compatibility



<<action>>

Confirm Fuel Type



<<action>>

Initiate Fuel Transfer



<<action>>

Monitor Flow & Stability



<<action>>

Emergency Shutdown



<<action>>

Complete Transfer



<<action>>

Adjust Flow Rate

