# axis\_tiny\_fifo.v

### **AUTHORS**

# JAY CONVERTINO

### **DATES**

### 2021/06/04

# **INFORMATION**

### **Brief**

**AXIS TINY FIFO** 

### **License MIT**

Copyright 2021 Jay Convertino

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

# axis\_tiny\_fifo

```
module axis_tiny_fifo #(
parameter
FIFO_DEPTH
=
4,
parameter
BUS_WIDTH
=
8
) ( input aclk, input arstn, output [(BUS_WIDTH*8)-1:0] m_axis_tdata, output
```

AXIS fifo that uses a shift register to buffer data. This Adds latency to the design in the amount of the FIFO\_DEPTH. Though if the destination isn't ready it will build up data to that FIFO\_DEPTH and overwrite any non-valid data inserted.

#### **Parameters**

FIFO\_DEPTH Number of transactions to buffer.

parameter

**BUS\_WIDTH** Width of the input/output bus in bytes.

parameter

#### **Ports**

aclk Clock for AXIS

arstn Negative reset for AXIS

m\_axis\_tdata Output data

m\_axis\_tvalid When active high the output data is valid

m\_axis\_tlast Indicates last word in stream.

**m\_axis\_tready** When set active high the output device is ready for data.

s\_axis\_tdata Input data

s\_axis\_tvalid When set active high the input data is valid
 s\_axis\_tlast Is this the last word in the stream (active high).
 s\_axis\_tready When active high the device is ready for input data.

# **VARIABLES**

## s axis tready

```
assign s_axis_tready = ~&reg_valid_buffer || m_axis_tready
```

If any valid is 0, we are ready for data

## m axis tdata

```
assign m_axis_tdata = reg_data_buffer[0]
```

assign output data as soon as its ready

## m axis tvalid

```
assign m_axis_tvalid = reg_valid_buffer[0]
```

assign output data as soon as its ready

# m\_axis\_tlast

```
assign m_axis_tlast = reg_last_buffer[0]
```

assign output data as soon as its ready