SIEMENS

INSTALLATION INSTRUCTIONS
Model K-CBL
Interface cable for use with Keltron 90 Series Miniprinter

Introduction

Model K-CBL is an interface cable which is used to connect a user supplied Keltron 90 Series Miniprinter to Siemens FireFinder XLS/Desigo Fire Safety Modular/Cerberus PRO Modular panel. The printer provides the RS232 interface such that when used with Siemens model K-CBL, P/N S54430-C24-A1, it can connect to PMI/PMI-2/PMI-3 (XLS), FCM2041-U2 (Desigo Fire Safety Modular), FCM2041-U3 (Cerberus PRO Modular). You may install one printer per fire panel to provide a paper record of panel activity.

For additional information on the FireFinder XLS/Desigo Fire Safety Modular/Cerberus PRO Modular System, refer to the FireFinder-XLS Control Panel Installation, Operation and Maintenance Manual, P/N 315-033744, the Desigo Fire Safety Modular Manual, Document ID A6V11231620, or the Cerberus PRO Modular Manual, Document ID A6V11231627.

The Keltron printer and its associated cabinet are to be mounted externally from the fire panel enclosure but within 6 ft of such. The printer must be in the same room as the fire panel enclosure and connected through an electrical conduit. Installation mounting instructions for the Keltron printer and its associated cabinet are not included in this document as they should be provided by Keltron.

Keltron parts ordering information is as follow:

- 90 Series printer, RS232C compatible — Order no. VS4095/5
- Red wall mount cabinet — Order no. VS ENCRED

Installation of the Keltron printer in a FireFinder-XLS/Desigo Fire Safety Modular/Cerberus PRO Modular System requires the following:

- P/N A5Q00075175 — Cable PMI-3 to Keltron Printer
- Two-conductor power cable, length is up to 10 ft.

Interface Options

The FireFinder XLS/Desigo Fire Safety Modular/Cerberus PRO Modular fire panel communicates with the Keltron printer via RS232C Interface signals. Proper baud rate and function settings are required and are set via Switch Pack #1 and Switch Pack # 2 as indicated below. Refer to the Keltron 90 Series Miniprinter Installation and Operation Manual, Appendix A for meaning of switch pack settings.

Siemens Industry, Inc.
Building Technologies Division

SWITCH PACK # 1								SWICH PACK # 2							
8	7	6	5	4	3	2	1	8	7	6	5	4	3	2	1
ON	**ON**	**OFF**	**ON**	**OFF**	**OFF**	**OFF**	**OFF**	**OFF**	**ON**	**OFF**	**OFF**	**OFF**	**OFF**	**OFF**	**OFF**

Electrical Installation

The data cable (P/N A5Q00075175) is contained in the Keltron cable kit, P/N S54430-C24-A1. The two-conductor power cable, length up to 10 feet, is user supplied.

Cut the two-wire power cable to the length needed and strip the insulation from both ends of the wire ¼"-3/8". One end connects to terminals on TB4 of the PSC-12 or PSX-12, with the red wire going to the positive (+) terminal and the back wire going to the negative (-) terminal. The other end connects to the 2-position screw/terminal strip mounted on the side of the Keltron printer, with the red wire going to the DC IN+ terminal and the black wire going to the DC IN- terminal.

CAUTION!!!!!!!!!!!!! DO NOT reverse polarity!!!!!!!!!!!!!!!!!

The data cable connects to the Keltron Serial Interface and to either JP4 on the back of the PMI (note that the silk screen on the PMI indicates NIM-1M) or to J13 on the back of the PMI-2/PMI-3 (XLS), FCM2041-U2 (Desigo Fire Safety Modular), FCM2041-U3 (Cerberus PRO Modular) (note that the silk screen on the PMI-2/PMI-3 [XLS], FCM2041-U2 [Desigo Fire Safety Modular], FCM2041-U3 [Cerberus PRO Modular] indicates TSP-40A). Both ends of the data cable have a keyed plug that fits only one way onto the connectors.

Electrical Ratings

Input Power: +24V

Idle Current: 100mA max.

Printing Current: 1A max.

Installing or changing the Paper Roll

Refer to the Keltron 90 Series Miniprinter Installation and Operation Manual, Section 5 Maintenance and supplies.

Programming

The Keltron Series 90 printer must be enabled in the Zeus Programming Tool in order to operate in a FireFinder-XLS/Desigo Fire Safety Modular/Cerberus PRO Modular System. It must be enabled as a TSP-40A printer.

Cyber security disclaimer

Siemens provides a portfolio of products, solutions, systems and services that includes security functions that support the secure operation of plants, systems, machines and networks. In the field of Building Technologies, this includes building automation and control, fire safety, security management as well as physical security systems.

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art security concept. Siemens' portfolio only forms one element of such a concept. You are responsible for preventing unauthorized access to your plants, systems, machines and networks which should only be connected to an enterprise network or the internet if and to the extent such a connection is necessary and only when appropriate security measures (e.g. firewalls and/or network segmentation) are in place. Additionally, Siemens' guidance on appropriate security measures should be taken into account. For additional information, please contact your Siemens sales representative or visit https://www.siemens.com/global/en/home/company/topicareas/future-of-manufacturing/industrial-security.html.

Siemens' portfolio undergoes continuous development to make it more secure. Siemens strongly recommends that updates are applied as soon as they are available and that the latest versions are used. Use of versions that are no longer supported, and failure to apply the latest updates may increase your exposure to cyber threats. Siemens strongly recommends to comply with security advisories on the latest security threats, patches and other related measures, published, among others, under https://www.siemens.com/cert/en/cert-security-advisories.htm.