SIEMENS

Installation Instructions
Model DB-HR

Detector Base




Figure 1
DB-HR Wiring Diagram Using HFP-11 Series and SFP-11 Series Detectors

DETECTOR AND BASE PLACEMENT

Detector and base locations shall follow the drawings provided or approved by Siemens Industry, Inc. or its authorized distributors. This is extremely important! The detector placements shown on these drawings were chosen after a careful evaluation of all facets of the protected area. When drawings are not available, refer to *Detector Placement* section of detector Installation/ Wiring Instructions and to NFPA 72, National Fire Alarm Code and CAN/ULC-S524.

BASE WIRING

The Model DB-HR from Siemens Industry, Inc. is a polarity insensitive detector base and works with HFP-11, HFPT-11, HFPO-11, SFP-11*, SFPT-11* and SFPO-11* detectors only. Detectors should be interconnected as shown in Figure 1 and wired to the DLC (refer to DLC Installation Instructions, P/N 315-033090), FS-DLC (refer to FS-250 Installation, Operation and Maintenance Manual, P/N 315-049353) or FDLC (refer to FS-250C Installation, Operation and Maintenance Manual, P/N 315-049589C), as applicable. Line 1 and Line 2 can be either line of the loop. **Note any limitations on the number of detectors and restrictions on the use of remote devices permitted for each circuit.**

*SFP-11, SFPT-11 and SFPO-11 detectors are approved for use in Canada only.

Siemens Industry, Inc.
Building Technologies Division
Florham Park, NJ

Siemens Building Technologies, Ltd.
Fire Safety & Security Products
2 Kenview Boulevard
Brampton, Ontario
L6T 5E4 Canada

P/N 315-033220-5

DETECTOR MOUNTING USING THE DB-HR BASE

The detector is provided with a separate base which attaches to a standard 4 inch square or a 4 inch octagonal electrical box, with the box size and depth required by the NEC for the number and size of conductors used. Wire size: max – 14 AWG, min – 18 AWG.

Refer to Figure 2.

1. Route all wires outward from outlet box.
2. When the ALARM LED viewing is critical, position the LED mark in the base in the intended direction.
3. Route wires through the hole in the center of the base and mount base to outlet box. Make connections directly to the base terminals. Refer to Figures 1 and 2 for details.
4. After all bases are installed, check wiring integrity.
5. To insure proper installation of the detector head into the base:
   a. Route wires away from connector terminals.
   b. Take up all slack in the outlet box.
   c. Properly dress and position all wires flat against the base.
   d. Check that screw terminals are tight.




Figure 2
Mounting the Base