

MW-XF Running on Linux

1. Introduction

This document describes the steps to install the MW-XF daemon on a Linux server.

2. Installing the daemon

Decompress the file MW-XF.taz on any folder.

Replace the file *MW-XF.jar* on this folder with the latest version. You can ask Exemys to send you this file or get it from the installation folder on a Windows computer with the MW-XF previously installed.

The provided files will run on Linux x86 32bits platform. If you are using a different platform you must replace the files *libwrapper.so* and *wrapper* with the corresponding ones.

You can download them from here: downloads.exemys.com/downloads/OtherWrappers.tar

Then install the daemon executing this command:

sudo '/yourFolder/MW-XF/mwxf.in' install

After doing this the daemon will start running on the server using the default ports.

3. Running the MW-XF Administrator

To change the MW-XF configuration you will have to install the MW-XF Administrator on a Windows based computer. You can download if from here www.exemys.com/mwadmin

For further technical questions please contact us at support@exemys.com

Juan B. Justo 4054 C1416DJU Capital Federal, Argentina Tel: (54 11) 4585-7585 Fax: (54 11) 4585-7278

www.exemys.com