


 Chapter:
 9

 Page:
 1

 Rev:
 0

 Date:
 20 Oct 07

FANS-1/A Operations Manual





 Chapter:
 9

 Page:
 2

 Rev:
 0

 Date:
 20 Oct 07

INTENTIONALLY LEFT BLANK.



 Chapter:
 9

 Page:
 3

 Rev:
 0

 Date:
 20 Oct 07

Table of Contents

1	INTRODUCTION	11
2	ACRONYM LIST	12
3	ATS FACILITIES NOTIFICATION (AFN) CONNECTION MAN	IAGEMENT
3.1 3.1.1 3.1.2	Pre-Flight Phase	14 14 14
3.2 3.2.1 3.2.2 3.2.3 3.2.4 3.2.4.1 3.2.4.2 3.2.4.3 3.2.4.3	The AFN Logon Prerequisite for CPDLC and / or ADS-C connection Initiating an AFN logon Purpose of an AFN logon The initial AFN logon Parameter time for performing the initial AFN logon Notification of ATS variations Constructing the FN_CON message FMS and ACARS flight identification	15 15 15 15 15 16 16
3.3 3.3.1 3.3.2 3.3.3 3.3.4 3.3.4.1	CPDLC Connection	
3.4 3.4.1 3.4.2 3.4.2.1 3.4.2.2 3.4.3 3.4.3.1 3.4.3.2	Next Data Authority Notification	19 19 19 19 19 20 20 20
3.5 3.5.1 3.5.2 3.5.3 3.5.3.1 3.5.3.2	AFN Logon Triggered By Address Forwarding Purpose and procedure An aircraft transferring from one data link area to another Aircraft transiting data link areas Options for initiating the AFN logon Transferring CPDLC for short transits	21 21 21 21 22 22
3.6 3.6.1 3.6.1.1 3.6.1.2 3.6.1.3 3.6.1.4 3.6.1.5 3.6.1.6 3.6.2	End of Service and CPDLC Connection Transfer	23 23 23 23 24 24 24 25 25



 Chapter:
 9

 Page:
 4

 Rev:
 0

 Date:
 20 Oct 07

3.6.2.2	Non-automatic termination of the connection	25
4	CPDLC PROCEDURES	27
4.1	Means of Communication	27
4.1.1	General	27
4.1.2	Voice communications	27
4.1.2.1	Notification of frequencies to the preceding ATSU	27
4.1.2.2	Notification of HF frequencies by CPDLC	27
4.2	CPDLC Capability	27
4.2.1	Notification of CPDLC capability	27
4.2.2	Downlink messages	27
4.2.3	Uplink messages	28
4.3	Use of Pre-Formatted and Free Text Messages	28
4.3.1	Preferred use of pre-formatted messages	28
4.3.2	Standardized free text messages	28
4.3.3	Storing free text messages	28
4.4	Exchange of CPDLC messages	28
4.4.1	Message assurance	28
4.4.2	Ambiguous dialogues	28
4.4.3	Interruption of a CPDLC dialogue	28
4.4.4	Approval of request or clearance / instruction	29
4.4.4.1	Affirmative response to a clearance/instruction	29
4.4.4.2	Affirmative response to a clearance request	29
4.4.4.3	Conditions relating to a specific clearance	29
4.4.4.4	Affirmative response to a negotiation request	29
4.4.5	Negative response to a downlink request	29
4.4.5.1	Negative response to a clearance request	29
4.4.5.2	Explanation of negative response	29
4.4.5.3	Offering alternative clearances to downlink requests	29
4.4.6	Negative response to an uplink request	29
4.4.7	Time period between receiving and responding to a message	29
4.4.7.1	Delays in responding	30
4.4.7.2	Delay expected after receiving a "STANDBY" message	30
4.4.7.2	Re-sending Messages	30
4.4.8.1	Re-sending messages Re-sending of a message when no alert received	30
4.4.8.2		
4.4.6.2 4.4.9	Re-sending of a message when an alert has been received Duplicate requests received	30
_		30
4.4.9.1	Second identical request after an uplink "STANDBY" message	30
4.4.9.2	Multiple identical requests	30
4.4.10	Altitude change clearances	30
4.4.10.1	Issuing conditional altitude change clearances	30
4.4.10.2	Level report requirements for climb or descent clearances	31
4.4.10.3	Canceling block altitude clearances	31
4.4.10.4	Issuing Level Restrictions	31
4.4.11	Requesting an aircraft's speed	32
4.4.12	Advising a wake turbulence offset	32
4.4.13	Direct Tracking and UPR Aircraft	32
4.4.14	Planned Airborne Re-route Procedure – DARP (Datalink Aircraft)	32
4.5	Multi-Element Requests	33
4.5.1	Avoiding multiple element clearance requests	33
4.5.2	Responding to multiple element clearance requests	33
4.5.2.1	Multiple clearance requests in one message: All approved	33



 Chapter:
 9

 Page:
 5

 Rev:
 0

 Date:
 20 Oct 07

4.5.2.2 4.5.2.3	Multiple clearance requests in one message: All not approved Multiple clearance requests in one message: Some approved / Some not approved	34 34
4.6	Multi-element Uplink Messages	34
4.6.1	Combining multiple elements into a single message	34
4.6.2	Dependent Clearances	34
4.7	Message Closure	35
4.7.1	General	35
4.7.2	Answering an uplink free text	35
4.7.3	Dialogue commenced via CPDLC and continued via voice	36
4.8	Position Reporting	36
4.8.1	General	36
4.8.2	Downlink of position report	36
4.8.3	Flexible track position reports	36
4.8.4	First position report	36
4.8.5	Sending of ATC waypoints only	36
4.8.6	Updating a waypoint estimate	36
4.8.7	Non-receipt of a scheduled position report	36
4.8.8	Sequencing 'ABEAM' waypoints in excess of FMC parameters	36
4.8.9	ARINC 424 fix names	37
4.9	FANS-1/A CPDLC Message Set and Intent	37
4.9.1	Response Requirements Key:	37
4.9.2	Uplink - Responses and Acknowledgements	37
4.9.3	Uplink - Vertical Clearances	38
4.9.4	Uplink - Crossing Constraints	40
4.9.5	Uplink - Lateral Offsets	42
4.9.6	Uplink - Route Modifications	42
4.9.7	Uplink - Speed Changes	44
4.9.8	Uplink - Contact/Monitor/Surveillance Requests	44
4.9.9	Uplink - Report/Confirmation Requests	45
4.9.10	Uplink - Negotiation Requests	46
4.9.11	Uplink - Air Traffic Advisories	47
4.9.12	Uplink - System Management Messages	47
4.9.13	Uplink - Additional Messages	47
4.9.14	Downlink - Responses	48
4.9.15	Downlink - Vertical Requests	48
4.9.16	Downlink - Lateral Off-Set Requests	49
4.9.17	Downlink - Speed Requests	49
4.9.18	Downlink - Voice Contact Requests	49
4.9.19	Downlink - Route Modification Requests	49
4.9.20	Downlink - Reports	49
4.9.21	Downlink - Negotiation Requests	51
4.9.22	Downlink - Emergency Messages	51
4.9.23	Downlink -System Management Messages	51
4.9.24	Downlink -Additional Messages	52
4.10	FANS-1/A CPDLC Standard Free Text Messages	54
4.10.1	Uplink - Free Text Report/ Confirmation Requests	54
4.10.2	Uplink - Free Text Instructions	55
4.10.3	Uplink - Free text Advisories	55
4.10.4	Uplink - Free Text Speed Messages	56
4.10.5	Uplink - Free Text Emergency Acknowledgment	56
4.10.6	Downlink - Free Text Advisories	57



 Chapter:
 9

 Page:
 6

 Rev:
 0

 Date:
 20 Oct 07

5	ADS-C PROCEDURES	58
5.1	Introduction	58
5.2	ADS-C Description	
5.2.1	The periodic contract	58
5.2.2	The event contract	58
5.2.3 5.2.4	The demand contract	59
5.2.4	Emergency mode	59
5.3 5.3.1	Factors To Be Considered When Using ADS-CVertical and lateral variations	
5.3.1	Figure of Merit data in ADS-C reports	59 60
5.3.3	Flight crew modification of active route	60
5.4	ADS-C Connection Management	60
5.4.1	Priority for the ADS-C connection	60
5.4.1.1	Allocation of ADS-C connections	60
5.4.2	Near boundary ADS-C connections	60
5.4.2.1	Monitoring of an aircraft operating close to an airspace boundary	60
5.4.2.2	Other ground facilities requesting ADS-C contracts	61
5.4.3	ADS-C connections not available	61
5.4.4	Ground system termination of ADS-C connections	62
5.5	Reporting Rates	
5.5.1	General	62
5.5.2	Appropriate reporting rates	63
5.5.3	Avoid high periodic reporting rates	63
5.5.4 5.5.5	Other factors to be considered Default periodic reporting rates	63 63
5.6 5.6.1	Separation	
5.6.2	Appropriate ADS-C reporting requirements	63 63
5.6.3	Appropriate separation standard Vertical separation	63
5.6.3.1	Vertical tolerance consistency	63
5.6.3.2	Application of vertical tolerances	64
5.6.3.3	ADS-C level information does not satisfy vertical tolerance	64
5.6.3.4	Use of ADS-C level information	64
5.6.3.5	Passing or leaving a level	64
5.6.4	Longitudinal separation	64
5.6.4.1	Limitations on the use of tools	64
5.6.4.2	Establishing longitudinal separation	64
5.6.4.3	Using extrapolated or interpolated positions	64
5.6.4.4	Validity of displayed information	64
5.6.4.5	Time-based separation	64
5.6.4.6	.Distance-based separation	65
5.6.5	Lateral separation	65
5.6.5.1	Areas of lateral conflict	65
5.7	Air Traffic Clearance Monitoring	
5.7.1	Deviations from ATC clearances	65
5.8	Coordination	
5.8.1	Duty of care responsibility	65
5.8.2	Coordinated data inconsistent with ADS displayed data	65
5.9	Alerting service	65



 Chapter:
 9

 Page:
 7

 Rev:
 0

 Date:
 20 Oct 07

	ETIHAD AIDWAYS _ LINITED ADAR EMIDATES	
7.2	ATSU Designators	74
7.1	Introduction	74
7	FANS-1/A IMPLEMENTATION	74
6.6.1 6.6.2 6.6.3	Multiple weather deviations Deviations either side of track Reporting back on track	72 73 73
6.6	Weather deviation procedures	72
6.5	Using CPDLC to relay messages	72
6.4	Total Communications Failure	71
6.3.6	Unexpected avionics system shutdown	71
6.3.4.2 6.3.5	Loss of ADS-C Unexpected communication service provider shutdown	71 71
6.3.4.1	ADS only failure	71
6.3.4	Data link component shutdown	70
6.3.2 6.3.3	Planned data link shutdowns Resumption of data link operations	70 70
6.3.1	Unexpected data link shutdowns	70
6.3	Data link System Shutdowns	
6.2.3	Inability to establish the data link connection	69
6.2.2	Detected by the controller Detected by the airborne system	69 69
6.2 6.2.1	Data Link Connection Failures	69 69
0.1.7		
6.1.6 6.1.7	Normal emergency procedures Coordination in the case of emergency	69 69
6.1.5.2	Executive control responsibility	69
6.1.5.1	Communications responsibility	69
6.1.4.1 6.1.5	Voice contact Retaining the active connection	68 69
6.1.4	CPDLC acknowledgment	68
6.1.3	Acknowledgement of an emergency message	68
6.1.2	Confirmation of emergency activation	68
6.1 6.1.1	Emergency procedures Response to an emergency message	68 68
6	EMERGENCY AND NON-ROUTINE PROCEDURES	62
5.11.2.1	Actions to be followed when there is an estimate discrepancy	67
5.11.2	Discrepancies between ADS-C and CPDLC estimates	66
5.11.1.3	Updating waypoint estimates Non-compulsory waypoints	66 66
5.11.1.2 5.11.1.3	CPDLC report at FIR entry position	66
5.11.1.1	Publishing reporting requirements	66
5.11.1	Position reporting requirements in ADS airspace	66
5.11	Position Reporting	66
5.10.2	Sequencing subsequent waypoints	66
5.10.1	Aircraft in heading select mode	66
5.10	Aircraft Navigation	66
5.9.1	Late or missing ADS-C Reports	65



 Chapter:
 9

 Page:
 8

 Rev:
 0

 Date:
 20 Oct 07

7.3	HF Voice Communications Requirements	75
7.3.1	Crossing International FIR Boundaries	75
7.3.2	CPDLC Services in specific FIR's	76
7.3.2.1	Brisbane & Melbourne FIRs	76
General	76	
CPDLC	76	
	cedures for Brisbane & Melbourne FIR	76
Inbound P		76
	Procedures	76
ADS	76	a . 4la a
	PDLC Level Change request is received for operations within Class G airspace	
	oller shall respond with relevant free text Traffic information and in the same m nd the pre-formatted element REPORT REACHING [level].	iessage shali 76
	& Contingency Procedures	77
	Ç ,	=0
7.3.2.3.	Auckland FIR	
-	ocedures for Auckland FIR	78
Inbound P	Procedures	78 78
	& Contingency Procedures	78 78
7.3.2.4.	Chennai & Kolkata FIRs	78 79
General	79	19
CPDLC	79	
	ocedures for Chennai & Kolkata FIR	79
ADS	79	,,
	mination of Data link Service	79
Abnormal	& Contingency Procedures	80
	eppesen	
7.3.2.5.	Sri Lankan airspace (Colombo FIR)	81
General	81	
CPDLC	81	0.1
Inbound P	ocedures for Colombo FIR	81 81
	f Voice communications to CPDLC	81
ADS	81	61
_	on of Data link Services	82
	& Contingency Procedures	82
7.3.2.6.	Mauritius airspace	83
General	83	
CPDLC	83	0.2
	mited Services in Mauritius FIR	83
	ocedures for Mauritius FIR	83
	of Voice communications to CPDLC on of Data link Services	83
ADS	84	83
_	eporting Requirements	84
	& Contingency Procedures	84
7.3.2.7.	Yangon FIR	85
General	85 85	
CPDLC	85	0.5
	ocedures for Auckland FIR f Voice communications to CPDLC	85 85
	on of Data link Services	85 85
	& Contingency Procedures	87
, whomat	a contingency i recodules	07



 Chapter:
 9

 Page:
 9

 Rev:
 0

 Date:
 20 Oct 07

General 88	A FID
Logon Procedures for Maastrich Logon Procedures	t FIR 88 88
Inbound Procedures	89
Outbound Procedures	89
Termination of Datalink Services	
Level Changes	89
Route Clearance Requests	89
Abnormal & Contingency Proce	dures 89
7.3.2.9. Gander FIR	90
Logon Procedures for Gander F	
Westbound Procedures	90
Eastbound Procedures	90
Abnormal or Contingency Proce	dures 90
CPDLC 90	
ADS 91	
Level changes	91
Oceanic/Route Clearance Requ	ests 91
7.3.2.10. New York FIR	92
Logon Procedures for New York	FIR 92
Westbound Procedures	92
Eastbound Procedures	92
Abnormal or Contingency Proce	dures 92
CPDLC 92	
ADS 92	02
Level changes Oceanic/Route Clearance Requ	92 ests 92
Oceanic/Notice Clearance Requ	525
7.3.2.11. Reykjavik FIR	93
Logon Procedures for Reykjavik	FIR 93
Westbound Procedures	93
Eastbound Procedures (r	· · · · · · · · · · · · · · · · · · ·
Abnormal or Contingency Proce CPDLC 93	dures 93
CPDLC 93 ADS 93	
Level changes	93
Oceanic/Route Clearance Requ	
·	
	94
Logon Procedures for Santa Ma Westbound Procedures	
Eastbound Procedures	94 94
Abnormal or Contingency Proce	
CPDLC 94	
ADS 94	
Level changes	94
Oceanic/Route Clearance Requ	ests 94
7.3.2.13. Shanwick FIR	95
Logon Procedures for Shanwick	
Westbound Procedures	95
Eastbound Procedures (r	
Abnormal or Contingency Proce	dures 95
CPDLC 95	
ADS 95	



 Chapter:
 9

 Page:
 10

 Rev:
 0

 Date:
 20 Oct 07

7.3.2.2	c/Route Clearance Requests	96 96 97 97
7.4.	Differences of Use of FANS-1/A Messages	98
7.5.	Position Reporting Requirements: CPDLC and ADS-C Environments	98
7.6.	Aircraft Data	98
7.6.2.	Verifying registration number	98
7.6.3.	CPDLC connection requests	99
7.6.4.	Flight crew display:- response and acknowledgment	99
7.6.5.	FMS processing of waypoints	100
7.6.6.	Multiple request messages	100
7.6.7.	Waypoint sequencing	101
7.6.8.	Offset using the FMS	102



Chapter: 9
Page: 11
Rev: 0
Date: 20 Oct 07

1 Introduction

The FANS-1/A Operations Manual (FOM) details the FANS-1/A procedures and requirements officially adopted by and applicable in the following FIRs: ¹

- 1. Accral
- 2. Algeria
- 3. Anchorage Oceanic
- 4. Atlantico
- 5. Auckland Oceanic
- 6. Antananarivo (Madagascar)
- 7. Bahrain
- 8. Brisbane
- 9. Canarias
- 10. Casablanca
- 11. Colombo
- 12. Dakar Oceanic
- 13. Egypt
- 14. Emirates
- 15. Fukuoka
- 16. Honiara
- 17. India
- 18. Indonesia
- 19. Iraq
- 20. Johannesburg Oceanic
- 21. Jordan
- 22. Kuwait
- 23. Lebanon
- 24. Libya
- 25. Lisbon
- 26. Luanda
- 27. Malaysia
- 28. Mauritius
- 29. Melbourne
- 30. Morocco
- 31. Myanmar
- 32. Nadi
- 33. Nauru
- 34. Oakland
- 35. Oman
- 36. Palestinian Gaza
- 37. Qatar
- 38. Sal
- 39. Saudi Arabia
- 40. Seychelles
- 41. Singapore
- 42. Sudan
- 43. Syria
- 44. Tahiti
- 45. Thailand
- 46. Tunisia
- 47. Yemen



 Chapter:
 9

 Page:
 12

 Rev:
 0

 Date:
 20 Oct 07

2 Acronym List

AAR	Air-to-Air Refueling
ACAC	Arab Civil Aviation Commission
ACARS	Aircraft Communications Addressing and Reporting System
ACAS	Aircraft Collision Avoidance System (ICAO)
ADS	Automatic Dependent Surveillance
ADS-B	Automatic Dependent Surveillance – Broadcast
ADS-C	Automatic Dependent Surveillance – Contract (e.g. FANS)
AEEC	Airline Electronic Engineering Committee
AFN	ATS Facilities Notification
AIDC	ATC Inter-Facility Ground/Ground Data Communications
AIP	Aeronautical Information Publication
ALTRV	Altitude Reservation
AOC	Airline Operational Communications
APANPIRG	Asia/Pacific Air Navigation Planning and Implementation Regional Group
AR	Aerial Refueling
ARCP	Air Refueling Control Point
AREX	Air Refueling Exit Point
ARINC	Aeronautical Radio Incorporate
ARIP	Air Refueling Initial Point
ASECNA	Agence Pour la Securite de la Navigation Aerienne en Afrique et a Madagascar
ATC	Air Traffic Control
ATM	Air Traffic Management
ATNS	Air Traffic and Navigation Services (Africa)
ATS	Air Traffic Services
ATSU	ATS unit
AVICOM	AVICOM Japan Co. LTD
CAA	Civil Aviation Authority
CNS	Communications, Navigation, Surveillance
CPDLC	Controller Pilot Data Link Communications
CRA	Central Reporting Agency
CRASA	CRA Support Agency
CRC	Cyclic Redundancy Check
DM	Downlink message
EUROCAE	European Organisation for Civil Aviation Equipment
FAA	Federal Aviation Administration
FANS	Future Air Navigation System
FIR	Flight Information Region
FIT	FANS Interoperability Team
1	
FMC	Flight Management Computer



 Chapter:
 9

 Page:
 13

 Rev:
 0

 Date:
 20 Oct 07

GES	Ground Earth Station (satellite)
GPS	Global Positioning System (USA)
HF	High Frequency (3-30 Mhz)
IATA	International Air Transport Association
ICAO	International Civil Aviation Organisation
IFATCA	International Federation of Air Traffic Controllers Associations
IFALPA	International Federation of Air Line Pilots' Associations
IIOACG	Informal Indian Ocean ATS Coordination Group
IOOM	Indian Ocean Operations Manual
IPACG	Informal Pacific ATC Coordinating Group
ISPACG	Informal South Pacific ATS Coordinating Group
JCAB	Civil Aviation Bureau Japan
MCDU	Multipurpose Control Display Unit (ACARS & FMC)
MU	Management Unit (ACARS)
NDA	Next Data Authority
NOTAM	NOtice To AirMen
ocs	Oceanic Control System (Datalink system for the Auckland FIR)
ODP	Oceanic Air Traffic Control Data Processing System (Datalink system for the Fukuoka FIR)
RNP	Required Navigation Performance
RVSM	Reduced Vertical Separation Minima
SATCOM	Satellite Communication
SATVOICE	Satellite Voice Communication
SEAC	Service d'Etat de l'Aviation Civile (French Polynesia)
SITA	Société Internationale de Télécommunications Aéronautiques
SR&O	System Requirements and Objectives (FANS-1 document)
TCAS	Traffic Alert and Collision Avoidance System (USA)
TMU	Traffic Management Unit
UM	Uplink message
VHF	Very High Frequency (30-300 Mhz)
VIVO	Visualisation des Vols Océaniques (Situation display & datalink system for the Tahiti FIR)



 Chapter:
 9

 Page:
 14

 Rev:
 0

 Date:
 20 Oct 07

3 ATS Facilities Notification (AFN) Connection Management

3.1 Pre-Flight Phase

3.1.1 Identifying data link aircraft

ATS systems use Item 10 (Equipment) of the standard ICAO flight plan to identify an aircraft's data link capabilities. The operator is responsible for inserting the following items in the ICAO flight plan:

- Item 10 The letter "J" to indicate data link capability;
- Item 10 The letter "D" in the Surveillance field to indicate ADS-C capability;
- Item 18 The letters DAT/ followed by one or more letters as appropriate to indicate the type of data link equipment carried when "J" is entered in Item 10. (Refer ICAO PANS/ATM)

Example:

ICAO Item 10:J.....J....D

ICAO Item 18: REG/.....DAT/SV (for a satellite and VHF data link equipped aircraft)

Letter following DAT/	Type of data link
S	Satellite data link
Н	HF data link
V	VHF data link
M	SSR Mode S data link

Table 1: Specifying CPDLC Capability in FPL

3.1.2 Registration number

ATS systems compare the registration number of the aircraft contained in Field 18 (Other Information) of the ICAO flight plan with the registration contained in the AFN logon. The operator is responsible for ensuring that the correct aircraft registration is filed in Field 18 of the ICAO flight plan.



Chapter: 9
Page: 15
Rev: 0
Date: 20 Oct 07

3.2 The AFN Logon

3.2.1 Prerequisite for CPDLC and / or ADS-C connection

The AFN logon is a prerequisite to any CPDLC or ADS-C connection.

3.2.2 Initiating an AFN logon

The AFN logon can be initiated:

- · Manually by the pilot during an "initial logon", or
- By an ATSU using the address forwarding process.

3.2.3 Purpose of an AFN logon

The AFN (ATS Facilities Notification) logon serves the following purposes:

- a) To provide an ATSU with the data link application context of the aircraft, namely:
 - The ATS data link applications supported on board (CPDLC, ADS-C),
 - Their version numbers, and
 - The associated addresses (in the FANS-1/A context, these are the ACARS addresses unique to each aircraft).
- b) To provide an ATSU with information such as the flight identification and the registration number. This information will allow the correlation of the flight attempting to logon with the corresponding flight data held by the ATS system. The aircraft logging on will then be positively identified by the ATS system.
- c) To allow ATSUs to establish both ADS-C and CPDLC connections, where applicable.

3.2.4 The initial AFN logon

The initial AFN logon is performed by the pilot manually sending an **AFN contact** message (FN_CON) containing the 4 character ICAO code of the ATSU.

An initial AFN logon is required when the aircraft does not already have an ADS-C or CPDLC connection, such as:

- When the aircraft is preparing to depart from an airport and the first logon to a ground system is executed, or
- When the aircraft will enter a CPDLC area from an area where CPDLC services have not been provided.
- When requested by ATC for situation such as when an unsuccessful address forwarding or next data authority has occurred.




Figure 1: Initial AFN Logon

3.2.4.1 Parameter time for performing the initial AFN logon

For aircraft that will enter an area where CPDLC services will be provided and an initial logon is required, the pilot should send an AFN Contact message (FN_CON) between 15 and 45 minutes



 Chapter:
 9

 Page:
 16

 Rev:
 0

 Date:
 20 Oct 07

prior to entering the area. ATSUs should ensure that an FN_CON message sent within this time frame would be accepted by the applicable ground system.

3.2.4.2 Notification of ATS variations

Any ATSU where the ground system is unable to accept an FN_CON message sent between 15 and 45 minutes prior to the ETD or the estimate for entering the FIR shall publish instructions notifying the parameters during which a logon will be accepted.

3.2.4.3 Constructing the FN_CON message

To avoid an automatic rejection of the logon, the pilot shall ensure that the flight identification and registration numbers contained in the FN_CON message are <u>exactly the same</u> as the flight identification and registration numbers filed in the flight plan.

3.2.4.4 FMS and ACARS flight identification

When comparing aircraft identifiers to enable flight plan coupling with the logon, the ATSU shall only use the flight identifier and aircraft registration as contained within the end system (CRC'd) portion of AFN logon message. The flight identifier in the ACARS message header has a different format to that required by the ground system (i.e. a two alpha character airline identifier followed by up to four numeric characters) and should not be used by the pilot to notify aircraft identification.



Chapter: 9
Page: 17
Rev: 0
Date: 20 Oct 07

3.3 CPDLC Connection

3.3.1 Purpose CPDLC connection

The purpose of a CPDLC connection is to allow the exchange of CPDLC messages between an aircraft and an ATSU.

3.3.2 Management Of CPDLC connections

ATSUs shall manage CPDLC connections to ensure that wherever possible the active CPDLC connection is held by the ATSU with responsibility for the flight. Connections should be maintained and terminated to support this requirement; however aircraft may be connected with another ATSU or sector on occasions such as:

- a) When an aircraft is transiting a CPDLC serviceable FIR subject to coordination between ATSUs;
- b) During the CPDLC connection transfer process;
- c) Where the active connection is retained by the transferring ATSU subject to prior coordination;
- d) When the aircraft is within a non-serviceable or non-CPDLC FIR and logs on to the ATSU responsible for the next FIR; or
- e) In emergency circumstances.

Care must be taken not to issue clearances or instructions to a flight via CPDLC when it is under the control of another sector/ATSU.

3.3.3 CPDLC connection sequence

A CPDLC connection attempt can only occur after the AFN logon has been completed. The CPDLC connection is initiated by sending the **Connection Request** message by the ATSU and is established when the **Connection Confirm** message is received from the aircraft:

- a) If there is no existing connection, the avionics will accept this connection as the active connection.
- b) If there is an existing connection, the avionics will check that the initiating ATSU has been established as the next data authority. If so, the avionics will accept this connection as the non-active connection.
- c) In all other situations, the avionics will reject the connection request.




Figure 2: CPDLC Connection Sequence

3.3.4 Active and inactive CPDLC connections

A CPDLC connection established between an aircraft and an ATSU is either active or non-active.

- a) A connection is active when CPDLC messages can be exchanged.
- b) A connection is non-active when CPDLC messages cannot be exchanged.

FANS-1/A aircraft can have two CPDLC connections established, each with a different ATSU. Only one of these connections can be active at any given time. A non-active connection becomes active as soon as the active connection is terminated.



 Chapter:
 9

 Page:
 18

 Rev:
 0

 Date:
 20 Oct 07

3.3.4.1 Determination of an active CPDLC connection

When the aircraft had a CPDLC connection with the previous ATSU, there are two ways for the controller to know if the CPDLC connection is active:

- a) To send a message with the possibility of receiving a **Not Current Data Authority** error message if the connection is not yet active; or
- b) To wait until a CPDLC message is received from the pilot.



Chapter: 9
Page: 19
Rev: 0
Date: 20 Oct 07

3.4 Next Data Authority Notification

3.4.1 Purpose of the NDA message

Definition: The ATSU holding the active connection with the aircraft is known as the 'Data Authority'.

The purpose of the Next Data Authority (NDA) message is to advise the avionics of the next ATSU to become the Data Authority. The sending of the NDA message is the first step in the CPDLC transfer sequence between an aircraft and two ATSUs. The avionics will only accept a CPDLC connection request from the ATSU quoted in the NDA message.

3.4.2 Procedure for the NDA notification

The ATSU with the current active connection notifies the avionics of the Next Data Authority by sending a **NEXT DATA AUTHORITY [icaofacilitydesignation]** message.





Figure 3: Next Data Authority Notification

3.4.2.1 Sequence of the NDA and FN_CAD messages

The CPDLC connection sequence can be initiated by automated systems immediately following the AFN logon, the NDA message shall be sent prior to the **AFN contact advisory** (FN_CAD) to avoid a rejection of the connection. The avionics must receive the NDA prior to receiving a connection request message; otherwise the connection request will be rejected.

3.4.2.2 Change of the NDA

If the next data authority should change after the NDA message has been sent (e.g. an aircraft reroute due to weather), a new NDA message must be sent. This new NDA will supersede the original NDA message in the avionics and will disconnect any inactive connection already established by the unit that had been previously designated as the Next Data Authority. In the following diagram, an inactive connection that is established with ATSU 2 would be dropped when a new NDA designating ATSU 3 is received.





 Chapter:
 9

 Page:
 20

 Rev:
 0

 Date:
 20 Oct 07

Figure 4: Subsequent Next Data Authority Notification

3.4.3 Abnormal cases relating to the NDA notification

If the NDA message (containing the correct Next Data Authority designation) is not received by the avionics before receiving the **CONNECTION REQUEST** message sent by the subsequent ATSU, the connection request message will be rejected. The pilot has no indication that the **CONNECTION REQUEST** has been rejected.

3.4.3.1 Unsuccessful NDA delivery

When the NDA delivery has not been successful, the controller's initial action should be to send another NDA message. If this is also unsuccessful, the controller shall instruct the pilot to manually initiate an AFN logon with the subsequent ATSU after termination of the CPDLC connection. An **END SERVICE** message is not required in this case.

The phraseology to be used via CPDLC or voice will be:

Controller	CONTACT [icaounitname] [frequency]	
	Select ATC Com Off then Logon to [ATSU name]	
	(Note: When via CPDLC, this last element will be free text)	
Pilot	WILCO	

The [ATSU name] is the relevant four character ICAO code.

Note: Instructing the pilot to Select ATC Com off will result in loss of CPDLC connectivity. This procedure should only be applied approaching the FIR boundary with the next ATSU.

3.4.3.2 Duplication of the NDA message

Receipt by the aircraft of a second NDA message may (depending on the aircraft equipment) disconnect the non-active CPDLC connection, even if the NDA message specifies the same (non-active) ATSU that is already connected. Therefore, under normal circumstances, duplicate NDA messages shall not be uplinked.



Chapter: 9
Page: 21
Rev: 0
Date: 20 Oct 07

3.5 AFN Logon Triggered By Address Forwarding

3.5.1 Purpose and procedure

The Address Forwarding process is initiated by the ground system and consists of an ATSU sending an **AFN contact advisory** message (FN_CAD) to the avionics. The FN_CAD instructs the avionics to automatically perform an AFN logon to the ATSU address included in the message. Address Forwarding is used to allow a subsequent ATSU to establish an inactive CPDLC connection and ADS contracts, and to allow adjacent ATSUs to establish ADS contracts for monitoring purposes.

Note: The FN_CAD message should be sent at least 15 minutes prior to the estimated time of arrival at the FIR boundary.

3.5.2 An aircraft transferring from one data link area to another




Figure 5: Transfer between areas where data link is provided

The address forwarding process is invisible to the flight crew. As a result, the flight crew does not receive an indication as to whether or not the FN_CON or FN_AK messages have been delivered correctly. However, the crew does receive an indication of a change to the active ATSU following a successful CPDLC connection transfer.

3.5.3 Aircraft transiting data link areas

Multiple examples have been found of connection transfer failures attributed to controllers or systems not completing all of the messaging requirements for the connection transfer during a short transit time across a portion of the FIR.

When an ATSU will only have jurisdiction over a data link connected aircraft for a relatively short duration (e.g. less than 30 minutes flying time), the requirements for the transfer of communications for the aircraft should be coordinated between the controlling and affected units, or covered in appropriate Letters of Agreement between all affected ATSUs. If the ATSU concerned requires ADS contracts to monitor the transit of the aircraft across a portion of the FIR, but the transfer of CPDLC is not required, the controlling unit should perform address forwarding in the order of priority described by the following diagram.



Chapter: 9
Page: 22
Rev: 0
Date: 20 Oct 07




Figure 6: Transiting data link areas

ATSU 1 should address forward to ATSU 3 (Priority 1) to ensure that a CPDLC connection and ADS contracts are established prior to address forwarding to ATSU 2 (Priority 2) so that ADS contracts can be established for monitoring the transit of the aircraft across the relevant portion of the FIR.

3.5.3.1 Options for initiating the AFN logon

The AFN logon may be initiated by one of the following options.

- a) Option 1 Initial AFN Logon: CPDLC shall cease between the aircraft and ATSU 1. The aircraft will enter ATSU 2 using voice. Pilots should initiate an initial AFN logon to ATSU 3 between 15 and 45 minutes prior to the estimated time at the FIR boundary.
- b) Option 2 AFN LOGON triggered by address forwarding: Address forwarding may be used to "jump" the connections over a FIR not requiring a CPDLC connection when agreed by the appropriate ATSUs. In this circumstance the controller shall inform the pilot of this intention by appending the free text message CONTACT WITH [ATSU name] NOT REQUIRED to the frequency transfer instructions For example: AT TEKEP MONITOR NADI CENTER 13261. CONTACT WITH AUCKLAND NOT REQUIRED.

3.5.3.2 Transferring CPDLC for short transits

Where an ATS Unit decides to accept the transfer of data link for a short transit across its FIR, the receiving controller needs to be aware of whether any automated transfer process to the subsequent unit will be affected by the relatively short transit period across the FIR.

If so, then the controller must ensure that all messages required to successfully transfer the connections to the next unit (e.g. NDA, Address Forwarding, Monitor/Contact information, and End Service messages) are sent in the proper sequence at the correct time, whether they are sent automatically by the system or manually by the controller.



Chapter: 9
Page: 23
Rev: 0
Date: 20 Oct 07

Note: The receiving unit must also be the Current Data Authority (CDA) before any of these messages can be sent successfully. For example, if the receiving unit tries to send the NDA message prior to becoming the CDA to account for a short transit time, the messages will fail.

3.6 End of Service and CPDLC Connection Transfer

3.6.1 Purpose and procedure

Under normal conditions, the current ATSU initiates the CPDLC connection termination sequence by sending an **END Service** uplink message. In response to an **END Service** message:

- The avionics will downlink a **DISCONNECT** message. The avionics will consider the aircraft to be disconnected as soon as the **DISCONNECT** message is sent.
- The current connection will be terminated, activating the non-active connection. The subsequent ATSU will now be able to exchange CPDLC messages with the aircraft.

The success of the CPDLC transfer is dependent upon the next ATSU establishing its own CPDLC connection prior to the **END SERVICE** message being received by the aircraft. Failure of the next ATSU to establish a CPDLC connection before the **END SERVICE** reaches the aircraft will leave the aircraft without CPDLC connectivity.

There are two cases in which the avionics will terminate established CPDLC connections.

- Depending on the software load, when any uplink messages remain open when the aircraft receives an End Service.
- When the END SERVICE element is part of a multi-element message where none of the elements require a WILCO response.

In both cases an error message will be generated to both ATS systems.

If any downlink messages remain open when the aircraft receives an **END SERVICE** message, the avionics will close the messages and terminate the CPDLC connection with the current ATSU. This will not affect the CPDLC connection with the next ATSU.

3.6.1.1 Uplink messages to be closed before the END SERVICE

The controller shall ensure that no open uplink CPDLC messages exist prior to the uplinking of an **END SERVICE** message. In the event that a CPDLC uplink is unanswered, ATC should uplink the free text: CHECK AND RESPOND TO OPEN CPDLC MESSAGES

3.6.1.2 Use of Contact/Monitor Uplink Message

The purpose of the Contact/Monitor uplink messages (UM#117 to UM#122) is to advise the pilot when (and where) a change to the nominated frequency is required. When any of the "Monitor" uplink messages are received the pilot shall change to the nominated frequency at the appropriate time. A check call is not required on the frequency. When any of the "Contact" messages are received the pilot shall change to the nominated frequency at the appropriate time and perform a check call on the frequency.

The sending or receipt of any of the "Contact" uplink messages is not an indication to the pilot that CPDLC use must be terminated or suspended once voice contact is established. If termination or suspension of CPDLC use is intended by the controller when voice contact is established then the requirement must be specifically stated in addition to the CONTACT message element.

3.6.1.3 Synchronizing the CPDLC and voice transfer

If the CPDLC MONITOR (OR CONTACT) [icaounitname] [frequency] message element and the END SERVICE message element are to be sent as separate uplink messages, the END SERVICE message should be sent as soon as possible after the receipt of the WILCO response. This is to ensure synchronization of the CPDLC and the voice communication transfers.



Chapter: 9
Page: 24
Rev: 0
Date: 20 Oct 07

3.6.1.4 Timing of the transfer of communications

The Monitor (or Contact) [icaounitname] [frequency] and End Service message elements should normally be sent after receipt of the last position report before crossing the FIR boundary, but not less than 5 minutes prior to the FIR boundary. This allows the next ATSU's connection to be active when the aircraft crosses the FIR boundary.

3.6.1.5 Aircraft entering VHF coverage

For aircraft entering airspace where radar and air-ground VHF are provided, and the aircraft will not cross an FIR boundary, it is not necessary to send an **END SERVICE** message to disconnect CPDLC. In this case, the CPDLC connection will remain active until termination of flight. If subsequent control sectors within the system do not have CPDLC capability, and local instructions do not exist to the contrary, the controller with jurisdiction for CPDLC must ensure that CPDLC clearances or instructions are not issued to the aircraft while it is under the control of another sector.

3.6.1.6 Timing of the CPDLC connection

Under normal circumstances the CPDLC connection should be established with the next data authority prior to the connection between the aircraft and the current data authority being terminated.

Either of the following options may be utilized to complete the CPDLC connection transfer process:

a) Option 1 the Monitor (or Contact) [icaounitname] [frequency] and END SERVICE message elements are sent in the same CPDLC uplink message.

Note. Because the CPDLC connection will be terminated when the pilot sends the WILCO response, this multi element message should not be sent more than 10 minutes from the frequency transfer point.




Figure 7: CPDLC connection transfer - Option 1

b) Option 2: the Monitor (or Contact) [icaounitname] [frequency] and the End Service message elements are sent as separate CPDLC uplink messages. The End Service is sent as soon as possible after the receipt of the Wilco response to the Monitor (or Contact) instruction.



 Chapter:
 9

 Page:
 25

 Rev:
 0

 Date:
 20 Oct 07





Figure 8: CPDLC connection transfer - Option 2

c) Option 3: the AT [position](or AT [time]) MONITOR (OR CONTACT) [icaounitname] [frequency] and the END SERVICE message elements are sent as separate CPDLC uplink messages. The END SERVICE is sent after the receipt of the WILCO response to the MONITOR (OR CONTACT) instruction, and approaching the FIR boundary



3.6.2 Abnormal cases at the time of the connection / disconnection

3.6.2.1 Non-delivery of END SERVICE message

There may be unusual situations where a CPDLC connection cannot be automatically terminated (e.g. if the END SERVICE message does not trigger the disconnection, or if the END SERVICE message is not delivered to the avionics). If the controller is aware that the END SERVICE message has been unsuccessful, the controller's initial action should be to send another END SERVICE message. If this is also unsuccessful the pilot will be instructed to terminate the CPDLC connection and logon to the next unit.

The voice phraseology to be used will be:

Controller	Select ATC Com Off then Logon to [ATSU name]
Pilot	Roger

The [ATSU name] is the four character ICAO code.

3.6.2.2 Non-automatic termination of the connection

If the CPDLC connection with the current ATSU does not terminate automatically at the appropriate time (i.e. before the position or time notified in the CONTACT/MONITOR message), then the pilot shall send the CPDLC position report to the current active center. If receipt of the position report does not prompt the current centre to send an End Service message within three minutes of the report being sent, then the pilot should manually disconnect from the current ATSU and logon to the subsequent ATSU.



 Chapter:
 9

 Page:
 26

 Rev:
 0

 Date:
 20 Oct 07

If the CPDLC transfer is intended to be delayed until after the aircraft has passed the FIR transfer point, the controller shall notify the pilot of the intended delay with the free text message EXPECT CPDLC TRANSFER AT [time].

If the aircraft crosses the FIR boundary prior to the time notified in the free text uplink, the boundary position will be sent to the ATSU with the active connection.

If the CPDLC transfer has not been completed by the time notified in the uplink message, the pilot is entitled to manually disconnect from the active ATSU and logon to the subsequent ATSU.



Chapter: 9
Page: 27
Rev: 0
Date: 20 Oct 07

4 CPDLC Procedures

4.1 Means of Communication

4.1.1 General

Generally, when a CPDLC aircraft is operating within a CPDLC airspace beyond the range of VHF voice communications, and other local rules do not apply, then:

- CPDLC will be the primary means of communication, and
- Voice will be used as the backup communication medium (for example VHF, direct HF, third party HF, SATVOICE).

The response to a CPDLC message should be via CPDLC, and a response to voice should be via voice.

4.1.2 Voice communications

4.1.2.1 Notification of frequencies to the preceding ATSU

ATSUs shall advise frequencies to the preceding ATSU, in accordance with the appropriate letters of agreement.

4.1.2.2 Notification of HF frequencies by CPDLC

The uplink CPDLC frequency transfer message elements can accommodate only one frequency variable. Due to this limitation, the controller will insert the primary HF frequency in these messages. This applies to the following uplinks:

UM#117	CONTACT [icaounitname][frequency]
UM#118	AT [position] CONTACT [icaounitname][frequency]
UM#119	AT [time] CONTACT [icaounitname][frequency]
UM#120	MONITOR [icaounitname][frequency]
UM#121	AT [position] MONITOR [icaounitname][frequency]
UM#122	AT [time] MONITOR [icaounitname][frequency]

In areas of poor HF coverage, the controller may consider appending free text nominating a secondary HF frequency. The format of this message is described in Part 5.9. In the **CONTACT** and **MONITOR** messages RADIO is not an option within the **[icaounitname]** field. Therefore CENTER will be used to identify a RADIO facility.

4.2 CPDLC Capability

4.2.1 Notification of CPDLC capability

An AIP Supplement, or similar, shall be published to advise the CPDLC capability of an ATS system and its AFN logon address. An aircraft's CPDLC capability shall be notified in the flight plan.

4.2.2 Downlink messages

ATS systems that allow the use of all elements contained in the FANS-1/A message set should be capable of correctly processing all the FANS-1/A downlink message elements. However, where specific CPDLC implementations do not include all message set elements, such as domestic airspace or initial and temporary situations, the ATSUs involved should publish the reduced message set with appropriate explanatory material. Where these reduced implementations occur across a group of adjoining ATSUs, every attempt should be made to ensure that the message set chosen is common to all applicable airspace within the implementation boundaries. ATSUs should exercise caution when specifying reduced message sets, ensuring that the messages handled are adequate for all envisaged scenarios in the airspace to be served by CPDLC.



 Chapter:
 9

 Page:
 28

 Rev:
 0

 Date:
 20 Oct 07

If the ground system receives a downlink message that is not supported by the implemented message set, then the free text uplink message (UM#169) MESSAGE NOT SUPPORTED BY THIS FACILITY should be sent rather than terminating the connection.

4.2.3 Uplink messages

For various reasons some States may not have implemented specific FANS-1/A uplink message elements contained in the message set in Section 5.8 (e.g. UM#33 **CRUISE [altitude]**). These individual implementations shall not impact overall operations.

4.3 Use of Pre-Formatted and Free Text Messages

4.3.1 Preferred use of pre-formatted messages

Free text messages shall be used only when an appropriate pre-formatted message element does not exist. In particular, the creation of a clearance request and the issuing of a clearance shall be performed by the use of pre-formatted message elements only. The use of pre-formatted message elements allows on board data processing such as the automatic insertion of the clearance information into the FMC. It also allows the controller to respond more quickly when the ATS system has the capability to automatically link a pre-formatted request to a pre-formatted response. Additionally, this process minimizes the risk of input errors.

When a free text message is required, standard ATC phraseology and format shall be used. Non-essential words and phrases should be avoided. Abbreviations should only be included in free text messages when they form part of standard ICAO phraseology, e.g. ETA.

4.3.2 Standardized free text messages

While pre-formatted message elements are required to be used whenever possible, there are occasions where frequent use of free text allows the meaning and appropriate response to be standardized. The Standard Free text message set is shown in Section 5.10.

4.3.3 Storing free text messages

ATSUs capable of storing free text messages should select those message elements from the standard free text message set (see <u>FANS-1/A CPDLC Standard Free Text Messages</u>) appropriate to their particular environments. When the storage of free text messages is not possible, controllers shall use the same message formats when typing free text messages.

4.4 Exchange of CPDLC messages

4.4.1 Message assurance

The FANS-1/A system does not provide for <u>end-to-end</u> message assurance. Therefore, there can be no guarantee provided by the ground system or the avionics that the message has been delivered to the controller or pilot. However:

- The ATS system will receive a network acknowledgment (MAS Message Assurance) to an uplink
 message indicating that the message has been delivered to the aircraft's ACARS MU, and
- The avionics will receive a network acknowledgment to a downlink message indicating that the message has been delivered to the communication service provider's system.

4.4.2 Ambiguous dialogues

In the case of a controller or pilot having any doubt as to the intent of a message, or if any other ambiguity exists, clarification shall be sought through the use of voice communication.

4.4.3 Interruption of a CPDLC dialogue

If a CPDLC dialogue is interrupted by a system shutdown, the entire dialogue shall be re-commenced by voice communication.



Chapter: 9
Page: 29
Rev: 0
Date: 20 Oct 07

4.4.4 Approval of request or clearance / instruction

4.4.4.1 Affirmative response to a clearance/instruction

The **Wilco** downlink message indicates that the pilot will comply fully with the clearance/instruction contained in the associated uplink message. The readback of a clearance or instruction issued by CPDLC is not required.

4.4.4.2 Affirmative response to a clearance request

The **Roger** or **Affirm** uplinks are not appropriate responses to a clearance request and shall not be used for this purpose. The controller shall only approve a clearance request by uplinking a message containing an actual clearance.

4.4.4.3 Conditions relating to a specific clearance

Terms or conditions relating to a specific clearance shall be included in the clearance uplink message. They shall not be sent as a separate message.

4.4.4.4 Affirmative response to a negotiation request

AFFIRM is an appropriate response to an uplinked negotiation request message that is acceptable (e.g. CAN YOU ACCEPT [altitude] AT [time]).

4.4.5 Negative response to a downlink request

4.4.5.1 Negative response to a clearance request

When a clearance request is denied, the controller shall use the element **UNABLE** (not **NEGATIVE**) in the uplink response. The aircraft's current clearance <u>shall not be</u> re-stated.

4.4.5.2 Explanation of negative response

Pre-formatted elements such as **Due to traffic** (or a free text element) should be added to the response message if clarification is considered necessary. Additional elements (including free text elements) in the form of an explanation must be included when responding to a multiple clearance request where some, but not all clearance requests can be granted.

4.4.5.3 Offering alternative clearances to downlink requests

If the clearance contained in a downlink request is not available, but an alternative (similar) clearance is available, ATC must not simply respond to the downlink request with the alternative uplink clearance. An UNABLE must be uplinked to close the original clearance request. Depending on workload and traffic, ATC may then uplink an alternative clearance.

Example:

Pilot REQUEST CLIMB TO F370 Controller UNABLE. DUE TO TRAFFIC

Controller CLIMB TO AND MAINTAIN F350. REPORT LEVEL F350

The ATC response in the following example is incorrect and should not be used

Pilot REQUEST CLIMB TO F370

Controller UNABLE. CLIMB TO AND MAINTAIN F350. REPORT LEVEL F350

4.4.6 Negative response to an uplink request

NEGATIVE is an appropriate response to an uplink negotiation request that is not acceptable (e.g. **CAN YOU ACCEPT [altitude] AT [time]**).

4.4.7 Time period between receiving and responding to a message

The controller and the pilot shall respond to incoming requests as soon as practicable to avoid duplicate messages entering the system.



 Chapter:
 9

 Page:
 30

 Rev:
 0

 Date:
 20 Oct 07

4.4.7.1 Delays in responding

The controller and the pilot should consider that it takes up to one minute for a message to be received, time for the pilot (or the controller) to take action and respond, and up to one minute for the reply to be received. Nevertheless, they should be aware that extra delays could occur in the transmission of any response to a CPDLC message.

Note. Transmission times for messages may vary depending on the transmission media.

4.4.7.2 Delay expected after receiving a "STANDBY" message

If the **Standby** response is received, a further response can be expected within 10 minutes. The message remains open. If the pilot (or the controller) does not respond within this time, the next message should be in the form of an inquiry, not a duplicated request.

4.4.8 Re-sending Messages

4.4.8.1 Re-sending of a message when no alert received

When the pilot (or the controller) elects to re-send a message after a reasonable period of time has passed and no error message has been received indicating the non-delivery of the message, the message shall be sent as a query message. Alternatively, voice communication may be used.

Pilot	REQUEST CLIMB [level]
Pilot	WHEN CAN I EXPECT [level]

4.4.8.2 Re-sending of a message when an alert has been received

When an error message indicating the non-delivery of the message has been received at the flight deck or at the controller work station, the pilot (or the controller) may elect to re-send an identical message. Alternatively, voice may be used.

4.4.9 Duplicate requests received

4.4.9.1 Second identical request after an uplink "STANDBY" message

If a second identical downlink request is sent by the pilot after a reasonable period (more than 10 minutes) has passed since receiving a **STANDBY** response to an earlier request, the controller should respond with **UNABLE REQUEST DEFERRED**. This will close out the second message, inform the pilot that the reply will take longer, and will leave only one open message requiring a response.

4.4.9.2 Multiple identical requests

All messages requiring a response must be answered. If the controller (or the pilot) receives a second identical CPDLC request prior to having answered the first, they shall respond to both of the messages to ensure message closure. On rare occasions, the first uplink message may generate an "invalid reference number" error message, in the avionics.

4.4.10 Altitude change clearances

4.4.10.1 Issuing conditional altitude change clearances

The potential exists for the restriction "AT" contained at the beginning of the following conditional clearances to be missed by aircrew and consequently the clearance may be executed prematurely.

- UM#21 AT [time] CLIMB TO AND MAINTAIN [altitude]
- UM#22 AT [position] CLIMB TO AND MAINTAIN [altitude]
- UM#24 AT [time] DESCEND TO AND MAINTAIN [altitude]
- UM#25 AT [position] DESCEND TO AND MAINTAIN [altitude]



Chapter: 9
Page: 31
Rev: 0
Date: 20 Oct 07

Controllers shall precede UM#21, UM#22, UM#24 and UM#25 with UM#19 **Maintain [altitude]** indicating to aircrew to maintain their present altitude until the condition of the clearance is satisfied.

4.4.10.2 Level report requirements for climb or descent clearances

If a CPDLC level report <u>is required</u>, controllers shall append UM#129 REPORT LEVEL [altitude] to any vertical change clearance to a single altitude so that flight crews have access to the pre-formatted downlink report.

If no **REPORT LEVEL [altitude]** is received, the crew has no requirement to report maintaining the cleared flight level.

Example clearance issued to a flight currently cruising at FL310 requesting climb to FL350 when the climb can not be executed until the aircraft is at MICKY MAINTAIN FL310, AT MICKY CLIMB TO AND MAINTAIN FL350, REPORT LEVEL FL350

Note: Some States do not require this CPDLC level report in airspace in which ADS-C is in use.

4.4.10.3 Canceling block altitude clearances

A block altitude clearance is an authorization for an aircraft to operate between and at the levels specified in the clearance. A pilot report at the floor or ceiling of the block altitude clearance does not cancel the block altitude clearance – the clearance is only cancelled by the pilot acceptance of a subsequent (vertical) clearance issued by ATC. If the current block altitude clearance is no longer required, the pilot should request the level(s) preferred.

To cancel a previously issued block clearance and limit the aircraft to one specific level the controller shall issue an appropriate vertical instruction such as:

- UM#19 Maintain [altitude];
- UM#20 CLIMB TO AND MAINTAIN [altitude]; or
- UM#28 DESCEND TO REACH [altitude] BY [time].

The controller should also add UM#129 REPORT LEVEL [altitude].

The Wilco response to the vertical clearance uplink cancels any previously issued block clearance.

4.4.10.4 Issuing Level Restrictions

Depending on how they are used, certain CPDLC message elements may be used as either:

- 1. A "stand-alone" clearance; or
- 2. A level requirement for an interim level, when appended to another CPDLC vertical clearance

This applies to the following message elements:

- UM#26 CLIMB TO REACH [altitude] BY [time]
- UM#27 CLIMB TO REACH [altitude] BY [position]
- UM#28 DESCEND TO REACH [altitude] BY [time]
- UM#29 DESCEND TO REACH [altitude] BY [position]

Example 1:

Example 1.	
ATC	CLIMB TO REACH FL390 BY 2200
Meaning	The aircraft is cleared to climb to FL390 and is required to be maintaining FL390 by 2200.

Example 2: The following format may be used to issue a requirement for an interim level. The example shown reflects ICAO phraseology. Some FIRs may choose to reverse the order of the elements shown in the example, so long as both are included.



Chapter: 9
Page: 32
Rev: 0
Date: 20 Oct 07

ATC	CLIMB TO AND MAINTAIN FL390 CLIMB TO REACH FL370 BY 0100
Meaning	The aircraft is cleared to climb to FL390, and is required to reach FL370 (or higher) by 0100.

Note 1. Because of limitations in the FANS-1/A message set, there is no specific message element to issue a requirement for an intermediate level.

Note 2. In the ICAO CPDLC Message set, CLIMB TO [level].REACH [level] BY [time/position] would be used (see Example 2a)

Example 2a:

ATC	CLIMB TO AND MAINTAIN FL390 REACH FL370 BY 0100
Meaning	The aircraft is cleared to climb to FL390, and is required to reach FL370 (or higher) by 0100.

Example 3: Confusion may occur if the vertical clearance and the requirement were sent separately. (This scenario might occur, for example, if the controller decided to add a requirement <u>after</u> issuing the initial clearance):

ATC PILOT	CLÍMB TO AND MAINTAIN FL390 WILCO
	followed by
ATC	CLIMB TO REACH FL370 BY 2200

Technically, the second clearance amends the final cleared level of the aircraft (to FL370), which was not the intention of the controller. Because of the confusion inherent in this type of message exchange, this message should not be used in this manner; instead, the entire clearance should be re-stated; *i.e.* CLIMB TO AND MAINTAIN FL390. CLIMB TO REACH FL370 BY 2200

4.4.11 Requesting an aircraft's speed

When the aircraft's Mach number or indicated airspeed is requested, the controller shall use the preformatted message element **CONFIRM SPEED**.

4.4.12 Advising a wake turbulence offset

In the event of a pilot initiating a wake turbulence offset (up to 2nm either side of track) in RVSM airspace for which the controller is not required to issue a clearance, the pilot shall advise the controller. The following data or voice phraseology shall be used:

Pilot	Wake Dev [direction] Direction L or R (left or right) as appropriate
-------	--

4.4.13 Direct Tracking and UPR Aircraft

UPRs are calculated by airline flight planning systems as being the optimal route clearance for the specific aircraft taking into account the latest available weather information. As such, controllers should not offer unsolicited direct tracking to aircraft flying a UPR as the direct route may be less optimal than the aircraft's current route.

4.4.14 Planned Airborne Re-route Procedure – DARP (Datalink Aircraft)

A planned airborne re-route will occur periodically on long haul Pacific routes when a new forecast is issued after departure, indicating that significant time and/or fuel savings can be made. The following procedures apply when aircraft request a planned re-route while en-route. Note:(At the time of



Chapter: 9
Page: 33
Rev: 0
Date: 20 Oct 07

incorporation into the FOM, this Section applies only to routes transiting directly from/to Auckland / Oakland Oceanic Airspace Use of these procedures in other FIR's/areas is appropriate without further FOM modification, provided some written agreement between the participants is in place.)

AOC will plan the re-route and uplink the route to the aircraft, commencing from the waypoint on the current route, ahead of the Aircraft and finishing at destination. Note: Some Flight Management Systems allow AOC uplinks to the Active Route. It is recommended that all AOC route uplinks are directed to the Inactive Route.

Flight crew will load the re-route into the "Inactive Route" of the FMC then Downlink the unedited route request to the ATSU. Note: Crew are not permitted to edit the route, other than to delete a waypoint that may have been crossed between the re-route being prepared by the AOC, and the ATC route request being sent.

ATC (1) receives the downlink re-route request (message #24)

REQUEST [departure airport:xxxx destination airport:xxxx (fix1)(fix2)(fix3) ...]

The ground system will "auto populate" the uplink reply

ATC (1) will do either "a" or "b" below:

a) uplink route clearance (message #83) with the departure airport deleted:

AT [fix 1] CLEARED [destination airport:xxxx (fix1)(fix2)(fix3) ...]

and then ATC (1) will then transmit the new route to ATC (2) via AIDC messaging;

b) reply "UNABLE" due to traffic where conflicting traffic prevents route clearance at the current flight

level.

The following operational requirements apply:

- a) The requested route must commence from the waypoint on the current route ahead of the aircraft, and (if the divergence waypoint is not the next fix ahead of the aircraft) must contain all waypoints on the current route ahead of the aircraft up to the divergence waypoint, followed by the revised routing to destination.
- b) The re-route request must be made at least 20min before the divergence waypoint, to allow processing time.
- c) The re-route request must not be made within 60min of the common FIR boundary to allow electronic route data transfer ATC(1) to ATC(2). [AIDC messaging].
- d) The re-route request may be made to the new Data Authority, immediately after crossing the common FIR boundary

4.5 Multi-Element Requests

4.5.1 Avoiding multiple element clearance requests

To avoid potential ambiguity, pilots should, where possible, avoid sending multiple clearance requests in the one downlink message.

4.5.2 Responding to multiple element clearance requests

4.5.2.1 Multiple clearance requests in one message: All approved

Where a multiple clearance request <u>is</u> received and all clearance request elements can be approved, each clearance request element shall be specifically addressed in the response.

Example

Pilot	REQUEST CLIMB TO [level]
	REQUEST DIRECT TO [position]
Controller	CLIMB TO AND MAINTAIN [level]
Controller	PROCEED DIRECT TO [position]



 Chapter:
 9

 Page:
 34

 Rev:
 0

 Date:
 20 Oct 07

4.5.2.2 Multiple clearance requests in one message: All not approved

If the response to a multi-element message is **UNABLE** then the reply applies to <u>all</u> elements of the original message. The aircraft's current clearance <u>shall not be</u> re-stated.

Example

Pilot	REQUEST CLIMB TO [level] REQUEST DIRECT TO [position]
Controller	UNABLE

4.5.2.3 Multiple clearance requests in one message: Some approved / Some not approved

When a multi-element clearance request is received and part of it can be granted and part of it cannot, the uplink <u>shall not</u> contain the single word **UNABLE** and a clearance. If **UNABLE** is used within a clearance message, it must contain a qualifier to remove any ambiguity.

The following examples illustrate correct ATC responses.

First correct example:

	Pilot	REQUEST CLIMB TO [level]
		REQUEST DIRECT TO [position]
	Controller	UNABLE Higher altitude
	Controller	PROCEED DIRECT TO [position]

Second correct example:

Pilot	REQUEST CLIMB TO [level]
	REQUEST DIRECT TO [position]
Controller	UNABLE Higher altitude
Controller	PROCEED DIRECT TO [position]

The ATC response in the following example is incorrect and shall never be used:

Pilot	REQUEST CLIMB TO [level] REQUEST DIRECT TO [position]
Controller	UNABLE PROCEED DIRECT TO [position]

4.6 Multi-element Uplink Messages

4.6.1 Combining multiple elements into a single message

Only uplink elements that are related to the overall message should be combined into a single message. Messages that contain unrelated elements could either cause confusion or result in the crew rejecting the entire message when one of the elements on its own could have been acceptable. The following multi-element uplink is an example of a clearance that can be unambiguously sent as a single message.

WHEN READY DESCEND TO AND MAINTAIN FL280 REPORT LEVEL FL280

When the elements are not dependent on each other, controllers should send a single element clearance and wait for the response before sending a subsequent instruction.

4.6.2 Dependent Clearances

A dependent clearance is a message consisting of more than one clearance element, where the pilot must comply with each of the elements. A rejection of any of the elements, either singly or in combination, renders the entire clearance invalid. The following multi-element uplink is an example of a dependent clearance:



Chapter: 9
Page: 35
Rev: 0
Date: 20 Oct 07

CLIMB TO AND MAINTAIN FL330 AT FL330 PROCEED DIRECT TO TUNTO REPORT LEVEL FL330.

In this example the aircraft must complete a change of level in order to be issued with an amended route clearance.

Whenever possible, all elements of a dependent clearance should be sent in a single uplink message. Sending the elements as individual messages may compromise safety or separation if the pilot accepts the first uplink of a dependent clearance, complies with the instruction, and then responds UNABLE to the next message when received. By the time that the controller has received the UNABLE response, the aircraft could have begun executing the first instruction of a clearance that is invalid if the pilot cannot comply with the second element.

The response to a multi-element uplink message will either be a WILCO or UNABLE that refers to the entire message. It is not possible for the pilot to respond to individual elements of a multi-element message.

NOTE: Care must be taken in the construction of dependent clearances to ensure that there is no ambiguity present in the message. In the example above, the second element has been carefully chosen to reinforce the requirement instead of using the word THEN followed by the route clearance PROCEED DIRECT TO TUNTO.

The following message is an example of poor message construction as it does not unambiguously convey to the pilot that the climb clearance must be completed prior to commencing the route clearance component. This format SHOULD NOT be used for dependent clearances:

CLIMB TO AND MAINTAIN FL330 THEN PROCEED DIRECT TO TUNTO

4.7 Message Closure

4.7.1 General

Definitions:

- A message requiring a response remains open until a referenced response is received.
- A message is **closed** when either a response is not technically required, or after a referenced response other than **STANDBY** or **REQUEST DEFERRED** has been received.

A normal downlink free text message (based on downlink message element DM#67) does not require a response from the controller to close the CPDLC exchange. However, a downlink free text message based on downlink message element DM#68 (Distress attribute) does require a response and the message will remain open until a referenced response is received.

Any uplink message containing only free text requires a **Roger** response. The message will remain open until a referenced response containing **Roger** is received.

4.7.2 Answering an uplink free text

When the controller sends a message containing only free text, or a free text element combined with elements that do not require a response, the pilot must respond to the free text with a **ROGER** response before responding to the actual contents of the message.



 Chapter:
 9

 Page:
 36

 Rev:
 0

 Date:
 20 Oct 07

4.7.3 Dialogue commenced via CPDLC and continued via voice

If a CPDLC message requiring a closure response is subsequently negotiated by voice, a CPDLC closure response message is still necessary to ensure the proper synchronization of ground and aircraft systems.

4.8 Position Reporting

4.8.1 General

To harmonize waypoint position reports by either voice or data, the "Position" and "Next Position" shall only contain compulsory reporting points unless requested otherwise by ATC. The "Ensuing Significant Point" may be either the compulsory or non-compulsory reporting point after the "Next Position" (Refer AIREP form PANS/ATM, Appendix 1).

4.8.2 Downlink of position report

When a CPDLC connection exists in a procedural, non-ADS-C environment, pilots shall ensure that position reporting is conducted via CPDLC. A CPDLC position report shall be sent manually by the pilot whenever an ATC waypoint is passed over, (or passed abeam when offset flight is in progress). ATC expects position reports based on downlink message DM#48 - **POSITION REPORT**.

4.8.3 Flexible track position reports

All waypoints published for an independent flex track or user preferred route (UPR) are compulsory reporting points. However, when the track follows a published ATS route, position reports are not required at any non-compulsory waypoints defined for that ATS route.

4.8.4 First position report

Pilots shall downlink a CPDLC position report (ATC waypoint) to the next ATSU after the completion of:

- An initial CPDLC connection (when inbound from an area not providing CPDLC services), or during a connection transfer;
- **Either** when the CPDLC connection transfer has been completed; <u>or</u> at the associated FIR boundary.

This position report is required whether or not there is an ADS-C contract in place. It serves as confirmation that the receiving centre is the Current Data Authority.

4.8.5 Sending of ATC waypoints only

Additional non-ATC waypoints may be sequenced by the FMC, however information relating to these waypoints is not of interest to ATC. It is the pilot's responsibility to report only at ATC waypoints.

4.8.6 Updating a waypoint estimate

When it is necessary to update a waypoint ETA a free text message shall be sent in the form of – Revised ETA [position] [time].

4.8.7 Non-receipt of a scheduled position report

If a scheduled position report is not received via CPDLC, the use of voice communication by the controller is not mandatory. The controller may obtain the report by uplinking message UM#147 - REQUEST POSITION REPORT.

4.8.8 Sequencing 'ABEAM' waypoints in excess of FMC parameters

When an aircraft passes abeam a waypoint in excess of the defined sequencing parameter for the aircraft type the FMC will not sequence the active waypoint on the Legs and Position Report pages. Operators shall develop appropriate airborne procedures to ensure correct waypoint sequencing.

Note: **Some** ATS systems use current GPS position that is included in the ATC position report to update their ground systems.



Chapter: 9
Page: 37
Rev: 0
Date: 20 Oct 07

4.8.9 ARINC 424 fix names

Crews should be aware that ATC ground systems can not process latitudes and longitudes encoded as fix names in the ARINC 424 format. Example 10N40 (indicates lat/long of 10N140W). Downlinks containing such fix names may be rejected by ATC systems.

4.9 FANS-1/A CPDLC Message Set and Intent

This Section contains a complete listing of the message intent for all FANS-1/A CPDLC messages as defined by the OPLINK Panel. Additional comments provided by the ISPACG forum are displayed in Italics.

4.9.1 Response Requirements Key:

CLOSURE RESPONSES
WILCO, UNABLE, will close the uplink message.
AFFIRM, NEGATIVE, will close the uplink message.
ROGER, will close the uplink message.
Most messages with an NE attribute require an operational response. Only the correct operational response is presented to the pilot. The uplink message is considered to be closed on sending and does not require a response to close the dialogue. The WILCO, UNABLE, AFFIRM, NEGATIVE, ROGER, and STANDBY responses are not enabled for pilot selection.
Response required.
Response not required

Note: Under some circumstances, an ERROR message will also close an uplink message.

Multi element uplink messages require only a single closure response. The response required for a multi element message is the highest priority response out of each of the elements in the message. When determining the highest priority, the following priority order is used:

W/U

A/N

R

ΝE

For example, the uplink CLIMB TO AND MAINTAIN FL370. REPORT LEVEL FL370 contains two elements. The first element requires a "W/U" response, the second an "R" response. The highest priority response is W/U, therefore this is the response required for closure.

4.9.2 Uplink - Responses and Acknowledgements

UM	MESSAGE ELEMENT	Message Intent	RESPONSE
0	UNABLE	Indicates that ATS cannot comply with the request.	
1	STANDBY	Indicates that ATS has received the message and will respond. The pilot is informed that the request is being assessed and there will be a short-term delay (within 10 minutes). The exchange is not closed and the request will be responded to when conditions allow.	NE
2	REQUEST DEFERRE D	Indicates that ATS has received the request but it has been deferred until later. The pilot is informed that the request is being assessed and a long-term delay can be expected. The exchange is not closed and the request will be responded to when conditions allow.	
3	ROGER	Indicates that ATS has received and understood the message.	NE
4	AFFIRM	Yes	NE
5	NEGATIVE	No	NE



 Chapter: 9

 Page: 38

 Rev: 0

 Date: 20 Oct 07

4.9.3 Uplink - Vertical Clearances

UM	Message Element	MESSAGE INTENT	RESPONSE
6	EXPECT [altitude]	Notification that a level change instruction	R
	LAFLOT [attitude]	should be expected.	IX
7	EXPECT CLIMB AT [time]	Notification that an instruction should be expected for the aircraft to commence climb at the specified time.	R
8	EXPECT CLIMB AT [position]	Notification that an instruction should be expected for the aircraft to commence climb at the specified position.	R
9	EXPECT DESCENT AT [time]	Notification that an instruction should be expected for the aircraft to commence descent at the specified time.	R
10	EXPECT DESCENT AT [position]	Notification that an instruction should be expected for the aircraft to commence descent at the specified position.	R
11	EXPECT CRUISE CLIMB AT [time]	Notification that an instruction should be expected for the aircraft to commence cruise climb at the specified time. Due to different interpretations between the various ATS units this element should be avoided.	R
12	EXPECT CRUISE CLIMB AT [position]	Notification that an instruction should be expected for the aircraft to commence cruise climb at the specified position. Due to different interpretations between the various ATS units this element should be avoided	R
13	AT [time] EXPECT CLIMB TO [altitude]	Notification that an instruction should be expected for the aircraft to commence climb at the specified time to the specified level.	R
14	AT [position] EXPECT CLIMB TO [altitude]	Notification that an instruction should be expected for the aircraft to commence climb at the specified position to the specified level.	R
15	AT [time] EXPECT DESCENT TO [altitude]	Notification that an instruction should be expected for the aircraft to commence descent at the specified time to the specified level.	R
16	AT [position] EXPECT DESCENT TO [altitude]	Notification that an instruction should be expected for the aircraft to commence descent at the specified position to the specified level.	R
17	AT [time] EXPECT CRUISE CLIMB TO [altitude]	Notification that an instruction should be expected for the aircraft to commence cruise climb at the specified time to the specified level. Due to different interpretations between the various ATS units, this element should be avoided.	R
18	AT [position] EXPECT CRUISE CLIMB TO [altitude]	Notification that an instruction should be expected for the aircraft to commence cruise climb at the specified position to the specified level. Due to different interpretations between the various ATS units, this element should	R



 Chapter:
 9

 Page:
 39

 Rev:
 0

 Date:
 20 Oct 07

		be avoided.	
19	MAINTAIN [altitude]	Instruction to maintain the specified level.	W/U
20	CLIMB TO AND MAINTAIN [altitude]	Instruction that a climb to the specified level is to commence and the level is to be maintained when reached.	W/U
21	AT [time] CLIMB TO AND MAINTAIN [altitude]	Instruction that at the specified time, a climb to the specified level is to commence and once reached the specified level is to be maintained.	W/U
22	AT [position] CLIMB TO AND MAINTAIN [altitude]	Instruction that at the specified position, a climb to the specified level is to commence and once reached the specified level is to be maintained.	W/U
23	DESCEND TO AND MAINTAIN [altitude]	Instruction that a descent to the specified level is to commence and the level is to be maintained when reached.	W/U
24	AT [time] DESCEND TO AND MAINTAIN [altitude]	Instruction that at the specified time a decent to the specified level is to commence and once reached the specified level is to be maintained.	W/U
25	AT [position] DESCEND TO AND MAINTAIN [altitude]	Instruction that at the specified position a descent to the specified level is to commence and when the specified level is reached it is to be maintained.	W/U
26	CLIMB TO REACH [altitude] BY [time]	Instruction that a climb is to commence at a rate such that the specified level is reached at or before the specified time. When this element is not concatenated with another vertical clearance the level specified is the assigned level which is to be maintained.	W/U
27	CLIMB TO REACH [altitude] BY [position]	Instruction that a climb is to commence at a rate such that the specified level is reached at or before the specified position. When this element is not concatenated with another vertical clearance the level specified is the assigned level which is to be maintained.	W/U
28	DESCEND TO REACH [altitude] BY [time]	Instruction that a descent is to commence at a rate such that the specified level is reached at or before the specified time. When this element is not concatenated with another vertical clearance the level specified is the assigned level which is to be maintained.	W/U
29	DESCEND TO REACH [altitude] BY [position]	Instruction that a descent is to commence at a rate such that the specified level is reached at or before the specified position. When this element is not concatenated with another vertical clearance the level specified is the assigned level which is to be maintained.	W/U
30	MAINTAIN BLOCK [altitude] TO [altitude]	A level within the specified vertical range is to be maintained.	W/U
31	CLIMB TO AND MAINTAIN BLOCK	Instruction that a climb to a level within	W/U



 Chapter:
 9

 Page:
 40

 Rev:
 0

 Date:
 20 Oct 07

	[altitude] TO [altitude]	the specified vertical range is to	
	[]	commence.	
32	DESCEND TO AND MAINTAIN BLOCK [altitude] TO [altitude]	Instruction that a descent to a level within the specified vertical range is to commence.	W/U
33	CRUISE [altitude]	Instruction that authorizes a pilot to conduct flight at any altitude from the minimum altitude up to and including the altitude specified in the clearance. further, it is approval for the pilot to proceed to and make an approach at the destination airport. Due to different interpretations between the various ATS units, this element should be avoided.	
34	CRUISE CLIMB TO [altitude]	A cruise climb is to commence and continue until the specified level is reached. Due to different interpretations between the various ATS units, this element should be avoided.	W/U
35	CRUISE CLIMB ABOVE [altitude]	A cruise climb can commence once above the specified level. Due to different interpretations between the various ATS units, this element should be avoided.	W/U
36	EXPEDITE CLIMB TO [altitude]	The climb to the specified level should be made at the aircraft's best rate.	W/U
37	EXPEDITE DESCENT TO [altitude]	The descent to the specified level should be made at the aircraft's best rate.	W/U
38	IMMEDIATELY CLIMB TO [altitude]	Urgent instruction to immediately climb to the specified level.	W/U
39	IMMEDIATELY DESCEND TO [altitude]	Urgent instruction to immediately descend to the specified level.	W/U
40	IMMEDIATELY STOP CLIMB AT [altitude]	Urgent instruction to immediately stop a climb once the specified level is reached.	W/U
41	IMMEDIATELY STOP DESCENT AT [altitude]	Urgent instruction to immediately stop a descent once the specified level is reached.	W/U
171	CLIMB AT [vertical rate] MINIMUM	Instruction to climb at not less than the specified rate.	W/U
172	CLIMB AT [vertical rate] MAXIMUM	Instruction to climb at not above the specified rate.	W/U
173	DESCEND AT [vertical rate] MINIMUM	Instruction to descend at not less than the specified rate.	W/U
174	DESCEND AT [vertical rate] MAXIMUM	Instruction to descend at not above the specified rate.	W/U

4.9.4 Uplink - Crossing Constraints

UM	Message Element	Message Intent	RESPONSE
42	EXPECT TO CROSS [position] AT [altitude]	Notification that a level change instruction should be expected which will require the specified position to be crossed at the specified level.	R
43	EXPECT TO CROSS [position] AT OR ABOVE [altitude]	Notification that a level change instruction should be expected which will require the specified position to be crossed at or	R



 Chapter:
 9

 Page:
 41

 Rev:
 0

 Date:
 20 Oct 07

		above the specified level.	
44	EXPECT TO CROSS [position] AT OR BELOW [altitude]	Notification that a level change instruction should be expected which will require the specified position to be crossed at or below the specified level.	R
45	EXPECT TO CROSS [position] AT AND MAINTAIN [altitude]	Notification that a level change instruction should be expected which will require the specified position to be crossed at the specified level which is to be maintained subsequently.	R
46	CROSS [position] AT [altitude]	The specified position is to be crossed at the specified level. This may require the aircraft to modify its climb or descent profile.	W/U
47	CROSS [position] AT OR ABOVE [altitude]	The specified position is to be crossed at or above the specified level.	W/U
48	CROSS [position] AT OR BELOW [altitude]	The specified position is to be crossed at or below the specified level.	W/U
49	CROSS [position] AT AND MAINTAIN [altitude]	Instruction that the specified position is to be crossed at the specified level and that level is to be maintained when reached.	W/U
50	CROSS [position] BETWEEN [altitude]	The specified position is to be crossed at a level between the specified levels.	W/U
51	CROSS [position] AT [time]	The specified position is to be crossed at the specified time.	W/U
52	CROSS [position] AT OR BEFORE [time]	The specified position is to be crossed at or before the specified time.	W/U
53	CROSS [position] AT OR AFTER [time]	The specified position is to be crossed at or after the specified time.	W/U
54	CROSS [position] BETWEEN [time] AND [time]	The specified position is to be crossed at a time between the specified times.	W/U
55	CROSS [position] AT [speed]	The specified position is to be crossed at the specified speed and the specified speed is to be maintained until further advised.	W/U
56	CROSS [position] AT OR LESS THAN [speed]	The specified position is to be crossed at a speed equal to or less than the specified speed and the specified speed or less is to be maintained until further advised.	W/U
57	CROSS [position] AT OR GREATER THAN [speed]	The specified position is to be crossed at a speed equal to or greater than the specified speed and the specified speed or greater is to be maintained until further advised.	W/U
58	CROSS [position] AT [time] AT [altitude]	The specified position is to be crossed at the specified time and the specified level.	W/U
59	CROSS [position] AT OR BEFORE [time] AT [altitude]	The specified position is to be crossed at or before the specified time and at the specified level.	W/U
60	CROSS [position] AT OR AFTER [time] AT [altitude]	The specified position is to be crossed at or after the specified time and at the specified level.	W/U
61	CROSS [position] AT AND MAINTAIN [altitude] AT [speed]	Instruction that the specified position is to be crossed at the specified level and speed and the level and speed are to be maintained.	W/U



 Chapter:
 9

 Page:
 42

 Rev:
 0

 Date:
 20 Oct 07

62	AT [time] CROSS [position] AT AND MAINTAIN [altitude]	Instruction that at the specified time the specified position is to be crossed at the specified level and the level is to be maintained.	W/U
63	AT [time] CROSS [position] AT AND MAINTAIN [altitude] AT [speed]	Instruction that at the specified time the specified position is to be crossed at the specified level and speed and the level and speed are to be maintained.	W/U

4.9.5 Uplink - Lateral Offsets

UM	Message Element	MESSAGE INTENT	RESPONSE
64	OFFSET [distance offset] [direction] OF ROUTE	Instruction to fly a parallel track to the cleared route at a displacement of the specified distance in the specified direction.	W/U
65	AT [position] OFFSET [distance offset] [direction] OF ROUTE	Instruction to fly a parallel track to the cleared route at a displacement of the specified distance in the specified direction and commencing at the specified position.	W/U
66	AT [time] OFFSET [distance offset] [direction] OF ROUTE	Instruction to fly a parallel track to the cleared route at a displacement of the specified distance in the specified direction and commencing at the specified time.	W/U
67	PROCEED BACK ON ROUTE	The cleared flight route is to be rejoined.	W/U
68	REJOIN ROUTE BY [position]	The cleared flight route is to be rejoined at or before the specified position.	W/U
69	REJOIN ROUTE BY [time]	The cleared flight route is to be rejoined at or before the specified time.	W/U
70	EXPECT BACK ON ROUTE BY [position]	Notification that a clearance may be issued to enable the aircraft to rejoin the cleared route at or before the specified position.	R
71	EXPECT BACK ON ROUTE BY [time]	Notification that a clearance may be issued to enable the aircraft to rejoin the cleared route at or before the specified time.	R
72	RESUME OWN NAVIGATION	Instruction to resume own navigation following a period of tracking or heading clearances. May be used in conjunction with an instruction on how or where to rejoin the cleared route.	W/U

4.9.6 Uplink - Route Modifications

UM	MESSAGE ELEMENT	MESSAGE INTENT	RESPONSE
73	[predepartureclearance]	Notification to the aircraft of the instructions to be followed from departure until the specified clearance limit.	W/U
74	PROCEED DIRECT TO [position]	Instruction to proceed directly from the present position to the specified position.	W/U
75	WHEN ABLE PROCEED DIRECT TO [position]	Instruction to proceed, when able, directly to the specified position.	W/U
76	AT [time] PROCEED DIRECT TO [position]	Instruction to proceed, at the specified time, directly to the specified position.	W/U



 Chapter:
 9

 Page:
 43

 Rev:
 0

 Date:
 20 Oct 07

		landon at the constitued	
77	AT [position] PROCEED DIRECT TO [position]	Instruction to proceed, at the specified position, directly to the next specified position.	W/U
78	AT [altitude] PROCEED DIRECT TO [position]	Instruction to proceed, upon reaching the specified level, directly to the specified position.	W/U
79	CLEARED TO [position] VIA [route clearance]	Instruction to proceed to the specified position via the specified route.	W/U
80	CLEARED [route clearance]	Instruction to proceed via the specified route.	W/U
81	CLEARED [procedure name]	Instruction to proceed in accordance with the specified procedure.	W/U
82	CLEARED TO DEVIATE UP TO [distance offset] [direction] OF ROUTE	Approval to deviate up to the specified distance from the cleared route in the specified direction.	W/U
83	AT [position] CLEARED [route clearance]	Instruction to proceed from the specified position via the specified route.	W/U
84	AT [position] CLEARED [procedure name]	Instruction to proceed from the specified position via the specified procedure.	W/U
85	EXPECT [route clearance]	Notification that a clearance to fly on the specified route may be issued.	R
86	AT [position] EXPECT [route clearance]	Notification that a clearance to fly on the specified route from the specified position may be issued.	R
87	EXPECT DIRECT TO [position]	Notification that a clearance to fly directly to the specified position may be issued.	R
88	AT [position] EXPECT DIRECT TO [position]	Notification that a clearance to fly directly from the first specified position to the next specified position may be issued.	R
89	AT [time] EXPECT DIRECT TO [position]	Notification that a clearance to fly directly to the specified position commencing at the specified time may be issued.	R
90	AT [altitude] EXPECT DIRECT TO [position]	Notification that a clearance to fly directly to the specified position commencing when the specified level is reached may be issued.	R
91	HOLD AT [position] MAINTAIN [altitude] INBOUND TRACK [degrees][direction] TURN LEG TIME [leg type]	Instruction to enter a holding pattern with the specified characteristics at the specified position and level.	W/U
92	HOLD AT [position] AS PUBLISHED MAINTAIN [altitude]	Instruction to enter a holding pattern with the published characteristics at the specified position and level.	W/U
93	EXPECT FURTHER CLEARANCE AT [time]	Notification that an onwards clearance may be issued at the specified time.	R
94	TURN [direction] HEADING [degrees]	Instruction to turn left or right as specified onto the specified heading.	W/U
95	TURN [direction] GROUND TRACK [degrees]	Instruction to turn left or right as specified onto the specified track.	W/U
96	FLY PRESENT HEADING	Instruction to continue to fly on the current heading.	W/U
97	AT [position] FLY HEADING [degrees]	Instruction to fly on the specified heading from the specified position.	W/U
98	IMMEDIATELY TURN [direction] HEADING [degrees]	Instruction to turn immediately left or right as specified onto the specified heading.	W/U
99	EXPECT [procedure name]	Notification that a clearance may be	R



 Chapter:
 9

 Page:
 44

 Rev:
 0

 Date:
 20 Oct 07

		issued for the aircraft to fly the specified	
		procedure.	
178	TRACK DETAIL MESSAGE	Message not defined.	

4.9.7 Uplink - Speed Changes

UM	Message Element	Message Intent	RESPONSE
CIVI	WIESSAGE ELEWIEN	Notification that a speed instruction may	INESPUNSE
100	AT [time] EXPECT [speed]	be issued to be effective at the specified time.	R
101	AT [position] EXPECT [speed]	Notification that a speed instruction may be issued to be effective at the specified position.	R
102	AT [altitude] EXPECT [speed]	Notification that a speed instruction may be issued to be effective at the specified level.	R
103	AT [time] EXPECT [speed] TO [speed]	Notification that a speed range instruction may be issued to be effective at the specified time.	R
104	AT [position] EXPECT [speed] TO [speed]	Notification that a speed range instruction may be issued to be effective at the specified position.	R
105	AT [altitude] EXPECT [speed] TO [speed]	Notification that a speed range instruction may be issued to be effective at the specified level.	R
106	MAINTAIN [speed]	The specified speed is to be maintained.	W/U
107	MAINTAIN PRESENT SPEED	The present speed is to be maintained.	W/U
108	MAINTAIN [speed] OR GREATER	The specified speed or a greater speed is to be maintained.	W/U
109	MAINTAIN [speed] OR LESS	The specified speed or a lesser speed is to be maintained.	W/U
110	MAINTAIN [speed] TO [speed]	A speed within the specified range is to be maintained.	W/U
111	INCREASE SPEED TO [speed]	The present speed is to be increased to the specified speed and maintained until further advised.	W/U
112	INCREASE SPEED TO [speed] OR GREATER	The present speed is to be increased to the specified speed or greater, and maintained at or above the specified speed until further advised.	W/U
113	REDUCE SPEED TO [speed]	The present speed is to be reduced to the specified speed and maintained until further advised.	W/U
114	REDUCE SPEED TO [speed] OR LESS	The present speed is to be reduced to the specified speed or less and maintained at or below the specified speed until further advised.	W/U
115	DO NOT EXCEED [speed]	The specified speed is not to be exceeded.	W/U
116	RESUME NORMAL SPEED	Notification that the aircraft need no longer comply with the previously issued speed restriction.	W/U

4.9.8 Uplink - Contact/Monitor/Surveillance Requests

UM	Message Element	Message Intent	RESPONSE
•			



 Chapter:
 9

 Page:
 45

 Rev:
 0

 Date:
 20 Oct 07

117	CONTACT [icaounitname][frequency]	The pilot is required to call the ATS facility on the specified frequency.	W/U
118	AT [position] CONTACT [icaounitname] [frequency]	At the specified position the ATS unit with the specified ATS unit name is to be contacted on the specified frequency.	W/U
119	AT [time] CONTACT [icaounitname] [frequency]	At the specified time the ATS unit with the specified ATS unit name is to be contacted on the specified frequency.	W/U
120	MONITOR [icaounitname][frequency]	The pilot is required to monitor the specified ATS facility on the specified frequency. The Pilot is not required to check in.	W/U
121	AT [position] MONITOR [icaounitname] [frequency]	At the specified position the ATS unit with the specified ATS unit name is to be monitored on the specified frequency.	W/U
122	AT [time] MONITOR [icaounitname] [frequency]	At the specified time the ATS unit with the specified ATS unit name is to be monitored on the specified frequency.	W/U
123	SQUAWK [beacon code]	The specified code (SSR code) is to be selected.	W/U
124	STOP SQUAWK	The SSR transponder responses are to be disabled.	W/U
125	SQUAWK ALTITUDE	The SSR transponder responses should include level information.	W/U
126	STOP ALTITUDE SQUAWK	The SSR transponder responses should no longer include level information.	W/U
179	SQUAWK IDENT	The 'ident' function on the SSR transponder is to be actuated.	W/U

4.9.9 Uplink - Report/Confirmation Requests

UM	Message Element	Message Intent	RESPONSE
127	REPORT BACK ON ROUTE	Instruction to report when the aircraft is back on the cleared route.	R
128	REPORT LEAVING [altitude]	Instruction to report when the aircraft has left the specified level. Either a level that has been maintained, or a level passed through on climb or descent.	R
129	REPORT LEVEL [altitude]	Instruction to report when the aircraft is in level flight at the specified level. Some States do not to use this message in order to avoid confusion because it does not comply with existing voice phraseology	R
175	REPORT REACHING [altitude]	Instruction to report when the aircraft has reached the specified level. To be interpreted as "Report reaching an assigned level."	R
180	REPORT REACHING BLOCK [altitude]	Instruction to report when the aircraft is within the specified vertical range.	R
130	REPORT PASSING [position]	Instruction to report when the aircraft has passed the specified position.	R
181	REPORT DISTANCE [to/from] [position]	Instruction to report the present distance to or from the specified position.	NE
131	REPORT REMAINING FUEL AND	Instruction to report the amount of fuel	NE



 Chapter:
 9

 Page:
 46

 Rev:
 0

 Date:
 20 Oct 07

	SOULS ON BOARD	remaining and the number of persons on board.	
132	CONFIRM POSITION	Instruction to report the present position.	NE
133	CONFIRM ALTITUDE	Instruction to report the present level.	NE
134	CONFIRM SPEED	Instruction to report the present speed.	NE
135	CONFIRM ASSIGNED ALTITUDE	Instruction to confirm and acknowledge the currently assigned level.	NE
136	CONFIRM ASSIGNED SPEED	Instruction to confirm and acknowledge the currently assigned speed.	NE
137	CONFIRM ASSIGNED ROUTE	Instruction to confirm and acknowledge the currently assigned route.	NE
138	CONFIRM TIME OVER REPORTED WAYPOINT	Instruction to confirm the previously reported time over the last reported waypoint.	NE
139	CONFIRM REPORTED WAYPOINT	Instruction to confirm the identity of the previously reported waypoint.	NE
140	CONFIRM NEXT WAYPOINT	Instruction to confirm the identity of the next waypoint.	NE
141	CONFIRM NEXT WAYPOINT ETA	Instruction to confirm the previously reported estimated time at the next waypoint.	NE
142	CONFIRM ENSUING WAYPOINT	Instruction to confirm the identity of the next plus one waypoint.	NE
143	CONFIRM REQUEST	The request was not understood. It should be clarified and resubmitted.	NE
144	CONFIRM SQUAWK	Instruction to report the currently selected transponder code.	NE
145	CONFIRM HEADING	Instruction to report the present heading.	NE
146	CONFIRM GROUND TRACK	Instruction to report the present ground track.	NE
182	CONFIRM ATIS CODE	Instruction to report the identification code of the last ATIS received.	NE
147	REQUEST POSITION REPORT	Instruction to make a position report. To be used if the controller does not receive a scheduled position report.	NE

4.9.10 Uplink - Negotiation Requests

UM	Message Element	Message Intent	BESPONSE
UIVI		IVIESSAGE INTENT	RESPONSE
148	WHEN CAN YOU ACCEPT [altitude]	Request for the earliest time at which the specified level can be accepted.	NE
149	CAN YOU ACCEPT [altitude] AT [position]	Instruction to report whether or not the specified level can be accepted at the specified position.	A/N
150	CAN YOU ACCEPT [altitude] AT [time]	Instruction to report whether or not the specified level can be accepted at the specified time.	A/N
151	WHEN CAN YOU ACCEPT [speed]	Instruction to report the earliest time when the specified speed can be accepted.	NE
152	WHEN CAN YOU ACCEPT [direction] [distance offset] OFFSET	Instruction to report the earliest time when the specified offset track can be accepted.	NE



 Chapter:
 9

 Page:
 47

 Rev:
 0

 Date:
 20 Oct 07

4.9.11 Uplink - Air Traffic Advisories

UM	Message Element	MESSAGE INTENT	RESPONSE
153	ALTIMETER [altimeter]	ATS advisory that the altimeter setting should be the specified setting.	R
154	RADAR SERVICES TERMINATED	ATS advisory that the radar service is terminated.	R
155	RADAR CONTACT [position]	ATS advisory that radar contact has been established at the specified position.	R
156	RADAR CONTACT LOST	ATS advisory that radar contact has been lost.	R
157	CHECK STUCK MICROPHONE [frequency]	A continuous transmission is detected on the specified frequency. Check the microphone button.	R
158	ATIS [atis code]	ATS advisory that the ATIS information identified by the specified code is the current ATIS information.	R

4.9.12 Uplink - System Management Messages

UM	MESSAGE ELEMENT	MESSAGE INTENT	RESPONSE
159	ERROR [error information]	A system generated message that the ground system has detected an error.	NE
160	NEXT DATA AUTHORITY [facility designation]	Notification to the avionics that the next data authority is the specified ATSU.	NE
161	END SERVICE	Notification to the avionics that the data link connection with the current data authority is being terminated.	NE
162	SERVICE UNAVAILABLE	Notification that the ground system does not support this message.	NE
163	[icao facility designation] [tp4Table]	Notification to the pilot of an ATSU identifier.	NE

4.9.13 Uplink - Additional Messages

UM	MESSAGE ELEMENT	Message Intent	RESPONSE
164	WHEN READY	The associated instruction may be complied with at any future time.	NE
165	THEN	Used to link two messages, indicating the proper order of execution of clearances/instructions.	NE
166	DUE TO TRAFFIC	The associated instruction is issued due to traffic considerations.	NE
167	DUE TO AIRSPACE RESTRICTION	The associated instruction is issued due to airspace restrictions.	NE
168	DISREGARD	The indicated communication should be ignored. The previously sent uplink CPDLC message shall be ignored. DISREGARD should not refer to a clearance or instruction. If DISREGARD is used, another element shall be added to clarify which message is to be disregarded.	R
176	MAINTAIN OWN SEPARATION AND VMC	Notification that the pilot is responsible for maintaining separation from other traffic and is also responsible for maintaining Visual Meteorological Conditions.	W/U
177	AT PILOTS DISCRETION	Used in conjunction with a clearance or	N



 Chapter:
 9

 Page:
 48

 Rev:
 0

 Date:
 20 Oct 07

		instruction to indicate that the pilot may execute when prepared to do so.	
169	[free text]	Normal urgency attribute	R
170	[free text]	Distress urgency attribute	R

4.9.14 Downlink - Responses

DM	Message Element	Message Intent	RESPONSE
0	WILCO	The instruction is understood and will be complied with.	N
1	UNABLE	The instruction cannot be complied with.	N
2	STANDBY	Wait for a reply. The controller is informed that the request is being assessed and there will be a short term delay (within 10 minutes). The exchange is not closed and the request will be responded to when conditions allow.	N
3	ROGER	Message received and understood. ROGER is the only correct response to an uplink free text message. Under no circumstances will ROGER be used instead of AFFIRM.	N
4	AFFIRM	Yes AFFIRM is an appropriate response to an uplinked negotiation request message (e.g. CAN YOU ACCEPT [altitude] AT [time]).	N
5	NEGATIVE	No NEGATIVE is an appropriate response to an uplinked negotiation request message (e.g. CAN YOU ACCEPT [altitude] AT [time]).	N

4.9.15 Downlink - Vertical Requests

DM	Message Element	Message Intent	RESPONSE
6	REQUEST [altitude]	Request to fly at the specified level.	Y
7	REQUEST BLOCK [altitude] TO [altitude]	Request to fly at a level within the specified vertical range.	Y
8	REQUEST CRUISE CLIMB TO [altitude]	Request to cruise climb to the specified level. Due to different interpretations between the various ATS units, this element should be avoided.	Y
9	REQUEST CLIMB TO [altitude]	Request to climb to the specified level.	Y
10	REQUEST DESCENT TO [altitude]	Request to descend to the specified level.	Y
11	AT [position] REQUEST CLIMB TO [altitude]	Request that at the specified position a climb to the specified level be approved.	Y
12	AT [position] REQUEST DESCENT TO [altitude]	Request that at the specified position a descent to the specified level be approved.	Y
13	AT [time] REQUEST CLIMB TO [altitude]	Request that at the specified time a climb to the specified level be approved.	Υ



 Chapter:
 9

 Page:
 49

 Rev:
 0

 Date:
 20 Oct 07

14	AT [time] REQUEST DESCENT TO [altitude]	Request that at the specified time a descent to the specified level be	Y
	[aiiituuc]	approved.	

4.9.16 Downlink - Lateral Off-Set Requests

DM	MESSAGE ELEMENT	MESSAGE INTENT	RESPONSE
15	REQUEST OFFSET [distance offset] [direction] OF ROUTE	Request that a parallel track, offset from the cleared track by the specified distance in the specified direction, be approved.	Y
16	AT [position] REQUEST OFFSET [distance offset] [direction] OF ROUTE	Request that a parallel track, offset from the cleared track by the specified distance in the specified direction, be approved from the specified position.	Υ
17	AT [time] REQUEST OFFSET [distance offset] [direction] OF ROUTE	Request that a parallel track, offset from the cleared track by the specified distance in the specified direction, be approved from the specified time.	Y

4.9.17 Downlink - Speed Requests

DM	Message Element	Message Intent	RESPONSE
18	REQUEST [speed]	Request to fly at the specified speed.	Y
19	REQUEST [speed] TO [speed]	Request to fly within the specified speed range.	Y

4.9.18 Downlink - Voice Contact Requests

DM	Message Element	MESSAGE INTENT	RESPONSE
20	REQUEST VOICE CONTACT	Request for voice contact.	Y
21	REQUEST VOICE CONTACT [frequency]	Request for voice contact on the specified frequency.	Y

4.9.19 Downlink - Route Modification Requests

DM	Message Element	MESSAGE INTENT	RESPONSE
22	REQUEST DIRECT TO [position]	Request to track from the present position direct to the specified position.	Y
23	REQUEST [procedure name]	Request for the specified procedure clearance.	Y
24	REQUEST [route clearance]	Request for a route clearance.	Y
25	REQUEST CLEARANCE	Request for either a pre-departure or route clearance.	Y
26	REQUEST WEATHER DEVIATION TO [position] VIA [route clearance]	Request for a weather deviation to the specified position via the specified route.	Υ
27	REQUEST WEATHER DEVIATION UP TO [distance offset] [direction] OF ROUTE	Request for a weather deviation up to the specified distance off track in the specified direction.	Y
70	REQUEST HEADING [degrees]	Request a clearance to adopt the specified heading.	Y
71	REQUEST GROUND TRACK [degrees]	Request a clearance to adopt the specified ground track.	Y

4.9.20 Downlink - Reports

DM	MESSAGE ELEMENT	MESSAGE INTENT	RESPONSE		
28	LEAVING [altitude]	Notification of leaving the specified level.	N		
	FTIHAD AIRWAYS – UNITED ARAB FMIRATES				



 Chapter:
 9

 Page:
 50

 Rev:
 0

 Date:
 20 Oct 07

29	CLIMBING TO [altitude]	Notification of climbing to the specified level.	N
30	DESCENDING TO [altitude]	Notification of descending to the specified level.	N
31	PASSING [position]	Notification of passing the specified position.	N
78	AT [time] [distance] [to/from] [position]	At the specified time, the aircraft's position was as specified.	N
32	PRESENT ALTITUDE [altitude]	Notification of the present level.	N
33	PRESENT POSITION [position]	Notification of the present position.	N
34	PRESENT SPEED [speed]	Notification of the present speed.	N
35	PRESENT HEADING [degrees]	Notification of the present heading in degrees.	N
36	PRESENT GROUND TRACK [degrees]	Notification of the present ground track in degrees.	N
37	LEVEL [altitude]	Notification that the aircraft is maintaining the specified level.	N
72	REACHING [altitude]	Notification that the aircraft has reached the specified level.	N
76	REACHING BLOCK [altitude] TO [altitude]	Notification that the aircraft has reached a level within the specified vertical range.	N
38	ASSIGNED ALTITUDE [altitude]	Read-back of the assigned level.	N
77	ASSIGNED BLOCK [altitude] TO [altitude]	Read-back of the assigned vertical range.	N
39	ASSIGNED SPEED [speed]	Read-back of the assigned speed.	N
40	ASSIGNED ROUTE [route clearance]	Read-back of the assigned route.	N
41	BACK ON ROUTE	The aircraft has regained the cleared route.	N
42	NEXT WAYPOINT [position]	The next waypoint is the specified position.	N
43	NEXT WAYPOINT ETA [time]	The ETA at the next waypoint is as specified.	N
44	ENSUING WAYPOINT [position]	The next plus one waypoint is the specified position.	N
45	REPORTED WAYPOINT [position]	Clarification of previously reported waypoint passage.	N
46	REPORTED WAYPOINT [time]	Clarification of time over previously reported waypoint.	N
47	SQUAWKING [beacon code]	The specified (SSR) code has been selected.	N
48	POSITION REPORT [position report]	Reports the current position of the aircraft when the pilot presses the button to send this message. ATC expects position reports based on this downlink message	N



 Chapter:
 9

 Page:
 51

 Rev:
 0

 Date:
 20 Oct 07

79	ATIS [atis code]	The code of the latest ATIS received is as specified.	N
80	DEVIATING [direction] [distance offset] OF ROUTE	Notification that the aircraft is deviating from the cleared route by the specified distance in the specified direction.	N

4.9.21 Downlink - Negotiation Requests

DM	MESSAGE ELEMENT	MESSAGE INTENT	RESPONSE
49	WHEN CAN WE EXPECT [speed]	Request for the earliest time at which a clearance to the specified speed can be expected.	Y
50	WHEN CAN WE EXPECT [speed] TO [speed]	Request for the earliest time at which a clearance to a speed within the specified range can be expected.	Υ
51	WHEN CAN WE EXPECT BACK ON ROUTE	Request for the earliest time at which a clearance to regain the planned route can be expected.	Y
52	WHEN CAN WE EXPECT LOWER ALTITUDE	Request for the earliest time at which a clearance to descend can be expected.	Y
53	WHEN CAN WE EXPECT HIGHER ALTITUDE	Request for the earliest time at which a clearance to climb can be expected.	Y
54	WHEN CAN WE EXPECT CRUISE CLIMB TO [altitude]	Request for the earliest time at which a clearance to cruise climb to the specified level can be expected.	Υ

4.9.22 Downlink - Emergency Messages

DM	Message Element	MESSAGE INTENT	RESPONSE
55	PAN PAN PAN	Urgency prefix.	N
56	MAYDAY MAYDAY MAYDAY	Distress prefix.	N
57	[remaining fuel] OF FUEL REMAINING AND [souls on board] SOULS ON BOARD	Notification of fuel remaining and number of persons on board.	N
58	CANCEL EMERGENCY	Notification that the pilot wishes to cancel the emergency condition.	N
59	DIVERTING TO [position] or DIVERTING TO [position] VIA [x]	Notification that the aircraft is diverting to the specified position via the specified route.	N
60	OFFSETTING [direction] [distance offset] OF ROUTE	Notification that the aircraft is deviating the specified distance in the specified direction off the cleared route and maintaining a parallel track.	N
61	DESCENDING TO [altitude]	Notification that the aircraft is descending to the specified level.	N

4.9.23 Downlink -System Management Messages

DM	Message Element	Message Intent	RESPONSE	
62	ERROR [error information]	A system generated message that the avionics has detected an error.	N	
63	NOT CURRENT DATA AUTHORITY	A system generated denial to any CPDLC message sent from a ground facility that is not the Current Data Authority.	N	
64	[icao facility designation]	Notification to the ground system that the specified ATSU is the current data authority.	N	
	ETHIAD AIDWAYC LIMITED ADAD FMIDATEC			



 Chapter: 9

 Page: 52

 Rev: 0

 Date: 20 Oct 07

73	[version number]	A system generated message indicating the software version number.	N
----	------------------	--	---

4.9.24 Downlink -Additional Messages

DM	Message Element	Message Intent	RESPONSE
65	DUE TO WEATHER	Used to explain reasons for aircraft	N
05		operator's message.	IN
66	DUE TO AIRCRAFT PERFORMANCE	Used to explain reasons for aircraft operator's message.	N
74	MAINTAIN OWN SEPARATION AND VMC	States a desire by the pilot to provide his/her own separation and remain in VMC.	N
75	AT PILOTS DISCRETION	Used in conjunction with another message to indicate that the pilot wishes to execute the request when the pilot is prepared to do so.	N
67	[free text]	Normal urgency attribute	N
67 b	WE CAN ACCEPT [altitude] AT [time]	We can accept the specified level at the specified time.	N
67c	WE CAN ACCEPT [speed] AT [time]	We can accept the specified speed at the specified time.	N
67 d	WE CAN ACCEPT [direction] [distance offset] AT [time]	We can accept a parallel track offset the specified distance in the specified direction at the specified time.	N
67e	WE CANNOT ACCEPT [altitude]	We cannot accept the specified level.	N
67f	WE CANNOT ACCEPT [speed]	We cannot accept the specified speed.	N
67 g	WE CANNOT ACCEPT [direction] [distance offset]	We cannot accept a parallel track offset the specified distance in the specified direction.	N
67 h	WHEN CAN WE EXPECT CLIMB TO [altitude]	Request for the earliest time at which a clearance to climb to the specified level can be expected.	N
67i	WHEN CAN WE EXPECT DESCENT TO [altitude]	Request for the earliest time at which a clearance to descend to the specified level can be expected.	N
67 L	TO DELAY FOR AIR REFUEL AT [position] UNTIL [time]; and	The tanker is requesting a clearance to delay at the ARCP until the rendezvous with the receiver. [position] is the ARCP as filed in the tanker?s flight plan. [time] is the time the tanker expects to pass the ARCP and commence refueling along the refueling track. It is also the end of the delay time.	
67 n	DL# 67 EXPECT END OF REFUEL AT [xxxxx]	The tanker pilot is providing notification that the end of refueling is imminent. [xxxxx] may be either position or time.	
67 o	DL# 67 JOINING ALTRV [xxxxx] AT [xxxxx]	[XXXXX] can be either a point or a time Example: JOINING ALTRV CW413 AT HEMLO or JOINING ALTRV CW413 AT 1530Z	
67	ACCEPT MARSA WITH [callsign(s)		



 Chapter:
 9

 Page:
 53

 Rev:
 0

 Date:
 20 Oct 07

р	of other aircraft]	The tanker is accepting MARSA procedures with the receiver Note: [receiver callsign] is the flight planned callsign of the receiver	
68	[free text]	Distress urgency attribute	Υ



 Chapter:
 9

 Page:
 54

 Rev:
 0

 Date:
 20 Oct 07

4.10 FANS-1/A CPDLC Standard Free Text Messages

This Section contains a complete listing of the standard free text messages and intent for FANS-1/A CPDLC.

When a free text uplink message has been received, the pilot shall respond with the QUICK RESPONSE from the table before responding to the message.

4.10.1 Uplink - Free Text Report/ Confirmation Requests

	FREE TEXT MESSAGE	QUICK RESPONSE
Controller	REPORT SIGHTING AND PASSING OPPOSITE DIRECTION [traffic description] ETP [time] The traffic description is to be inserted by the controller and shall include the aircraft identification (callsign), flight level and aircraft type. ETP = Estimated Time of Passing. Example of the traffic description: SIA228 B747 FL370	
Pilot Response	[traffic identification] SIGHTED AND PASSED Example - SIA228 SIGHTED AND PASSED or [traffic identification] NOT SIGHTED	ROGER
Message Intent	The controller is requesting that the pilot notify when the specified traffic has been seen by visual contact and passed. The level specified in the traffic description is the level being maintained by the opposite direction aircraft.	

	Free Text Message	QUICK RESPONSE
Controller	REPORT GROUND SPEED	
Pilot	GS [speed]	ROGER
Response	Example - GS 490	
Message	The controller is requesting the pilot to report the present ground	
Intent	speed.	

	Free Text Message	QUICK RESPONSE
Controller	STATE PREFERRED LEVEL	
Controller	(Ref: ICAO UM231)	
Pilot	FL [altitude]	ROGER
Response	Example - FL 350	
Message	The controller is requesting that the pilot advise the preferred	
Intent	flight level for the flight.	

	Free Text Message	QUICK RESPONSE
Controller	REPORT ETA [position] Example – REPORT ETA BILBO (Ref: ICAO UM228)	
Pilot	[position] [time]	ROGER
Response	Example - BILBO 0413	ROGER
Message Intent	The controller is requesting an estimate for the specified waypoint.	

	Free Text Message	QUICK RESPONSE
Controller	WHEN WILL YOU MAINTAIN FL [altitude]	
Pilot	FL [altitude] AT [time]	ROGER
Response	Example - FL 350 AT 2317	RUGER
Message	The controller is requesting from the pilot the time at which the	
Intent	aircraft will maintain the specified level.	



 Chapter:
 9

 Page:
 55

 Rev:
 0

 Date:
 20 Oct 07

	Free Text Message	QUICK RESPONSE
Controller	AT WHAT DISTANCE [position / waypoint] WILL YOU MAINTAIN FL [altitude]	
Pilot Response	FL [altitude] AT [distance] NM [direction] [position / waypoint] Example - FL 350 AT 26 NM W IPEMA	ROGER
Message Intent	The controller is requesting the distance from the specified position or waypoint at which the aircraft will maintain the specified level. The pilot shall include the direction from the waypoint as a cardinal point, e.g. N, NE, NW, S, SW, SE, E or W.	

	Free Text Message	QUICK RESPONSE
Controller	REPORT RADIAL AND DISTANCE [to/from] [position]	
Pilot	[radial] R [distance] NM [to/from] [position]	ROGER
Response	Example - 320 R 26 NM FROM MCY	
Message Intent	The controller is requesting that the pilot report the radial on which the aircraft is proceeding and the distance from the specified VOR.	

	FREE TEXT MESSAGE	QUICK RESPONSE
Controller	REQUEST VOICE CONTACT [frequency]	
Pilot		ROGER
Response		RUGER
Message	The controller is requesting that the pilot makes voice contact /	
Intent	radio check call on the specified frequency.	

4.10.2 Uplink - Free Text Instructions

	FREE TEXT MESSAGE	QUICK RESPONSE
Controller	CHECK AND RESPOND TO OPEN CPDLC MESSAGES	
Pilot Response		ROGER
Message Intent	The controller has detected that uplink messages exist that the pilot has not yet responded to. The pilot is required to check the ATC log page and to respond to unanswered uplink messages.	

4.10.3 Uplink - Free text Advisories

	FREE TEXT MESSAGE	QUICK RESPONSE
Controller	EXPECT SELCAL CHECK HF [frequency]	
Pilot		ROGER
Response		ROGER
Message	The controller is notifying the pilot that a selcal check will be	
Intent	made on the specified HF frequency.	

	FREE TEXT MESSAGE	QUICK RESPONSE
Controller	EXPECT CPDLC TRANSFER AT [time]	
Pilot Response		ROGER
Message Intent	The controller is notifying the pilot that the CPDLC transfer process will not be completed at the FIR boundary and will be delayed until the specified time. If the CPDLC transfer is not completed by the specified time, the pilot shall manually disconnect and logon to the next centre.	



 Chapter:
 9

 Page:
 56

 Rev:
 0

 Date:
 20 Oct 07

	Free Text Message	QUICK RESPONSE
Controller	EXPECT NEXT CENTER [ATSU name]. CONTACT WITH [ATSU name] NOT REQUIRED	
Pilot Response		ROGER
Message Intent	The controller is notifying the pilot that CPDLC connection is not required by the next FIR (where the flight's transition time of that FIR is short) and CPDLC connection will be transferred to the subsequent FIR.	

The [ATSU name] is the relevant four character ICAO code.

	FREE TEXT MESSAGE	QUICK RESPONSE
Controller	TRAFFIC IS [traffic description]	
Pilot	(optional) TRAFFIC SIGHTED	ROGER
Response		RUGER
	The controller is notifying the pilot of traffic significant to the	
Message	flight. The description will include the aircraft type and any other	
Intent	relevant information to assist the pilot in sighting the traffic. The	
	pilot may respond that the traffic has been sighted.	

	Free Text Message	QUICK RESPONSE
Controller	SECONDARY HF [frequency]	
Pilot		ROGER
Response		RUGER
Message	The controller is notifying the pilot of the secondary HF	
Intent	frequency for the area.	

4.10.4 Uplink - Free Text Speed Messages

	FREE TEXT MESSAGE	QUICK RESPONSE
Controller	EXPECT TO MAINTAIN [speed] UNTIL [time / position]	
Pilot		POCED
Response		ROGER
Message	The controller is notifying the pilot that a speed instruction may	
Intent	be issued to be effective until the specified time.	

4.10.5 Uplink - Free Text Emergency Acknowledgment

	FREE TEXT MESSAGE	QUICK RESPONSE
Controller	ROGER MAYDAY	
Pilot Response		ROGER
Message Intent	The controller has acknowledged receipt of a MAYDAY downlink message. The controller shall attempt to make voice contact with the pilot. The pilot should only respond with ROGER if or when able to do so. If the aircraft is inbound to an airport within the FIR, a ROGER response is not required.	

	FREE TEXT MESSAGE	QUICK RESPONSE
Controller	ROGER PAN	
Pilot Response		ROGER
Message Intent	The controller has acknowledged receipt of a PAN downlink message. The controller shall attempt to make voice contact with the pilot. The pilot should only respond with ROGER if or when	



 Chapter:
 9

 Page:
 57

 Rev:
 0

 Date:
 20 Oct 07

able to do so. If the aircraft is inbound to an airport within the FIR, a ROGER response is not required.

4.10.6 Downlink - Free Text Advisories

	FREE TEXT MESSAGE	RESPONSE
Pilot	WAKE DEV [direction]	
1 not	Direction L or R (left or right) as appropriate	
Controller Response		ROGER
Message Intent	The pilot is offsetting due wake turbulence in accordance with RVSM procedures (offset will not exceed 2nm). The controller is not required to respond or issue a clearance.	

	FREE TEXT MESSAGE	RESPONSE
Pilot	REVISED ETA [position] [time]	
Controller Response		ROGER
Message Intent	The pilot is advising ATC of an update a waypoint ETA.	



Chapter: 9
Page: 58
Rev: 0
Date: 20 Oct 07

5 ADS-C Procedures

5.1 Introduction

In the CNS/ATM environment, surveillance may be provided by Automatic Dependent Surveillance (ADS).

ADS-C allows the establishment of communication contracts between ground systems and an aircraft's avionics system. An ADS-C contract contains the ATC data requirements for ADS reporting as well as frequency of the ADS reports.

The implementation of ADS-C provides surveillance capability in oceanic and en-route continental airspace and is intended to replace CPDLC and verbal position reporting in areas where non-radar separation is currently applied.

In non-radar airspace, the effective use of ADS-C in the provision of air traffic services enhances flight safety, facilitates the reduction of separation minima and better accommodates user-preferred flight profiles.

5.2 ADS-C Description

Three types of ADS-C contracts can be established with an aircraft. Each of these contracts operates independently from the others. These contracts are the:

- Periodic:
- Event; and
- Demand.

The establishment of ADS-C contracts is initiated by the ground system and does not require pilot action providing that the airborne system is armed. The pilot has the ability to cancel all contracts by selecting ADS off.

5.2.1 The periodic contract

The periodic contract allows an ATSU to specify the reporting frequency, to request that optional data groups be added to the basic ADS-C report, and to specify the frequency at which the optional groups are to be included in the reports.

The periodic reporting rate can generally be altered by the controller to allow for situations where a higher or lower reporting rate may be required. Only one periodic contract can be established between a ground system and a particular aircraft at any one time. Whenever a new periodic contract is established, the previous periodic contract is replaced. The periodic contract will remain in effect until it is modified or cancelled.

5.2.2 The event contract

An event contract specifies a request for reports to be transmitted by the aircraft whenever a defined "event" occurs. Only one event contract can be established between a ground system and a particular aircraft at any one time, however the event contract can contain multiple event types.

Note that multiple ATSUs with ADS-C connections can each establish their own event contracts with an aircraft.

Once an event contract has been established, it remains in effect until the specific event requests are fulfilled, or it is cancelled by the ground system.

The **Vertical Rate Change Event** is triggered when the aircraft's vertical rate is either less than or greater than a parameter defined in the contract.



Chapter: 9
Page: 59
Rev: 0
Date: 20 Oct 07

The Lateral Deviation Change Event is triggered when the aircraft's actual position exceeds a lateral distance parameter from the aircraft's expected position on the active flight plan.

The **Altitude Range Change Event** is triggered when the aircraft's altitude exceeds the altitude ceiling or floor defined in the contract by the ground system.

Once a vertical rate change, lateral deviation change, or altitude range event trigger has occurred, a recurrence of this event no longer triggers an event report. The ground system must initiate a new event contract every time that one of these specific events occurs.

The **Waypoint Change Event** is triggered by a change to the next or the next-plus-one waypoints. Such a

change normally occurs due to routine waypoint sequencing. However, it will also be triggered by occurrences such as a change to a non-ATS waypoint entered by the pilot for operational reasons, or execution of a new route affecting the next or next-plus-one waypoints. Unlike the other event contracts, the waypoint change event

trigger remains in effect for all waypoint changes.

5.2.3 The demand contract

The demand contract is a "one-off" request from the ground system for the FMS to provide an ADS report containing specific data as defined in the request. A demand contract can be requested by the ground system at any time. The demand contract request will not affect any existing contracts.

5.2.4 Emergency mode

The emergency mode can only be activated by the pilot and is normally cancelled by the pilot. While it is possible for some ground systems to cancel the emergency mode status, most ground systems do not have this capability although some ground systems can control the "display" of the emergency mode status to the controller. The pilot normally activates the ADS emergency mode automatically by sending a CPDLC MAYDAY message, although the ADS emergency mode can also be set independently. When the ADS emergency mode is set, the aircraft immediately sends an ADS report containing an emergency flag that is interpreted by all ground systems that currently have periodic or event contracts established with that aircraft. The aircraft does not automatically send an ADS report at the time that the emergency mode is set.

When the pilot cancels the emergency mode, the aircraft will send an emergency mode cancellation message to each ground station receiving the emergency mode reports with the next periodic report, whenever it may be due. The cancellation message will remove the emergency flag from the periodic contract, but the data contents will remain the same as per the emergency contract. Any previously existing data groups requested by the ground system will not be restored unless the ground system re-negotiates the periodic contract following receipt of the emergency cancellation message. Existing event contracts are unaffected by the emergency cancellation.

Note: the Boeing B717 and B737 models will send the ADS emergency cancellation message immediately after being selected by the pilot.

5.3 Factors To Be Considered When Using ADS-C

5.3.1 Vertical and lateral variations

Where the Altitude Range Change Event and Lateral Deviation Event contracts are established, the controller will only be alerted to vertical or lateral variations that exceed the associated tolerances.

Note: If a regular periodic report is sent as the aircraft is deviating from cleared level or route (but still within the level or lateral tolerances) the controller will still be alerted to the variation despite no event report having been sent.



 Chapter:
 9

 Page:
 60

 Rev:
 0

 Date:
 20 Oct 07

5.3.2 Figure of Merit data in ADS-C reports

ADS-C reports contain FMS information relating to the Figure of Merit, ACAS/TCAS and the aircraft's navigational redundancy. Some automated ground systems use the FOM value received in an ADS-C report to determine whether to display the report to controllers, or to display a "high" or "low" quality ADS symbol.

FOM data is **not** required for the use of current separation standards. However, where the separation standard being applied requires specific navigational accuracy, such as RNP, controllers shall rely on pilot advice as to the extent of any navigational degradation and shall adjust separation accordingly.

5.3.3 Flight crew modification of active route

The flight crew will often insert non-ATS waypoints into the active flight plan in the FMS for flight system monitoring, or will modify the active route for planning purposes. Once the change is activated, a Waypoint Change Event report may be triggered. If so, non-ATS waypoints included in the active flight plan will be reflected in the Predicted Route Group, as well as the Intermediate and Fixed Projected Intent Groups, which may result in the next, or the next-plus-one waypoints from the report not being waypoints expected in the ATS flight plan or flight data record.

5.4 ADS-C Connection Management

5.4.1 Priority for the ADS-C connection

FANS-1/A equipped aircraft can have up to five ADS-C connections. One of the five connections is reserved for use by the AOC. The aircraft has the capacity to report to four different ATSUs simultaneously using ADS.

The FANS-1/A system does not assign any technical priority to ADS-C connections; therefore the controlling ATSU may not be aware of other connections established with the aircraft. As a result, a procedural hierarchy controlled by the Address Forwarding process (FN_CAD message) has been established.

5.4.1.1 Allocation of ADS-C connections

Using the Address Forwarding process, the current controlling authority shall allocate ADS-C connection priority to the next ATSU that will have air traffic control responsibility for the aircraft. The priority for the allocation of ADS-C connections shall be in accordance with the following list:

- 1. The Current Data Authority,
- 2. The Next Data Authority,
- 3. An ATSU requiring a connection for monitoring operations close to a boundary,
- 4. Airline AOC
- 5. Other miscellaneous connections.

5.4.2 Near boundary ADS-C connections

5.4.2.1 Monitoring of an aircraft operating close to an airspace boundary

When an aircraft will operate within the defined coordination parameter of the boundary with an adjacent ADS-C capable FIR, controllers shall determine during coordination whether that ATSU requires an ADS-C contract to monitor the aircraft's progress near the boundary.



Chapter: 9
Page: 61
Rev: 0
Date: 20 Oct 07




Figure 9: Priorities for ADS-C connections

An ADS-C contract is required by ATSU 2 to monitor the aircraft's progress near the FIR boundary. To ensure that the next unit with direct control responsibility for the aircraft has priority over the ADS-C connections, Address Forwarding to ATSU 3 will be initiated by ATSU 1 prior to Address Forwarding to ATSU 2.

5.4.2.2 Other ground facilities requesting ADS-C contracts

All ground facilities, without having direct control or monitoring requirements for that aircraft, seeking an ADS-C contract with a specific aircraft (e.g. for ADS-C test purposes) must coordinate with the controlling authorities and the operator prior to the departure of the flight.

5.4.3 ADS-C connections not available

When all available ADS-C connections with a particular aircraft have been established (see Figure 2), any other ATSUs attempting to connect with the aircraft will receive an ADS DISCONNECT REQUEST message with "reason code 1" (Congestion).

When an ADS DISCONNECT REQUEST is received by an ATSU, which would normally have priority for an ADS-C connection, the current controlling authority should be notified. The controlling authority shall resolve the situation.

The controlling authority has a number of options available, such as coordination with the previous ATSU or other adjacent ATSUs to ensure that existing ADS-C connections are still required, or when considered absolutely necessary, instructing the pilot to turn the ADS application off and turn it on again. The latter option will terminate all current ADS-C contracts; therefore, the controlling authority should consider the operational effect on other ATSUs prior to employing this method.

Once all contracts have been terminated, the controlling authority shall allocate priority for the connections to other ATSUs via the Address Forwarding process. Only ATSUs with direct control or monitoring responsibilities shall re-establish contracts with the aircraft.



 Chapter:
 9

 Page:
 62

 Rev:
 0

 Date:
 20 Oct 07




Figure 10: ADS-C connection not available

The aircraft has ADS-C connections with four ground facilities and the airline AOC:

Connection:

- 1 with ATSU 1,
- 2 with ATSU 2.
- 3 with the previous controlling authority,
- 4 with the airline AOC,
- 5 with a ground facility collecting test data.

ATSU 3, the next controlling authority, is unable to establish an ADS-C connection with the aircraft due to congestion.

5.4.4 Ground system termination of ADS-C connections

The termination of ADS-C contracts with an aircraft, whether performed automatically or manually, should be strictly monitored to avoid situations leading to congestion. ADS-C contracts and connections should be terminated by the ground system when the:

- Aircraft has crossed an FIR boundary and has passed beyond the normal "back coordination" parameter; or
- The ground system's FDPS flight plan for the aircraft has been cancelled or has finished; or
- Previous ATSU, the controlling authority or an adjacent ATSU has no further surveillance or monitoring requirements for a particular flight.

5.5 Reporting Rates

5.5.1 General

There are a number of situations where a controller may consider the use of a reporting rate other than that used as the default in the periodic reporting contract. Some automated systems have the capability of defining reporting rates that can automatically change from one area to another along the route segment to take into account changes in traffic density along the route.

Where the ground system does not contain the ability to automatically change the reporting rate, the controller should take action, where possible, to manually change the periodic reporting rate when operationally required. Some examples where a change to the rate may be required are:

- When the aircraft is approaching a crossing route on which there is other traffic;
- When the aircraft is approaching areas of known significant weather;
- During periods of turbulence; or
- When an unauthorized deviation from the clearance is detected.



 Chapter:
 9

 Page:
 63

 Rev:
 0

 Date:
 20 Oct 07

5.5.2 Appropriate reporting rates

ATSUs should ensure that the periodic reporting rate in use is in accordance with the position reporting requirements of the separation standards being used. When not required for the application of separation, or other factors, ATSUs should consider using less frequent periodic reporting rates for individual aircraft to reduce overall costs to the system.

5.5.3 Avoid high periodic reporting rates

Arbitrarily selecting high periodic reporting rates adds undue economic costs and unnecessarily loads the data link system.

5.5.4 Other factors to be considered

Depending on individual circumstances the controlling authority should limit the periodic reporting rate to not more frequently than five (5) minutes. Adjacent ATSUs with ADS-C contracts established with the same aircraft should restrict the periodic reporting rate to not more frequently than 15 minutes unless coordination is performed with the controlling authority and the controlling authority agrees to reduce any relatively high reporting rate currently in effect.

5.5.5 Default periodic reporting rates

When setting a default periodic reporting rate, ATSUs should take into account factors such as conformance with ATC clearance requirements, traffic levels, alerting service requirements, and separation standard requirements.

5.6 Separation

ADS-C may be used for the application of procedural separation within a mixed surveillance environment, such as airspace where position reports are provided by a mixture of ADS-C, CPDLC and voice.

For example, ADS-C may be used to determine separation between two or more aircraft reporting by ADS-C, between ADS-C and non-ADS aircraft, between ADS-C aircraft and an aircraft identified on radar, and to ensure separation between ADS-C aircraft and special use airspace, such as military restricted areas.

5.6.1 Appropriate ADS-C reporting requirements

When position reporting is being provided via ADS-C, to ensure that estimates being used for the application of separation are accurate ATSUs should establish appropriate:

- ADS-C contracts: and
- Periodic reporting frequencies.

5.6.2 Appropriate separation standard

A separation standard to be applied in a mixed surveillance environment must be appropriate to the communications and navigational capability of the relevant aircraft. In the case of separation being applied between ADS-C and non-ADS aircraft, the separation standard must be appropriate to the capabilities of the non-ADS aircraft.

5.6.3 Vertical separation

5.6.3.1 Vertical tolerance consistency

Where practical, the tolerances used to determine whether a specific level is occupied by an ADS-C reporting aircraft within the airspace of a specific ATSU should be consistent with other tolerances used throughout the airspace. For example, the vertical tolerances for ADS-C should be consistent with vertical tolerances used for level adherence monitoring by other forms of surveillance, such as radar.



 Chapter:
 9

 Page:
 64

 Rev:
 0

 Date:
 20 Oct 07

5.6.3.2 Application of vertical tolerances

Where other vertical tolerances do not exist, the vertical tolerances to be applied for ADS-C shall be (\pm) 300 feet. However, an individual ATSU may specify in local instructions and the AIP that a tolerance of not less than (\pm) 200 feet will be used to provide consistency with other vertical tolerances applied within the FIR.

5.6.3.3 ADS-C level information does not satisfy vertical tolerance

If displayed ADS-C level information does not satisfy the required tolerance for an individual ATSU then the pilot shall be advised accordingly and requested to confirm the aircraft's level. If following confirmation of the level the displayed ADS-C level information is still beyond the required tolerance, another method of separation or another method of determining level information may need to be applied.

5.6.3.4 Use of ADS-C level information

When displayed ADS-C level information is within the specified tolerance of the expected or cleared flight level, the ADS-C level information may be used for the application of vertical separation, and to determine that an aircraft has reached or is maintaining a specified level.

5.6.3.5 Passing or leaving a level

An aircraft can be considered to have left a specified level when the displayed ADS-C level information indicates that the aircraft has passed the level in the required direction by more than the required tolerance.

5.6.4 Longitudinal separation

5.6.4.1 Limitations on the use of tools

ATSUs that use approved or integrated measurement tools for the purpose of determining screenbased separation should publish in local documentation any limitations on the use of such tools for the establishment and monitoring of separation standards.

5.6.4.2 Establishing longitudinal separation

ADS-C reports may be used to establish and monitor longitudinal time and distance separation standards.

5.6.4.3 Using extrapolated or interpolated positions

Some ground systems display an extrapolated or interpolated ADS symbol between the receipt of ADS-C reports. Providing that the periodic reporting rate in use is in accordance with any reporting rate required by the separation standard, separation may be determined between the extrapolated/interpolated symbols by the use of screen-based measurement tools, or by the use of automated conflict detection tools.

5.6.4.4 Validity of displayed information

When extrapolated or interpolated ADS symbols are being used to provide separation and any doubt exists as to the integrity or validity of the information being presented, the controller shall send a Demand Contract Request to update the relevant information. If doubt still exists, the controller should consider the use of an alternative method of separation.

5.6.4.5 Time-based separation

Ground system flight data records updated by ADS-C reports may be used in the application of appropriate time-based separation standards. Methods of determination may include reference to:

- Estimates at actual waypoints;
- Calculated estimates for positions not contained in the ATS flight plan;
- Screen-based measurement tools; or
- Automated conflict detection tools.



Chapter: 9
Page: 65
Rev: 0
Date: 20 Oct 07

5.6.4.6 .Distance-based separation

ADS-C reports may be used for the application of appropriate longitudinal distance standards. Methods of determination may include:

- The use of automated system tools to measure the displayed positions of two or more aircraft reporting by ADS-C;
- Comparing the displayed position of an ADS-C aircraft with the position of another aircraft determined by an alternative form of surveillance; or
- The use of automated conflict detection tools.

5.6.5 Lateral separation

5.6.5.1 Areas of lateral conflict

ADS-C reports can be used to determine whether an aircraft is within or beyond an area of lateral conflict. Where lateral conflict calculations are not made by automated conflict detection tools, an ADS-C report observed outside an area of lateral conflict displayed or calculated on the screen is confirmation that the aircraft is outside the area of conflict.

5.7 Air Traffic Clearance Monitoring

ADS-C reports can be used to monitor conformance with air traffic clearances.

5.7.1 Deviations from ATC clearances

The pilot of an ADS aircraft observed to deviate significantly from its cleared flight profile shall be advised accordingly. The controller shall also take action as appropriate if such deviation is likely to affect the air traffic service being provided.

5.8 Coordination

5.8.1 Duty of care responsibility

As airlines bear the cost of datalink communications, ATSUs should be aware of Duty of Care responsibility issues when ADS and other technologies allow the surveillance of aircraft and the possible detection of conflicts inside another ATSU's airspace. Local ATS instructions and/or Letters of Agreement between units should detail the coordination response required from one ATSU in the case of a suspected conflict being detected in the adjacent ATSU's airspace. Unless required for safety purposes, ATSUs should ensure that ADS-C is only enabled for aircraft inside their Area of Interest.

5.8.2 Coordinated data inconsistent with ADS displayed data

The transferring controller shall advise during coordination if the aircraft is currently at a level or on a route different from that intended for the boundary crossing. When the coordination information relating to the transfer of control is different from the displayed ADS information and the required advice has not been provided, the receiving controller shall confirm the coordinated information with the transferring controller.

5.9 Alerting service

For ADS-equipped aircraft, the provision of the alerting service should be based on the scheduled position reports provided by the periodic reporting contract.

5.9.1 Late or missing ADS-C Reports

Whenever an ADS-C report (either a periodic or waypoint report) is not received within a parameter of the expected time, the controller should initiate a demand contract request or establish a new periodic contract with the aircraft



 Chapter:
 9

 Page:
 66

 Rev:
 0

 Date:
 20 Oct 07

5.10 Aircraft Navigation

5.10.1 Aircraft in heading select mode

When the aircraft is in Heading Select Mode, the intent and predicted route information being transmitted by the aircraft will project towards the next FMS flight plan waypoint regardless of the actual position and heading of the aircraft. Predicted information is based on the FMS intent, which may not necessarily be the intent of the pilot.

If the aircraft is in Heading Select Mode, and the aircraft passes abeam a flight planned waypoint by more than a defined parameter the FMS will not sequence this or subsequent waypoints. The effect on a ground system of a waypoint that has not been sequenced is that the intent information, once the aircraft has passed the waypoint, will be directed back towards the non-sequenced waypoint. As a result, some ground systems may see an extrapolated symbol move in a different direction to the actual track of the aircraft.

5.10.2 Sequencing subsequent waypoints

If a waypoint is passed abeam by more than the aircraft FMS parameter while flying in Heading Select Mode, the FMS must be re-programmed (e.g. to fly direct to the next relevant waypoint) to enable subsequent waypoints to be sequenced.

(See also CPDLC Sequencing "ABEAM" waypoints in excess of FMS parameters)

5.11 Position Reporting

5.11.1 Position reporting requirements in ADS airspace

ATSUs may promulgate in the AIP that ADS-C reports fulfill all normal position reporting requirements within the nominated FIR.

5.11.1.1 Publishing reporting requirements

ATSUs should publish ADS and CPDLC position reporting requirements in the AIP.

5.11.1.2 CPDLC report at FIR entry position

When an ATSU has nominated the use of ADS-C reporting only within the associated FIR, a CPDLC position report at the FIR entry position is still required to confirm that the ATSU holds the status of Current Data Authority. Following the initial CPDLC report at the boundary, no further CPDLC or voice position reports will be required for operations within the FIR.

5.11.1.3 Updating waypoint estimates

ATSUs should publish in the AIP that pilots are not required to update estimates for waypoints when the aircraft is reporting by ADS-C in airspace where additional CPDLC or voice reports are not required. Exceptions to this rule are that updates to estimates are required when:

- An estimate previously advised by voice or CPDLC will change by more than 2 minutes; or
- A pilot-initiated action, such as a change in speed, will change the estimate for the next reporting point by more than 2 minutes.

5.11.1.4 Non-compulsory waypoints

When reporting by ADS-C only, the flight crew is **not** required to modify the route to remove non-compulsory waypoints. Waypoint event reports will be sent at all non-compulsory reporting points and will be reflected in the predicted route group.

5.11.2 Discrepancies between ADS-C and CPDLC estimates

Controllers should be aware that CPDLC and ADS-C estimates received from the same aircraft for the same position may differ as a result of the ADS-C application reporting time to the second and the time reported by CPDLC application either being truncated or rounded to the nearest full minute



 Chapter:
 9

 Page:
 67

 Rev:
 0

 Date:
 20 Oct 07

(depending on aircraft type). The pilot also has the ability to modify the estimate for the next position in the CPDLC position report. Any such modification will not be reflected in the ADS-C report.

5.11.2.1 Actions to be followed when there is an estimate discrepancy

When an ATSU is using both ADS-C and CPDLC reporting and a discrepancy of less than 3 minutes between the reports is detected, the ATSU should detail in local documentation methods to be used by the controller for the reconciliation of the time difference. Where the time difference exceeds 3 minutes, the controller shall query the estimate received in the CPDLC position report and request confirmation of the estimate for the waypoint in question.



 Chapter:
 9

 Page:
 68

 Rev:
 0

 Date:
 20 Oct 07

6 Emergency and Non-routine Procedures

6.1 Emergency procedures

Although an emergency CPDLC message such as MAYDAY or PAN PAN does not require a closure response, the controller must acknowledge receipt of the message and attempt to determine the nature of the emergency and ascertain any assistance required.

6.1.1 Response to an emergency message

When a CPDLC or ADS emergency message is received the controlling authority, in order to better assess the nature of the emergency shall respond as in Section 7.1 above, and may also choose to:
a) Increase the PERIODIC contract reporting rate to 5 minutes, or

b) Send an ON DEMAND contract request. (Note. This is not required if the periodic reporting rate has been increased – an ADS report will have already been triggered by the avionics when the new periodic contract is received).

Note. Increasing the ADS-C reporting rate also reduces the period between cancellation of the ADS emergency and receipt of the ADS Cancel Emergency downlink.

6.1.2 Confirmation of emergency activation

When the ADS emergency mode is activated without a CPDLC emergency message or voice confirmation, and the demand contract report appears to indicate that the aircraft is maintaining normal operations (e.g. the aircraft is not in descent or involved in abrupt maneuvers), the aircraft may be subject to unlawful interference. To check for covert or inadvertent activation of the ADS emergency mode the free text uplink "Confirm ADS" shall be appended to a "Confirm Speed" data or voice request:

Controller	Confirm Speed
	Confirm ADS

The pilot shall then check the status of the aircraft's ADS Emergency Mode and if the emergency mode has been activated inadvertently, the pilot shall select ADS Emergency Mode to "OFF" and advise ATC by voice or the following CPDLC free text downlink.

Pilot ADS reset

If the aircraft continues with the ADS emergency mode activated ATC shall assume the aircraft is in emergency conditions and follow normal alerting procedures.

6.1.3 Acknowledgement of an emergency message

When an ADS emergency accompanied by a CPDLC emergency message is received, the controller shall immediately acknowledge receipt of the emergency with the pilot by the most appropriate means (voice or CPDLC).

6.1.4 CPDLC acknowledgment

A CPDLC acknowledgment shall be in the form of a free text message using the words ROGER MAYDAY or ROGER PAN. This uplink free text message requires a response from the pilot to close the CPDLC exchange. Depending on the nature of the emergency, the free text message may or may not be acknowledged by the pilot.

6.1.4.1 Voice contact

When an emergency is acknowledged by CPDLC, controllers may also attempt to make voice contact with the aircraft.



Chapter: 9
Page: 69
Rev: 0
Date: 20 Oct 07

6.1.5 Retaining the active connection

If CPDLC is the best (or only) communications medium available between the aircraft and any ATSU, the ATSU with the active connection should maintain that connection until better assistance can be provided by another means. In this case, transfer of the connection should not occur to another unit, and any automatic transfer capability should be disabled, if possible, in order to improve the chances of the CPDLC connection being retained.

6.1.5.1 Communications responsibility

It is recognized that if a transfer of the CPDLC connection does not occur, then the responsibility for maintaining communications with the aircraft is retained by the current ATSU.

6.1.5.2 Executive control responsibility

In accordance with established procedures, the responsibility for the control of the flight rests with the ATSU within whose airspace the aircraft is operating. If the pilot takes action contrary to a clearance that has already been coordinated with another sector or ATSU and further coordination is not possible in the time available, then this action would be performed under the pilot's emergency authority.

6.1.6 Normal emergency procedures

After receipt of the emergency message is acknowledged, normal emergency response procedures shall be followed.

6.1.7 Coordination in the case of emergency

When the ADS emergency mode is observed by an ATSU that is not in control of the aircraft, that ATSU shall coordinate with the controlling authority to ensure that the emergency report has been received. Adjacent ATSUs shall not increase the reporting rate of the periodic contract.

6.2 Data Link Connection Failures

6.2.1 Detected by the controller

When the controller recognizes a failure of the data link connection, the controller shall instruct the pilot to terminate the connection, by selecting ATC Com Off, and then initiate another AFN logon. Once the AFN logon

is established, the ATS system should send a **CONNECTION REQUEST** message to re-establish the connection.

The voice phraseology to be used shall be:

Controller	Data link failed. Select ATC Com Off then Logon to [ATSU name]
Pilot	Roger

The [ATSU name] is the 4 character ICAO code.

6.2.2 Detected by the airborne system

When the avionics/pilot recognizes a failure of the data link connection, the pilot shall terminate the connection

by selecting ATC Com Off and then initiate a new AFN logon (FN_CON) to the current controlling authority.

6.2.3 Inability to establish the data link connection

In situations where a data link connection cannot be established successfully, the ATS system should indicate to the controller that no connection has been established.



 Chapter:
 9

 Page:
 70

 Rev:
 0

 Date:
 20 Oct 07

6.3 Data link System Shutdowns

6.3.1 Unexpected data link shutdowns

In the event of an unexpected data link shutdown, the relevant ATSU shall inform:

• All currently connected FANS-1/A equipped aircraft via voice;

The voice phraseology to be used shall be:

Controller	Data link failed. Select ATC Com Off. Continue on voice
Pilot	Roger

- The adjacent ATSUs by direct coordination; and
- All relevant parties via the publication of a NOTAM, if appropriate.

Pilots shall terminate the data link connection and use voice until informed by the ATSU that the data link system has resumed normal operations.

6.3.2 Planned data link shutdowns

When a planned data link system shutdown of the communications network, or of the ATS system, occurs a NOTAM shall be published to inform all affected parties of the shutdown period. During that time period, voice shall be used.

The following voice or data phraseology shall be used to advise airborne aircraft prior to the commencement of the shutdown.

Controller	Data link will be shutdown. Select ATC Com Off. Continue on voice (The pilot shall select ATC Com Off when the message is received)
Pilot	Roger

6.3.3 Resumption of data link operations

The following voice phraseology shall be used to advise pilots that the data link system has resumed operations.

Controller	Data link operational Logon to [ATSU name]
Pilot	Logon [ATSU name]

The [ATSU name] is the 4 character ICAO code.

6.3.4 Data link component shutdown

Some ATSUs are not equipped with both CPDLC and ADS-C and consequently may experience shutdown of a single component of the data link system (i.e. CPDLC or ADS-C). For those ATSUs that have both CPDLC and ADS-C it is not likely that just one component will shutdown, however it is possible.

ATSUs experiencing a shutdown of either CPDLC or ADS-C shall follow the procedures above for data link shutdowns as appropriate.



Chapter: 9
Page: 71
Rev: 0
Date: 20 Oct 07

6.3.4.1 ADS only failure

When a shutdown of the ground component of the ADS system occurs, the ATSU affected shall inform all other affected parties of the shutdown and likely period. During that time period, position reports (via CPDLC if available, or via voice) will be required.

If a CPDLC service is still available, a CPDLC free text message shall be sent to the pilot notifying reporting requirements. The following phraseology shall be used:

Controller	ADS shutdown revert to ATC data link position reports
Pilot	Roger

6.3.4.2 Loss of ADS-C

If it is not possible to establish ADS-C contracts, or if ADS-C reporting from an aircraft ceases unexpectedly, it is possible that the pilot may have inadvertently selected ADS-C off. If CPDLC is still available, a CPDLC free text message shall be sent to the pilot, using the following phraseology.

6.3.5 Unexpected communication service provider shutdown

In the event of an unexpected communications service provider system, the communications service providers shall inform ATSUs and airline dispatch of the situation. ATSUs shall consequently inform:

All currently connected FANS equipped aircraft via voice,

The voice phraseology to be used shall be:

Controller	Data link failed Select ATC Com Off. Continue on voice
Pilot	Roger

- The adjacent ATSUs by direct coordination,
- All relevant parties via the publication of a NOTAM, if appropriate.

Pilots shall terminate CPDLC connections with the ATSU and use voice communications until informed by the ATSU that the system is again fully functional.

6.3.6 Unexpected avionics system shutdown

In the event of an unexpected avionics data link shutdown, pilots shall inform the ATSU of the situation using voice.

The voice phraseology to be used shall be:

Pilot	Data link failed. Selecting ATC Com Off. Continuing on voice
Controller	Roger. Continue on voice

Pilots shall continue to use voice until the functionality of the avionics can be re-established.

6.4 Total Communications Failure

The procedures covering complete communications failure (CPDLC and voice) shall be in accordance with current ICAO procedures.



Chapter: 9
Page: 72
Rev: 0
Date: 20 Oct 07

6.5 Using CPDLC to relay messages

When an ATSU and an aircraft cannot communicate, and an intermediary data link aircraft is used for relaying messages, the following shall apply:

- Only a free text message shall be used:
- The first word in the message shall be "RELAY".

Note 1: The use of pre-formatted messages is prohibited because the intermediary aircraft's FMS could be unintentionally armed.

Note: The call sign of the aircraft should be expressed as the radiotelephony call sign, rather than the ICAO three letter or IATA two letter designator.

Example

Controller	Relay. [atsu] clears [call-sign] Climb to and maintain F340
(all Free text)	
Pilot	Relay from [call-sign] Climbing F340
(all Free text)	

6.6 Weather deviation procedures

6.6.1 Multiple weather deviations

The distance off track contained in a weather deviation request or clearance is measured reference the nominally cleared track of the aircraft. Subsequent weather deviations or route clearances supercede any previous weather deviation clearance.

Example

Aircraft requests and is cleared to operate 20NM left of track

	Pilot	REQUEST WEATHER DEVIATION UP TO LEFT 20NM (free text) AND 20NM RIGHT
Co	ontroller	CLEARED TO DEVIATE UP TO 20NM EITHER SIDE OF ROUTE
	Pilot	WILCO

If the aircraft then requires a clearance to operate a further 30NM left of track, the clearance request shall be based on the nominal route rather in relation to the current weather deviation clearance.

Pilot	REQUEST WEATHER DEVIATION UP TO 50NM L OF TRACK
Controller	CLEARED TO DEVIATE UP TO 50NM L OF TRACK
Pilot	WILCO

If the aircraft then requires a clearance to operate 30NM right of track

Pilot	REQUEST WEATHER DEVIATION UP TO 30NM R OF TRACK
Controller	CLEARED TO DEVIATE UP TO 30NM R OF TRACK
Pilot	WILCO

Whilst the aircraft navigates from one side of track to the other in order to comply with the above clearance, it is the responsibility of ATC to ensure that the appropriate separation standards are being applied. The aircraft should expeditiously navigate so as to establish itself to the right side of track



Chapter: 9
Page: 73
Rev: 0
Date: 20 Oct 07

6.6.2 Deviations either side of track

There are a number of valid formats for the CPDLC [direction] variable. A number of aircraft types, however, can only request directions left or right in weather deviation requests. If one of these aircraft requires a deviation to the left and right of track, the following procedure should be used:

- Construct a preformatted weather deviation downlink request for a deviation on one side of track, and
- Append free text describing the distance to the other side of track

Example

Pilot	REQUEST WEATHER DEVIATION UP TO L 20NM. (free text) AND 20NM R	
Controller	CLEARED TO DEVIATE UP TO **********L 20NM OF TRACK	
Pilot	WILCO	

6.6.3 Reporting back on track

A weather deviation clearance remains in effect until either:

- · A "back on route" report is received; or
- The aircraft reaches a subsequent waypoint to which it has been cleared when clear of weather.



 Chapter:
 9

 Page:
 74

 Rev:
 0

 Date:
 20 Oct 07

7 FANS-1/A Implementation

7.1 Introduction

• This Part provides information of FANS-1/A datalink implementations by Etihad Airways.

7.2 ATSU Designators

The following table contains the various ATSU ACARS addresses, and the ICAO facility designations (also called "4 character ICAO code") of the associated FIR.

ATS Units	ATS System	ICAO facility designation	ATSU Address
Anchorage	ocs	PAZA	ANCXFXA
Antananarivo (Madagascar)		FMMM	
Auckland	ocs	NZZO	AKLCDYA
Brisbane	TAAATS	YBBB	BNECAYA
Colombo		VCCC	
Honiara	TAAATS	YBBB	BNECAYA
Johannesburg	SAAATS	FAJO	
Mauritius		FIMM	
Melbourne	TAAATS	YMMM	MELCAYA
Nadi	Eurocat 2000X	NFFF	NANCDYA
Nauru	TAAATS	YBBB	BNECAYA
Oakland	ODL	KZAK	OAKODYA
Seychelles		FSSS	
Tahiti	VIVO	NTTT	PPTCDYA
Fukuoka	ODP	RJJJ	FUKJJYA



 Chapter:
 9

 Page:
 75

 Rev:
 0

 Date:
 20 Oct 07

7.3 HF Voice Communications Requirements

7.3.1 Crossing International FIR Boundaries

When entering an FIR from an adjacent international FIR and CPDLC is serviceable, the CPDLC CONTACT or MONITOR message shall be sent as detailed below:

<u>FIR</u>	CPDLC Instruction	
Anchorage	CONTACT PAZA CENTER [frequency]	
Oceanic		
Antananarivo		
(Madagascar)		
Auckland	MONITOR NZZO CENTER [frequency]	
Oceanic		
Brisbane	Monitor YBBB Center [frequency]	
Colombo		
Honiara ¹	MONITOR YBBB CENTER [frequency]	
Johannesburg		
Maldives		
Mauritius		
Melbourne	MONITOR YMMM CENTER [frequency]	
Nadi	MONITOR NFFF CENTER [frequency]	
Nauru ¹	MONITOR YBBB CENTER [frequency]	
	CONTACT KSFO CENTER [frequency]	
Oakland	KSFO (San Francisco Radio) will provide all primary and secondary HF	
	frequencies, and HF transfer points along the route of flight.	
Tob:#:	CONTACT NTTT CENTER [frequency]	
Tahiti	A SELCAL check is required.	
Fukuoka	CONTACT FUKUOKA CENTER [frequency]	



Chapter: 9
Page: 76
Rev: 0
Date: 20 Oct 07

7.3.2 CPDLC Services in specific FIR's

7.3.2.1 Brisbane & Melbourne FIRs

General

When operating in a Traffic Information only environment (Class G), flight crews should still send CPDLC requests for changes of level and/or amended tracking that will apply to route segments wholly within Class G airspace. This action will update the controller's flight data record, ensuring that the most accurate information is presented to the controller.

CPDLC

- In Australian Oceanic airspace, CPDLC is the primary means of communications, whereas in continental airspace, VHF will be the primary means of communication with ATC. CPDLC can be used as a back-up. The use of free text should be kept to a minimum.
- To ensure the correct synchronization of messages, controller/pilot dialogues opened by voice must, wherever possible, be closed by voice. Controller/pilot dialogues opened by CPDLC must be closed by CPDLC.
- To avoid ambiguity, a CPDLC downlink message should not contain more than one clearance request.
- The downlink message ACCEPT (WILCO) indicates that the pilot accepts the full terms of an entire uplink message including any clearance or instruction.
- STAND BY A short-term delay of less than 10 minutes can be expected.
- REQUEST DEFERRED A longer-term delay of greater than 10 minutes can be expected.

Logon Procedures for Brisbane & Melbourne FIR

The CPDLC logon address for Brisbane FIR is YBBB and for Melbourne FIR is YMMM.

Inbound Procedures

- A SELCAL check should be made on the appropriate HF frequency.
- Logon to either FIR approximately 15 minutes (but not before 45 minutes) prior to the FIR boundary.
- ADS must remain armed.
- A CPDLC position report shall be made at the FIR boundary. Do not make CPDLC route or altitude change requests until inside the FIR.

Outbound Procedures

- Logon on when outside 45 NM from departure airport. Do not logon on the ground. This
 restriction avoids nuisance ADS messages to ATC.
- A CPDLC position report shall be made as soon as convenient after the data link connection is established.
- A SELCAL check should be made on the appropriate HF frequency.

ADS

If a CPDLC <u>Level Change</u> request is received for operations within Class G airspace; the
controller shall respond with relevant free text Traffic information and in the same message
shall append the pre-formatted element REPORT REACHING [level].

Example:



Chapter: 9
Page: 77
Rev: 0
Date: 20 Oct 07

Pilot Request climb to 350

Controller No reported IFR traffic FL350 Report reaching 350

- All aircraft entering Australian controlled Oceanic airspace from Class G airspace shall obtain
 <u>Route Clearance</u> at or after the last flight planned waypoint prior to crossing the clearance
 boundary (when boundary position becomes the active FMS waypoint), flight crew shall
 request a route clearance using downlink element #24, REQUEST CLEARANCE [route
 clearance]. Prior to sending the request, the flight crew must remove any arrival procedures
 associated with destination airport. The controller will respond with uplink element #83, AT
 [position] CLEARED [route clearance].
- When there is a <u>Change to Route Detail</u>, a route change request is required before the normal position for requesting the route clearance, the flight crew will downlink the full route field using downlink element #24, REQUEST CLEARANCE [route clearance], after removing any arrival procedures associated with the destination airport. The controller will then uplink the full route field from the requested waypoint to the destination. To distinguish the OCTA and CTA portions of the route, the controller will add relevant free text.

Example:

Pilot REQUEST CLEARANCE [route clearance]

Controller CLEARED [route clearance] NO REPORTED IFR TRAFFIC SOUTH OF 45 SOUTH FL350 CLEARANCE ONLY APPLIES FROM 45S

<u>Position Reporting Requirements</u> in Brisbane & Melbourne FIRs require an initial CPDLC position report at the FIR boundary entry point, then ADS reporting only. Because of the gaps in radar cover over the Australian continent, ATC will use ADS position reporting to supplement radar information. This is a unique application of using the aircraft downlinks to enhance position tracking in ATC.

Abnormal & Contingency Procedures

Special procedures apply. Refer to Jeppesen Pacific Ocean pages.



Chapter: 9
Page: 78
Rev: 0
Date: 20 Oct 07

7.3.2.3. Auckland FIR

CPDLC

- In Auckland Oceanic airspace, CPDLC is the primary means of communications. Back-up communications will be HF Voice or SATCOM Inmarsat #451201.
- The use of free text should be kept to a minimum.
- To ensure the correct synchronization of messages, controller/pilot dialogues opened by voice must, wherever possible, be closed by voice. Controller/pilot dialogues opened by CPDLC must be closed by CPDLC.
- To avoid ambiguity, a CPDLC downlink message should not contain more than one clearance request.
- The downlink ACCEPT (WILCO) indicates that the pilot accepts the full terms of an entire
 uplink message including any clearance or instruction.
- STAND BY a short-term delay of less than 10 minutes can be expected.
- REQUEST DEFERRED A longer-term delay of greater than 10 minutes can be expected.

Logon Procedures for Auckland FIR

The CPDLC logon address for Auckland FIR is NZZO.

Inbound Procedures

- A SELCAL check should be made on the appropriate HF frequency.
- Logon to NZZO approximately 15 minutes (but not before 45 minutes) prior to the NZZO FIR boundary.
- · ADS must remain armed.
- A CPDLC position report shall be made at the FIR boundary. Do not make CPDLC route or altitude change requests until inside NZZO FIR.

Outbound Procedures

- Logon to NZZO when outside 45 NM from departure airport. Do not logon on the ground. This
 restriction avoids nuisance ADS messages to ATC.
- A CPDLC position report shall be made as soon as convenient after the data link connection is established.
- A SELCAL check should be made on the appropriate HF frequency.

ADS

Aircraft **Position Reporting** via ADS is not required to downlink CPDLC position reports or report position via Voice except:

- That a CPDLC position report is required at the FIR boundary on entry to the Auckland Oceanic FIR (includes outbound from New Zealand); and
- When requested by ATC. Change: Repagination

Abnormal & Contingency Procedures

Special procedures apply. Refer to Jeppesen Pacific Ocean pages.



Chapter: 9
Page: 79
Rev: 0
Date: 20 Oct 07

7.3.2.4. Chennai & Kolkata FIRs

General

A pilot recognizing a failure of Datalink connection shall immediately establish communications using appropriate voice frequency. The voice communications shall continue until CPDLC connection is reestablished and the controller has authorized a return to Datalink communication.

CPDLC

- CPDLC will be the primary means of communication with Chennai FIR outside control areas and HF or VHF will be the backup for communications.
- Hand over to WMFC FIR on VHF is by CPDLC before exiting VOMF airspace.
- CPDLC will be the primary means of communication on the following airways within Chennai¹
 Kolkata² FIR over oceanic airspace in Bay of Bengal, outside control areas and HF or VHF will be the backup for communications.
 - (1) N877, P628, P574, N571 and L645.
 - (2) N877, P628, L759, M770, N895, G472, L507, P646 & L301.
- An emergency message shall be sent by CPDLC as well as by HF or VHF voice communication.
- Special and other non-routine aircraft observation of severe turbulence should be reported by HF or VHF voice communication.
- Flight information services will be provided by HF or VHF voice communication.

Logon Procedures for Chennai & Kolkata FIR

The CPDLC logon address for Chennai FIR is VOMM and for Kolkata FIR is VECC.

- Hours of operation 0230-2030 UTC for Chennai only (not applicable to Kolkata).
- Data link-equipped aircraft entering the airspace where data link services are provided are required to logon 20 minutes prior to entering the FIR.
- If an AFN logon attempt is rejected, a second attempt with an interval of more than 5 minutes after the first logon failure is recommended.
- SELCAL checking is required to verify the RTF serviceability.

ADS

ADS will be the primary means of surveillance for suitably equipped aircraft and Datalink established aircraft within Chennai & Kolkata FIRs outside control areas and voice position reporting will be a backup.

If Datalink communications is established, **Position Reporting** using HF or VHF is not required outside the control areas.

Termination of Data link Service

Aircraft, which have data link connection entering the range of radar within Chennai¹ & Kolkata²FIR will be informed by the following CPDLC uplink messages that the data link services are terminated:

- (1) CONTACT CHENNAI RADAR (Frequency) AT (Waypoint)."
- (2) CONTACT KOLKATA RADAR (Frequency) DATALINK SERVICE TERMINATED"



 Chapter:
 9

 Page:
 80

 Rev:
 0

 Date:
 20 Oct 07

Abnormal & Contingency Procedures

Refer to Jeppesen.



Chapter: 9
Page: 81
Rev: 0
Date: 20 Oct 07

7.3.2.5. Sri Lankan airspace (Colombo FIR)

General

CPDLC services are available to FANS 1/A equipped aircraft operating in the Colombo FIR on trial basis.

Datalink (either VHF or satellite) will be utilized for communication between airborne and ground systems, and between controller and pilot. SATVOICE is NOT available. Beyond the range of radar within Colombo FIR, ADS and CPDLC will be available to Datalink-equipped aircraft. Those aircraft are requested to make position reports via CPDLC instead of HF voice communication. (Note: Radar coverage is 200NM).

Datalink-equipped aircraft shall conduct an HF radio check with Colombo Radio prior to entering Colombo FIR where Datalink services are provided. The pilots will then be informed of the primary and secondary HF voice frequencies to be used as backup communication by Colombo.

CPDLC

- Voice read back by the pilot of an ATC clearance/instruction that is issued by data link is not required within this airspace.
- In order to avoid potential ambiguity in exchanging message, each CPDLC downlink message should contain only a single clearance request.
- An emergency message shall be sent by CPDLC as well as by HF or VHF voice communication.
- Special and other non-routine aircraft observation of severe turbulence should be reported by HF or VHF voice communication.
- Flight information services will be provided by HF or VHF voice communication.

Logon Procedures for Colombo FIR

The CPDLC logon address for Colombo FIR is VCCC.

Inbound Procedures

- Datalink equipped aircraft entering the airspace where data link services are provided are required to logon at least 10 minutes prior to entering the airspace.
- The pilots should inform ATC of the completion of CPDLC connection by the following voice phraseology "CPDLC CONNECTION COMPLETED".
- If an AFN logon attempt is rejected, a second attempt with an interval of more than 5 minutes after logon failure is recommended.

Transfer of Voice communications to CPDLC

 The aircraft, which has completed CPDLC connection, departing from the radar coverage within Colombo FIR and entering the airspace where Datalink services are provided will be instructed to transfer to CPDLC as well as to Colombo radio by the following voice phraseology: CONTACT COLOMBO ON HF (Frequency) AND TRANSFER TO COLOMBO AIRWAYS ON DATA LINK". Colombo and Colombo Airways means Colombo Radio and Colombo ACC, respectively.

ADS



Chapter: 9
Page: 82
Rev: 0
Date: 20 Oct 07

Procedures for Level Changes, Route Clearance Requests and Position Reporting Requirements are standard.

 The pilots should inform Colombo radio of the completion of CPDLC connection and send CPDLC reports.

Termination of Data link Services

Aircraft, which have data link connection entering the range of radar within Colombo FIR will be informed by the following CPDLC uplink messages that the data link services are terminated: CONTACT COLOMBO RADAR (Frequency) DATALINK SERVICE TERMINATED".

Abnormal & Contingency Procedures

Refer to Jeppesen.



Chapter: 9
Page: 83
Rev: 0
Date: 20 Oct 07

7.3.2.6. Mauritius airspace

General

Data link (VHF and/or satellite) will be utilized for communication between airborne and ground systems, and between controller and pilot. SATVOICE is NOT available.

CPDLC

- CPDLC is the primary means of communications when operating beyond the range of VHF.
 Voice will be used as a backup.
- To ensure the correct synchronization of messages, controller/pilot dialogues opened by voice must, wherever possible, be closed by voice. Controller/pilot dialogues opened by CPDLC must be closed by CPDLC.
- Pilots departing Mauritius FIR to a non-CPDLC FIR will be instructed to CONTACT the next unit by voice.
- Pilots departing Mauritius FIR to a CPDLC capable FIR will be instructed to MONITOR the next unit by voice, however CPDLC will remain the primary means of communication.
- CONTACT [unit name] [frequency] and END OF SERVICE messages will be sent as separate messages, with the END OF SERVICE message only being sent after a WILCO has been received in acknowledgement of the CONTACT message.
- STAND BY A short-term delay of less than 10 minutes can be expected.
- REQUEST DEFERRED A longer-term delay of greater than 10 minutes can be expected.

CPDLC Limited Services in Mauritius FIR

- ATC will not issue uplink messages relating to Cruise Climbs nor "At Pilot Discretion"
- Any instruction containing a Conditional
- Clearance will be pre-fixed with an instruction to remain at the currently cleared altitude; e.g. MAINTAIN 330, AT 2215 CLIMB TO AND MAINTAIN 370.
- When inbound to destinations within the FIMM FIR, CPDLC & ADS will remain active until landing. Pilots will be instructed to transfer to VHF by the message "CONTACT MAURITIUS CENTRE [frequency]"

Logon Procedures for Mauritius FIR

The logon address for the Mauritius FIR is FIMM.

- Data link-equipped aircraft entering FIMM airspace where data link services are provided are required to logon between 10 and 15 minutes prior to entering the airspace. The pilots should inform ATC of the completion of CPDLC connection by the following voice phraseology "CPDLC CONNECTION COMPLETED".
- Datalink-equipped aircraft entering FIMM airspace from non-CPDLC
- Pilots are required to logon between 45 and 15 minutes prior to entering the airspace.
- Aircraft departing from Mauritius SSR Airport should logon at 40 nm or more from PLS VOR.
- If an AFN logon attempt is rejected, a second attempt with an interval of more than 5 minutes after logon failure is recommended.

Transfer of Voice communications to CPDLC

 Pilots will be instructed via Voice when a transfer to CPDLC is required: "Transfer to Mauritius Centre on Data Link. Monitor [frequency]"

Termination of Data link Services

- Aircraft departing Mauritius airspace to adjoining CPDLC capable FIR can expect to be Address Forwarded to that FIR prior to the FIMM boundary.
- The pilot should acknowledge this message by sending "WILCO".

ETIHAD AIRWAYS – UNITED ARAB EMIRATES



 Chapter:
 9

 Page:
 84

 Rev:
 0

 Date:
 20 Oct 07

ADS

Procedures for Level Changes & Route Clearance Requests are standard.

Position Reporting Requirements

- Mauritius FIR requires an initial CPDLC position report at the FIR boundary, then ADS reporting only.
- An aircraft is required to downlink a CPDLC position report when instructed by voice to transfer to Datalink.
- Pilots must advise ATC of any revised waypoint estimates that are greater than 2 minutes to a previous estimate. This maybe done by voice, a CPDLC position report with a revised estimate, or a free text message "Revised ETA [position] [time]"

Abnormal & Contingency Procedures

Refer to Jeppesen.



Chapter: 9
Page: 85
Rev: 0
Date: 20 Oct 07

7.3.2.7. Yangon FIR

General

Data link (VHF and/or satellite) will be utilized for communication between airborne and ground systems, and between controller and pilot. SATVOICE is NOT available.

CPDLC

- CPDLC is the primary means of communications when operating beyond the range of VHF.
 Voice will be used as a backup.
- To ensure the correct synchronization of messages, controller/pilot dialogues opened by voice must, wherever possible, be closed by voice. Controller/pilot dialogues opened by CPDLC must be closed by CPDLC.
- Beyond the range of radar within Yangon FIR, ADS & CPDLC will be available to data link equipped aircraft.
- Aircraft with a CPDLC connection are requested to make position reports via CPDLC.
- Radar coverage is 200nm based on N16 53 39 E096 08 41.
- Data link equipped aircraft shall conduct an HF radio check with Yangon ACC prior to entering the Yangon FIR where data link services are provided. The pilots will then be informed of the primary & secondary frequencies to use for backup communication with Yangon Radio.

Logon Procedures for Auckland FIR

The CPDLC logon address for Yangon FIR is VYYF.

Data link-equipped aircraft entering Yangon (VYYY) airspace where Datalink services are provided are required to logon between 5 and 10 minutes prior to entering the airspace. The pilots should inform ATC of the completion of CPDLC connection by the following voice phraseology "CPDLC CONNECTION COMPLETED".

If an AFN logon attempt is rejected, a second attempt with an interval of more than 5 minutes after logon failure is recommended.

Transfer of Voice communications to CPDLC

- An aircraft, which has completed a CPDLC connection, departing from the radar coverage within Yangon FIR and entering the airspace where Datalink services are provided will be instructed to transfer to CPDLC as well as to contact Yangon Radio by the following voice phraseology: "CONTACT YANGON [frequency] AND TRANSFER TO YANGON CONTROL ON DATA LINK"
- The pilot should inform Yangon Radio of the completion of the CPDLC connection and send the CPDLC reports.
- The aircraft which has completed a CPDLC connection, from adjacent FIRs to Yangon FIR
 entering the airspace where data link services are provided should inform Yangon Radio of
 the completion of the CPDLC connection & send the CPDLC reports.

Termination of Data link Services

- Aircraft departing Yangon FIR will be informed by the following CPDLC uplink message that data link services are terminated: "CONTACT YANGON [frequency], DATALINK SERVICE TERMINATED"
- The pilot should acknowledge this message by sending "WILCO". Upon receiving the WILCO message, an "END SERVICE" message will be uplinked to terminate the CPDLC connection.
- Aircraft which have a Datalink connection, entering the range of radar within Yangon FIR will be informed by the following CPDLC uplink message that the data link services are terminated: "CONTACT [ICAO unit name] [frequency], DATA LINK SERVICE TERMINATED"
- The pilot should acknowledge this message by sending "WILCO".



 Chapter:
 9

 Page:
 86

 Rev:
 0

 Date:
 20 Oct 07

 After voice communication is established with the appropriate ATC unit, the pilot should terminate the data link connection by selecting "ATC COM OFF"



 Chapter:
 9

 Page:
 87

 Rev:
 0

 Date:
 20 Oct 07

ADS

Procedures for Level Changes, Route Clearance Requests and Position Reporting Requirements are standard.

Abnormal & Contingency Procedures

Refer to Jeppesen.



Chapter: 9
Page: 88
Rev: 0
Date: 20 Oct 07

7.3.2.8. Maastricht FIR

General

- In this airspace Datalink is a supplemental means of communication. Voice remains the primary means of communication. Crew must always initiate a voice contact with the given Maastricht frequency after a Contact has been received, even when using Datalink.
- Remember, CPDLC is only allowed when you are under the control of a Maastricht UAC controller, so only send messages when you are 'talking' to Maastricht.
- If an aircrew has any doubt regarding a Datalink message they must go to voice to clarify the situation with ATC.
- Maastricht is operating Datalink with a restricted message set [see below].

CPDLC

Aircrew may receive the following uplink messages sent by Maastricht UAC;

- Proceed Direct to [point]
- Contact [unitname] [frequency]
- Squawk [code]
- Squawk Ident
- Check Stuck Microphone [frequency]

Uplink messages should be replied to with an appropriate downlink response, which are;

- WILCO
- STANDBY, or
- UNABLE
- All CPDLC messages shall use pre-formatted message elements. Free text messages shall NOT be used when communicating via CPDLC with Maastricht UAC. Use of such a free-text message will result in an ERROR response.

If ATC instructs you, via the R/T to "Terminate CPDLC. Disconnect and revert to voice," then the aircrew must immediately disconnect the active ATC CPDLC Comm. link, and use only voice after that.

- If an aircrew receives an ERROR response to an operational reply that they have sent, do not re-send it. It will only generate another error. Go to voice.
- Use of CPDLC is not mandatory in this airspace & is conducted at the discretion of ATC and
 the aircrew concerned. If either the aircrew or ATC consider that CPDLC should not be used
 in the prevailing circumstances, then the operation shall be suspended or terminated and the
 other party informed by voice communication.
- CPDLC is intended for use by ATC in Maastricht UAC only in strategic and non-tactical circumstances. There will be occasions, mainly in tactical situations and flows, when CPDLC will not be used, even after logon by the crew. As Maastricht adds more CPDLC messages, this functionality will be used more dynamically.

Logon Procedures for Maastricht FIR

The CPDLC logon address for Maastricht FIR is EDYY.

Logon Procedures

 Datalink services [with a restricted message set - see below] are available for aircraft operating within the upper airspace (above FL245) under the responsibility of Maastricht



 Chapter:
 9

 Page:
 89

 Rev:
 0

 Date:
 20 Oct 07

UAC. Irrespective of the number of Maastricht sectors entered during their flight only one logon per flight is required.

• If a DLIC - (Data Link Initiation Capability) logon attempt is rejected, a second attempt with an interval of more than 5 minutes after logon failure is recommended.

Inbound Procedures

Data link-equipped aircraft entering EDYY airspace are required to logon around 30 minutes prior to entering the airspace.

Outbound Procedures

For aircraft departing from an aerodrome in close proximity to Maastricht UAC airspace, log-on can be initiated when the aircraft is on the ground.

Termination of Datalink Services

Datalink log off is automatic on exiting Maastricht UAC airspace. No aircrew action is required.

Level Changes

Aircrew should NOT request level changes via Datalink in Maastricht. Voice must be used for vertical clearances, until further advised.

Route Clearance Requests

Aircrew may request, via data link clearance direct to a point on their route. This is currently the only appropriate downlink request message in the Maastricht UAC.

Voice read-back by the pilot of an ATC clearance/instruction that is issued by data link is not required within this airspace. Clearances shall be executed when the WILCO message is sent.

ADS

This service is not available with Maastricht FIR.

Abnormal & Contingency Procedures

Refer to Jeppesen.



 Chapter:
 9

 Page:
 90

 Rev:
 0

 Date:
 20 Oct 07

7.3.2.9. Gander FIR

Logon Procedures for Gander FIR

The CPDLC logon address for Gander FIR is CZQX.

Westbound Procedures

- Entering from Reykavik FIR, expect voice instruction to contact Gander at a specific time or waypoint.
- By 15 to 45 minutes prior to entry, logon to CZQX. Expect CPDLC connection approximately 20 minutes before Oceanic FIR boundary. Confirm 'Active ATC CZQX'.
- Entering from Shanwick expect CPDLC (or Voice) transfer to Gander then, automatic assignment of Gander as the next data authority. Confirm 'Active ATC CZQX'.
- Call Gander Aeradio using the term "C-P-D-L-C". Obtain SELCAL check. Do not transmit a
 position report.
- Expect 'voice reports not required in Gander FIR' and to receive the frequency for the next domestic FIR via voice or CPDLC.
- Contact the next domestic CTA at the FIR boundary, expect end of service message.

Eastbound Procedures

- Contact Gander for clearance either via VHF or ACARS using Gander Oceanic Clearance Delivery procedures.
- Refer to NAT Track message for clearance delivery frequency assignment, if using VHF.
- Confirm Oceanic entry point from Jeppesen chart and OFP.
- Arrange domestic clearance to the entry point if the cleared entry point is different to the flight plan.
- Review and crosscheck cleared route as per MNPS procedures.
- At 15 45mins prior to entry, logon to CZQX. Expect CPDLC connection approximately 20 minutes before Oceanic FIR boundary. Confirm 'Active ATC CZQX'.
- Call Gander Aeradio using the term "C-P-D-L-C". State next FIR. Obtain SELCAL check. Do not transmit a position report.
- Expect 'voice reports not required in Gander FIR' and to receive the frequencies for the next FIR via voice or CPDLC.
- Expect automatic assignment of the next data authority if Shanwick. Otherwise end of service message if Reykjavik or Santa Maria.
- Contact the next Oceanic CTA at the FIR boundary or required time for SELCAL check.

Abnormal or Contingency Procedures

- · Revert to voice.
- Emergency ADS available.
- However, CPDLC emergency messages will be responded to with free text. "ROGER PAN' or 'ROGER MAYDAY' as appropriate. Aircraft will be considered to be in an emergency state.

CPDLC

- In Gander oceanic airspace, CPDLC is the primary means of communication. Back-up communication will be HF voice.
- Limited message sets available.
- Prompt response to all messages required.
- Close all messages even if a separate voice response received.



Chapter: 9
Page: 91
Rev: 0
Date: 20 Oct 07

ADS

- Use Auto Pilot (1)one
- ADS WPR only active and will be the primary means of position reporting.
- Expect statement/message: 'position reports not required.'
- If next position changes by 3 minutes or more transmit revised estimate via HF voice.

Level changes

- Available but may be restricted due to traffic density.
- All altitude clearances will include the uplink element to 'REPORT LEVEL'. This message should be initiated automatically by the FMGEC monitoring.

Oceanic/Route Clearance Requests

• Not available by CPDLC. Refer to Gander Oceanic Clearance Delivery.



Chapter: 9
Page: 92
Rev: 0
Date: 20 Oct 07

7.3.2.10. New York FIR

Logon Procedures for New York FIR

The CPDLC logon address for the New York FIR is KZWY.

Westbound Procedures

- Entering from Gander expect voice or CPDLC instruction to contact New York, then automatic assignment of New York as next data authority. Confirm 'Active ATC KZWY'.
- Call New York Aeradio using the term "C-P-D-L-C". Obtain SELCAL check. Do not transmit a
 position report.
- Voice reports are required in New York FIR unless otherwise advised. Expect to receive the frequency for the next domestic FIR via voice or CPDLC.
- Contact the next domestic CTA at the FIR boundary, expect end of service message.

Eastbound Procedures

- Contact New York for Oceanic Clearance via VHF.
- Confirm Oceanic entry point from Jeppesen chart and CFP.
- Arrange domestic clearance to the entry point if necessary.
- Review and crosscheck cleared route as per MNPS procedures.
- At 15 45mins prior to entry, logon to KZWY. This may mean logon shortly after take-off. Confirm 'Active ATC KZWY'
- Call New York Aeradio using the term "C-P-D-L-C". State next FIR. Obtain SELCAL check.
- Voice position reports are required in New York FIR unless otherwise advised.
- Expect to receive the frequencies for the next FIR via voice or CPDLC.
- Expect automatic assignment of the next data authority if Gander.
- Contact the next Oceanic CTA at the FIR boundary or required time for SELCAL check.

Abnormal or Contingency Procedures

- · Revert to voice.
- Emergency ADS available.
- However, CPDLC emergency messages will be responded to with free text. "ROGER PAN' or 'ROGER MAYDAY' as appropriate. Aircraft will be considered to be in an emergency state.

CPDLC

- In New York oceanic airspace, CPDLC is the primary means of communication and the secondary means of position reports. Backup communication will be HF voice.
- Limited message sets available. However, more functionality and message sets are available than other NAT FIRs.
- Prompt response to all messages required.
- Close all messages even if a separate voice response received.

ADS

- Use Auto Pilot (1) one.
- ADS WPR only active and will be the primary means of position reporting.
- Voice position reports required unless advised.
- If next position changes by 3 minutes or more transmit revised estimate.

Level changes

- Available but may be restricted due to traffic density.
- All altitude clearances will include the uplink element to 'REPORT LEVEL'. This message should be initiated automatically by the monitoring function of the FMGEC.

Oceanic/Route Clearance Requests

Not available by CPDLC. Refer to Jeppesen chart for voice procedure.

ETIHAD AIRWAYS - UNITED ARAB EMIRATES



Chapter: 9
Page: 93
Rev: 0
Date: 20 Oct 07

7.3.2.11. Reykjavik FIR

Logon Procedures for Reykjavik FIR

The ADS logon address for the Reykjavik FIR is 'BIRD'.

Westbound Procedures

- Contact Reykjavik for clearance either via HF/VHF. Westbound clearances are typically delivered by a local domestic controller (Stavanger, Bodo, Scottish) if your flight is not transiting Shanwick at any point.
- Confirm Oceanic entry point from Jeppesen chart and CFP.
- Arrange domestic clearance to the Oceanic entry point if the cleared entry point is different to the flight plan.
- Review and crosscheck cleared route as per MNPS procedures.
- At 15 45mins prior to entry logon to 'BIRD'. Confirm 'BIRD notified'
- Call Reykjavik Aeradio using the term "A-D-S". State next FIR. Obtain SELCAL check.
- Expect CPDLC service not available in Reykjavik 'voice reports not required in Reykjavik FIR' and to receive the frequencies for the next FIR via voice.
- Manual log-on required for next FIR with CPDLC services (example: CZQX prior to Gander FIR).
- Contact the next Oceanic Aeradio at the FIR boundary or required time for SELCAL check.

Eastbound Procedures (next FIR being domestic)

- Do not change current CPDLC Log-on.
- Contact Reykjavik Aeradio at the FIR boundary or required time for SELCAL check using the term "C-P-D-L-C". Include the OTS Track letter or the names of the last two fixes if not on the OTS.
- Expect to be told CPDLC SERVICE NOT AVAILABLE IN Reykavik 'voice reports not required in Reykjavik FIR' and to receive the frequency for the next domestic FIR via voice.
- Contact Aeradio if the next domestic frequency not received by 10 minutes prior to the domestic boundary.

Abnormal or Contingency Procedures

- · Revert to voice.
- Emergency ADS available.
- Special procedures apply. Refer to Route Manual MNPS and Jeppesen NAT pages.

CPDLC

- None
- In Reykjavik Oceanic airspace, radio is the primary means of communication.

ADS

- Use Auto Pilot (1) one.
- ADS WPR only active and will be the primary means of position reporting.
- Voice position report still required unless advised.
- If next position changes by 3 minutes or more transmit revised estimate via HF voice.

Level changes

• Available by voice but may be restricted due to traffic density.

Oceanic/Route Clearance Requests

Not available by Datalink. Refer to Jeppesen chart for voice procedure.



Chapter: 9
Page: 94
Rev: 0
Date: 20 Oct 07

7.3.2.12. Santa Maria FIR

Logon Procedures for Santa Maria FIR

The ADS logon address for the Santa Maria FIR is 'LPPO'

Westbound Procedures

- Contact Santa Maria for clearance via HF/VHF.
- Confirm Oceanic entry point from Jeppesen chart and CFP.
- Arrange domestic clearance to the Oceanic entry point if the cleared entry point is different to the flight plan.
- Review and crosscheck cleared route as per MNPS procedures.
- At 15 45mins prior to entry, logon to 'LPPO'. Confirm 'LPPO notified'
- Call Santa Maria Aeradio using the term "C-P-D-L-C". State next FIR. Obtain SELCAL check.
- Expect CPDLC service not available in Santa Maria 'voice reports not required in Santa Maria FIR' and to receive the frequencies for the next FIR via voice.
- Manual log-on required for next FIR with CPDLC services (example: KZWY prior to New York FIR).
- Contact the next Oceanic Aeradio at the FIR boundary or required time for SELCAL check.

Eastbound Procedures

- Do not change current log-on.
- Contact Santa Maria Aeradio at the FIR boundary or required time for SELCAL check using the term "C-P-D-L-C". Include the OTS Track letter or the names of the last two fixes if not on the OTS.
- Expect CPDLC service not available in Santa Maria 'voice reports not required in Santa Maria FIR' and to receive the frequency for the next domestic FIR via voice.
- Contact Aeradio if the next domestic frequency not received by 10 minutes prior to the domestic boundary.

Abnormal or Contingency Procedures

- Revert to voice.
- Emergency ADS available.
- Special procedures apply. Refer to Jeppesen NAT pages.

CPDLC

- None.
- In Santa Maria Oceanic airspace, radio is the primary means of communication.

ADS

- Use Auto Pilot (1) one.
- ADS WPR only active and will be the primary means of position reporting.
- Voice position report still required unless advised.
- If next position changes by 3 minutes or more transmit revised estimate via HF voice.

Level changes

Available by voice but may be restricted due to traffic density.

Oceanic/Route Clearance Requests

Not available by Datalink. Refer Jeppesen chart for voice procedure.



Chapter: Page: 95 Rev: 0

Date: 20 Oct 07

7.3.2.13. Shanwick FIR

Logon Procedures for Shanwick FIR

The CPDLC logon address for the Shanwick FIR is EGGX

In the Shanwick FIR, the AFN Logon will be rejected unless the Oceanic clearance has been issued to the flight.

As well, the Shanwick system will reject AFN logons from westbound flights proceeding into or transiting the Madrid FIR, because the limited benefit for such flights does not justify the workload associated with providing CPDLC services to them.

Westbound Procedures

- Contact Shanwick for clearance either via ACARS using ORCA or via VHF/HF
- Confirm Oceanic entry point from Jeppesen chart and CFP.
- Arrange domestic clearance to the entry point if the cleared entry point is different to the flight
- Review and crosscheck cleared route as per MNPS procedures.
- At 15 45mins prior to entry, logon to EGGX. Confirm 'Active ATC EGGX'
- Call Shanwick Aeradio using the term "C-P-D-L-C". State next FIR. Obtain SELCAL check. Do not transmit a position report.
- Expect 'voice reports not required in Shanwick FIR' and to receive the frequencies for the next FIR via voice or CPDLC.
- Expect automatic assignment of the next data authority if Gander.
- Contact the next Oceanic CTA at the FIR boundary or required time for SELCAL check.

Eastbound Procedures (next FIR being domestic)

- If entering from Gander, expect automatic assignment of Shanwick as the next data authority.
- Contact Shanwick Aeradio at the FIR boundary or required time for SELCAL check using the term 'C-P-D-L-C'. Include the OTS Track letter or the names of the last two fixes if not on the OTS. Do not transmit a position report.
- Expect 'voice reports not required in Shanwick FIR' and to receive the frequency for the next domestic FIR via voice or CPDLC.
- Contact Aeradio if the next domestic frequency not received by 10 minutes prior to the domestic boundary.

Abnormal or Contingency Procedures

- Revert to voice.
- Emergency ADS available.
- However, CPDLC emergency messages will be responded to with free text. "ROGER PAN' or 'ROGER MAYDAY' as appropriate. Aircraft will be considered to be in an emergency state.
- Special procedures apply. Refer to Jeppesen NAT pages.

CPDLC

- In Shanwick Oceanic airspace, CPDLC is the primary means of communication. Back-up communication will be HF voice.
- Limited message sets available.
- Prompt response to all messages required.
- Close all messages even if a separate voice response received.

ADS

- Use Auto Pilot (1) one.
- ADS WPR only active and will be the primary means of position reporting.
- Expect statement/message: 'position reports not required.'

ETIHAD AIRWAYS – UNITED ARAB EMIRATES



 Chapter:
 9

 Page:
 96

 Rev:
 0

 Date:
 20 Oct 07

• If next position changes by 3 minutes or more - transmit revised estimate via HF voice.

Level changes

- Available but may be restricted due to traffic density.
- All altitude clearances will include the uplink element to 'REPORT LEVEL'. This message should be initiated automatically by the monitoring function of the FMGEC.

Oceanic/Route Clearance Requests

Not available by CPDLC. Refer to Shanwick ORCA procedures.



Chapter: 9
Page: 97
Rev: 0
Date: 20 Oct 07

7.3.2.2 Fukuoka FIR CPDLC Services

Initial notification of emergency status may be accepted by CPDLC. Depending on the nature of the emergency condition experienced, the pilot should notify ATC of the circumstances by the most efficient means (voice or CPDLC).

Clearances/instructions relating to cruise climb are not issued within the Fukuoka FIR. Therefore, downlink request DM#8 "REQUEST CRUISE CLIMB TO [level]" should not be used.

Pre-formatted messages regarding route modifications, including route clearance are not able to be uplinked. These messages include UM#79, UM#80, UM#81, UM#83, UM#84, UM#85 and UM#86. CONTROLLER-PILOT DATA LINK COMMUNICATIONS (CPDLC) MESSAGE SET of the ICAO PANS/ATM. The route clearance should, therefore be requested and issued by HF or VHF voice communication.

Special and other non-routine aircraft observation, i.e. moderate turbulence (transonic and supersonic aircraft only), severe turbulence, and volcanic activity should be reported by HF or VHF voice communication.

Flight information services will be provided by HF or VHF voice communication.

Logon Procedures within the Fukuoka FIR

Datalink-equipped aircraft inbound from non-Datalink airspace or radar airspace to Fukuoka Oceanic Controlled airspace are required to log on between 15 and 45 minutes prior to entering Datalink airspace within the Fukuoka FIR. On initial contact with Tokyo Radio, the pilot should inform Tokyo Radio that they have the CPDLC connection using the voice phraseology "WE HAVE CPDLC CONNECTION", and should downlink a CPDLC position report.

Datalink-equipped aircraft inbound from the Anchorage FIR or Oakland FIR to Fukuoka Oceanic Controlled airspace will be automatically transferred to "RJJJ" by Anchorage or Oakland. If the process is not successful and "RJJJ" is not the active center, the pilot shall, within 5 minutes after crossing the Fukuoka and Anchorage/Oakland common FIR boundary, terminate the connection by selecting ATC Datalink off, then log on with "RJJJ". Once a CPDLC connection has been established with "RJJJ (Fukuoka ACC)", the pilot should inform Tokyo Radio that they have the CPDLC connection using the voice phraseology "WE HAVE CPDLC CONNECTION", and should downlink a CPDLC position report.



 Chapter:
 9

 Page:
 98

 Rev:
 0

 Date:
 20 Oct 07

7.4. Differences of Use of FANS-1/A Messages

The States listed in the box on the right do NOT use these two messages.

33	ИМ	Cruise [altitude]	Australia, Fiji, Japan, Mauritius, New Zealand, South Africa, and Tahiti do not use this message.
129	UM	Report level[altitude]	The United States has not used this message, but will be phasing it in during the 2003-4 time period.

7.5. Position Reporting Requirements: CPDLC and ADS-C Environments

The following table lists the position reporting requirements of individual ATSUs.

ATSU	Reporting Requirements	
Anchorage	Requires an initial CPDLC position report at the FIR boundary entry point, then ADS-C reporting only.	
Antananarivo (Madagascar)		
Auckland	Requires an initial CPDLC position report at the FIR boundary entry point, then ADS reporting only.	
Brisbane	Requires an initial CPDLC position report at the FIR boundary entry point, then ADS reporting only.	
Colombo	Currently trialing ADS and CPDLC. CPDLC position reports requested at each waypoint. Primary communications via voice. Full HF reporting still required	
Maldives		
Mauritius	Requires an initial CPDLC position report at the FIR boundary entry point, then ADS reporting only.	
Melbourne	Requires an initial CPDLC position report at the FIR boundary entry point, then ADS reporting only.	
Nadi	Requires an initial CPDLC position report at the FIR boundary entry point, then ADS reporting only.	
Oakland	Requires an initial CPDLC position report at the FIR boundary entry point, then ADS-C reporting only.	
Seychelles		
Johannesburg	hannesburg Requires an initial CPDLC position report at the FIR boundary entry point, then ADS reporting only.	
Tahiti Requires an initial CPDLC position report at the FIR entry point, then ADS reporting only.		
Fukuoka	Accepts CPDLC position reports in lieu of HF voice.	

7.6. Aircraft Data

7.6.2. Verifying registration number

A330-A340

On Airbus aircraft, the pilot could not initially change the registration number provided by the avionics. This will be possible in the second version of ATSU, and this change will then be reflected in the FN_CON message.

B777

These aircraft do not have an essential data source for this datum, which means that the pilot must

ETIHAD AIRWAYS – UNITED ARAB EMIRATES



Chapter: 9
Page: 99
Rev: 0
Date: 20 Oct 07

verify that the registration number is correct.

7.6.3. CPDLC connection requests

A330-A340

B777

- The only Connection Request message processed normally by FANS-1 is the first Connection Request following an AFN logon (i.e., an AFN logon initiated when no CPDLC connection exists).
- If the CPDLC connection in the avionics is not terminated, and a new AFN logon transmitted, before sending the new **Connection Request** message any subsequent **Connection Request** messages received from that ATSU are processed, however they have no effect on the "active" connection (i.e. the avionics is not informed of an ATS system shutdown and will therefore consider that the original connection is still active).
- The avionics will not accept a connection if the AFN logon is initiated manually by the pilot while another connection was active, even if the active connection is terminated before the connection from the new ATSU is received

7.6.4. Flight crew display:- response and acknowledgment

A330-A340

In response to an uplink message that requires a closure response (WILCO, ROGER, AFFIRM, UNABLE, NEGATIVE), the pilot is presented with prompts corresponding to the closure responses required by DO-219 for the specific uplink message. EG prompts presented upon receipt of an uplink clearance are **WILCO**, **UNABLE**, and **STANDBY**.

B777

In response to an uplink message that requires a response element (WILCO, ROGER, AFFIRM, UNABLE or NEGATIVE), the pilot is presented with two prompts (Accept and Reject).

- If the correct response to the uplink message is affirmative (WILCO, ROGER, or AFFIRM), then the
 pilot will select the Accept prompt.
- If the correct response to the uplink message is negative (UNABLE or NEGATIVE), then the pilot will select the Reject prompt.

When the pilot selects either the **Accept** or the **Reject** prompt, the FANS-1 automatically transmits the correct response (**WILCO, ROGER**, **AFFIRM, UNABLE**, or **NEGATIVE**) for the corresponding message.

On the FANS-1 equipped aircraft, the pilot cannot add any other element to a positive response.



Chapter: 9
Page: 100
Rev: 0
Date: 20 Oct 07

7.6.5. FMS processing of waypoints

A330-A340

The FMS cannot distinguish between ATC mandatory waypoints and waypoints inserted by the pilot. However, the pilot can over-write any avionics-determined default data contained in reports and confirm messages.

B777

The FMC's on Boeing aircraft do not distinguish between ATC mandatory waypoints and FMC sequenced waypoints for position reports. However, the FANS-1 of these aircraft will allow the pilot to overwrite the FMC-determined default "reported waypoint" position and time (Downlink element DM#45)

7.6.6. Multiple request messages

A330-A340

There is no network acknowledgment timer on Airbus aircraft for the establishment of a connection. Once CPDLC is established, there is a timer which is currently set at 2 minutes.



Chapter: 9
Page: 101
Rev: 0
Date: 20 Oct 07

B777

This network acknowledgment timer does not apply to the B777.

7.6.7. Waypoint sequencing

A330-A340

Waypoint sequencing will only occur when the aircraft is within 7 NM of the flight plan track (as modified by any parallel offset that may have been entered). Therefore ADS-C waypoint change event reports and armed REPORT PASSING messages will not be transmitted automatically when the aircraft is outside these limits.

B777

Waypoint sequencing will only occur when the aircraft is within 21 NM of the flight plan track (as modified by any parallel offset that may have been entered). Therefore ADS-C waypoint change event reports and armed REPORT PASSING messages will not be transmitted automatically when the aircraft is outside these limits.



Chapter: 9
Page: 102
Rev: 0
Date: 20 Oct 07

7.6.8. Offset using the FMS

When a pilot is flying an FMS offset, the Airbus and Boeing parameters previously mentioned (7 NM and 21 NM respectively) are not an issue as all flight plan waypoints will be sequenced by the FMS without taking into account the offset distance being flown. However, when an offset is executed using the FMS, Boeing aircraft and Airbus aircraft will transmit intent and predicted route information as follows:

A330-A340

The Intent and Predicted Route Group information is projected along the offset route.

B777

The Predicted Route Group when flying an FMS offset is always along the offset route.

The projection of intent information currently depends on the aircraft type, and the version of software is installed as defined below:

B747-400 - Load 14 and before, towards the next FMS waypoint. Load 15 and after, along the offset path.

B757/B767 - Pegasus 99 and before, towards the next FMS waypoint. Pegasus 2000 and after, along the offset path.

B777 - Block Point 98, towards the next FMS waypoint. Block Point 99 and after, along the offset path.

MD90 - 920 FMS, towards the next FMS waypoint. 921 FMS and after, along the offset path.

MD10 / MD11 / B717 - Always along the offset path.



Chapter: 9
Page: 103
Rev: 0
Date: 20 Oct 07

Date: 20 Oct 07

5. AIR TRAFFIC SERVICES DATA LINK OPERATIONS

5.1 Introduction

- 5.1.1 The Department of Civil Aviation will implement ATS Data Link operations within Class A and Class C airspace. The ATS Data Link applications which utilise the SITA AirCOM (VHF and Satellite) network will be addressed to FANS-1/A equipped aircraft.
- 5.1.2 Flight crews using these data link facilities must be trained in the use of data link equipment to a level approved by the State of Registry. Receipt of a logon request will notify ATC that flight crews meet this requirement.
- 5.1.3 The data link applications supported by the FANS-1/A system are Controller Pilot Data link Communications (CPDLC) and Automatic Dependent Surveillance (ADS).

The CPDLC function supports:

- (a) Emergency alerting,
- (b) Uplink of ATC clearances and instruction,
- (c) Downlink of position reports and clearance requests, and
- (d) Free text as a supplement to preformatted elements.

The ADS function supports:

- (a) Emergency alerting, and
- (b) Automatic reporting by the aircraft's Flight Management System (FMS) of aircraft position and intent information in accordance with parameters established in contracts by the ground system.
- 5.1.4 Before ADS and CPDLC connection can be established, the aircraft must "LOGON" to the ground system. This is achieved via the ATS Facility Notification (AFN) LOGON. This process is initiated by the pilot in accordance with company procedures.

5.2 LOGON Procedures

- (a) The LOGON address for the Mauritius FIR is: FIMM
- (b) To avoid automatic rejection of the logon, the flight identification number and the aircraft registration contained in the logon message must be identical to the flight identification number and tail number filed in the flight plan.
- (c) Aircraft proceeding inbound to Mauritius FIR from a non-CPDLC FIR and requesting data link services must logon between 45 and 15 minutes prior to the estimate for entering the FIR.
- (d) Aircraft departing from airports in Mauritius, requesting data link service, should logon as per the following table:

Airport	Address	Logon Timing
SSR International Airport	FIMM	At 40 NM or more from "PLS"
Other Airports	FIMM	On the ground or shortly after
		departure



Chapter: 9
Page: 104
Rev: 0
Date: 20 Oct 07

(e) Aircraft departing Mauritius airspace to an adjoining CPDLC – capable FIR can expect to be Address Forwarded to that FIR prior to the FIR Boundary.

- (f) Logons prior to departure must not occur earlier than 15 minutes prior to ETD to avoid automatic rejection of the logon.
- (g) The provision of Pre-Departure Clearance (PDC) via CPDLC to departing aircraft is not available as part of the initial stages of the Mauritius ATM program.

5.3 CPDLC Applications

5.3.1 General

- (a) CPDLC will be the primary means of communications between ATC and FANS-1/A equipped aircraft beyond the range of VHF voice. Voice will be used as the backup communications medium. The controller communicating by CPDLC will hold the responsibility for SAR and communications alerting.
- (b) Standard pre-formatted message elements must be used whenever possible. Free text message elements should be used only when an appropriate pre-formatted message element does not exist, or to supplement an existing pre-formatted message element. The use of free text should be kept to a minimum.
- (c) To ensure correct synchronisation of messages, controller/pilot dialogues opened by voice must be closed by voice wherever possible. Controller/ pilot dialogues opened by CPDLC must be closed by CPDLC.
- (d) To avoid ambiguity, a CPDLC downlink message should not contain more than one clearance request.
- (e) If multiple clearance requests are contained in a single downlink message and the controller cannot comply with all requests, the uplink message element UNABLE will be sent as a response to the entire message. A separate message containing a response to those requests that can be complied with will then be sent by the controller.
- (f) If any ambiguity exists as to the intent of a particular message, clarification must be sought by voice.
- (g) Due to inherent integrity checks and a coded reference to any preceding related message contained within CPDLC dialogues, a clearance issued by CPDLC requires only the appropriate CPDLC response, not a read-back as would be required if the clearance had been delivered by voice.
- (h) The downlink response WILCO indicates that the pilot accepts the full terms of an entire uplink message including any CLEARANCE or INSTRUCTION.
- (i) The use of the STANDBY message element notifies the receiver that the request is being assessed and a short-term delay of less than 10 minutes can be expected until a response will be sent. The original message remains open.
- (j) The use of the REQUEST DEFERRED message element notifies the receiver that the request is being assessed and a longer-term delay of greater than 10 minutes can be expected until a response will be sent. The original message remains open.

5.3.2 Message Restrictions



Chapter: 9
Page: 105
Rev: 0
Date: 20 Oct 07

 ATS will not issue uplink instructions relating to cruise climbs, or the uplink element CRUISE [altitude]. As an alternative, controllers will endeavour, where possible, to issue block clearances.

- b. Owing to different interpretations in meaning, ATS will not issue uplink instructions containing the "AT PILOT DISCRETION" element. In response to a downlink request containing this message element, ATS may instead offer a block level clearance.
- c. Due to cockpit display limitations, any instruction containing a Conditional Clearance (e.g. "AT {time/place} CLIMB/DESCEND TO AND MAINTAIN {altitude}"), will be prefixed with an instruction to remain at the currently cleared level; e.g.

"MAINTAIN 330. AT 2215 CLIMB TO AND MAINTAIN 370"

5.3.3 Position Reporting

- (a) The following apply with regard to position reporting:
 - i. Inbound to The Mauritius Airspace:
 - CPDLC connected aircraft inbound to the Mauritius FIR are required to downlink a CPDLC position report entering the FIR. This is to establish the appropriate FIR (i.e. FIMM) as the Current Data Authority.
 - Aircraft that are not CPDLC connected entering the airspace are required to downlink a CPDLC position report when the CPDLC connection is established.
 - ii. Departing or Transiting Mauritius Airspace:
 - An aircraft is required to downlink a CPDLC position report when instructed on voice to transfer to datalink.
- (b) Following the initial CPDLC position report, ADS reporting will fulfill normal position reporting requirements within the FIR. Neither CPDLC position reports nor voice position reports will be required while ADS reporting is operational.
- (c) In the event of ADS failure, the pilot shall be instructed to resume normal reporting by either voice or CPDLC as appropriate.

5.3.4 Revision of Estimates

- (a) Under normal circumstances, an aircraft position reporting via ADS is not required to advise ATC of any revised way-point estimates. Exceptions to this are:
 - revisions of greater than two (2) minutes to a previous pilot advised estimate (i.e. by voice or CPDLC); or
 - following a pilot initiated action (e.g. speed change) resulting in an amended estimate of greater than two (2) minutes.
- (b) If required, a pilot may advise a revised estimate in one of the following manners:
 - i bv voice: or
 - by downlinking a CPDLC position report containing the revised
 - by downlinking the free text message "REVISED ETA {position} {time}"

5.3.5 Transfers to and from CPDLC



Chapter: 9
Page: 106
Rev: 0
Date: 20 Oct 07

(a) Where CPDLC is to be used as the primary means of communications (beyond VHF voice coverage) pilots will be instructed on voice when a transfer to CPDLC is required by use of the phraseology:

"TRANSFER TO MAURITIUS CENTRE ON DATA LINK. MONITOR [frequency]".

- (b) On transfer to data link, the pilot is required to downlink a CPDLC position report. Following this initial position report, ADS reporting will fulfill normal position reporting requirements within the FIR.
- (c) Pilots departing the Mauritius FIR into a non-CPDLC FIR will be instructed to CONTACT the next unit by voice.
- (d) Pilots departing the Mauritius FIR into a CPDLC-capable FIR will be instructed to MONITOR the next unit by voice. CPDLC remains the primary means of communication.
- (d) Due to size limitations in the uplink message elements "CONTACT [unit name] [frequency]" and "MONITOR [unit name] [frequency]", only the primary HF frequency will be notified to the pilot. The secondary frequency will be available on request.
- (e) The CONTACT [unit name] [frequency] message and the END SERVICE message will be sent as separate messages. The END SERVICE message will be sent after receipt of the WILCO response to the CONTACT message.

5.3.6 Specific Procedures

- (a) Specific procedures in the Mauritius FIR are as follows:
 - For aircraft inbound to destinations within the Mauritius FIR, CPDLC and ADS connections will be maintained until the aircraft has landed. Pilots will be instructed when the transfer to VHF voice is required by use of the CPDLC uplink element: CONTACT MAURITIUS CENTRE [frequency].
 - ii. For aircraft departing from airports within the FIMM FIR, a CPDLC connection will be established manually by the Air Traffic controller when CPDLC is required.

6. APPLICATION OF ADS

- 6.1 To facilitate reliable ADS monitoring, pilots must ensure that ADS is left ARMED.
- 6.2 ADS Periodic and Event contracts will be established automatically on receipt of the LOGON.
- 6.3 Following an initial CPDLC position report on first contact, ADS reporting will fulfill normal position reporting requirements within the FIR. CPDLC or voice position reports will not be required while ADS is operational.
- 6.4 ADS contracts will be terminated automatically at a system parameter time after the aircraft has left the FIR.

7. DATA LINK FAILURE

7.1 Flight crew recognising a failure of a CPDLC connection must immediately establish communications on the appropriate voice frequency. When voice communications have been established, voice must continue to be used as the primary medium until a CPDLC connection has been re-established and the controller has authorised the return to data link.



Chapter: 9
Page: 107
Rev: 0
Date: 20 Oct 07

7.1 In the event of an unexpected CPDLC shutdown, the controller will advise all data link connected aircraft of the failure by voice. Instructions will continue to be issued by voice until the return of the data link system. The return of the system to an operational state will require a new AFN logon from affected aircraft.

8 NOTIFICATION OF EMERGENCY

- 8.1 Depending on the nature of the emergency condition experienced, flight crew should notify ATS of the circumstances by the most efficient means (voice or data link).
- 8.2 If a CPDLC MAYDAY or PAN message is received by the ground system, the controller will respond with the free text uplink message ROGER MAYDAY (PAN). The controller will not expect a ROGER response to the uplink until being notified that the emergency situation has been cancelled or stabilised to the extent that messages are able to continue being exchanged (if data link is considered to be the best communications medium for the situation).
- 8.3 If the emergency situation no longer exists, the pilot should cancel the ADS emergency mode.

9 HF SELCAL CHECK

9.1 For aircraft departing Mauritian airspace, a SELCAL check is not mandatory. However, flight crews wishing to satisfy themselves with HF performance should perform a SELCAL check after departure, but prior to being transferred to CPDLC. The primary HF frequency will be advised with the transfer instruction. The HF operator will confirm the primary and secondary HF frequencies on first contact.

Please refer to the below link for source of the document : http://www.crasa.cra-japan.org