LATERAL OFFSETS IN OCEANIC CONTROL AREAS (OCA)

Aircraft operating in OCA in the Australian FIRs are authorized to use lateral offsets in accordance with the requirements detailed below.

- 1. The offset shall only be applied by aircraft with automatic offset tracking capability.
- When an offset is applied, the offset must be established at a distance of 1 NM or 2 NM to the RIGHT of track relative to the direction of flight.
- 3. The offset must only be applied during the enroute phase of flight.
- 4. The offset must not be used in addition to diversions or other offsets; eg, weather or wake turbulence.
- 5. The offset must not be applied at levels where obstacle clearance would be affected.
- Identified aircraft:
 - a. may continue an offset; and
 - b. must advise ATC prior to initiating or changing an offset.

The decision to apply a lateral offset is the responsibility of the pilot-in-command. Other than when an identified aircraft initiates or changes a lateral offset, pilots are not required to notify ATC that a lateral offset is being applied.