Commercial ACS Maneuvers (Cessna 172S) 1/16/2025

CHAPS = Clear area; Heading&Alt. estab'd¬ed; Position near emergency landing field; Set power & config.

STEEP TURNS

CHAPS: (A) > 3000' AGL (S) 2100 RPM, Mix-Lean, 95kts Bank 50°, slight pitch up Add power to maintain speed

Rudder - keep ball in center Roll out on original heading Repeat, opposite direction Altitude +/- 100,

Speed +/- 10, Bank +/- 5°, Heading +/- 10 on rollout

SLOW FLIGHT

CHAPS: (A) > 3000' AGL (S) 1500 RPM, Mix-Rich, Carb Ht. Hold atl. while slowing and... ...adding flaps Add power below Vy

Slow to stall horn, then +5kts Power as needed to hold alt. Altitude +/-50, Heading +/-10,

Speed +5/0, Bank +/-5° **POWER OFF STALL**

CHAPS: (A) > 3000' AGL (S) 1500 RPM, Mix-Rich Slow to 65 Kts, holding alt... ...and adding full flaps

Descend power-off at 65 kts Pitch up slowly for full-stall Acknowledge stall horn

Continue pitch up for stall break Recover: (1) pitch down, full power, flaps 20°

(2) Climb Vy, retract flaps gradually Heading +/-10, Bank max 20° +/-5°

POWER ON STALL

CHAPS: (A) > 3000' AGL (S) 1500 RPM, Mix-Rich

Slow to Vx (62 kts), holding alt. Add >65% power Pitch up gradually for full-stall Acknowledge stall horn Continue pitch up until stall break Recover:

(1) pitch down, full power

(2) Climb Vy, retract flaps above 70kts At 180°: pitch and bank level Heading +/-10°, Bank max 20° +/-10°

ACCELERATED STALL

CHAPS: (A) > 3000' AGL on recovery (S) 2000 RPM, Mix-Lean, 85kts Turn w/ 45° bank Increase back pressure until stall horn Recover at stall horn! climb Vx or Vy to original altitude

8's on PYLON

Pick 2 "pylons", 1/2 mile apart Pylons should be perpendic. to wind CHAPS: (A) 900' AGL (S) 2200 RPM, Mix-Lean, 100Kts Enter 45° downwind, ~900' AGL Pivotal Alt.(670' at 87, 1100' at 113 kts) If pylon gets AHEAD of ref line, descend! If plyon gets BEHIND ref line, climb! Fly S&L 3-5 seconds between pylons Taxi without stop, 10° flaps Max bank 40°

Keep reference line on pylon

STEEP SPIRAL

Pick reference point (low and close) Determine wind direction Altitude - for 3 turns (4000') Power - Idle Speed - 70 kts +/- 10 Bank - steepest < 60° Bank - steepest downwind of point Speed +/-10, Bank max 60°, >1500'

CHANDELLE

CHAPS: (H) Pick reference on wingtip (S) 2100 RPM, Mix-rich, 95kts Bank 30°, Power - FULL Pitch - slowly increase to 15° After 90°, Hold pitch, reduce bank After 180°, speed just above stall

Hold altitude, accelerate to cruise Rollout +/-10°, Speed near stall

LAZY EIGHT

CHAPS: (H) Pick reference on wingtip Full power, Flaps 20° (S) 2100 RPM, Mix-rich, 95kts Gentle Pitch and Bank changes! At 45°: Max pitch up, 15° bank At 90°: Zero pitch, 30° bank At 135°: Max pitch down, 15°. bank Repeat other direction

Speed at 90°, about 60 kts After 180°, +-100 feet, +- 10 kts

SHORT FIELD TAKE OFF

Use full runway length, flaps 10° Hold brakes, add full power Check Gauges, release brakes Climb @ 56 to agreed obstacle ht. Accelerate to Vy, flaps UP Speed +5/-5

SHORT FIELD LANDING

ID touchdown target Approach 61 kts (+ gust factor) Aimimg point 100-200 feet short Touchdown at or beyond target Lower nose, brake, retract flaps Speed +5/-5

Land at or beyond, but within 100 ft.

SOFT FIELD TAKE OFF

Slowly add full power Keep tail low, balance on mains After liftoff, pitch down Accelerate Vx or Vy in gnd effect Climb at Vx or Vy, retract flaps Speed +5/-5

SOFT FIELD LANDING

Approach 65 kts(+ gust factor) Smooth roundout & flare Add power if necessary for soft ldg Hold nose high, minimal brakes Speed +5/-5

POWER-OFF 180 APPROACH

ID touchdown target Power - IDLE, downwind abeam Speed - best glide or as required Short final - 61 kts (+ gust factor) Aimimg point 100-200 feet short Touchdown at or beyond target Land at or beyond, but within 200 ft.

GO AROUND

Pitch up for Vy Offset to side of runway (if traffic) Retract Flaps > 60 kts Radio - report going around Speed Vy +5/-5