Commercial ACS Maneuvers (Cessna 172S)

STEEP TURNS

Altitude > 3000 AGL Pick heading reference Entry Speed - 2100 RPM, 95 kts Bank 50°, slight pitch up Add power to maintain speed Rudder - keep ball in center Roll out on original heading Repeat, opposite direction Altitude +/- 100, Speed +/- 10, Bank +/- 5°,

Heading +/- 10 on rollout **SLOW FLIGHT**

Altitude > 3000 AGL

Power - 1500 RPM, Carb Ht Hold Altitude, Add power < Vy Fly S&L 3-5 seconds between pylon

Slow to stall horn, then +5 knot Max bank 40° Power as needed to hold altitud Keep reference line on pylon

Altitude +/-50, Heading +/-10,

Speed +5/0, Bank +/-5°

POWER OFF STALL Altitude > 3000 AGL Power - 1500 RPM

Slow to 65 Kts, holding altitude Speed - 70 kts +/- 10 Descend power-off at 65 kts Pitch up slowly for full-stall

Acknowledge stall horn

Continue pitch up for stall break Recover: pitch down, full power Pick Reference on wingtip

...Flaps 20, then up, Climb Vy

POWER ON STALL

Altitude > 3000 AGL Power - 1500 RPM

Slow to Vx (63 kts), holding altiti Hold altitude, accelerate to cruise Aiming point 100-200 feet short

Add >65% power

Pitch up gradually for full-stall Acknowledge stall horn

Recover: pitch down

At 180°: pitch and bank level Repeat other direction

Speed at 90°, about 60 kts After 180°, +-100 feet, +- 10 kts

Prior to airwork: Clearing turns (2 x 90 degrees) ID emergency landing field ACCELERATED STALL

Altitude > 3000 AGL on recovery Use full runway length, flaps 10 Power/Speed: 2000 RPM, 85 KIAS Hold brakes, add full power Turn w/ 45° bank

Recover at stall horn! climb Vx or Vy to original altitude Speed +5/-5

8's on PYLON

Pick 2 "pylons", 1/2 mile apart Pylons should be perpendic. to win Approach 61 kts (+ gust factor) Enter 45° downwind, ~900'

If pylon gets AHEAD of ref line, desc Speed +5/-5 If plyon gets BEHIND ref line, climb! Land at or beyond, but within 100 ft.

STEEP SPIRAL

Determine wind direction Altitude - for 3 turns (4000') Power - Idle Bank - steepest < 60° Bank - steepest downwind of point Smooth roundout & flare

CHANDELLE

Entry Speed - 2100 RPM, 95 kts Heading +/-10, Bank max 20° +/-5° Bank 30°, Power - FULL Pitch - slowly increase to max After 180°, speed just above stall

Rollout +/-10°, Speed near stall LAZY EIGHT

Pick Reference on wingtip Continue pitch up until stall brea Entry Speed - 2100 RPM, 95 kts Gentle Pitch and Bank changes! Climb Vy full-power, carb heat off At 45°: Max pitch up, 15° bank Heading +/-10°, Bank max 20° +/-11 At 90°: Zero pitch, 30° bank

Offset to side of runway (if traffic) Retract Flaps > 60 kts

At 135°: Max pitch down, 15°. bank Radio - report going around

Speed Vy +5/-5

Pitch up for Vy

Full power, Flaps 20

SHORT FIELD TAKE OFF

Check Gauges, release brakes Increase back pressure until stall hc Climb @ 56 to agreed obstacle ht. Accelerate to Vy, flaps UP

SHORT FIELD LANDING

ID touchdown target Entry Speed - 2200 RPM, 100 kts Aimimg point 100-200 feet short Touchdown at or beyond target Pivotal Alt.(670' at 87, 1100' at 113 Lower nose, brake, retract flaps

SOFT FIELD TAKE OFF

taxi without stop, 10 flaps Slowly add full power Keep tail low, balance on mains Pick reference point (low and close) After liftoff, pitch down Accelerate Vx or Vy in gnd effect Climb at Vx or Vy, retract flaps Speed +5/-5

SOFT FIELD LANDING

Approach 65 kts(+ gust factor) Speed +/-10, Bank max 60°, >1500' Add power if necessary for soft ldg Hold nose high, minimal brakes Speed +5/-5

POWER-OFF 180 APPROACH

ID touchdown target Power - IDLE, downwind abeam After 90°, Hold pitch, reduce bank Speed - best glide or as required Short final - 61 kts (+ gust factor) Touchdown at or beyond target Land at or beyond, but within 200 ft. GO AROUND