Commercial ACS Maneuvers (Cessna 182T) 7/12/2023

SLOW FLIGHT

Altitude > 3000 AGI Cowl flaps open

Throt to 1800, then prop-full, then 18"

Hold alt. while slowing and adding full flaps Add power to maintain speed Add power on back side of curve Slow to stall horn, then +5 knot Power as needed to hold altitude

-- w/flaps: 2000rpm, 55kts -- no/flaps: 1900rpm, 63kts

Altitude +/-50, Heading +/-10, Speed +5/0, Bank +/-5°

POWER ON STALL

Altitude > 3000 AGL, Rich Mix, CFlps-Open

Entry: Slow Flight down to 55kts, 10° flaps Turn w/ 45° bank

Add power: 21" MP (67% power) Pitch up gradually for full-stall Acknowledge stall horn Continue pitch up until stall break

Recover: pitch down, full power

Climb Vy (80 KIAS)

Cowl Flaps Open

Heading +/-10°, Bank max 20° +/-10°

POWER OFF STALL

Altitude > 3000 AGL, Rich Mix, CFlps-Closed Enter 45° downwind, ~900'

Entry: Slow flight to 65kts

while holding altitude and adding full flaps

Descend power-off at 65 kts Pitch up slowly for full-stall Acknowledge stall horn Continue pitch up for stall break Recover: pitch down, full power... ...Flaps 20°, 55 KIAS, Cowl Open Retact flaps slowly after 70 KIAS

Heading +/-10, Bank max 20° +/-5°

STEEP TURNS

Altitude > 3000 AGL; Pick heading reference Entry: 100kts (18", 2200, mix lean)

Bank 50°, slight pitch up

Rudder - keep ball in center Roll out on heading (1/2 bank) Repeat, opposite direction

Altitude +/- 100, Speed +/- 10, Bank +/- 5°, Heading +/- 10 on rollout

ACCELERATED STALL

Altitude > 3000 AGL on recovery Prop-full, Mx Rich, NO flaps

Entry: 85kts (prop-full, throttle to 2300)

Increase back pressure until stall horn

Recover at stall horn!

Lower pitch, Level wings Full Power, Climb 80 KIAS

climb Vx or Vy to original altitude

8's on PYLON

Pick 2 "pylons", 1/2 mile apart

Pylons should be perpendic, to wind

Entry: 100kts (18", 2200)

Pivotal Alt.(670' at 87, 1100' at 113 kts) If pylon gets AHEAD of ref line, descend! If plyon gets BEHIND ref line, climb! Fly S&L 3-5 seconds between pylons Max bank 40°; Keep reference line on pylon

STEEP SPIRAL

Pick reference point (low and close) Determine wind direc.; close cowl flaps

Altitude - for 3 turns (>=4500')

Entry: 80kts (idle)

Bank - steepest < 60°

Bank - steepest downwind of point Speed +/-10, Bank max 60°, >1500' AGL

SHORT FIELD TAKE OFF

Use full runway length, flaps 20° Hold brakes, add full power Check Gauges, release brakes Climb @ 58 (12.5°) to agreed obstacle ht. Accelerate to Vy, flaps UP>70 Speed +5/-5

SOFT FIELD TAKE OFF

taxi without stop, 20° flaps Slowly add full power Keep tail low, balance on mains After liftoff, pitch down Accelerate Vx or Vy in gnd effect (70kts) Climb at Vx or Vy, retract flaps (80kts)

NORMAL LANDING

200 ft. touchdown zone

Speed +5/-5

GO AROUND

Full power, Flaps 20° Climb at 55 KIAS

Offset to side of runway (if traffic)

Open cowl flaps

Retract Flaps slowly > 70 KIAS Radio - report going around

Speed Vy +5/-5

SHORT FIELD LANDING

ID touchdown target Approach 60 kts (+ gust factor) Aiming point 100-200 feet short Touchdown at or beyond target Lower nose, brake, retract flaps Speed +5/-5

Land at or beyond, but within 100 ft.

SOFT FIELD LANDING

Approach 65 kts(+ gust factor) Smooth roundout & flare Add power if necessary for soft ldg Hold nose high, minimal brakes Speed +5/-5

POWER-OFF 180 APPROACH

ID touchdown target Power - IDLE, downwind abeam Speed - best glide 70 KIAS Short final - 60 kts (+ gust factor) Aimimg point 100-200 feet short Touchdown at or beyond target Brake heavily, Retract flaps Land at or beyond, but within 200 ft.

CHANDELLE

Pick Reference on wingtip, Mix Rich Cowl flaps open

Entry: Prop-full, 16" MP

Bank 30°, Power - FULL

Pitch - slowly increase to max (17.5°) After 90°, Hold pitch, reduce bank After 180°, speed just above stall Hold altitude, accelerate to cruise Rollout +/-10°, Speed near stall

LAZY EIGHT

Pick Reference on wingtip Cowl flaps - Closed Entry: 100kts (18", 2200)

Gentle Pitch and Bank changes! At 45°: Max pitch up (15°), 15° bank At 90°: Zero pitch, 30° bank

At 135°: Max pitch down (10°), 15° bank

At 180°: pitch and bank level Repeat other direction

Speed at 90°, about 60 kts After 180°, +-100 feet, +- 10 kts