


Print, cut and tape


Tuck-top mailer box — 220 × 160 × 60 mm internal — 6 sheets of US Letter landscape

- 1 Print every sheet at 100%. In the print dialog turn OFF "fit to page", "shrink oversized pages" and any scaling. Choose Actual size.
- 2 Check the 100 mm bar on any sheet against a ruler before cutting. If it is short, the print scaled: fix the setting and print again.
- 3 Cut each sheet along the long-dashed grey frame, on all four sides. The short blue dashes inside it are creases - do not cut those.
- 4 Lay the sheets out in the grid below and butt the cut edges together - do not overlap them. Tape on the back.
- 5 On the assembled sheet the magenta line is the knife line and the blue dashes are creases. Score the creases with a blunt point, then fold away from the score.



Assembled, the blank is 346 × 479 mm. Cartony is a drafting tool: check a folded proof against your product, and your converter, before ordering tooling.

A technical drawing of a lid, showing a rectangular shape with a pink outline and a blue dashed line indicating a fold or hinge. The word "Lid" is written in the center.



This bar must measure 100 mm (3.94 in). If it is shorter, the printer scaled the page: print again at 100% / Actual size.




479 mm

Side

Back

Base





Side





This bar must measure 100 mm (3.94 in). If it is shorter, the printer scaled the page: print again at 100% / Actual size.



Side

