

Smart Warehouse Platform

Operation manual

Version: 2026-10-03.1

Guidance for shipped workflows. This document grants no permission or equipment control authority. Check the current warehouse and deployment; all destination routes independently authorize. Links are deployment-relative paths, not external customer URLs.

Getting started and access

Sign in at your deployment's login page. Check the current warehouse and execution source before investigating work. Switching warehouse changes effective permissions and clears the previous workspace context.

A role label is not authorization. Viewing requires `operations.view`; history requires `audit.view`. Receipt/order creation, transport execution and alarm response require separate permissions. Hidden or disabled controls do not replace backend checks.

Expired or revoked sessions require sign-in again. Do not repeatedly submit a mutation after an uncertain response; inspect task and history evidence first. Production identity-provider integration and account administration are not complete product capabilities yet.

Open Operations Home: `/operations` (`operations.view`)

Daily work and task investigation

Start with attention items on Operations Home, then inspect the task queue and task detail. Read source/destination, recorded state, blocking reason and related alarms before technical identifiers.

Task assignment records intended work, not physical movement. Unknown outcomes are unresolved, never success. The current queue is bounded; use task search and all-history view when a record is not visible.

For shift operators, investigate work and freshness first; for exception responders, inspect alarms and affected tasks; for reviewers, follow permitted audit evidence. These are work paths, not hard-coded role grants.

Open task queue: `/operations/tasks` (`operations.view`)

Open alarms: `/operations/alarms` (`operations.view`)

Inbound and outbound

Inbound: choose configured source/destination and enter item quantity, then create a receipt. Inspect its transport task and recorded route. Execution requires transport.execute and explicit confirmation; creation alone does not prove stock was stored.

Outbound: create an order and inspect its allocation and transport work. Available stock excludes reserved quantities; insufficient stock is a failure, not a partial success claim. Confirm execution only after reviewing warehouse, quantity and destination.

Inventory changes follow accepted execution outcomes. A timeout, disconnected device or browser animation is not evidence of completion. Follow the task detail and permitted audit history when the outcome is unclear.

Open inbound: `/operations/inbound` (operations.view)

Open outbound: `/operations/outbound` (operations.view)

Inventory, loads and locations

Inventory shows recorded stock and reservations. Loads show original received quantity separately from optional current stock. Missing inventory means not recorded, not zero; shipped historical stock has zero current balance.

Location status is configured, not a physical occupancy or safe-to-command guarantee. Recorded load/stock counts are rows, not mixed-SKU quantities or capacity. A readable location code is not a topology node ID; correlation requires an explicit active-version binding.

Use literal search and load-more within the current warehouse. Related stock/load links are substring searches, not exact occupancy filters. Configuration editing and stock adjustments are not available in these read-only workspaces.

Open inventory: `/operations/inventory` (operations.view)

Open loads: `/operations/loads` (operations.view)

Open locations: `/operations/locations` (operations.view)

Live View and trustworthy observations

Current position requires active equipment, connected/good/current telemetry and the matching active topology version and node. Evidence expires after the server's received-observation window. The browser can only downgrade evidence, never establish current state.

Last-known means usable historical evidence, not ongoing movement. Unknown position means there is no usable qualified position. Reported work and assigned work are separate; unresolved task context does not prove equipment is idle.

Live View is read-only and is not a calibrated physical floorplan or command authority. The topology inspector is an engineering diagram. Physical calibration, layout administration and commissioned hardware controls remain later capabilities.

Open Live View: `/operations/warehouse` (operations.view)

Open topology inspector: `/operations/warehouse/topology` (operations.view)

Alarms and unknown outcomes

Inspect the affected task and last trustworthy observation. Acknowledgement records awareness; it does not clear the underlying fault. Recovery requires its own permission, a strategy, a resolution note and explicit confirmation.

Resume or release only when the backend allows that recovery. Unknown command outcomes require reconciliation; do not infer success or repeatedly issue a new command. Safety interlocks and emergency stop remain independently authoritative equipment/site responsibilities.

No general-purpose manual override, automatic reset/replay or reconciliation editor is shipped yet. Preserve evidence and escalate unresolved divergence through your site's operating procedure; repository tests are not safety certification.

Open alarm response: `/operations/alarms` (operations.view)

Inspect affected work: `/operations/tasks` (operations.view)

Accountable history

With audit.view, inspect actor, action, resource and correlation evidence. Workflow links carry supported resource context; use history pagination to investigate older evidence. Sensitive fields are redacted and unknown actions remain explicitly unknown.

Audit history is not a full physical replay or proof that an unobserved movement occurred. Retention policy and reset preservation are governed separately; this screen cannot erase evidence or configure retention.

Open audit history: `/operations/audit` (audit.view)

Troubleshooting and terminology

No results: check warehouse, search and bounded coverage before concluding no work exists. Unavailable or stale: retain last-known evidence, refresh and inspect connectivity; do not act on a frozen current label. Access denied: check effective warehouse permissions with your authorized administrator.

Receipt: inbound business record. Order: outbound intent. Load: tracked carrier/content record. Inventory: persisted stock truth. Transport task: execution work. Topology: versioned connectivity. Observation: qualified equipment report, not inventory or authorization truth.

FAQ - Can I reset or replay here? Not yet. Can I edit warehouse/equipment configuration? Not yet. Does simulation prove production hardware safety? No; commissioned integration requires site-specific safety/security approval and failure drills.

Open read diagnostics: `/operations/projections (operations.view)`