

**Document C**

Health & Safety Management Plan

Version 1.1 · August 2026

Next review: August 2027

— HOW WE RUN THE SYSTEM

HEALTH & SAFETY MANAGEMENT PLAN

This plan explains how Portobello Plumbing Co meets its duties under the Health and Safety at Work Act 2015. It is written for a small, owner-operated plumbing business working mainly in occupied homes, including tenanted properties managed by principals such as Barfoot & Thompson Property Management.

Draft for review. Licence and insurance details below are taken from current records. First aid is recorded as a planned action until a workplace certificate is held. It is not legal advice.

1. ABOUT THE BUSINESS

Item	Detail
Trading name	Portobello Plumbing Co
Legal entity / NZBN	Portobello Plumbing Company Limited · NZBN 9429053083524
Director / Officer	Jonathan David Ian Elton
Base	15A Sainsbury Rd, Mt Albert, Auckland
Typical work	General plumbing, blocked drains (plumbing work only), hot water (non-gas), bathrooms, kitchens, ladder-access roofing and spouting, water treatment, pre-purchase inspections. Central and West Auckland.
Typical workplaces	Occupied residential properties, light commercial sites, roofs, underfloor spaces, bathrooms and kitchens under renovation, public berms and driveways when accessing services.
PGDB registration / licence	19395 – registered plumber. No drainlaying or gasfitting licence.
Insurance (period)	SMARTpak package via Arthur J. Gallagher, 1 July 2026 – 1 July 2027. Policy PRO9203V-0 · cover 2286268-000. Insurers: Monument Insurance (NZ) as underwriting agent for IAG New Zealand Ltd, AIG Insurance NZ Ltd, Vero Insurance NZ Ltd.
Public / products liability	\$5,000,000 public liability any one occurrence · \$5,000,000 products liability in the aggregate · New Zealand only.
Statutory liability	\$1,000,000 any one claim and in the aggregate.
Motor legal liability	\$10,000,000 (2018 Fiat Ducato LPA76, third party only on the vehicle itself).

Material damage	Plant \$10,000 · stock \$2,000 at 15A Sainsbury Road, plus anywhere-in-NZ plant/stock endorsement to \$25,000 any one event.
Hours	Monday–Friday 8:30am–5:00pm, plus agreed after-hours work
People on the tools	Primarily the Director only. Occasional subcontract tradespeople may be engaged. An apprentice may be taken on later. This plan already covers those people when they work under our direction.

2. SCOPE OF THIS PLAN

This plan covers all Portobello work, plant and vehicles. It sits under the Company Health & Safety Policy and is used with the Harm Register / Risk Management Procedure. Where a principal contractor or building site has its own plan, we follow the stricter of the two requirements and coordinate before starting.

Out of scope (stop and refer):

- gasfitting, gas appliance installation or servicing;
- licensed drainlaying (we hold plumbing licence 19395 only);
- roof work that WorkSafe guidance would require a harness, scaffold or roof platform to do safely – we work from a ladder only;
- trenches larger than about 600 mm × 600 mm, and any excavation that could collapse, trap a person or meet the definition of a confined space;
- tanks, manholes and other true confined spaces;
- disturbing suspected asbestos.

3. ROLES AND RESPONSIBILITIES

Director (Officer and typically the person on the tools)

- Set and resource the health and safety system.
- Maintain licences, insurance, plant and training records.
- Complete or review site risk checks for higher-risk work.
- Stop work that cannot be done safely.
- Notify WorkSafe of notifiable events and preserve the scene when required.
- Review incidents, the Harm Register and this plan.

Workers, subcontractors and apprentices (when engaged)

- Work only within competence and licence conditions.
- Complete induction on this plan before starting a live job.
- Follow this plan, site rules, hot-work permits and agreed controls.
- Use plant and PPE as intended and report defects.
- Report hazards, incidents and near misses the same day.
- An apprentice works only under the supervision required by the PGDB.

Customers / occupiers / other PCBUs

- Provide safe, reasonable access and disclose known hazards (asbestos, services, previous repairs, animals, occupants).
- Keep children, visitors and animals clear of the work area.

- Consult, cooperate and coordinate activities that could affect each other.

4. RISK MANAGEMENT

Risk management follows Document D. In short:

1. Identify hazards for the trade (Harm Register) and for the specific site.
2. Assess likelihood and consequence.
3. Apply the hierarchy of controls – eliminate first, then minimise.
4. Do not start high-risk tasks until controls are in place.
5. Review after incidents, near misses, new plant or a change of method.

A dynamic site check is completed at arrival: access, occupants, pets, weather, services, working at height, asbestos indicators, isolation needs and emergency exits. If conditions change, we reassess.

5. TRAINING, COMPETENCE AND INDUCTION

Licensed plumbing work is only done by a person holding the correct PGDB registration (licence 19395), or by a trainee under the supervision required by the Plumbers, Gasfitters and Drainlayers Act. We do not carry out gasfitting or licensed drainlaying.

Minimum competence we maintain or require:

- Current PGDB practising licence 19395 for plumbing work.
- Driver licence appropriate to the vehicle.
- Workplace first aid – **planned action:** the Director does not currently hold a first-aid certificate. A workplace first aid course will be completed (target: by 30 November 2026). Until then a stocked first-aid kit is carried in the vehicle, a fire extinguisher is carried in the vehicle, and serious harm is managed by calling 111.
- Working at height: ladder work only, following current WorkSafe guidance. If a harness or scaffold would be required, the job is out of remit.
- Asbestos awareness: historical UK training, not a current New Zealand course. We still treat pre-2000 materials as suspect and do not disturb them. A New Zealand asbestos-awareness refresh is a planned action.
- Site-specific induction on controlled building sites or a principal's induction (including property-manager site rules) as required.

Before a subcontractor or apprentice starts a live job they are inducted on this plan, the Harm Register, emergency contacts (including Rosie), incident reporting, PPE, hot-work rules and the right to stop work. We keep a short signed induction record.

6. PLANT, TOOLS, VEHICLES AND EQUIPMENT

- Vehicles are roadworthy, loaded so that tools cannot become projectiles, and not driven while fatigued or under the influence of drugs or alcohol.
- Ladders, electrical tools, hired digging equipment, drain machines and pressure equipment are checked before use. Damaged gear is tagged out. Hired plant is used within the hire conditions and the operator's competence.

- Electrical tools used on site are in-test where a residual current device and inspection regime is required by the site or by the nature of the work.
- Hot water cylinders, baths and other heavy items are moved with a planned lift, trolley or two-person method — not a rushed one-person strain.
- Plant is used only for its intended purpose and within manufacturer limits.

7. HAZARDOUS SUBSTANCES

Substances we carry are limited: turpentine, acetone, and butane cartridges for a soldering / brazing torch. We do not carry LPG cylinders, acid drain openers or other bulk chemicals. We will:

- keep a simple inventory and current safety data sheets;
- store products upright, labelled and away from occupants and ignition sources;
- use the smallest practical quantity and the least-hazardous product that will do the job;
- wear the PPE specified on the SDS; and
- not mix incompatible chemicals (especially acids and oxidisers, or products that release toxic gas).

8. PERSONAL PROTECTIVE EQUIPMENT

PPE is the last line of defence, not the first. Standard site kit includes sturdy footwear, eye protection, gloves suited to the task, hearing protection for noisy plant, and a hi-vis garment when working near traffic or on a construction site. Extra PPE is used for the task: P2 or higher respiratory protection for silica/dust or sewage aerosols, chemical-resistant gloves and eye protection when using solvents, cut-resistant gloves for sheet metal and roofing, and sun protection for roof work. PPE is maintained, replaced when worn, and not a substitute for isolation or a safer method.

9. HIGH-RISK WORK WE COMMONLY FACE

Working at height

Ladder access only, following WorkSafe working-at-height guidance. Three points of contact. No roof work in high wind, rain or on fragile cladding. If the job needs a harness, scaffold or roof platform, it is out of remit — we stop and refer.

Asbestos

Assume asbestos may be present in Auckland homes built or renovated before 2000 (pipes, gaskets, vinyl, soffits, textured coatings). Do not drill, cut or disturb suspect material. Stop and arrange a competent survey or licensed removal if needed.

Services and excavation

Small pipe trenches only, about 600 mm × 600 mm maximum. Ask the occupier / property manager about known services, review available plans, locate where practicable, and hand-excavate near marked services. Hired equipment is used only within that size limit.

Biological hazards

Wastewater, blocked drains and underfloor work. Gloves, eye protection, hygiene, cover cuts, and keep occupants clear. Vaccination status (e.g. tetanus) is encouraged.

Electricity and water

Isolate power where work could contact electrical fittings or create a shock path. Do not work on live electrical equipment. Engage a licensed electrician when required.

Lone work and occupied homes

Tell Rosie the job location and expected finish (020 407 89812). Reassess if a tenant or occupier is aggressive, impaired or the site feels unsafe. Keep children and pets out of the work area.

10. HOT WORK

We occasionally solder, braze or grind. That is hot work: a flame, spark or hot surface that can start a fire, especially in occupied or tenanted homes.

- Prefer a cold method where it will do the job.
- Clear combustibles, protect surfaces, and ventilate.
- Have the van fire extinguisher at the work point, not left in the street.
- Keep occupants and pets out of the immediate area.
- Store butane cartridges upright, away from heat, and never in a hot vehicle cabin for long periods.
- Complete the Portobello Hot Work Permit (Appendix A) before starting, and keep it with the job record. If a principal (including a property manager) has their own permit, we use theirs as well or instead if it is stricter.
- Stay on site for a short fire-watch after the last flame or grind, then sign the permit closed.

11. EMERGENCY PREPAREDNESS

Situation	Immediate action
Serious injury / medical emergency	Call 111. First aid. Do not move the person unless they are in immediate danger. Notify the Director.
Fire	Evacuate, call 111, do not re-enter. Use the van fire extinguisher only if the fire is small and the exit is clear. Isolate electricity only if safe to do so.
Gas leak on site (we do not do gasfitting)	Do not attempt gasfitting repairs. Evacuate, eliminate ignition sources, ventilate if safe, call 111 / the gas emergency number. Do not operate electrical switches in the affected area. Refer remaining work to a licensed gasfitter.
Service strike (power, gas, fibre)	Stop work, keep people back, call the relevant emergency / network number, treat as live until confirmed otherwise.
Flooding / uncontrolled water	Isolate supply at the nearest safe valve. Keep electrical hazards in mind. Protect occupants and property if safe.
Needle stick / sewage exposure	Encourage bleeding of puncture wounds, wash, seek medical advice the same day.

Emergency contacts: 111 · Director / Jonathan Elton 027 549 9090 · next of kin / check-in: Rosie 020 407 89812 · WorkSafe 0800 030 040 (notifiable events). First-aid kit and fire extinguisher: carried in the van and taken to the work area for hot work.

12. INCIDENT, NEAR MISS AND NOTIFIABLE EVENTS

All injuries, near misses, property damage and dangerous occurrences are recorded the same day. The Director reviews the record, identifies causes and updates the Harm Register if needed.

A **notifiable event** (death, notifiable injury or illness, or notifiable incident as defined in HSWA) is reported to WorkSafe as soon as possible by the fastest means, then in writing within 48 hours where required. The scene is preserved until authorised, except to help the injured, make the area safe or prevent further harm.

Injured workers are supported to get treatment and a safe return to work. We do not victimise anyone for reporting a concern or refusing unsafe work.

13. WORKER ENGAGEMENT

Day to day this is a one-person business, so engagement is direct. When a subcontractor or apprentice is on a job we brief the work, the site risks and the stop-work rule, and we review any incident with the people involved. If the business grows past the small-PCBU threshold for formal representation, we will put worker participation practices in place as required by HSWA.

14. CONTRACTORS, APPRENTICES, VISITORS AND OVERLAPPING DUTIES

Before engaging a subcontractor we check competence, licences and insurance appropriate to the task, share this plan and relevant Harm Register entries, and complete the induction record. An apprentice, if engaged, is supervised to PGDB requirements and is not left to do licensed work alone. On a principal-controlled site – including work for a property manager such as Barfoot & Thompson – we follow their access, tenant-notification and permit rules as well as this plan, whichever is stricter. We coordinate with electricians, builders, roofers and other trades so one trade's work does not put another at risk.

15. HEALTH MONITORING AND WELLBEING

We watch for hearing, respiratory, skin and musculoskeletal issues linked to the work. Fatigue, heat on roofs, and the mental load of lone work and difficult sites are treated as health risks. Anyone impaired by alcohol, drugs or extreme fatigue does not work.

A vehicle first-aid kit is carried on every job. Completing a workplace first aid course (NZQA unit standards or equivalent) is a planned action for the Director by 30 November 2026.

16. RECORDS WE KEEP

- This plan, the Policy and the Harm Register (current version).
- Licences, training and induction records (including subcontractors and any apprentice).
- Plant / vehicle checks and residual-current / test tags where used.
- Hazardous substance inventory and SDS for turpentine, acetone and butane.
- Site risk checks for higher-risk jobs and completed hot-work permits.
- Incident and near-miss reports, investigations and corrective actions.
- WorkSafe notifications (if any).

Records are kept for at least the period required by law, and longer if they support an insurance or liability matter.

17. REVIEW

The Director reviews this plan at least annually, and after a notifiable event, a repeated near miss, a change in the type of work, or a change in legislation that affects us. Version control is by date on the cover block. Previous versions are archived, not overwritten without a record.

18. APPROVAL

Director / Officer

Jonathan David Ian Elton

Signature · Date

Reviewed with workers

Name · Signature · Date

APPENDIX A – HOT WORK PERMIT

Complete before soldering, brazing or grinding. One permit per job / work area. Keep with the job record. If the principal has a stricter permit, use that as well.

Portobello Plumbing Co – Hot Work Permit

Date

Permit no.

Site address

Principal / property manager (if any)

Work: solder / braze / grind (circle)

Location on site

Checks before starting (tick)

☐ Combustibles moved or protected · ☐ Occupants / tenants told · ☐ Pets clear

☐ Fire extinguisher at the work point · ☐ Ventilation adequate · ☐ Butane torch in good order

☐ No suspected asbestos in the work area · ☐ Services identified · ☐ Exit path clear

☐ Water isolated if needed · ☐ Floor / wall protection in place

Start time

Authorised by (print / sign)

Expected finish

Person doing the work

Close-out

☐ Fire-watch completed after last flame / grind · ☐ Area left cold and tidy · ☐ Occupant advised

Finish time

Closed by (sign)