

# Grill Recovery Cleaning


|                            |                                  |
|----------------------------|----------------------------------|
| Detail Clean               |                                  |
| Frequency                  | Quarterly or monthly if required |
| Models                     | All                              |
| Estimated Time to Complete | 45 minutes                       |

|                                                                                                                                                                                                                                                                                                                                                                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Health &amp; Safety Hazards</b> <div>  Slippery Floors            Hot Surfaces            Chemicals         </div> | <b>Food Safety</b> <div>  Critical Control Point.            Wash &amp; dry hands <b>after</b> performing task            Ensure nuts, bolts &amp; screws are tight            Inspect equipment - do not use if damaged         </div> |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|


### Equipment




SIZZLE® PLUS Heat Activated Grill & Toaster Cleaner




No-Scratch Pad & Compact Pad Holder



Ecolab® Hi-Temp Double-Sided Brush




Scraper



Warm Water




Visor



Grill Scraper



GTW Bucket



Long Gauntlets



Squeegee




Grill Cloth






Ensure grill has been programmed for Grill Recovery.

## Recovery Clean




1




Turn grill to "RECOVERY" (141°C). Leave filters in place. Grill will take approximately 15 minutes to cool.

2




Clean grill surfaces in the usual manner.

3




Pull on visor and gauntlets, then open packet of Hi-Temp Grill Cleaner.




Empty grease troughs into the black GTW bucket and then into the blue barrel. Replace the grease troughs.

5



Pour a small amount of SIZZLE PLUS onto a grill cloth and clean exposed surfaces of release sheets.

6



Remove release sheet clips, rods and splash shields and take to back sink for 4-step cleaning.

7




Remove upper release sheets and place on nearby flat surface while grill platen cleaning is completed.




When at the correct temperature the display states 'Recovery'

9




Using a damp cloth and a container of warm water, wipe upper platen including edges.

10




Using the plastic scraper remove as much loose carbon as possible from the upper platens.

11




Pour SIZZLE PLUS onto the grill tool and apply to all platen sides.




For hard to reach areas apply SIZZLE PLUS to a grill cloth and wipe area.

13




Ensure Sizzle Plus has been applied to all platen edges

14




Pour remaining SIZZLE PLUS directly onto the lower platen.

15



Using the grill tool spread SIZZLE PLUS across the grill.




Lower all platens and allow cook time to complete. This will take 17 minutes.

17

**WARNING  
DO NOT USE!  
CLEANING  
IN PROGRESS**


Place 'Cleaning in Progress' sign over grill bar to ensure program is not cancelled.

18




When platens raise use the double sided brush to scrub grill, upper platens including rear and edges, until carbon liquefies. Lower platens as needed.

19




Pull grill out for better access when cleaning rear of platens.




Repeat for all platens. Reapply Sizzle Plus from the lower grill as needed throughout the clean.

21




Use the scraper or grill tool where needed to remove remaining carbon.

22




Scrub the lower grill surface using the grill tool.

23




Squeegee all Sizzle Plus into grease trough.



Using a damp cloth and a container of warm water, rinse upper platen including edges.

25



Squeegee away any excess water and wipe the platens with a damp grill cloth for a final time.

26




Reinstall release sheets, clips and splash shields.

27




Wipe all surfaces with a clean, sanitised grill cloth. Discard cloth in dirty cloth bucket once completed.




Empty grease troughs into back room sink (NOT black bucket) and spray out.

29



Turn grill OFF at interlock/main power switch. (24hrs - Leave for at least 10 seconds before turning back on)

30



All grill tools (grill scraper, squeegee, spatula, tongs, tool holder) must be cleaned using 4-Step Cleaning Method.

31



Sweep and mop area, including under the grill. Pull grill weekly. Refer to Pulling Grills card.