

Refrigeration: Grillside/Wall Mounted/Refrigeration Units

Check Condition/Brush Clean Condenser Fins

Frequency	Monthly
Models	Grillside/Wall Mounted/Refrigeration Units
Estimated Time to Complete	15 - 30 Minutes per unit

Health & Safety Hazards

-  Slippery Floors / Tripping
-  Sharp Objects / Surfaces
-  Chemicals

Food Safety

-  Critical Control Point
-  Inspect equipment. Do not use if damaged
-  Wash and dry hands **after** performing this task

Equipment

1



2



3



4



5



6



1 KAY Heavy-Duty Degreaser Solution


2 Blue Round Brush


3 Bucket Warm Water

4 Blue Border Cloths


5 Cleaning Gloves

6 Fin Comb



NB


(Where applicable). Turn OFF the refrigeration unit at the main switch located on the front of the unit.

1


Isolate the refrigerator unit before starting.

2


Wearing cleaning gloves, locate the condenser fins on the unit and remove the cover. **NB** Some units will require condenser fin covers to be unscrewed.

3

Check for any damaged/misshapen fins, using the fin comb, straighten the fins.

4

Use a dry Blue Round Brush in an upward motion to remove any debris caught between the condenser fins until clean.
NB Brush the debris/dust outwards not into the condensor fins.


5

(Where applicable) Wipe away any dust build-up around the condenser coils using a Blue Border Cloth.


6

If further cleaning is required, due to heavy dust/debris build-up, follow steps 7-10.

Caution: When using degreaser solution avoid spraying near electrics.

7



Apply Kay Heavy-Duty Degreaser by spraying onto the condenser fins.

8


Leave unit for 5 mins, allowing degreaser solution to work.

9


Dampen the Blue Round Brush in the bucket of warm water.
Brush the condenser fins in an upward motion until any remaining debris has been removed.
NB Brush the debris/dust outwards not into the condensor fins.

**10**


Lightly wipe over the condenser fins and surrounding area, using a Blue Border Cloth to remove any excess moisture.

11

Replace the cover to the condenser fins.

12

Reconnect the power supply to the refrigeration unit.
(Where applicable). Turn ON the refrigeration unit at the main switch.

13

NB For Grill Side Freezer/Chillers, slide out the Drip Pan on the underside of the unit. Take to the backroom sinks, to rinse/clean and replace again.