

Fryers: All Models

Perform Maintenance Check

Frequency

Weekly

Models

All Models

Estimated Time to Complete

15 Minutes per Unit

Health & Safety Hazards



Hot Surfaces



Hot Oil

Food Safety



Wash and dry hands **after** performing this task



Ensure nuts, bolts & screws are tight



Inspect equipment. Do not use if damaged

Check for the Following

- 1 Electrical plug is in good condition, no loose screws and loose/damaged wires
- 2 Power cable has no kinks/nicks/splits or other damage
- 3 Power cable entry to appliance is secure and wires not damaged (behind fryer)
- 4 Timer membranes are not damaged or severely worn
- 5 Doors are present and hinges intact
- 6 Self-filtering cart has all casters present, in good condition and free to roll
- 7 Crumb catcher, bottom filter and filter paper holder are present and complete
- 8 Side and back panels are secure with all screws present and tightened (external surfaces)
- 9 Basket catchers are present and secure
- 10 Fry baskets have no loose wires/damaged wires
- 11 Vat covers present and handles secure
- 12 (Where applicable) side grease cans and drip tray present, in position and secure

NB For restaurants without self-filtering vats exclude steps 6 & 7

