

Hobart AMXXL Dishwasher

Card No. AMXXL

Frequency

Models

HOBART

Estimated Time to Complete

Food Safety



Wash and dry hands after performing this task

Ensure nuts, bolts & screws are tight inspect equipment. do not use if damaged

Health and Safety Hazards



Slippery floors / tripping



Chemicals




1



Check there are chemicals in the containers.

2



Switch on the machine by pressing the big green button. Use the hood-lift button to open and close the hood.

3



The machine will begin to fill, the screen will indicate how far along the filling is. Once the main button is fully green the machine is ready for use.

4



If the screen indicates that the softener needs re-filling the button will turn red and a notice will show on the display.

5



Open the hood and identify the salt cap. Open the cap, and using a funnel top up the salt using granular salt.

6



Once the machine is ready for use the main button will be fully green.

7



Load the machine using the correct racks for the items being washed (examples above).

8



Use the 'clock' icon to select through the cycles until you find your desired cycle.

9



Use the hood-lift button to lower the hood, then the wash cycle will automatically begin.

10



Once the cycle is complete the hood will automatically lift, you can then unload your items.