structure box asm BTM 5-6 body 60

body-0502 | QTY 1 IN BTM RUN | INCHES | TOP / FRONT / BOTTOM SCALE 1:5

01 / TOP - FACE A



02 / FRONT - EDGE VIEW

03 / BOTTOM - FACE B



F01 - X DIMENSIONS APPLY TO MATCHING COLUMNS

04 / SECTION A-A

X = 2" FROM END A

SECTION SCALE 1:4

05 / ISOMETRIC



ISOMETRIC REFERENCE / NTS

FEATURE / DATUM NOTES

HOLES / SLOTS LOCATED ON FACE B

X: FROM END A / Y: FROM EDGE C

Dimensions are to feature centers.

Shared columns use one X chain.

Equal row spacing is counted once.

TAB CENTRES / END A

FIRST: 4-3/32"

Irregular spacing follows source profile.

SOLIDWORKS HOLE WIZARD SPECS

Exact part / active configuration matched to STEP.

Locations and quantities remain model-derived.

DATUM / REVIEW

END A is the left material extent in both face views.

EDGE C is marked on the bottom face view.

Fractions to 1/32; exact feature sizes/pitches as needed.