

Properties of Materials

Theme: Introduction

Lecture 0: The Intro

Dr James Kratz


james.kratz@bristol.ac.uk

Room 0.65 Queen's Building

© Copyright University of Bristol

1

Materials



Future of Engineering Design is Materials

© Copyright University of Bristol

2

Materials

Process

Structure

Properties

Performance

Impact of processing on properties will become even more critical as Additive Manufacturing replaces Removal Manufacturing.




Image: Dragonfly, DESIGN OF MECHANICAL PARTS FOR ADDITIVE MANUFACTURING

© Copyright University of Bristol

3

What do we mean by properties?



Heat flow

Thermal conductivity

$$q = -k \nabla u$$

Light Bulb
Electrical resistivity


$$P = I^2 R = I^2 \frac{\rho l}{A}$$



© Copyright University of Bristol

4

What do we mean by properties?



© Copyright University of Bristol

5

Properties

Secondary interest

Primary interest of
this course

Lots to
choose from

Table 1.1 Classes of Property

| Class | Property |
|--------------------------------|---|
| Economic and environmental | Price and availability Recyclability Sustainability Carbon footprint |
| General physical Mechanical | Density Modulus Yield and tensile strength Hardness Fracture toughness Fatigue strength Creep strength Damping |
| Thermal | Thermal conductivity Specific heat Thermal expansion coefficient |
| Electrical and magnetic | Resistivity Dielectric constant Magnetic permeability |
| Environmental interaction | Oxidation Corrosion |
| Production | Wear Ease of manufacture Joining |
| Aesthetic | Finishing Color Texture Feel |

© Copyright University of Bristol

6

Themes

- Theme 1: **Observed Properties**
 - Empirically observed
 - Definitions
 - How we measure them
- Theme 2: **Material Selection**
 - Rational material selection
 - Ashby method
 - Material indices
- Theme 3: **Structure**
 - Atoms and bonding
 - Crystals and crystallography
- Theme 4: **Polymers and composites**
 - Structure
 - Viscoelasticity
 - Composites, foams and novel materials

© Copyright University of Bristol

7

Assessment 2017-18

- Why are we starting Materials in Week 9?
 1. Me
 2. Course evaluation 2016-17
- Materials component of STM1
 - 7% Materials Selection Group Assignment (T2)
 - You will need your Lab data for this (T1)
 - 3% Online Materials Test (T1)
 - 2 Exam Questions (T3-4)

Due
Wednesday
January 31st
at 14:00

© Copyright University of Bristol

8

Reference Textbooks

M.F. Ashby, H. Shercliff, and D. Cebon.
Materials: Engineering, Science, Processing and Design.
Butterworth-Heinemann.

Supplementary reading:

W.D. Callister. Materials Science and Engineering: An Introduction. Wiley.
F.C. Campbell. Manufacturing Technology for Aerospace Structural Materials. Elsevier.

© Copyright University of Bristol

9

Properties of Materials

Theme: Observed Properties

Lecture 1: Elastic Behaviour

Dr James Kratz

james.kratz@bristol.ac.uk

Room 0.65 Queen's Building

© Copyright University of Bristol

10

Intended Learning Objectives


Describe simple material properties in terms of desirable engineering characteristics

- Lecture 1:
 - Engineering stress/strain and mechanical testing
 - Elastic properties (modulus)
- Lecture 2:
 - True stress/strain
 - Plastic properties (yield, resilience, and strength)
- Lecture 3
 - Ductility and Resilience
- Lecture 4:
 - Toughness
- Lecture 5:
 - Hardness and wear resistance

© Copyright University of Bristol

11

Engineering Stress and Strain



Eng. Stress:

$$\sigma = \frac{F}{A_0}$$

Eng. Strain:

$$\varepsilon = \frac{L - L_0}{L_0} = \frac{\Delta}{L_0}$$


- Tensile forces
 - Cause elongation
 - Reduction in area
- Compressive forces
 - Cause contraction
 - Increase in area
- Stress/strain
 - Normalise against dimensions

© Copyright University of Bristol

12

Shear Stress and Strain

- Shear causes change in shape but no change in area/volume



Shear Stress:

$$\tau = \frac{\text{Force, } F \text{ or Torque, } T}{\text{Area, } A_0}$$

Shear Strain:


$$\gamma = \tan(\theta)$$

© Copyright University of Bristol

13

Tensile Testing

- Aim
 - To provide a standard method for obtaining key mechanical properties
- Stretch sample
 - Measure load
 - Measure deformation




© Copyright University of Bristol

14

Tensile Test of a Carbon Fibre Composite

Please write
a comment,
make a test
request!...

Subscribe



<https://www.youtube.com/watch?v=aH9vcV7jzG0>

© Copyright University of Bristol

15

Tensile Test of a Metal




<https://www.youtube.com/watch?v=5QaqwmZ7Sic>

© Copyright University of Bristol

16

Tensile Behaviour of Metals



© Copyright University of Bristol

17

Building Block Approach


- Use of stress and strain eases comparison between tests and real structures




Good data at the coupon level provides a solid foundation for in-flight deflection estimates.

© Copyright University of Bristol

18



Modulus of Elasticity



- In the elastic regime
 - Strain is entirely recovered
 - Strain proportional to stress
- Young's modulus
Stress $\rightarrow \sigma = E\epsilon$ Strain
Shear stress $\rightarrow \tau = G\gamma$ Shear strain
Shear modulus
- Only true for linear elastic materials

© Copyright University of Bristol


19

Poisson's Ratio, ν

- The amount a material shrinks inwards as a tensile load is applied

$$\nu = -\frac{\text{transverse strain}}{\text{axial strain}} = -\frac{\epsilon_x}{\epsilon_z}$$

| Material | ν |
|--------------------|-------|
| Steel | 0.30 |
| Aluminum | 0.33 |
| Carbon fibre/epoxy | 0.25 |
| Rubber | 0.48 |
| Cork | 0 |



Relates Elastic and Shear Modulus:


$$E = 2G(1 + \nu)$$

© Copyright University of Bristol

20

Example: Elastic Deformation

A tensile stress is applied to a brass rod that has a 10 mm diameter. In groups of 2-3, determine the load required to produce a 2.5×10^{-3} mm reduction in diameter if the deformation is purely elastic.



| Metal | Young's Modulus | Shear Modulus | Poisson's Ratio |
|-------|-----------------|---------------|-----------------|
| Brass | 97 GPa | 37 GPa | 0.34 |

© Copyright University of Bristol

21

Compression tests




- Compression tests squash cylinders of material
 - Common for brittle materials (not used in tension)
 - Strength can be different in compression
 - No necking so max strain can be higher than for tension

© Copyright University of Bristol

22


Flexural Testing

- Useful for brittle materials
- Compressive stress above the mid-plane
- Tensile stress below the mid-plane
- Failure occurs in the half with lower strength
 - Results are difficult to interpret



23

Modulus of Engineering Materials



24

Summary

- Stiffness
 - Resistance to **elastic** deformation
 - Stiff materials have high E (Young's Modulus)

© Copyright University of Bristol

25

Properties of Materials

Theme: Observed Properties

Lecture 2: Plastic Behaviour

Dr James Kratz

james.kratz@bristol.ac.uk


Room 0.65 Queen's Building

© Copyright University of Bristol

26

Previously

- Elastic deformation of materials
- Materials with a higher Young's Modulus (E) deform less when subject to the same stress




© Copyright University of Bristol

27

Yield Strength

- Definitions
 - First movement of dislocations
 - Proportional limit
 - Elastic limit
 - 0.2% offset
- Needs TEM – not practical
- Values are a function of the quality of your kit
- Standard Method**
Stress to achieve arbitrary quantity of plastic deformation




© Copyright University of Bristol

28

Example: Yield Strength Calculation

Diameter = 6 mm, Length = 100 mm


In groups of 2-3, calculate the 0.2% yield stress (sometimes called proof stress)



© Copyright University of Bristol

29

Engineering v. True Stress/Strain





© Copyright University of Bristol

30

True Stress, σ_T

- True stress is given by the actual area not the initial area



- If no volume change occurs

$$A_i L_i = A_o L_o$$


$$\sigma_T = \sigma(1 + \varepsilon)$$

© Copyright University of Bristol

31

True Strain, ε_T

- Consider two tensile tests both resulting in a sample 20% longer



© Copyright University of Bristol

32

True Strain, ε_T

- When deformations are large we need an alternative measure

$$\varepsilon_T = \frac{L_1 - L_0}{L_0} + \frac{L_2 - L_1}{L_1} \dots \frac{L_n - L_{(n-1)}}{L_{(n-1)}}$$

$$\varepsilon_T = \int \frac{dL}{L} = \ln(L) - \ln(L_0) = \ln\left(\frac{L}{L_0}\right)$$

A tensile test is essentially lots of little increments of strain which must be integrated!
(Taylor Series)

- Define true strain in terms of engineering strain:

$$\varepsilon_T = \ln\left(\frac{\Delta L + L_0}{L_0}\right) = \ln(1 + \varepsilon)$$

This works if deformation is uniform i.e. before a neck starts (after neck you must measure the length)

© Copyright University of Bristol

33


Corrected True Stress-Strain

- Accounts for the complex stress state in neck
- Valid until necking, M'

$$\sigma_T = \sigma(1 + \varepsilon)$$

$$\varepsilon_T = \ln(1 + \varepsilon)$$



- Non-axial stress state
- Corrected stress:
 - Actual load
 - Cross-sectional area
 - Gauge length measurements



© Copyright University of Bristol

34

Plastic Behaviour



© Copyright University of Bristol

- The stress in the neck follows the true stress-strain curve
- Drop in engineering stress is due to reduction in area
- Calculate area before necking
- Measure area after necking (video)

35

Example: True Stress-Strain


A cylindrical specimen of steel having an original diameter of 12.8 mm is tested in uniaxial tension to fracture. An engineering tensile fracture strength of 460 MPa and cross-sectional diameter of 10.7 mm is reported at fracture. In groups of 2-3, determine:

- a) the true stress at fracture
- b) the true strain at fracture

© Copyright University of Bristol

36

Tensile Strength




© Copyright University of Bristol

37

Strength


Maximum stress reported on the Engineering stress/strain curve. Not normally used in metallic design because of the magnitude of plastic deformation. Can be used for some ceramics/ composites.



© Copyright University of Bristol

38

Strength of Engineering Materials



39

Summary

- Yield
 - Transition from Elastic to Plastic deformation
- Strength
 - Maximum stress sustained by a material

© Copyright University of Bristol

40

Materials 1: Properties of Materials


- Over the last 2 lectures, what new concept have you learned?
- As we end this lecture are there any aspects of elastic or plastic behaviour that are confusing to you?

41



© Copyright University of Bristol

43



© Copyright University of Bristol

44

Properties of Materials

Theme: Observed Properties

Lecture 3: Ductility and Resilience

Dr James Kratz

james.kratz@bristol.ac.uk



Room 0.65 Queen's Building

© Copyright University of Bristol

45

Previously

- Elastic and plastic deformation of materials
- Materials with a higher Young's Modulus (E) deform less when subject to the same stress




© Copyright University of Bristol

46

Ductility

Measure of the degree of plastic deformation that has been sustained at fracture.



- Two measures:

$$\%EL = \left(\frac{L - L_0}{L_0} \right) \times 100$$

$$\%RA = \left(\frac{A_0 - A}{A_0} \right) \times 100$$

- Two measures give slightly different results


In design: structure deformation before fracture

© Copyright University of Bristol

47

Ductility

- Arbitrary distinction into brittle vs ductile
 - Approx. 5% strain
- Ductile
 - Failure denoted by yield
- Brittle
 - Failure denoted by fracture



© Copyright University of Bristol

48

Example of In-service Ductility

- China Airlines 006
- February 1985
- Aircraft dropped 3140m in 33s
- Right wing down
- Vertical loading 5.1g
- Wings permanently deformed 50-75mm at wingtips



© Copyright University of Bristol

49

Resilience


- Capacity to store elastic energy
 - Loaded → Energy stored through deformation
 - Unloaded → Energy recovered



<https://www.youtube.com/watch?v=00I2uXDxbaE>

50

Modulus of Resilience, U_r



$$U_r = \frac{1}{2} \sigma_y \varepsilon_y = \frac{1}{2} \sigma_y \left(\frac{\sigma_y}{E} \right) = \frac{\sigma_y^2}{2E}$$

What material makes the best bumpers for low speed collisions?


| Material | σ_y (MPa) | E (GPa) | u (MPa / MJm^{-3}) |
|-----------|------------------|---------|-------------------------|
| Steel | 310 | 200 | 0.24 |
| Aluminium | 240 | 70 | 0.41 |
| Rubber | 20 | 0.05 | 4.0 |

© Copyright University of Bristol

51

Resilience in Automotive Impact

- Plastic collapse of metal is more important for safety
- Toughness/ductility




© Copyright University of Bristol


52

Impact Test

Charpy V-notch impact test



Sample: Square bar with notch






Energy absorbed is a measure of the difference in height of the hammer

© Copyright University of Bristol

53

Impact Test: Ductile Material







© Copyright University of Bristol

Dull surface

54


Impact Test: Brittle Material




© Copyright University of Bristol

55

Ductile to Brittle Transition Temperature



Testing needs to be performed at relevant service temperatures



Schenectady split in half while still at the dock!

The impact energy and the % shear fracture drop suddenly over a narrow temperature range

© Copyright University of Bristol

56

Summary

- Ductility
 - Highly desirable
 - Often only an issue for safety
- Resilience
 - Ability to absorb elastic energy

© Copyright University of Bristol

57

Properties of Materials

Theme: Observed Properties

Lecture 4: Toughness

Dr James Kratz

james.kratz@bristol.ac.uk


Room 0.65 Queen's Building

© Copyright University of Bristol

58

Previously

- Modulus: Deformation from an applied stress
- Strength: Plastic deformation
- Ductility: Strain at fracture




Today: Toughness

- Presence of flaws/cracks
- Measured performance lower than theoretical atomic bonding energy

59

Failure



Structural engineering is the art of modelling materials we do not wholly understand, into shapes we cannot precisely analyse so as to withstand forces we cannot properly assess, in such a way that the public has no reason to suspect the extent of our ignorance.

© Copyright University of Bristol

(Dykes, 1978)

60

Toughness

- Multiple meanings

- Capacity to absorb energy and plastically deform before fracture
- Fracture Toughness: resistance to crack growth
- Ability to tolerate impacts



Hail impact damage


Boeing 787 composite wingbox fracture test

© Copyright University of Bristol

61

Fracture Toughness

Clear plastic specimen with polarised light




- Tensile toughness
 - Easy to test but calculations difficult
- Fracture mechanics
 - Complex but good predictions
- Mathematical description of cracks
 - Characteristic strain pattern at cracks

© Copyright University of Bristol

62

Tensile Toughness


- Work required to cause failure
 - Area under stress strain curve up to fracture



63

Stress Concentrations


- Applied stress amplified at the crack tip



64

Brittle and Ductile Materials

- Is the material going to yield or fracture?



Brittle materials have high strength but this is limited by small cracks that always exist in all materials

Critical stress for crack growth in brittle materials:

$$\sigma_c = \left(\frac{2E\gamma_s}{\pi a} \right)^{1/2}$$

E = Young's modulus

γ_s = specific surface energy

a = half the length of internal crack


Ductile materials can tolerate these cracks so no effect on strength (yield first)

© Copyright University of Bristol

65

Fracture Toughness, K_c

- Measure of a material's resistance to brittle fracture when a crack is present



Infinite width plate with
central crack

$Y = 1.0$

Semi-infinite plate with
edge crack

$Y \sim 1.1$

$$K_c = Y \sigma_c \sqrt{\pi a}$$

Y = dimensionless parameter

Depends on:

- Crack length
- Specimen size
- Load application


Complex mathematical expressions for Y have been proposed for a variety of specimen geometries

© Copyright University of Bristol

66

Plain Strain Fracture Toughness, K_{Ic}

- If specimen thickness is much greater than crack dimensions, K_c becomes independent of thickness
- K_{Ic} , highest value of stress intensity that a material can withstand without fracture under plane-strain conditions



67

Example

A structural steel tie is to be welded into place and then tested for internal defects using ultrasonic detection. Due to access restrictions and limits with on-site testing, it is felt that the minimum reliably detectable crack length (a) is 2mm. What is the maximum stress that can be applied to the joint if there must be a safety factor with respect to stress of 1.5? What if the safety factor applies to the crack length instead? Assume $K_{Ic} = 77\text{MPa}\sqrt{\text{m}}$ and $Y=1$.

Smallest crack to design for


Extra margin of safety beyond estimated safe limit

© Copyright University of Bristol


68

Fracture Toughness Testing

- Three modes of crack surface displacement




- Common test specimen configurations in mode I



Compact Tension (CT)

© Copyright University of Bristol




Single Edge Notch Bending (SENB)

69


Critical Strain Energy Release Rate, G_c

- Energy absorbed in making a new crack surface




© Copyright University of Bristol

70



71



72

Summary

- Toughness
 - Measure of work done to cause failure
 - Usually describes propensity for fracture
 - Brittle materials have low toughness
- $G_c = \text{toughness}$ (sometimes: *critical strain energy release rate*); units kJ/m^2
- $K_{lc} = (EG_c)^{1/2} = \text{fracture toughness}$ (sometimes: *critical stress intensity factor*); units $\text{MN m}^{-3/2}$
- $K = \sigma(\pi a)^{1/2} = \text{stress intensity factor}$; units $\text{MN m}^{-3/2}$
- Cracks grow when $K = K_{lc}$

© Copyright University of Bristol

73

Properties of Materials

Theme: Observed Properties

Lecture 5: Hardness and Wear

Dr James Kratz

james.kratz@bristol.ac.uk

Room 0.65 Queen's Building

© Copyright University of Bristol

74

Wear

- Gradual accumulation of damage upon sliding contact of *two* surfaces



Tail-strike damage to a Singapore airlines B747



© Copyright University of Bristol

- Associated with friction and absence of lubrication
- Enormous impact on economics and productivity
 - Some estimates 5% lost GDP from wear and corrosion
- Tribology (science of surfaces) is *really* complex!
 - Chemistry, mechanics, physics

75

Wear Rate



$$W = \frac{\text{Volume of material removed}}{\text{Distance slid}}$$



Graph for self wear (pin material = ring material)
without lubrication

Other combinations
have different rates (see
friction)

76



Hardness

Hard pyramid shaped indenter

F

Plastic flow of material away from indenter

d_1

d_2

Projected area A

View of remaining "indent", looking directly at the surface of the material after removal of the indenter

20 μm

539 HV1

Good spatial resolution

© Copyright University of Bristol

79

Hardness

$HV = 1.854 \frac{P[\text{kg}]}{d^2[\text{mm}^2]}$

Present without units

Shape of Indentation

Standard gravity (9.807)

$$HV = 1.854 \frac{Pg}{1 \times 10^{-6}d^2} \times 1 \times 10^{-6} = 18.19 \frac{P}{d^2} [\text{MPa}]$$

kgf \rightarrow N

Pg

$\text{mm}^2 \rightarrow \text{m}^2$

$\text{Pa} \rightarrow \text{MPa}$

| Test | Indenter | Side View | Top View | Load | Formula for Hardness Number ^a |
|-----------------------------------|--|-----------|----------|------|--|
| Brinell | 10-mm sphere of steel or tungsten carbide | | | | $\text{HB} = \frac{2P}{\pi D(D - \sqrt{D^2 - d^2})}$ |
| Vickers microhardness | Diamond pyramid | | | | $\text{HV} = 1.854P/d_1^2$ |
| Knoop microhardness | Diamond pyramid | | | | $\text{HK} = 14.2P/l^2$ |
| Rockwell and superficial Rockwell | {Diamond cone; $\frac{1}{16}, \frac{1}{8}, \frac{1}{4}, \frac{1}{2}, 1$ -in. diameter steel spheres} | | | | $\begin{cases} 60 \text{ kg} \\ 100 \text{ kg} \\ 150 \text{ kg} \end{cases}$ Rockwell $\begin{cases} 15 \text{ kg} \\ 30 \text{ kg} \\ 45 \text{ kg} \end{cases}$ Superficial Rockwell |

Note load in obsolete kgf (use kg mass)

^aFor the hardness formulas given, P (the applied load) is in kg, whereas D , d , d_1 , and l are all in mm.

© Copyright University of Bristol

80

Hardness and Wear

Properties acting on similar length scales

$$P = \frac{F_n}{A_n}$$

$$P_{max} = CH$$

$$\Omega = k_a P = C \left(\frac{P}{P_{max}} \right) k_a H$$


Specific wear rate Wear rate constant Ratio of current pressure to max pressure

© Copyright University of Bristol

81

Hardness and Wear

Harder materials have a smaller wear rate



© Copyright University of Bristol

82

Summary

- Hardness
 - Resistance to local deformation
 - Cheap, non-destructive, easy
 - Physically challenging to interpret
- Wear resistance
 - Very difficult property to understand and quantify in industrially relevant manner
 - Typically assumed to correlate to hardness

© Copyright University of Bristol

83

© Copyright University of Bristol

84

Materials 1: Properties of Materials

- What are 1 or 2 things that supported your learning in these lectures?
- Please offer 1 or 2 suggestions that could have been done differently to support your learning.

85