

In aerobatics, Pugachev's Cobra is a dramatic and demanding manoeuvre in which an airplane flying at a moderate speed suddenly raises the nose momentarily to the vertical position and slightly beyond, before dropping it back to normal flight.

The manoeuvre is named after the Soviet test pilot Viktor Pugachev, who first performed the manoeuvre publicly in 1989 at the Paris Le Bourget air show

## Outline for today

- Symmetric manoeuvres
- Load factor
- Flight envelope
  - Manoeuvre envelope
  - Gust envelope
  - Combined envelope

### Aims for today

- Be able to recognize different types of symmetric manoeuvres
- Be able to define load factor
- Be able to define boundaries of manoeuvre flight envelope
- Be able to define manoeuvre point and corner speed
- Appreciate effects of gusts on an aircraft's flight envelope

Symmetric manoeuvres

Load factor

Flight envelope

Manoeuvre envelope

Gust envelope

Combined envelope

#### Symmetrical Manoeuvre

- motion is curvilinear
  - therefore must be a resultant force perpendicular to the flight path in order to give a normal acceleration
  - steady curved path with radius R

$$F = ma = \frac{W}{g} \frac{V^2}{R}$$

- only concerned here with symmetrical manoeuvres
  - variation in **lift** only
  - vertical manoeuvres loop, pull-up, push-over, outside loop
  - horizontal manoeuvres banked turn

Centripetal acceleration



Arrow loop from takeoff Thunderbirds 2:38 end <a href="http://www.youtube.com/watch?v=9mroDp-30Qg">http://www.youtube.com/watch?v=9mroDp-30Qg</a>



Outside loop <a href="http://www.youtube.com/watch?v=Ugm3mLnVTH4">http://www.youtube.com/watch?v=Ugm3mLnVTH4</a>

Magnús Norðdahl a former captain at Icelandair flying DC-3, DC-4 and DC-8 still enjoys flying, here making a low level outside loop in his CAP 10. He is 78 year old.

#### Load factor


- lift force variation can be large
  - typical 1:5 speed range translates into 1:25 variation in  $\frac{1}{2}\rho V^2$
  - limited by structural strength of airframe
  - limits specified in terms of **load factor** n
  - straight & level flight  $\equiv n = 1$

$$n = \frac{L}{W}$$

Centripetal acceleration


# Normal Acceleration in a Loop Consider a case with: lift = $2W \rightarrow$ constant load factor n=2

 loading in normal direction between components of the aircraft (eg pilot and his seat) remains constant



# Load factor regulations


| Aircraft Type     | <b>Max Positive</b> | <b>Max Negative</b> |
|-------------------|---------------------|---------------------|
| Normal            | 3.80                | 1.52                |
| Utility           | 4.40                | 1.76                |
| Acrobatic         | 6.00                | 3.00                |
| Commuter<br>Large | 3.80                | 1.52                |
| Transport         | 2.50                | 1.00                |



Things to add:
1 g line
Manoeuvre point?
Cruise velocity?
Dive velocity?
Stall velocity in cruise

#### Manoeuvre Envelope Limits

- maximum positive manoeuvring load factor n<sub>1</sub>
- maximum negative manoeuvring load factor n<sub>2</sub>
- manoeuvring load factor  $n_2$  Design Manoeuvring
  Speed  $V_A$  speed for safe application
  - speed for safe application of maximum control deflection
- Design Cruising Speed  $V_{C}$
- Design Diving Speed  $V_{D}$
- Stall speed (flaps up)  $V_{\it SI}$



#### Manoeuvre Point


• On stall boundary:

$$L = nW = 0.5 \rho V^2 SC_{L\text{max}}$$

$$n = \frac{\rho V^2 S C_{L \max}}{2W}$$


- When C<sub>L</sub> and n both maximum then corresponds to minimum turn radius and maximum turn rate, termed the manoeuvre point.
- Corresponds to the corner velocity,  $V^*$

$$V^* = \sqrt{\frac{2n_{\text{max}}W}{\rho SC_{L_{\text{max}}}}}$$



#### **Gust Flight Envelope**

- loads due to gusts (atmospheric turbulence)
  - ${\bf vertical\ gust\ velocities}$  ,  $V_{g}$  defined in Joint Airworthiness Requirements (JARs)
  - corresponding load factors depend on wing lift curve slope  $a_{\rm 1}$  and wing loading W/S and altitude




#### **Gust Velocities**

- 66 ft/s at gust penetration speed  $V_B$
- 50 ft/s at Cruising Speed  $V_C$
- 25 ft/s at Design Diving Speed  $V_D$
- constant up to 20,000ft reduce linearly up to 50,000ft
- gust velocity lines are linear and pass through +1
  - aircraft flying at velocity  $\emph{V}$  meets vertical gust of  $\emph{v}$
  - wing incidence increased by v/V (since v is small)

$$\Delta C_L = a_1 \frac{v}{V} \quad \Longrightarrow \quad \Delta L = \frac{1}{2} \rho V^2 S \ a_1 \frac{v}{V} = \frac{1}{2} \rho V S \ a_1 v$$

load factor will increase from +1 to n

$$\frac{\Delta L}{W} = n - 1 = \frac{\rho VS \ a_1 v}{2W} \quad \square \rangle \qquad n = \frac{\rho a_1 v}{2W/S} V + 1$$



### Example



- 1. Draw the manoeuvre flight envelope for an **acrobatic** aircraft with the following parameters:
  - mass = 2,300 kg
  - wing area,  $S = 19.3 \text{ m}^2$
  - $C_{Lmax} = 2.0$
  - $-ve C_{Lmax} = -1.2$
  - Design diving speed,  $V_D$ =250 m/s
  - Lift curve slope,  $a_1$  = 6.3/rad
- 2. Calculate the total load factor if the aircraft hits a gust of 4 m/s at the design diving speed at sea level

Answers: 1) See example V-n plot 2) 4.3

The Frecce Tricolori (Italian, literally Tricolour Arrows), The team flies the Aermacchi MB-339-A/PAN, a two-seat fighter-trainer craft capable of 898 km/h at sea level (250 m/s)


Use load factor limits for aerobatic aircraft, max positive load factor 6, max negative load factor -3

Calculate the total load factor if the aircraft hits a gust of 4 m/s at the design diving speed at sea level

$$n = \frac{\rho a_1 v}{2W/S} V + 1$$

$$= \frac{1.225 \times 6.3 \times 4}{2 \times 2300 \times 9.8/19.3} \times 250 + 1$$

$$= 4.3$$



Be able to recognize different types of symmetric manoeuvres

Be able to define load factor

Be able to define boundaries of manoeuvre flight envelope

Appreciate effects of gusts on an aircrafts flight envelope

## Follow-up materials

#### To help with exam:

• Introduction to Flight – 6.17

To help with exam: Introduction to Flight – 5.1-5.2

To aid in understanding: Understanding flight – Chapter 1

For interest:

Introduction to Flight – 5.19 (explanation of lift)