


Considering the box-spar as the main structural element

Model the thin-wall "semi-moncoque" structure as an end-load carrying boom idealisation based on effective areas. Assume the remaining skin carries only shear when buckled.



Assuming panels will buckle before reaching ultimate, we will claim only the skin areas stabilised by connection to the corner angle flanges when estimating the effective end load carrying boom areas.

This is a reasonable conservative simplification for the DBT box-spar initial sizing.

bilt



Assuming the effective boom area acts on the outer skin-line, we need to reduce the spar web and angle blade area contributions to avoid overestimating their 2nd mmt of area contributions to the box. For our DBT box-spar a reduction of the stabilised web and angle blade areas by one third should be reasonable.

*** Note sketches show curved skins but

for the latest embedded box-spar design

the skins can be flat!

3 Il Jam 2016

SCHEMES:

Configuration:


Channel section spars + support angles + skins

Box-spar chord $b_c = 75 \text{mm}^*$

Section height, b_{aft} , b_{fwd} according to chosen h/c% and aerofoil coordinates for a wing chord of 450mm^*

All angles and flanges = $15mm^*$





bc

Skin, spar and angle thicknesses t = 0.4, 0.5, 0.6, 0.7, 0.9, 1.0mm

Rib pitch, LR

Web stiffener pitch, aw

Thicker gauges required on upper surface for stability in compression.

Note, for efficiency you should reduce thicknesses outboard along the span

Team Comms groups should investigate different trial schemes.

The Root end of the box-spar skins must allow for fixture attachment - further details tba.

*Compulsory dims

6 Il Jan 2016

Stiffness, Strength + Stability. CHECKS:

5.

Initially check the most critical inboard stations, e.g. near the root. Then check further stations outboard, e.g. where loading and section depth is reduced.

Stiffness:

check deflection of wing tip at limit using an incremental beam model

Strength:

check lower surface boom / skin tension/shear material failure at ultimate


Stability:

check upper boom compression column buckling at ultimate check upper skin compression panel buckling at at limit and ultimate check rear spar web panel in-plane bending + shear buckling at limit and ultimate check upper spar cap "blade" panel compression buckling at ultimate

Joints:

check spar-skin, skin-skin, web-web and root fixture joint fastener/plate bearing, shear and tension failure modes at ultimate @ Il Van 2016

E.g.:



6.

For item # @ station x

Design for: 0, 7 < 0, 7 * at LIMUTULT ->

Applied Allowable

RF = ##

Note, we will:

- Neglect non-unifrom stress distributions due to shear lag
- Neglect local stress distributions at details (apart from lower surface inspection holes).
- Correct elastic buckling estimates for plastic buckling
- Neglect local/global buckling interaction

TRIAL SCHEME CHECK RESULTS

Working in your Comms groups check a trial scheme by performing the calculations given in the "calc illustration" document. Compare results between Comms group members and with other Comms groups within your team then create a spreadsheet to automate your checks, including further critical stations along the wing and refining your methods. Check your results against your original hand calcs and team mates' calcs to identify any errors before relying on your automated xls results! "Check stress!"

Finally:

TRADE-OFF checked schemes - according to fitness for purpose.

i.e.: consider RF's, weight, manufacturing ease, cost for each trial scheme and of course the aero performance for the flight phases!

... then commit to a chosen scheme for your team and order materials!

A list of calcs in the illustration doc. is given below



@ Station x ...

8.

- 1. SCHEME
- 2. PART MODEL
- 3 SECTION MODEL
- a. Boom area properties
 - b. Box section area properties
- 4. STRESS
 - a. Direct stress due to bending
 - b. Shear stress due to transverse load
 - c. Shear stress due to torsion
 - d. Transverse + torsional shear stress by superposition
- 5. CHECK: STIFFNESS

Tip deflection at limit

- 6. CHECK: STRENGTH at ultimate
 - a.(i) Tension/shear material failure in lower aft boom (at ult)
 - a.(ii) Tension stress concentration material failure in lower skin (at ult)
- 7. CHECK: STABILITY at limit or ultimate
 - a. Compression column buckling in upper boom (at ult)
 - b. (i) Compression <u>panel</u> buckling in <u>upper skin</u> (at lim)
 - b.(ii) In-plane bending/shear panel buckling in rear spar web (at lim)
 - b.(iii) Compression panel "blade" buckling in upper aft spar flange (at ult)

