




# Combustion

Lecture 12



Objective: to describe the workings of a Combustion System







# **Combustion Key Issues**

- Average temperature rise up to 1000 K;
- Peak gas temperatures 1000K above melting point of walls;
- Energy release at rate of 150 MW enough to:
  - Boil 75000 kettles or
  - Or produce 100,000 Lb of thrust
- Walls glow cheery red
- Must ignite at:
  - - 8 °C, 0.4 bar for altitude relight
  - - 40 °C, air & fuel for cold start on ground





# COMBUSTION CHARACTERISTICS Desirable Characteristics

- ➤ Complete Combustion for Low emissions & Low smoke
- ➤ Low total pressure loss
- Stability of Combustion Process
- > Even temperature distribution with no hot spots
- ➤ Short length and small cross section
- > Freedom from flameout
- > Relight ability
- ➤ Operation over a wide range of conditions e.g. mass flow rates, pressures and temperatures

### **Chemistry of Combustion:**


 $C_{12}H_{24} + 18O_2 + 67.7N_2 \rightarrow 12CO_2 + 12H_2O + 67.7N_2 + heat$  where  $C_{12}H_{24}$  is kerosene.








# How does the combustor do it?








### LIMITS OF COMBUSTION KEROSENE











Temp: **800K**Temp Rise:
Velocity m/s ~150

2500K 1700K

30

2100K 1300K 1800K 1000K


AENG31102 Lectur € 52

Choked in NGV





# **Types of Combustion System**









## **Combustion Chamber Pressure Loss**


### Caused by:

- Rise in temperature due to Combustion
- Skin friction & Turbulence

**Pressure Loss Factor (PLF)** 

Fundamental Loss Cold Loss

 $(P_{oA} - P_{oB}) / \frac{1}{2} \rho C_A^2$ 




Suffix A refers to Air at inlet to combustion chamber
Suffix B refers to products of combustion at exit from the combustion chamber
AENG31102 Lecture 12


8





### **Combustion Efficiency**












## **Combustion Stability**








# DEPARTMENT OF

# Feeding the turbine: 'Temperature traverse'




- Right temperature distribution vital for life!
  - Overall temperature distribution factor for NGV's
  - Radial temperature distribution factor for rotors
- Use dilution air and rear cooling films to trim traverse








### **Annular Combustion Chamber**








### **Annular Combustion Chamber**








## **Ways of Cooling the Flame Tube**







### Reheat or Afterburner Systems



### Requirements:


Cool air to keep hot gases off the jet pipe

• Fuel injectors protected from hot gases

• Different fuel flow rates depending on gas temperature

• Sufficient length for stable operation

Variable Area Nozzle









## **Environmental Issues**

### What is the problem?


- Civil aviation contributes about 2% of global CO<sub>2</sub>.....
- .....about the same as the UK but traffic increasing!!
- Climate science is still in its infancy much still to be learned

"The absolute emissions by air traffic are small...compared to surface emissions. However, the greenhouse effect of emitted water and of nitrogen oxides at cruise altitude is potentially large compared to that of the same emissions near the earth's surface..."





### Fuel $C_nH_m$ (+S)







# NO<sub>x</sub> emissions from aircraft are small, so what is the concern?


- In the boundary layer (<1km)
  - NO<sub>x</sub> products are removed by wet and dry deposition to the surface (acid deposition)
- In the upper troposphere (8-12km)
  - NO<sub>x</sub> has a longer life-time as these removal processes are not significant
  - − O<sub>3</sub> production is more efficient
  - aircraft are cruising in the most sensitive part of the atmosphere to radiative forcing by  $O_3$








## The effect of Altitude on Emissions










20

# **Emissions Legislation**

- Smoke limit to eliminate visible trails
- UHC, CO and NOx limited around LTO cycle:




- Legislation is being tightened progressively
  - Limits mass of pollutant permitted over LTO cycle
- Driven by local air quality no cruise limits at AENG31102 Lecture 12 present (LTO: landing and take-off)





## Variation of emissions with power




CO<sub>2</sub> A function of Fuel Burn

NOx Oxides of Nitrogen CO Carbon Monoxide

HC Unburnt Hydrocar Singlific Singlific Carbon particles












# The variation of NO<sub>x</sub> with time








# Combustion technology development

### Single Annular Conventional




3rd Generation Rich Burn Rapid Quench Phase 5

- Trent and BR families
- ·Limited scope for further NOx reduction
- ·Limit 60-70% of CAEP2

#### Double annular

(Technology explored)



### Single Annular LDI

In service with GE90


AENG31102 Lecture 12

•50% CAEP2 NOx
•Can be developed further





# Single annular fuel staged LDI concept



- Nozzle includes pilot spray
- Pilot and main zones within single annular combustor
- No premixing duct
  - No flashback issue

Lean direct
injection nozzle
– large flow
area




Conventional rich burn fuel nozzle





# Combustor for a land based system



Emissions regulations for land based systems are more stringent than for aero engines and with no requirements for low weight or volume there is more scope premixing and staging.

**RB211 Dry Low Emissions combustor for industrial & marine applications** <sup>26</sup>





# **Ingredients for low NOx**

- Control temperature levels & have good mixing
- Fuel staging keep flame temperatures high at part power
- Minimise cooling flow to give more for NOx control
- Prevent instabilities
- Must be safe reliable and affordable
- Radical ideas being studied:
  - New architecture
  - More sophisticated controls
  - Must be capable of dealing with rapid manoeuvres (transients)







# Issues of policy

- Issue: sustainable development
  - balancing growth and environmental concerns
- Traffic growth currently about 5% pa
  - ~ doubling in 17 years
  - Fastest growth of all transport modes
  - "One of nature's biggest forces is exponential growth"

(Albert Einstein)

- LHR 3<sup>rd</sup> runway consultation
  - additional traffic will produce £5bn to UK economy



#### University of Bristol Department of Aerospace Engineering



## **Key Lessons from Lecture 12**

- Chemical reactions forming  $NO_X$  are much slower than for  $CO_2 \& H_2O$  and  $NO_X$  formation increases rapidly with temperature. Long time needed to reduce CO & UHC favours formation of  $NO_X$ .
- NO<sub>X</sub> & smoke are problems @ high thrust settings i.e. high Combustion Temperatures; CO & UHC worst at Taxi & Idle.
- CO & UHC require Combustion process to be prolonged @ high Temperature with ample O<sub>2</sub> to ensure all CO converted to CO<sub>2</sub>.
- $NO_X$  formation depends on both Temperature & Residence Time at that temperature. Standard approach is to reduce residence time (to keep  $NO_X$  low) keeping in mind other pollutants & efficiency. Hot gases are then quenched to drop temperatures below that at which  $NO_X$  formation is significant.
- Staged Combustion has different injectors & different regions for different phases of flight pilot for idle/taxi and main for high thrust.
- Land based systems use premixing, fuel vaporised & mixed prior to entering Combustion Chamber avoids stoichiometric burning but difficult to incorporate into an Aero Engine.





#### Lecture 13

# **Turbines**

# Objective: to describe the workings of the Turbine