BULL BAR PART# B35-6001 / 35-6001 2006-10 RIDGELINE

PART LIST:

TAKE LIGIT.			
1	GRILLE GUARD	1	
2	HE X BOLT	4	M12*30
3	FLAT WASHER	8	ф 12
4	S PR I N G W AS H ER	4	ф 12
5	HEX NUT	4	M 1 2
6	MOUNTING BRACKET	2	

STEP1.PLEASE PROTECT YOUR PRODUCT FROM BEING SCRATCHED DURING THE
PROCESS OF INSTALLING THE GRILLE GUARD).
STEP 2. FIRST, TAKE OFF THE HEX BOLT ON THE VEHICLE.
STEP 3. BE ATTENTION TO DISTINGUISH LEFT AND RIGHT MOUNTS, THEN
INSTALATE THEM (DONOT SCREW THE BOLTS TIGHTLY), AFTER THAT COMES
TO THE GRILLE GUARD. PUT IT IN PLACE. IN THE END, SCREW ALL THE BOLTS TIGHTLY.

