

G001 Visual System Reference Manual

Visual Database Architecture

The G001 visual system employs a hierarchical tile-based database architecture optimized for real-time rendering at 60Hz minimum frame rates across all operational scenarios. The visual database is structured in multiple resolution layers, with Level of Detail (LOD) transitions managed through proprietary distance-based algorithms that maintain visual continuity during dynamic viewpoint changes.

Database Layer Structure:

- **Layer 0 (Ultra-High Resolution):** 0-3 nautical miles from aircraft position, 0.5-meter texture resolution
- **Layer 1 (High Resolution):** 3-15 nautical miles, 2-meter texture resolution
- **Layer 2 (Medium Resolution):** 15-50 nautical miles, 8-meter texture resolution
- **Layer 3 (Low Resolution):** Beyond 50 nautical miles, 32-meter texture resolution

The database utilizes a 1km x 1km tile grid system with dynamic loading/unloading based on aircraft position and velocity vector prediction. Each tile contains terrain elevation data, cultural features, vegetation models, and texture mapping information stored in compressed proprietary .VDB format. Runway surfaces employ sub-centimeter accuracy elevation modeling to ensure proper nose gear steering dynamics and visual touchdown point correlation.

Airport environments feature enhanced detail zones extending 5 nautical miles from airport reference points, incorporating accurate taxiway geometry, lighting positions, and ground service equipment. All ILS-equipped runways include precision approach lighting systems (PALS) with individual lamp modeling for realistic approach guidance.

Database Verification Procedure:

1. Access Database Management Console via IG Control Station
2. Select "Database Integrity Check" from System menu
3. Verify CRC checksums match reference values in DBVER.LOG
4. Review tile loading performance metrics—should maintain <16ms load time per tile
5. Confirm LOD transition boundaries occur at specified distances using debug visualization mode

SAMPLE / NOT REAL

6. Document any discrepancies in Visual System Discrepancy Log (VSDL)

The system maintains a 15-second predictive tile cache based on current flight path, ensuring seamless visual continuity during high-speed low-altitude operations.

Database Reload Procedure

The visual database reload procedure is required when updating terrain, airport, or cultural feature data within the G001 visual system. This operation must be performed during scheduled maintenance windows as it requires temporary suspension of visual channel operations. The database management controller (DMC) coordinates the reload sequence across all image generator (IG) channels to ensure synchronized database versions.

Prior to initiating the reload, verify that all visual channels are displaying the READY status on the visual system control panel (VSCP) and that no active training sessions are in progress. The database integrity verification (DIV) process must complete successfully before the new database can be activated.

Database Reload Sequence:

1. Access the DMC interface through the maintenance workstation and authenticate using Level 2 credentials
2. Navigate to Database Management > Reload Operations
3. Select the target database package from the verified repository (confirm MD5 checksum matches documentation)
4. Initiate pre-load verification by selecting "Verify Database Integrity"
5. Review the verification report for any flagged discrepancies or missing texture files
6. If verification passes, select "Begin Staged Reload" to transfer database to IG channel buffer memory
7. Monitor transfer progress on all channels—typical reload time is 8-12 minutes depending on database size
8. Upon completion, select "Activate New Database" to switch from buffer to active memory
9. Execute automatic BIT sequence to confirm proper database loading
10. Perform visual spot-check of known reference points (runways, landmarks, nav aids) at three representative airports
11. Document database version, reload timestamp, and BIT results in the system maintenance log

SAMPLE / NOT REAL

If any channel reports a **FAULT** condition during reload, abort the sequence using the emergency rollback function to restore the previous database version. Investigate fault codes through the DMC diagnostic interface before reattempting the reload procedure.

Terrain Rendering Diagnostics

The G001 visual system employs a multi-layered terrain rendering pipeline that requires periodic diagnostic evaluation to maintain optimal performance during simulation sessions. Terrain mesh corruption, texture streaming failures, or LOD (Level of Detail) transition artifacts can significantly degrade training value and must be identified through systematic testing protocols.

Terrain Rendering Diagnostic Procedure

1. Access the Visual System Maintenance Panel (VSMP) via the IOS (Instructor Operating Station)
2. Navigate to **DIAGNOSTICS > VISUAL > TERRAIN RENDERING**
3. Select **FULL TERRAIN BIT** (Built-In Test) from the diagnostic menu
4. Observe the terrain mesh integrity scan progress on the secondary monitor
5. Review the LOD transition matrix for anomalous values exceeding $\pm 0.5\text{m}$ vertical deviation
6. Execute texture cache verification by selecting **VERIFY TEXTURE STREAMING**
7. Monitor GPU memory allocation percentages; nominal operation requires $< 75\%$ utilization
8. Document any fault codes in the Visual System Discrepancy Log

Common fault indicators include:

- **VIS-TERR-301**: Terrain mesh vertex buffer overflow detected
- **VIS-TERR-412**: Texture streaming bandwidth exceeded threshold
- **VIS-TERR-508**: LOD transition pop-in detected beyond acceptable parameters
- **VIS-TERR-625**: Elevation database checksum mismatch

When terrain rendering anomalies occur during active simulation, pilots may report visual discontinuities during approach phases, particularly when transitioning from cruise altitude to final approach segments. These artifacts often manifest as sudden terrain "popping" or texture resolution changes that can affect visual references during critical flight phases such as circling approaches or visual pattern work.

The terrain database correlation with navigation database effective dates must be verified quarterly. Mismatched database versions can result in terrain features appearing offset from published coordinates, potentially affecting TAWS (Terrain Awareness Warning System) correlation and synthetic vision system accuracy. Database version information is displayed in the VSMP header and should match the current AIRAC cycle loaded in the FMS.

Common Airport Database Issues (KJFK, KSFO, EGLL)

Common Airport Database Issues (KJFK, KSFO, EGLL)

Visual database discrepancies at high-traffic airports frequently manifest during instructor-led scenarios and recurrent training sessions. The three most commonly reported airports—KJFK, KSFO, and EGLL—exhibit recurring anomalies that operators should recognize to distinguish between system malfunctions and known database limitations.

KJFK (John F. Kennedy International)

Taxiway geometry misalignment between runways 4L/22R and 4R/22L has been documented in database versions 2301 through 2308. Pilots may observe a 2-3 meter lateral offset when tracking centerline guidance on taxiways Bravo and Alpha near the 22L threshold. This discrepancy does not affect ILS/LOC approach accuracy but may cause visual discontinuity during rollout phases. Additionally, terminal building textures at Terminal 4 occasionally exhibit Z-fighting artifacts under specific viewing angles (azimuth 045-090 degrees) when aircraft position is within 200 meters of the gate complex.

KSFO (San Francisco International)

Parallel runway operations on 28L/28R frequently trigger spurious GPWS Mode 4A alerts during visual approaches due to terrain mesh interpolation errors in the bay area. The visual system's terrain database samples elevation data at 1-meter resolution, while the TAWS database operates at 30-meter resolution, creating a mismatch that manifests as nuisance alerts below 500 feet RA. Workaround procedures include:

1. Verify TERR ON RAD switch positioned to TERR
2. Cross-reference radar altimeter with barometric altitude
3. Acknowledge GPWS alert using standard procedures
4. Continue approach if visual references confirm adequate clearance

5. Log occurrence in post-session debrief documentation

EGLL (London Heathrow)

Taxiway lighting intensity at northern apron stands (501-509) renders approximately 40% dimmer than ICAO Annex 14 specifications in dusk/night scenarios. This limitation stems from legacy texture mapping in database cycle 2207 and affects photometric calculations in the IG channel processors. Instructors should brief students that this represents a known database constraint rather than aircraft electrical system degradation.

Display Calibration

The G001 visual system requires periodic calibration to maintain geometric accuracy, color fidelity, and luminance uniformity across all display channels. Calibration procedures should be performed during scheduled maintenance intervals or whenever visual anomalies are reported by flight crews.

Pre-Calibration Requirements

Before initiating calibration sequences, ensure the visual system has been powered on for a minimum of 30 minutes to achieve thermal stability. All projector lamps must be within their operational life cycle (below 80% rated hours), and the cooling system must maintain ambient temperature between 18-24°C. Verify that the Image Generator (IG) is running the latest approved software revision and that all display channels are synchronized via the framelock distribution network.

Geometric Calibration Procedure

1. Access the Visual System Control Panel (VSCP) and select "Calibration Mode" from the maintenance menu
2. Load the geometric test pattern (Pattern ID: GEO-GRID-001) to all active channels
3. Using the alignment laser positioned at the design eye reference point (DERP), verify grid intersection accuracy within ± 0.5 pixels at screen center
4. Adjust warp mesh parameters for each projector using the edge-blending tool, ensuring seamless transitions in overlap zones
5. Validate field-of-view coverage: 200° horizontal by 40° vertical for standard configuration
6. Store calibration data to the Visual Database Controller (VDC) and timestamp the configuration file

SAMPLE / NOT REAL

Photometric Calibration

Color balance adjustment requires a calibrated spectrophotometer positioned at the DERP. Target white point should be D65 (6500K) with luminance uniformity within $\pm 10\%$ across the entire display surface. Measure center and nine-point grid positions, adjusting RGB gain values in the projector control interface until variance falls within specification. Black level should not exceed 0.15 cd/m^2 to maintain contrast ratio above 800:1.

Record all calibration values in the Visual System Maintenance Log (Form VS-102) and update the Configuration Management Database with the new baseline parameters.