THALES

payShield® 10K

Security Manual

007-001513-021



Date: November 2024

Rev: A1

Doc. Number: 007-001513-021

All information herein is either public information or is the property of and owned solely by Thales DIS France S.A. and/or its subsidiaries or affiliates who shall have and keep the sole right to file patent applications or any other kind of intellectual property protection in connection with such information.

Nothing herein shall be construed as implying or granting to you any rights, by license, grant or otherwise, under any intellectual and/or industrial property rights of or concerning any of Thales DIS France S.A. and any of its subsidiaries and affiliates (collectively referred to herein after as "Thales") information.

This document can be used for informational, non-commercial, internal and personal use only provided that:

- The copyright notice below, the confidentiality and proprietary legend and this full warning notice appear in all copies.
- This document shall not be posted on any network computer or broadcast in any media and no modification of any part of this document shall be made.

Use for any other purpose is expressly prohibited and may result in severe civil and criminal liabilities.

The information contained in this document is provided "AS IS" without any warranty of any kind. Unless otherwise expressly agreed in writing, Thales makes no warranty as to the value or accuracy of information contained herein.

The document could include technical inaccuracies or typographical errors. Changes are periodically added to the information herein. Furthermore, Thales reserves the right to make any change or improvement in the specifications data, information, and the like described herein, at any time.

Thales hereby disclaims all warranties and conditions with regard to the information contained herein, including all implied warranties of merchantability, fitness for a particular purpose, title and non-infringement. In no event shall Thales be liable, whether in contract, tort or otherwise, for any indirect, special or consequential damages or any damages whatsoever including but not limited to damages resulting from loss of use, data, profits, revenues, or customers, arising out of or in connection with the use or performance of information contained in this document.

Thales does not and shall not warrant that this product will be resistant to all possible attacks and shall not incur, and disclaims, any liability in this respect. Even if each product is compliant with current security standards in force on the date of their design, security mechanisms' resistance necessarily evolves according to the state of the art in security and notably under the emergence of new attacks. Under no circumstances, shall Thales be held liable for any third party actions and in particular in case of any successful attack against systems or equipment incorporating Thales products. Thales disclaims any liability with respect to security for direct, indirect, incidental or consequential damages that result from any use of its products. It is further stressed that independent testing and verification by the person using the product is particularly encouraged, especially in any application in which defective, incorrect or insecure functioning could result in damage to persons or property, denial of service or loss of privacy.

Copyright © 2018-2024 Thales Group. All rights reserved. Thales and the Thales logo are trademarks and service marks of Thales and/or its subsidiaries and affiliates and are registered in certain countries. All other trademarks and service marks, whether registered or not in specific countries, are the properties of their respective owners.

Follow this link to find the End User Licensing Agreement: https://cpl.thalesgroup.com/legal

Contents

1	Introduct	tion	11
	1.1 Ger	neral	11
2	Installatio	on Deployment	12
3	Configura	ation	13
	3.1 Cor	nfigure Alarm	13
	3.1.1	Motion Alarm	13
	3.1.2	Temperature Alarm	13
	3.2 Cor	nfigure Self-tests	14
	3.3 Cor	nfigure Security Settings	15
	3.3.1	Security Parameter Descriptions	16
	3.3.2	NIST SP800-57 and comparable strengths	30
	3.4 Cor	nfigure Commands	30
	3.5 Cor	nfigure PIN Block	31
	3.6 Cor	nfigure Fraud Detection	31
	3.6.1	Configuration Options	31
4	Tamper P	Protection	33
	4.1 Tan	mper Responsiveness	33
	4.1.1	Types of Tamper Actions	33
	4.1.1.1	Physical Access	34
	4.1.1.2	P Environmental Changes	
	4.1.1.3	Intended Erasure of Customer Key Material	34
	4.1.1.4	Fraud Attack	34
	4.2 Tan	mper States	35
	4.2.1	Medium Tamper	35
	4.2.1.1	Recovering from a Medium Tamper	35
	4.2.1.2	P Error Log Entries	36
	4.2.2	High Tamper	36
	4.2.2.1	Error Log Entries	37
	4.3 Ten	mperature Sensor	37
	4.3.1	Description	37
	4.3.2	Triggering of the Temperature Sensor	37
	4.4 Mot	tion Sensor	38
	4.4.1	Description	38
	4.4.2	Sensitivity of the sensor	38

	4.4.	3	If the Motion Sensor is activated	38
	4.4.	4	Enabling the Motion Alarm	39
5	TLS f	or H	ost Connections	40
	5.1	Intro	duction	40
	5.2	Gen	eral Description	40
	5.3	TLS	for Host Connections on payShield 10K	40
	5.3.	1	Host TLS Certificates	40
	5.3.	2	Client Certificates	41
	5.3.	3	Supported Cipher Suites	41
	5.3.	4	Cipher Suite Negotiation	41
	5.3	3.4.1	Out-of-Date Certificates	41
	5.3	3.4.2	Security Considerations	41
	5.3	3.4.3	FICON Interface	42
	5.3	3.4.4	HSM Recovery Key (HRK)	42
6	Secu		/IK Management	
	6.1	Veri	fying the Contents of the LMK Store	43
	6.2	Load	ding the Test Keys	44
7	The A		Log	
	7.1		oduction	
	7.2		rview	
	7.3		rect Use of the Audit Log	
	7.4		cibly recorded items	
	7.5		HSM Compliance	
	7.6		ording Deletion of Audit Log	
	7.7		cretionary Audit Log entries	
	7.8	Prot	ection of the Audit Log	48
8	Shipp	_	and Product Handling	
	8.1	Res	ponsibilities	49
	8.2	PCI	shipping requirements	50
9	Infor		on for Security Auditors	
	9.1		ifications	
	9.1.		NIST Cryptographic Module Validation Program (CMVP) – FIPS 140-2	
	9.1.		NIST Cryptographic Algorithm Validation Program CAVP	
	9.1.		PCI HSM	
	9.1.		Australian Payments Network (AusPayNet)	
	9.1.		Cartes Bancaires SAFIRE Evaluation	
	9.1.	6	GBIC (German Banking Industry Committee) / ZKA (Zentraler Kreditausschuss)	53

	9.1.7	Bancontact (Belgium)	54
	9.2 Refe	erences	54
10	Appendix	A - Security Recommendations	55
	10.1 Intro	oduction	55
	10.2 Proc	cedural Security	55
	10.2.1	Audit and records	56
	10.2.2	Identification and Authentication	57
	10.2.3	Use of Authorized State	57
	10.2.4	Use of Secure State	57
	10.2.5	Use of Offline State	58
	10.2.6	Use of the restricted role of the payShield Manager	58
	10.3 Com	nmand Security	58
	10.4 Mea	sures to Protect HSM Secure Area	58
	10.5 HSM	/I Configuration Functions	59
	10.6 Host	t Application Functions	60
	10.7 Loca	al payShield Manager Functions	60
	10.8 Cryp	otographic Key Management	60
	10.8.1	Cryptographic Key Generation	61
	10.8.2	Protection of Cryptographic Key Material	61
	10.8.3	Key Material Usage	61
	10.8.4	HSM PIN and Password Security	62
	10.8.5	Smartcard Security	62
	10.8.6	Physical Key Security	63
	10.8.7	HSM Recovery Key (HRK)	63
	10.9 HSM	/l Integrity	64
	10.9.1	HSM Traceability	64
	10.9.2	HSM Physical Integrity	64
	10.9.3	HSM Maintenance	65
	10.10 Norr	mal Operations	65
	10.10.1	Timely Return to the Online State	66
	10.11 Insp	ection Procedures	66
	10.11.1	Frequency of Inspection	66
	10.11.2	Initial Inspection Procedure	66
	10.11.3	Routine Inspection Procedure	67
	10.12 Secu	urity Guidelines for SNMP Configuration	68
11	Appendix	B – payShield Manager Recommendations Background	69
	11.1.1	Remote Management States	
	11.1.2	Remote Management Roles & Limitations	
	11.1.2.1	-	

	11.1.2.2	2 Customer Security Domain	70
	11.1.2.3	Recovery	70
	11.2 Pay	Shield Manager Best Practice	70
	11.2.1	Introduction	70
	11.2.2	Assumptions	70
	11.2.2.1	l Terminology	70
	11.2.3	Personnel	71
	11.2.4	Procedural Security	71
	11.2.5	Audit	71
	11.2.6	Physical Security	72
	11.2.7	HSM Security Configuration	73
	11.2.8	Customer Trust Authority	73
	11.2.9	Smartcard Security	75
	11.2.10	RLMK Smartcards	76
	11.2.11	Customer Security Domain	76
	11.2.12	Back-Up	77
	11.2.13	Operational Security	77
12	Appendix	C –TLS Security Recommendations	78
	12.1 Bacl	kground	78
	12.1.1	payShield 10K TLS Server	78
	12.1.2	Protocol Support	78
	12.1.3	Cipher Suite Support	78
	12.1.4	TLS Configuration Options	79
	12.1.5	Man-In-The-Middle Mitigation	79
	12.1.6	TLS Clients	79
	12.1.7	Client Mitigations	79
13	Appendix	D – Audit Log Messages	80

Revision Status

Document No.	Revision	Date	Changes
PUGD0536-001	001	April 2019	Initial issue
PUGD0536-002	002	July 2019	Update to default settings; update Health LED description Added: Section 3.3.2 NIST SP800-57 and comparable strengths Updated example of VR command output to reflect both PCI compliant output and non-PCI compliant output
PUGD0536-003	003	November 2020	Updated Security Settings to reflect that the import/export of a ZMK encrypted under a ZMK is permitted
PUGD0536-004	004	December 2020	Updated security parameter to include ECC: Enforce minimum key strength of 2048-bits for RSA and ECC? Yes or No
PUGD0536-005	005	May 2021	Section 2.1.2 Temperature Alarm updated Section 2. 3 Updated description for security parameters: Enforce minimum key strength of 2048-bits for RSA and ECC? Follow this link to page: 29 Enable import of ZMK: Follow this link to page: 29 Enable export of ZMK: Follow this link to page: 29 Prevent single-DES keys masquerading as double or triple-length keys: Follow this link to page: 29
007-001513-005	005	February 2022	New document number Clarification added to the "Select clear PINs" description

Document No.	Revision	Date	Changes
007-001513-006	006	June 2022	Inclusion of new Security Parameters
			Return PIN Length in PIN Translation Response: Yes or No
			Follow this link to page: 29
			Enable PIN Translation to BDK Encryption: Yes or No
			Follow this link to page: 29
			Added: Section 9.12 Security Guidelines for SNMP Configuration
			Updates to Section 9.1 Certifications
			Deleted Error Codes from manual, as covered in payShield 10K Installation and User Guide
			Updated text in security parameter:
			Single-DES: Enabled or Disabled
			Follow this link to page: 29
			Added: Appendix D – Audit Log Messages
007-001513-007	007	November 2022	Version 1.7a document number
007-001513-007	007 Rev B	January 2023	Update to Cipher Suite table found in Section 12.1.3 Cipher Suite Support
			Updated hyperlink in Section 8.2 PCI shipping requirements
007-001513-007	007 Rev C	February 2023	Update to Section 5.3.4 Supported Cipher Suites to refer user to Section 12.1.3 Cipher Suite Support
007-001513-007	007 Rev D	May 2023	New Section 2, Installation Deployment
			Updates to Sections:
			5.1, Introduction, (under Section 5, Secure Host Communications) to include: installation in protected network

Document No.	Revision	Date	Changes
			10.4, Measures to Protect HSM Secure Area to include reference to Section 2, Installation Deployment 10.5, HSM Configuration Functions to clarify that ACL for host ports only CAN be configured
007-001513-008	008	May 2023	New Security Parameter added: Use deprecated proprietary format (Tag J) when using PIN Blocks under AES Key Block LMK: Yes or No
007-001513-008	008 Rev B	July 2023	Update to cross-reference in Section 5.3.4 Supported Cipher Suites. (Note full discussion of supported Suites is contained in 12.1.3 Cipher Suite Support)
007-001513-009	009	September 2023	Update to Section 12.1.3 Cipher Suite Support – Standard RFC 8422 has replaced RFC 4492 Update to Section: 13 Appendix D – Audit Log Messages – to include number of payShield Manager login attempts along with the client's IP address. See pages: 82 and 85. Update to Section 2: Installation Deployment to include additional connectivity requirements (e.g., for NTP)
007-001513-009	009 Rev B	January 2024	Update to Section 9.1.6, GBIC (German Banking Industry Committee) / ZKA (Zentraler Kreditausschuss) Clarifications added to the Security Parameter descriptions; Section 3.3, Configure Security Settings
007-001513-020	020	April 2024	Update to 3.3.1 Security Parameter Descriptions to include parameter: Enable settings per LMK Editorial updates through out
007-001513-020	020 Rev A2	April 2024	Update to 3.3.1 Security Parameter Descriptions
007-001513-020	020b - Rev B1	August 2024	Version 2.0b – Rev B1 document number
007-001513-020	020c - Rev C1	September 2024	Version 2.0c – Rev C1 document number

Document No.	Revision	Date	Changes
007-001513-021	021 - Rev A1	November 2024	Text edit in Section 11.1.2.1, Customer Trust Authority Content revision in Chapter 5, TLS for Host Connections

1 Introduction

This manual provides regulatory user information for the payShield® 10K product.

The manual identifies the security implications of the security relevant choices available to the user, and provides guidance to assist the user when making those choices.

1.1 General

The payShield hardware security module (HSM) provides cryptographic functions to support network and point-to-point data security; therefore; it is imperative that the HSM itself is secure. The payShield is made physically secure by locks, electronic switches and tamper-detection circuits, and must be located in a secure area with controlled access.

HSM software security is provided by a combination of several security features including:

- Two front-panel rack locks with separate physical keys
- Personalized smartcards issued for Security and Authorizing Officers
- Personal Identification Numbers (PINs) issued for Security and Authorizing Officers
- A "SECURE" mode which requires the presence of two Security Officers holding separate physical keys for the front panel locks. (An equivalent card-controlled mode can be achieved via payShield Manager with the two "Administrator" cards.)
- An Authorized mode, requiring the presence of two Authorizing Officers with encrypted smartcards and PINs
- · A configurable motion sensor, to detect attempts to move the unit
- Configurable security parameters
- Error and Audit Logs
- Tamper evidence and tamper resistance with fully locked-down lid, and sensors to detect motion, voltage, and temperature anomalies
- Secure by default Where possible, default settings are the most secure option.

2 Installation Deployment

To deploy the payShield 10K in a way that meets the requirements of PCI requirement 3.5.1, HSM ISO 13491-2, and the PCI HSM security policy, the following steps should be taken:

- 1. Choose a secure physical location for the HSM: The HSM should be located in a secure area with limited access and controlled environmental conditions, such as temperature and humidity control.
- Implement strong access control measures: Only authorized personnel should have access to the HSM, and access should be granted on a need-to-know basis. Access attempts should be logged and monitored.
- 3. Protect the HSM from physical attacks: The HSM should be protected from tampering, environmental hazards, and other physical attacks. Physical security measures should be put in place to prevent unauthorized access.
- 4. Ensure connectivity:
 - The HSM should be connected to a stable power source.
 - It is important to note that the payShield was not designed to operate in a public network, therefore:
 - It MUST be installed in a private, secure network
 - If a Network Time Protocol (NTP) is used, the NTP Server MUST be located in a secure internal network. Public NTP servers should not be used.
 - Note the secure network MUST have all necessary security measures, such as network firewalls, IDS, ACL, in place to prevent unauthorized access and attacks.
- 5. Implement logging and auditing: All access attempts and transactions should be logged and audited to detect potential security breaches.
- 6. Regularly update firmware and software: The HSM should be regularly updated with the latest security patches and firmware releases to protect against known vulnerabilities.
- 7. Provide personnel training and authorization: All personnel responsible for managing and maintaining the HSM should be trained and authorized to perform their duties.
- 8. Use secure key management practices: The HSM should use secure key management practices to protect cryptographic keys and ensure the integrity of transactions.

By following these steps, the payShield 10K can be deployed and managed in a way that meets the requirements of PCI requirement 3.5.1, HSM ISO 13491-2, and the PCI HSM security policy. This ensures that the HSM provides a secure environment for payment card processing and helps to ensure the integrity of sensitive data and transactions.

3 Configuration

3.1 Configure Alarm

3.1.1 Motion Alarm

The HSM Motion Alarm should be turned on when the HSM is put into service. Once enabled, the Motion Alarm will need to be turned off if the HSM is to be moved.

To view and modify the current alarm settings using payShield Manager, navigate to **Configuration >**

General Settings > Alarms.




6

The **CL** console can also be used to change alarm settings.

The HSM must be in the Secure state to configure the Motion Alarm.



The Motion Alarm has four security level settings: off, low, medium, and high. Changing the setting to a lower level results in LMKs being erased. (See Section 4.4, Motion Sensor, for additional information.)



3.1.2 Temperature Alarm

The Temperature Alarm is permanently enabled and can not be disabled by users.

The alarm is triggered if the temperature inside the HSM exceeds a safe value.

The temperature sensor is active even if the payShield 10K is disconnected from an electrical power supply. The temperature sensing capability is maintained by the payShield 10K's internal battery, and will still initiate LMK deletion and tamper state.

If the temperature falls outside of predefined limits, the temperature sensor will initiate a tamper alarm causing the LMKs to be deleted and the unit will automatically reboot and attempt to clear the tamper state. If

the alarm condition persists, the unit will stop attempting to clear the tamper after 2 attempts and will remain powered on with limited functionality such that LMKs cannot be loaded. Deletion of the LMKs prevents the payShield 10K from executing Host commands or console commands which require an LMK to be present.

Once the stimulus that triggered the alarm has ended, the payShield 10K will need to be rebooted to clear the tamper state and allow the LMKs to be reloaded.

An entry will be made in the error log.

3.2 Configure Self-tests

Self-tests are run during the HSM boot-up.

PCI HSM requires that HSM self-tests are run automatically at least once every 24 hours.

By default, the HSM will run the self-tests at 09:00 daily.

To change the self-test run time:



The payShield is in the Offline or Secure state.

- Navigate to Status > Health Statistics/Diagnostics > Diagnostics.
- Click the tools icon (located on the far right of the display).
- Click Change time.

occurs, the device enters a tamper state.


- Enter your time preferences in the Enter Time display.
- · Select Apply.



The **DT** console command can also be used to change self-test settings.

settings.

Failures in the daily self-tests typically generate an Error log entry, reboot immediately. If another failure





3.3 Configure Security Settings

By default, the security settings are set to their most secure option with exceptions duly noted.

To configure security settings:




The payShield is in the Secure state.

- Navigate to: Configuration > Security Settings.
- Review/modify the settings on the General display.
- Select Apply.
- Select Initial.
- Review/modify the settings on the Initial display.
- Select Apply.



The Quick Links tab contains navigational shortcuts.





0

The CS console command can also be used to change security settings. The settings can be examined using the **QS** console command.

3.3.1 Security Parameter Descriptions

Security Parameter Description	Default Value
Echo: ON or OFF If set to 'ON', then passwords and other secret values are displayed on the console as	OFF
entered. Characters can be hidden by using '^' prior to entering the component or key.	
Enabling Echo is a security flazard and should not be used in a live system.	
User storage key length: SINGLE, DOUBLE, TRIPLE or VARIABLE	SINGLE
This is the length of the keys stored in user storage; it can be 'SINGLE', 'DOUBLE', 'TRIPLE' or 'VARIABLE' length. The number of keys that can be stored depends upon this setting.	
Display general information on payShield Manager Landing Page: YES or NO	NO
If set to 'YES', the landing (initial) page displayed by payShield Manager contains basic information about the HSM.	
Solicitation batch size: 00011024	1024
A method, supported by the payShield 10K, to enable customers to self-select their own PINs, is to use Solicitation mailers. This is a turnaround form that is sent to the cardholder. The cardholder records the PIN selection on the form and returns it to the issuer. The mailer data consists of the cardholder name and address and a reference number (an encrypted account number). As a security measure, the form returned to the issuer contains only the reference number and the PIN selection. A batch process is used to process these requests when returned. Small batch sizes must be avoided to prevent matching of reference numbers with account numbers.	
Use default card issuer password: YES or NO	YES
This option determines whether the default Card Issuer Password is user or not.	
This item should only be changed where customized HSM smartcards are being used. The original value must not be changed if standard Thales smartcards are in use.	
Use the CS console command to display this parameter. By design, it does not appear in output from the QS console command.	
See the row below for details on setting a non-default card issuer password.	

Security Parameter Description	Default Value
Card issuer password (local): 8 characters	N/A
This parameter is only valid if 'Use default card issuer password' is 'NO'.	
This option provides a method for users to set the password that the HSM sends to a smartcard prior to formatting the card. Most users will not need to change this value. If this setting is changed to a value that does not match the password on the smartcard, it will not be possible to format the smartcards using the 'FC' command. This setting is only relevant to standard HSM smartcards – not to payShield Manager smartcards.	
Use the CS console command to display this parameter. By design, it does not appear in output from the QS console command.	
Default LMK identifier: 0099	00
Identifies the Default LMK, which the HSM will use if it receives a command that does not explicitly state which LMK is to be used. The use of the Default LMK provides a "backward-compatible" mode, even when multiple LMKs are loaded in the HSM. The upper limit (99) is determined by the number of LMKs that can be installed concurrently.	
Management LMK identifier: 0099	00
Identifies the Management LMK, which will be used for authorizing certain management functions (e.g., setting the HSM's date/time), and for encrypting the audit MAC key. The upper limit (99) is determined by the number of LMKs that can be installed concurrently.	
Enable settings per LMK: YES or NO	NO
When this value is 'YES' the following can be configured per LMK when using multiple LMKs:	
Applicable Security Settings	
Enabling Host Commands	
Enabling PIN Block Formats	
When this value is 'NO', the above applies to all LMKs when using multiple LMKs, as is the case with releases before 2.0a.	
MODIFYING THIS PARAMETER REQUIRES ALL LMK(S) TO BE ERASED.	

THE FOLLOWING PARAMETERS APPLY TO SELECTED LMK WHEN SETTINGS PER LMK IS ENABLED

Security Parameter Description			
PIN length: 0412	04		
Encrypted PIN length:	05		
This value is used by the HSM to define the length of encrypted PINs, symbolized as "L" in the payShield 10K Host Command manuals in the "Length & Type" column. The value of L is one more than the value entered for the PIN length in the CS command. Cleartext PINs (as entered into the BA host command) must have a length of L; shorter PINs can be entered, but must be padded to the right with hexadecimal F digits.			
For example, if the PIN Length in CS has been set to 6 (i.e., $L=7$), and the 4-digit PIN "1234" is to be entered into the BA host command, the value that is included in the command is "1234FFF".			
All LMK-encrypted PINs will have a length of L.			
Where a PIN is generated (e.g., JA host command) and the PIN length specified in the command is less than L, the generated PIN is padded to the right with hexadecimal F characters to a length of L digits.			
When an LMK-encrypted PIN is decrypted using the NG host command, any F-padding used to expand a shorter PIN is presented in the decrypted PIN and will need to be stripped off to derive the shorter PIN.			
Once the length is set, it cannot be easily altered. If it has to be changed to accommodate longer PINs, all the existing encrypted PINs will have to be translated. This requires two operations: the old PINs are first translated to encryption under, for example, a ZPK; the HSM is then re-configured for the longer PIN length; the PINs are then translated back from the ZPK to the LMK.			
The above information applies to the following host commands: BA, BC, BE, BG, BQ, CE, CQ, DE, DG, EE, G2, G4, GA, GU, JA, JC, JE, JG, NG, PE, PG, QC, QK, QW, XK, XM, ZM.			

Security Parameter Description	Default Value		
Atalla ZMK variant support: ON or OFF	OFF		
For interoperation with Atalla systems. This enables the optional Atalla variants within commands. Any console command providing key support will prompt for an Atalla variant.			
Selection has no effect on host commands - Atalla variants can be supplied with any appropriate command regardless of this setting.			
When this parameter, Atalla ZMK variant support , is set to ON , you will be prompted with the following parameter:			
Enforce Atalla variant match to Thales key type:			
Continue to scroll down to see the description of the Enforce Atalla variant match to Thales key type parameter.			
Transaction key support: Racal, Australian or NONE			
Transaction key schemes are techniques whereby data-encrypting keys change with each transaction in a manner that cannot be followed by a third party. The payShield 10K supports three variants of transaction key schemes: Racal (i.e., Thales), Australian (AS2805), and DUKPT. There are command conflicts between the Racal and Australian schemes so only one can be selected. The use of DUKPT commands is not affected by this setting.			
The default value is 'NONE'. In this case, none of the Racal or Australian transaction key scheme commands are available to the host.			
Use of this setting may modify the functionality associated with some host commands.			
CHANGING THE FOLLOWING PARAMETERS REQUIRES THE LMK(S) TO BE ERASED			
Enforce Atalla variant match to Thales key type: YES or NO	NO		
This parameter is only valid if 'Atalla ZMK variant support' is 'ON'.			
If set to 'YES', a defined match between Atalla variant and Thales variant key types will be enforced.			
This parameter only appears if "Atalla ZMK variant support" was previously set to 'ON'.			

Security Parameter Description	Default Value
Select clear PINs: YES or NO	NO
The BA host command is NOT controlled by this setting.	
This enables the clear PIN support via the 'NG' host command. Authorized state is a requirement for this command to be processed by a host application.	
Note: This is a security risk unless precautions are taken at the host.	
Enable ZMK translate command: YES or NO	NO
This enables the 'BY' command that allows the translation of Zone Master Keys from under another Zone Master Key. Authorized state is required for this command to process within a host application.	
Note: The availability of this command is a significant security risk.	
Enable X9.17 for import: YES or NO	NO
This enables support for the ANSI X9.17 mechanism for key import. When being imported, each key of double or triple length is encrypted separately using the Electronic Code Book (ECB) mode of encryption. This is a lower security option, and is included for backward compatibility reasons only. It is strongly recommended that the X9 TR-31 keyblock is used instead of X9.17.	
Enable X9.17 for export: YES or NO	NO
Similar to the previous item, but used when exporting keys.	
ZMK length: SINGLE or DOUBLE	DOUBLE
The length of the Zone Master Key: 'SINGLE' or 'DOUBLE'. This is a backwards-compatible mode to enable the switching between 16H and 32H for ZMKs.	
Decimalization tables: ENCRYPTED or PLAINTEXT	ENCRYPTED
This option determines if the decimalization table will be encrypted or in plain text. The default setting is 'ENCRYPTED'; however, to allow for backward compatibility, plaintext decimalization tables can be selected. It is recommended that encrypted decimalization tables are used to protect against decimalization table manipulation attacks.	
Decimalization table checks: ENABLED or DISABLED	ENABLED
The values in the decimalization tables, used for deriving and verifying PIN offset values, are normally restricted to provide additional security by rejecting values which are potentially insecure. This can cause problems where existing tables fail the checks, so for backward compatibility, this parameter allows the restrictions to be disabled.	

Security Parameter Description	Default Value
PIN encryption algorithm: A (Visa method) or B (Racal method)	А
This selects the PIN encryption algorithm to be used when encrypted PINs are stored by the card issuer. The Racal algorithm is the best choice for a new installation; it is the stronger of the two methods. The Visa algorithm is offered for compatibility with older HSMs and for customers who already have a database of encrypted PINs.	
When the Racal method is used, the output of the encryption is hex characters whereas the Visa method produces decimal digits. Commands that use encrypted PINs describe them as 'LN or LH'.	
Use deprecated proprietary format (Tag J) when using PIN Blocks under AES Key Block LMK: YES or NO	NO
This determines whether the deprecated proprietary format (Tag J) is used to encrypt PIN Blocks when using an AES Key Block LMK. When set to NO, Thales PIN Block 48 format (Tag M) is used.	
This setting is only used with the following host commands - the other host commands supporting Tag J are not affected by this setting and use an alternative method to determine the format used: • JC (Translate a PIN from TPK to LMK Encryption) • JE (Translate a PIN from ZPK to LMK Encryption)	
Also note that using the above two commands to translate PIN Blocks from ISO Formats 0, 1, 3 and 4 (Thales PIN block formats 01, 05, 47 and 48 respectively) to encryption under an AES Key Block LMK using Tag 'J' are not allowed if the security setting 'Restrict PIN Block Usage for PCI Compliance' is set to 'YES'.	
Further information is given in the Host Programmer's Manual, Chapter 16, PIN Block Formats.	
Authorized State required when importing a key under an RSA key: YES or NO	YES
This setting determines whether Authorized State is mandatory for the import of DES keys using RSA keys (host command GI).	
If set to 'YES', the GI command always requires Authorized State (and the use of the signature field is optional).	
If set to 'NO', the GI command does not require Authorized State.	
Minimum HMAC length in bytes: 564	10
This setting determines the minimum length of HMAC keys that the HSM can generate. HMAC keys must satisfy the equation $L/2 \le$ key length, where $L =$ the size of the hash function output. For SHA-1 HMAC keys, $L=20$, and therefore the key length must be at least 10.	

Security Parameter Description	Default Value
Enable PKCS#11 import and export for HMAC keys: YES or NO	NO
This setting determines whether the host commands LU and LW can import or export HMAC keys in PKCS#11 format.	
Enable ANSI X9.17 import and export for HMAC keys: YES or NO	NO
This setting determines whether the host commands LU and LW can import or export HMAC keys in ANSI X9.17 format.	
Enable ZEK/TEK encryption of ASCII data or Binary data or None: ASCII or BINARY or NONE	NONE
This setting determines the type of messages that can be encrypted/decrypted/translated (using a ZEK or TEK) using the 'Message Encryption' host commands M0, M2 and M4:	
ASCII: the plaintext message must contain only ASCII (0x20-0x7F) characters;	
BINARY: no restrictions on the contents of the plaintext message;	
NONE: encryption using a ZEK or TEK is not permitted.	
Restrict key check value to 6 hex chars: YES or NO	YES
This setting determines whether Key Check Values (KCVs) should be restricted to consist of only 6 hex characters. The overall length of the KCV field will remain the same, regardless of this setting. However, when set to 'YES', only the first 6 characters will contain the KCV: any remaining characters will be ignored (when input to the HSM) or set to '0' (when returned from the HSM).	
Return PIN Length in PIN Translation Response: YES or NO	YES
This setting should be set to 'YES' for backward compatibility. If set to 'YES', the PIN length will be returned in the Host Commands AQ, CC, CA and G0.	
This setting should be set to 'NO' if the PIN Length returned in the Host Commands below is not required, or to comply with the requirements of the German Banking Industry (GBIC).	
Enable multiple authorized activities: YES or NO	YES
If set to 'YES', will allow precise selection of authorized activities (including timeout period if required). If disabled HSM reverts to global Authorized state.	

Security Parameter Description	Default Value
Allow persistent authorized activities: YES or NO	NO
If set to 'YES', will allow "persistent" authorized activities to be automatically restored when the HSM restarts following a power failure. This option is only presented if the response to the previous option is 'YES'. Even where persistent authorized activities are allowed, there will be a maximum limit of 12 hours for the time that any console command may remain authorized.	
Enable variable length PIN offset: YES or NO	NO
If set to 'YES', this will allow the IBM 3624 PIN Offset commands to return an Offset whose length matches the PIN, rather than being restricted to the Check Length parameter.	
Enable weak PIN checking: YES or NO	NO
If set to 'YES', the HSM's PIN generation/derivation host commands will check to ensure that the new PIN is not considered weak. The precise method used to determine a PIN's strength is selected in one of the three settings, below.	
If 'Enable weak PIN Checking' is set to 'YES', the following 3 parameters display:	
Check new PINs using global list of weak PINs: YES or NO	YES
If set to 'YES', the HSM's PIN generation/derivation host commands will check to ensure that the new PIN does not match one of the entries in the appropriate global 'Excluded PIN Table' (loaded into the HSM via the 'BM' host command). If a match is found in the list, then the command fails, returning error code 86.	
If set to 'NO', the HSM will not perform any weak PIN checking using the 'global' list of weak PINs.	
Check new PINs using local list of weak PINs: Yes or No	YES
If set to 'YES', the HSM's PIN generation/derivation host commands will check to ensure that the new PIN does not match one of the entries in the 'Excluded PIN Table' (supplied with the host command). If a match is found in the list, then the command fails, returning error code 86.	
If set to 'NO', the HSM will not perform any weak PIN checking using the 'local' list of weak PINs.	
Check new PINs using rules: YES or NO	YES
If set to 'YES', the HSM's PIN generation/derivation host commands will check to ensure that the new PIN is not considered weak using the rules defined below.	
A PIN is considered weak if any of the following are TRUE:	
>50% of the PIN's digits have the same value. (e.g., 1111, 0111, 1101, etc. are all weak);	
The PIN consists entirely of ascending or descending digits (e.g., 1234, 2345, etc. are all weak).	

Security Parameter Description	Default Value	
Enable PIN Block Format 34 as output format for PIN translations to ZPK: YES or NO		
If set to 'YES', the HSM will permit PIN block format 34 to be used as the output format of PIN translation commands.		
Enable translation of account number for LMK encrypted PINs: YES or NO	NO	
If set to 'YES', allows the account number (PAN) for an LMK-encrypted PIN to be changed without the customer PIN itself being changed, using the QK host command.		
Use HSM clock for date/time validation: YES or NO	YES	
If set to 'YES', the HSM uses its integral real-time clock to validate check the start/end date/time optional header blocks of keyblocks (when present).		
Additional padding to disguise key length: YES or NO	NO	
If set to 'YES', the HSM disguises the length of single or double length keys within a keyblock by adding 8 or 16 extra padding bytes, such that single, double and triple length DES keys all appear to be triple length keys.		
Key export and import in trusted format only: YES or NO	YES	
If set to 'YES', the HSM will only import/export keys using a keyblock format. In this case, any export/import process using keys in variant format (including X9.17 format) will be prohibited.		
Protect MULTOS cipher data checksums: YES or NO	YES	
This setting is used to control whether checksums generated over sensitive data will require encryption.		
Enable Key Scheme Tag 'X' (X9.17) for storing keys under LMK: YES or NO	NO	
This option determines whether keys encrypted under a Variant LMK will be permitted to use the key scheme tag 'X'. This is a lower security option, and is included for backward compatibility reasons only.		
If set to 'YES', the following host commands will support LMK-encrypted keys using key scheme 'X': B0, EA, FA, IA, CK, G0, EC, CI, CM, GQ, CC, GO, M0, M2, A0, and A6.		
Enable use of Tokens in PIN Translation: YES or NO	NO	
This option determines whether PIN Translation commands will support the use of Tokens, in the Account Number field for Source PIN Blocks, by providing a second Account Number field for the Destination PIN Block.		
If set to 'YES', allows the account number (PAN) for a ZMK-encrypted PIN to be changed without the customer PIN itself being changed, using the CC host command.		

Security Parameter Description	Default Value
Enable use of Tokens in PIN Verification: YES or NO	NO
This option determines whether PIN Verification commands will support the use of different Account Numbers/Tokens, for the PIN Block and reference value generation process.	
Enable PIN Translation to BDK Encryption: YES or NO	YES
This setting should be set to 'YES' for backward compatibility. If set to 'YES', translation to BDK encryption is enabled for Host Commands CA and G0.	
This setting should be set to 'NO' if translation to BDK encryption is not required, or to comply with the requirements of the German Banking Industry (GBIC).	
Ensure LMK Identifier in command corresponds with host port: YES or NO	NO
When using multiple Variant LMKs, there are two ways to specify which LMK a host command should use: by using a specific TCP port, or by specifying the LMK ID within the command. Conflicts may arise if both methods are used at once.	
If set to 'NO', an LMK ID field within a host command has priority over the TCP port used; if set to 'YES', an LMK ID field within a host command must match the LMK Id implied by the TCP port used.	
Ignore LMK ID in Key Block Header: YES or NO	NO
If set to 'YES', the LMK ID inside the header (bytes 14-15) of Thales Key Blocks will be ignored. Instead, the HSM will use the same mechanisms for deducing the LMK ID as used with Variant LMKs: i.e., by host port, or by specifying the LMK ID within the command.	
When set to 'NO', the LMK ID inside the header of Thales Key Blocks will be used to identify which LMK to use with a command.	
Enable import and export of RSA Private keys: YES or NO	NO
If set to 'YES', host commands 'L6' and 'L8' will be available (if the appropriate license is installed), permitting the import and export of RSA private keys. Otherwise, host commands 'L6' and 'L8' will be disabled, and immediately return error code '03'.	
Enable import of a ZMK: YES or NO	NO
If set to 'YES', console command 'IK' and host commands 'A6' and 'GI' will be able to import a ZMK by translating it from encryption under a (supplied) ZMK, to encryption under the LMK.	
Enable export of a ZMK: YES or NO	NO
If set to 'YES', console command 'KE' and host commands 'A8' and 'GK' will be able to export a ZMK by translating it from encryption under the LMK, to encryption under a (supplied) ZMK.	

THE FOLLOWING PARAMETERS AFFECT PCI HSM COMPLIANCE			
Security Parameter Description			
Prevent single-DES keys masquerading as double or triple-length keys: YES or NO	YES		
If set to 'YES', the HSM will prevent the use of single-length DES keys disguised as a double or triple length key.			
To operate in PCI HSM compliant mode, the HSM software must be PCI HSM certified and this option must be set to 'YES'.			
If this option is set to 'YES' and all other PCI HSM-relevant settings have PCI HSM compliant values, then it will not be possible to change any of these options without performing a factory reset and reloading the LMKs.			
Single-DES: ENABLED or DISABLED	DISABLED		
If set to 'ENABLED', the HSM will permit the use of single-length DES keys. This is a lower security option, and is included for backward compatibility reasons only.			
To operate in PCI HSM compliant mode, the HSM software must be PCI HSM certified and this option must be set to 'DISABLED'.			
If this option is set to 'DISABLED' and all other PCI HSM-relevant settings have PCI HSM compliant values, then it will not be possible to change any of these options without performing a factory reset and reloading the LMKs.			

Security Parameter Description	Default Value
Card/password authorization (local): C or P	С
This option selects the method of authenticating security officers requesting a security state change. The Authorized state is a mode that the HSM can be placed in for sensitive data processing. This authorized mode is required when input commands at the console or host use clear text data such as key components or unencrypted PINs. Authorized mode can be used in both Online and Offline host states and requires the Authorizing Officers to invoke the higher security level. Before the Authorized state can be set, the Authorizing Officers need to be verified by the HSM. Officer verification is done by checking either a smartcard and PIN or a password (16 alphanumeric characters.) If the Password option is not set when the LMK is created, the Password option will not be available as no password is created and stored with the LMK components. (Only relevant to standard HSM smartcards – not to PayShield Manager smartcards.)	
To operate in PCI HSM compliant mode, the HSM software must be PCI HSM certified and this option must be set to 'C'.	
If this option is set to 'C' and all other PCI HSM-relevant settings have PCI HSM compliant values, then it will not be possible to change any of these options without performing a factory reset and reloading the LMKs.	
Restrict PIN block usage for PCI HSM Compliance: YES or NO	NO
If set to 'YES', the HSM will prevent translations from ISO PIN block formats 0, 1, 3 and 4 (Thales PIN block formats 01, 05, 47 and 48 respectively) to any non-ISO format. The HSM will also prevent translation of PIN block formats that include the PAN to PIN block formats that do not include the PAN. Translations between PIN block formats that both include the PAN shall not allow a change in the PAN.	
The HSM will also restrict the calculation of values derived from the PIN and PAN such as PIN offsets and PIN Verification Values to ISO PIN block formats 0, 3 and 4 only (Thales PIN block formats 01, 47 and 48).	
To operate in PCI HSM compliant mode, the HSM software must be PCI HSM certified and this option must be set to 'YES'.	
If this option is set to 'YES' and all other PCI HSM-relevant settings have PCI HSM compliant values, then it will not be possible to change any of these options without performing a factory reset and reloading the LMKs.	

Security Parameter Description			
Enforce key type 002 separation for PCI HSM compliance: YES or NO	NO		
If set to 'YES', the HSM will separate the keys currently encrypted under LMK 14-15 (key type 002).			
If this option is enabled the following host commands are disabled: AA, AE, FC, FE, FG, HC, KA, OE.			
To operate in PCI HSM compliant mode, the HSM software must be PCI HSM certified and this option must be set to 'YES'.			
If this option is set to 'YES' and all other PCI HSM-relevant settings have PCI HSM compliant values, then it will not be possible to change any of these options without performing a factory reset and reloading the LMKs.			
Enforce Authorization Time Limit: YES or NO	YES		
If set to 'YES', the maximum authorization time limit for console commands is set to 720 minutes.			
If set to 'NO', the maximum authorization time limit for console commands is unlimited.			
To operate in PCI HSM compliant mode, the HSM software must be PCI HSM certified and this option must be set to 'YES'.			
If this option is set to 'YES' and all other PCI HSM-relevant settings have PCI HSM compliant values, then it will not be possible to change any of these options without performing a factory reset and reloading the LMKs.			
Enforce Multiple Key Components: YES or NO	YES		
If set to 'YES', all LMK and keys formed in the HSM must be formed from at least 2 different components.			
To operate in PCI HSM compliant mode, the HSM software must be PCI HSM certified and this option must be set to 'YES'.			
If this option is set to 'YES' and all other PCI HSM-relevant settings have PCI HSM compliant values, then it will not be possible to change any of these options without performing a factory reset and reloading the LMKs.			

Security Parameter Description				
Enforce PCI HSMv3 Key Equivalence for Key Wrapping? YES or NO	YES			
If set to 'YES', then a wrapping key must have equivalent or greater strength than the key being wrapped. Additionally, when wrapping using RSA, Pad Mode Identifier '01' (PKCS#1 v1.5 method (EME-PKCS1-v1_5)) cannot be used. Please refer to NIST SP800-57 for definitions of relative key strength and other key wrapping restrictions.				
To operate in PCI HSM compliant mode, the HSM software must be PCI HSM certified and this option must be set to 'YES'.				
If this option is set to 'YES' and all other PCI HSM-relevant settings have PCI HSM compliant values, then it will not be possible to change any of these options without performing a factory reset and reloading the LMKs.				
Enforce minimum key strength of 1024-bits for RSA signature verification? YES or NO	YES			
If set to 'YES', the HSM will not permit RSA signature verification using a key smaller than 1024 bits.				
To operate in PCI HSM compliant mode, the HSM software must be PCI HSM certified and this option must be set to 'YES'.				
If this option is set to 'YES' and all other PCI HSM-relevant settings have PCI HSM compliant values, then it will not be possible to change any of these options without performing a factory reset and reloading the LMKs.				
Enforce minimum key strength of 2048-bits for RSA and ECC? YES or NO	YES			
If set to 'YES', the HSM will enforce the minimum RSA and ECC key sizes mandated by PCI for use with key transport, exchange, or establishment and for data protection in connection with these requirements. It does not enforce the minimum key sizes for non-PCI payment brand relevant transactions (e.g. for Australian AS2805 commands, WebPIN commands, OBKM commands) nor for card issuance commands (including Multos).				
If this option is set to 'YES' and all other PCI HSM-relevant settings have PCI HSM compliant values, then it will not be possible to change any of these options without performing a factory reset and reloading the LMKs.				

3.3.2 NIST SP800-57 and comparable strengths

When 'Enforce PCI HSMv3 Key Equivalence for Key Wrapping' is set to 'YES', the HSM does not allow RSA keys greater than 1024 bits in length to be generated when using a double length 3DES Variant LMK. This is because NIST SP800-57 specifies that a double length 3DES key is equivalent in strength to a 1024 bit RSA key.

The following three settings refer to the NIST SP800-57 comparable strengths:

- 'Enforce PCI HSMv3 Key Equivalence for Key Wrapping': 'YES'
- 'Enforce minimum key strength of 1024-bits for RSA signature verification': 'YES'
- 'Enforce minimum key strength of 2048-bits for RSA': 'YES'

Extract from NIST SP800-57 – Comparable strengths:

Security Strength	Symmetric key algorithms	FFC (e.g., DSA, D-H)	IFC (e.g., RSA)	ECC (e.g., ECDSA)
≤ 80	2TDEA	<i>L</i> = 1024 <i>N</i> = 160	k = 1024	f = 160-223
112	3TDEA	L = 2048 N = 224	k = 2048	f = 224-255
128	AES-128	L = 3072 N = 256	k = 3072	f = 256-383
192	AES-192	L = 7680 N = 384	k = 7680	f = 384-511
256	AES-256	L = 15360 N = 512	k = 15360	f = 512+

3.4 Configure Commands

payShield 10K provides over 400 host commands. Typically, host applications use just 10% of these commands, depending on the payments functionality they are serving. Unused host commands left enabled could present a security risk, so all host commands are disabled at the factory.

Thales recommends that customers enable just those host and console commands which are required. Note that disabled commands are not available until they are re-enabled.


To enable or disable commands, navigate to the **Configuration** tab in payShield Manager and then select **Configure Commands**.



Note that disabled console commands return a "Function Disabled" error and host commands return an Error Code 68.



To view the list of enabled host and console commands, and (if in Secure state) to



enable or disable host and console commands, you can also use the console **CONFIGCMDS** command.

3.5 Configure PIN Block


A PIN Block is a cryptographic transformation of a PIN. It is a PCI requirement that the account number or a related number is included in the PIN Block transformation. There are several methods for PIN Blocks, not all of them are compliant with standards.

To enable or disable PIN Blocks, navigate to the **Configuration** tab in payShield Manager and select **General Settings**; from the general settings, select **PIN Blocks**.

To view the list of enabled PIN Blocks, and (if in Secure state) to enable or disable PIN Blocks, you can use the console command **CONFIGPB**.



The **CL** console can also be used to change alarm settings.



Note that by default, the "weakest" PIN block formats are disabled: Formats 02, 03, 04 & 34.

For additional information about PIN Blocks, see the payShield 10K Programmer's Manual and the payShield 10K Installation and User Guide.

3.6 Configure Fraud Detection

The payShield 10K's fraud detection functions are designed to detect and prevent "brute force" attacks, where, for example, large numbers of PINs are submitted until the correct PIN is discovered.

The detection works by counting the number of failed PIN verifies detected in one minute and in one hour. Each time that these counts exceed specified limits, the PIN Attack Counter is incremented. If the PIN Attack Counter exceeds the specified PIN Attack Limit, then a PIN Attack is assumed.

The fraud detection configuration also determines how the HSM will react. The user can select "On" for full pro-active response to the limits being exceeded, or "Logging Only" in order to record (in the Health Check Data) the limits being exceeded without taking any further action.



An entry is always made in the Audit Log if any of the limits are exceeded.

3.6.1 Configuration Options

f the Logging Only option is selected, then the payShield 10K provides counts of how many times the perminute and per-hour limits have been exceeded and the total number of PIN Attacks detected.

This information is provided as part of the Health Check Data. Initiating the data capture or resetting counts can be done via console command or via payShield Manager.



Note: The term "Logging" refers to capture of the information in the Health Check data. Audit Log entries are always made when the limits are exceeded.

If the "On" option has been selected, then the reporting provided by the Logging Only option is again provided. In addition, if either of the per-minute or per-hour counts exceed the specified limits, the HSM forces all PIN verification commands to return an Error 39 in their response.


The HSM will continue to return Error 39 until the console command **A7** is used to re-enable PIN verification. If the PIN Attack Counter reaches the PIN attack limit, then the HSM will clear the LMKs from it memory. Installing the LMKs will set the PIN attack counter to 0.

The following list specifies the PIN verification host commands to which the limits apply:

- DA Verify a Terminal PIN Using the IBM Method
- **EA** Verify an Interchange PIN Using the IBM Method
- **CG** Verify a Terminal PIN Using the Diebold Method
- EG Verify an Interchange PIN Using the Diebold Method
- DC Verify a Terminal PIN Using the Visa Method
- EC Verify an Interchange PIN Using the Visa Method
- BC Verify a Terminal PIN Using the Comparison Method
- BE Verify an Interchange PIN Using the Comparison Method

To enable fraud detection options using payShield Manager, navigate to the **Configuration** tab, then navigate to **General Settings**, select the **Fraud** tab.

To enable fraud detection, use the console **A5** command. For additional information, see the *payShield 10K Console Guide*.



Thales Group
All Rights Reserved

4 Tamper Protection

Tamper refers to an intentional manipulation of the system in order to attempt to compromise the secrets in the system, or enable unauthorized operation. Tamper protection is accomplished via tamper resistance, detection, and response.

Tamper protection is implemented in three tiers:

- Tamper resistance using a design that makes it difficult for the attacker to attempt to access the secure area of the payShield 10K. This is done partially using physical characteristics such as using toughened materials, or providing no path that can be used by probes to make contact with the electronics inside the HSM.
 - However, an HSM cannot prevent all attempts at physical access to its internal components. An HSM that could resist high-performance drills, gunshots, explosives, chemical attacks, oxyacetylene cutting torches, etc., would be so expensive, large, and heavy that it would not be a practicable proposition for potential users.
- 2. Tamper detection any tamper activity should be detected by the HSM. Detected tamper attempts must be evident to the owner of the HSM.

For example:

- payShield 10K has a permanently locked lid. Removal of the lid will put the payShield into a tampered state
- Detected tamper attempts are recorded in Error and Audit Logs
- LEDs are illuminated on the front panel of the payShield 10K to indicate a tamper has occurred
- Tamper responsiveness the payShield takes actions in response to a detected tamper event to
 ensure that the secret data being protected by the HSM cannot be accessed by attackers even
 where they have gained access to the internal components of the HSM.

This chapter focuses on the tamper protection and responsiveness of the payShield 10K.

4.1 Tamper Responsiveness

4.1.1 Types of Tamper Actions

A payShield 10K may be subjected to the following types of tamper attempts:

- 1. Physical access to the components inside the HSM.
- 2. Environmental changes
- 3. Intended erasure of Customer Key Material
- 4. Fraud Attack

These are discussed in the sections that follow.

4.1.1.1 Physical Access

An attacker may attempt to gain physical access to the components inside the HSM, for example, to attach probes to data paths or microchips in order to read data. This may be attempted by removing or bending the lid, or by drilling or cutting through the casing to reach the circuit boards inside the casing.

The payShield 10K can detect removal or partial removal of the lid, distortion of the lid, and physical access to the secure components of the HSM.

On detection of such an attempted tamper, the payShield 10K will enter the tamper state, as described in a later section.

4.1.1.2 Environmental Changes

An attacker may attempt to change environmental conditions, such as temperatures or voltages, in order to affect the operation of the HSM. The payShield 10K will detect such actions. The temperature sensor is described in more detail later in this chapter.

An attacker may also try to remove an HSM and take it to a workshop or to another location, where they can attempt attacks at their leisure. To thwart this threat, the unit is designed with a locking mechanism. When the unit is placed in either the Online or the Offline state, the mechanism engages and the unit is physically locked to the rack/cabinet. In addition, the payShield 10K has a configurable motion sensor that detects if the unit is being moved. The motion sensor is described in more detail later in this chapter.

On detection of such an attempted tamper, the payShield 10K will enter the tamper state, as described in a later section

4.1.1.3 Intended Erasure of Customer Key Material

A payShield 10K operator can voluntary trigger a tamper condition on the HSM, by inserting a probe into the "Erase" hole on the rear of the HSM. This might be done, for example, if the operator believes some kind of attack is being launched somewhere on their system and they want to rapidly disable the HSM.

On detection of such a voluntary tamper, the payShield 10K will enter a tamper state, as described in a later section.

4.1.1.4 Fraud Attack

Whereas the preceding tamper actions require physical access to the payShield 10K, a Fraud Attack could be launched from any computer that can communicate with the HSM.

A Fraud Attack is essentially a brute force attack to uncover PINs. By issuing a sequence of commands to the HSM to verify a PIN, the attacker can keep trying different PINs until they receive a positive PIN verification response to indicate that the PIN is correct.

The payShield 10K offers an optional Fraud Detection mechanism to protect against this type of attack.



For additional discussion, see Section 3.6, Configure Fraud Detection.

4.2 Tamper States

There are two levels of Tamper on payShield 10K:

- Medium tamper This tamper type indicates that the unit is experiencing persistent failures or abnormal conditions, and may no longer be able to ensure its security state. This may be an indication that the unit is under attack or is compromised. When this level of tamper is detected, the HSM erases all sensitive customer data.
- High tamper This tamper type indicates that the unit is no longer able to protect itself with
 assurance, and should be removed from service. There is a likelihood that the unit is under attack,
 has already been compromised, or has experienced a failure of a security-relevant component.
 When this level of tamper is detected, the HSM erases all sensitive data and permanently disables
 use of the unit.

4.2.1 Medium Tamper

When the payShield 10K detects a medium tamper attempt, it will:

- 1. Delete the HSM's customer-specific secrets.
- 2. Re-start the HSM.
- 3. Make an entry in the Error Log.
- 4. Illuminate the "Tamper" LED on the front panel of the payShield 10K; the LED will extinguish when the cause of the tamper is removed.
- 5. Turn the "Health" LED on the front panel of the payShield 10K red.
- 6. If Health Check Counts have been enabled, increment the tamper count.

As described above, detection of a medium tamper results in deletion of the HSM's secrets (depending on user settings, in the case of Fraud Attacks). The secrets that will be deleted are:

- Local Master Keys (LMKs)
 - The LMKs are stored in the HSM and used to encrypt all the keys that are protected by the payShield 10K, and some other data such as PINs and Decimalization tables. If the LMKs are deleted, the HSM can no longer decrypt any protected data and essentially becomes inoperative.
 - To re-enable the payShield 10K, the LMKs must be re-installed from components held on smartcards; this requires the co-operation of multiple (usually three) officers, ensuring that the HSM is not re-enabled until the cause of the tamper has been investigated.
- · Private keys
 - Private keys are used for capabilities such as payShield Manager and Secure Host Communications. To re-enable these capabilities, the Private keys must be re-loaded by using the HSM Recovery Key (HRK). (For additional information, refer to the payShield 10K Installation and User Guide.)

4.2.1.1 Recovering from a Medium Tamper

No attempt should be made to return the payShield 10K to an operational state until an appropriate incident management process has been followed to investigate the cause of the tamper, and determine whether a true attack took place and whether the attack was successful.

The LED indicators will show the following:

- 1. If the "Tamper" LED is still illuminated, the cause of the tamper state is still present and the payShield 10K should not be put into service.
- 2. The "Health" LED will turn red after the automatic restart, indicating that there are new Error Log entries that have occurred since the Error Log was last viewed. These new entries (which will include those resulting from the tamper detection) should be viewed, and the cause of the tamper identified and any appropriate action taken. Viewing the Error Log will cause the "Health" LED to return to normal (white).



When all investigatory and corrective actions have been taken, the LMK(s) must be reloaded. Where multiple LMKs are being used, they should be loaded into the same "slots" or IDs that they occupied before the tamper event.

Where the medium tamper condition arose from the Fraud Detection facility, PIN verification processing must be re-enabled by using the A7 console command. If a medium tamper state cannot be cleared or tamper states recur without apparent reason, users with support contracts should contact their support provider.

Only if you are confident that the payShield 10K has not been compromised should you return it to production use by:

- Re-installing LMKs
- Confirming that security settings have the correct values
- · Confirming that the correct host/console commands are enabled
- · Confirming that the correct PIN Block formats are enabled
- Confirming that the appropriate alarms are set
- Confirming that the host/management/console port settings are correct

4.2.1.2 Error Log Entries

When a tamper is detected, an entry is made in the payShield 10K's Error Log; this will in turn cause the "Health" LED on the front panel of the payShield 10K to turn red.

4.2.2 High Tamper

When the payShield 10K detects a high tamper attempt, the response is fundamentally the same as in the medium tamper response, with the following differences:

- 1. Delete all HSM's secrets, rendering the unit non-functional.
- 2. Re-start the HSM. The HSM will boot into a restricted Boot Manager.
- 3. Illuminate the "Tamper" LED on the front panel of the payShield 10K.
- 4. Turn the "Health" LED, on the front panel of the payShield 10K, red.
- 5. If Health Check Counts have been enabled, increment the tamper count.

As noted above, when a high tamper response occurs, all secrets in the unit, including customer keys, private keys for secure communications, and the HSM Recovery Key, are all deleted. In addition, the unit will boot only to a Boot Manager application, available via the console prompt. Code updates and other recovery actions are not possible. payShield Manager will no longer be able to connect to the machine. The payShield application will not boot.



The payShield never recovers from a high tamper state and the unit must be returned to Thales for disposal, or be disposed of by the customer.

4.2.2.1 Error Log Entries

As mentioned, with a high tamper, the payShield 10K loads into a Boot Manager application, as such, there is error information available to allow for a root cause analysis.




4.3 Temperature Sensor

4.3.1 Description

The payShield 10K is built around a secure cryptographic module called the Thales Advanced Security Platform (TASP). This provides the core of the security for the payShield 10K and is where all the processing occurs and all the sensitive material is held. The TASP is certified to FIPS 140-2 Level 3.

The TASP incorporates a temperature sensor. This is designed to detect an operational environment which could result in unreliable performance of the security processing within the payShield 10K, and if triggered, it will result in a tamper state. The temperature alarm cannot be disabled by users and is permanently enabled, as can be seen in payShield Manager Configuration / General Settings / Alarms:



The temperature sensor is active even if the payShield 10K

is disconnected from an electric power supply; in this environment, the temperature sensing capability is maintained by the payShield 10K's internal battery, and will still initiate LMK deletion and tamper state.

4.3.2 Triggering of the Temperature Sensor

If the monitored temperature falls outside of predefined limits, the temperature sensor will initiate a tamper response, causing the LMKs to be deleted and the unit will automatically reboot and attempt to clear the tamper state. If the alarm condition persists, the unit will stop attempting to clear the tamper after 2 attempts and will remain powered on with limited functionality, such that LMKs cannot be loaded. Deletion of the LMKs prevents the payShield 10K from executing host commands or console commands, which require an LMK to be present.

Once the stimulus that triggered the alarm has ended, the payShield 10K will need to be rebooted to clear the tamper state and allow the LMKs to be reloaded.

An entry will be made in the payShield 10K Error Log and the "Health" LED, on the front panel of the payShield 10K, will be illuminated to indicate that there is a new Error Log entry.

4.4 Motion Sensor

4.4.1 Description

The payShield 10K incorporates a motion sensor to allow operators additional protections against physical attacks in their operational environments, (e.g., removal from a rack). The user can configure the motion sensor for one of four settings:

- Off
- Low
- Medium
- High

The motion sensor, when enabled, uses an accelerometer to detect tilt in either the x or y axis, i.e., tilt, with variation in sensitivity controlled by the low, medium, and high setting. The motion sensor, if enabled, is active with/or without mains power due to the internal battery.

4.4.2 Sensitivity of the sensor

The motion sensor has 4 settings which are described below:

Motion Sensor Setting	Minimum Activation Tilt Angle (x or y axis)	Maximum Activation Tilt Angle (x or y axis)
Off	Disabled	Disabled
Low	8°	12°
Medium	4°	8°
High	1°	3°

Activation of the motion sensor is considered a "medium tamper" event which triggers several actions including erasure of the LMKs.

The sensor logic includes a high pass filter to remove very low frequency and static acceleration. The gravity acceleration vector is automatically adjusted to account for any slight tilt due to the unit not being perfectly level.

The logic also avoids triggering of the alarm by a sudden and short shock (e.g., someone bumping into the rack). An acceleration event occurs if the acceleration thresholds above are exceeded for 2 consecutive sampling periods (of 25 milliseconds each). For the alarm to be triggered, 12 acceleration events must be recorded over a period of 1.5 seconds.

4.4.3 If the Motion Sensor is activated

If a motion event exceeding the selected threshold level occurs, the motion sensor will initiate a tamper alarm causing the LMKs to be deleted and the unit will automatically reboot and attempt to clear the tamper state. Deletion of the LMKs prevents the payShield 10K from executing host commands or console commands, which require an LMK to be present.

Because a motion is a transient event, the payShield 10K will normally reboot and clear the tamper state (but the LMKs will still be deleted, of course). If the unit detects an additional motion event after the reset, it will go through the tamper process again.

An entry will be made in the payShield 10K Error Log and the health LED on the front panel of the payShield 10K will turn red to indicate that there is a new Error Log entry. The Tamper LED on the front panel will turn red, indicating a tamper.

4.4.4 Enabling the Motion Alarm

By default, the motion alarm is disabled when the payShield 10K is shipped by Thales. This is to prevent the unit entering a tamper state prior to delivery to the user as a result of movement during shipping.


This means that users must actively enable the motion alarm in order to benefit from the additional security

that this offers. This can be done by using:

The CL Console command, by entering "L", "M", or "H" to indicate the desired sensitivity level after the prompt: "Motion Alarm [Low/Med/High/ofF] (OFF):".

The Alarms dialogue box in the payShield Manager (General Settings tab in the Configuration section menu) provides a selection box with the Motion Alarm sensitivity options.

Full details are available in the payShield Manager 10K Installation and User Guide.



5 TLS for Host Connections

5.1 Introduction

payShield 10K supports the use of TLS to secure traffic to applications using the host port.

This chapter provides a general description of TLS and the implementation in payShield 10K. The security recommendations for TLS are provided in Appendix C –TLS Security Recommendations and detailed description is provided in the Installation and User Guide.

5.2 General Description

TLS provides a high level of security for sessions between an Ethernet connected client application and server application with no prior knowledge of each other and without any prior exchange of encryption keys. A mutually trusted third party (the CA, or Certificate Authority) is used to certify that the client and server are the owners of their respective private and public key pairs used in establishing the communication session.

This trusted environment provides:

- 1. Authentication the server may authenticate itself to the client (typically a browser), or the client and server may mutually authenticate themselves to each other.
- 2. Privacy the communications traffic is encrypted.
- 3. Integrity assurance using hash and signature algorithms.



Note that TLS works between applications. This means that both communicating applications must be TLS-enabled, rather than the host and client devices. Proxies can be implemented to allow non-TLS-enabled applications to be used over a TLS-protected link; here, the authentication is from/to the proxy rather than the application.

5.3 TLS for Host Connections on payShield 10K

payShield 10K provides support for client-server TLS for applications connecting to payShield 10K using the host port. Further details are provided in this section, but some key points are:

- payShield Manager provides the facilities to manage the Host TLS, client, Intermediate CA and CA certificates required to establish TLS sessions. Console commands are also provided.
- payShield 10K supports TLS v1.2.
- payShield 10K can simultaneously support TLS and non-secured (TCP or UDP) traffic. It is possible
 to disable all TLS or non-secured traffic.
- The client certificates must be installed on payShield 10K providing a "Whitelist" of applications that are entitled to use the HSM.

5.3.1 Host TLS Certificates

The Host TLS key pair for the HSM is created by the HSM.

An unencrypted copy of the private key is held in tamper-protected memory, and the HSM Recovery Key (HRK)-encrypted copy is held in non-volatile memory.

The HSM generates a Certificate Signing Request (CSR) containing its public key in PKCS#10 format. A security officer will generate a certificate signed by their chosen CA and return the public key certificate and CA's certificate chain to the HSM.

Intermediate CA certificates can be included to a maximum certificate chain depth of 6.

5.3.2 Client Certificates

Each application that wishes to establish a secure communications session using TLS needs to provide to the payShield 10K a public key in the form of a certificate signed by a CA (or by a hierarchy of CAs). The way that this certificate is obtained depends on the standard procedures of the organization and its selected CA mechanism.

The set of client endpoint certificates forms an effective "Whitelist" of applications that are entitled to use the HSM through TLS. This is used by the payShield 10K to mitigate against "man-in-the-middle" attacks.

If the clients are using a different CA to the HSM, the HSM's CA certificate also needs to be imported by the security officers to the client's applications.

Intermediate CA certificates can be included to a maximum certificate chain depth of 6.

5.3.3 Supported Cipher Suites

Please refer to Appendix C -TLS Security Recommendations.

5.3.4 Cipher Suite Negotiation

When negotiating Cipher Suites, the HSM's preferences will take precedence over the client's preferences.

Ephemeral key cipher suites are preferred by the payShield 10K. When selected, every new handshake will require new ephemeral keys to be generated; this provides perfect forward secrecy such that if an attacker should ever break the cryptography being used for a connection, then this will be of no use to the attacker in a subsequent connection.

When performing a renegotiation of an existing connection, the payShield 10K will always force a new session to be negotiated; this protects against a known renegotiation vulnerability.

Connections will not use data compression, protecting against the CRIME vulnerability.

5.3.4.1 Out-of-Date Certificates

If an attempt to establish a Secure Host Communications session is made using an out-of-date (i.e., expired or not yet valid) certificate, the connection fails. As a result, it is important for users to have suitable processes in place to manage certificate introduction and expiry.

As an option, users can audit attempts to use out-of-date certificates.

5.3.4.2 Security Considerations

TLS can only provide a secure environment when implemented correctly. Please refer to Appendix C which details the security recommendations.

5.3.4.3 FICON Interface

Please note that FICON does not support the use of TLS, so TLS cannot be configured for use on the FICON interface.

5.3.4.4 HSM Recovery Key (HRK)

The HSM Recovery Key (HRK) is used to encrypt the Host and Management TLS private keys and the in establishing the TLS sessions.

The HRK-encrypted private key is held outside of the tamper-protected memory such that if the HSM detects a tamper event it is not lost; the unencrypted private key used during live running is held in tamper-protected memory and is lost if the HSM detects a tamper event. The private keys can therefore be recovered after a tamper event, once the HRK is installed, by decrypting the encrypted version.

Two different passphrases are required for the HRK, each entered by a different security officer. These passphrases must be stored securely (in the same way as key components) to allow subsequent HRK recovery if the HSM enters a tampered state. The passphrases must be of an acceptable complexity.



It is important to note that both the encrypted and unencrypted copies of the HRK are held within the payShield 10K tamper protected physical boundary.

6 Secure LMK Management

At least two copies should be made, one for storage onsite and one for offsite.

Serious consideration should be given to the creation of extra copies to provide a greater level of resilience against the failure of any one smartcard. Copies of the same card made for resilience against card failure can be kept together.



AT NO TIME SHOULD ANY ONE PERSON HAVE GAINED ACCESS TO MORE THAN ONE COMPONENT SET.

LMKs in the unit can be verified and the LMK Component Sets on the smartcards can be checked. It is recommended that:

- LMKs in the HSM are verified at 6-month intervals
- LMKs on smartcards (including all the spare copies) are checked at 12-month intervals
- LMKs are changed at 2-year intervals. This ensures that the procedures required for the change are regularly exercised and updated where necessary.

LMKs (in particular, "old" LMKs) MUST be deleted from the HSM when no longer required.

6.1 Verifying the Contents of the LMK Store

The LMKs installed in the HSM should be checked periodically.





The payShield is in the Secure state.

To display the current LMKs installed in the Local Master Key table and Key Change Storage table using payShield Manager,

- Navigate to: Summary > Local Master Key
- · The system displays both tables.

The original and duplicate LMK Component Set smartcards should be individually checked periodically – to confirm that they work correctly with an HSM and produce the same check values.





To inspect a smartcard using payShield Manager:

- · Select the card icon.
- The system displays two options.
- Select Inspect Smart Card
- The smart card details page displays.



(The **V** and **NC** console commands provide the equivalent functionality.)



Serial Number	7307001107072979
Certificate Number	04C4CDE8AEDDBE66
Version	1.03
Warranted	Yes
Bonded	No
Commissioned	Yes
Has Security Domain Share	No
Has LMK Share	No
Has HSM Settings	No
Has PIN	Yes
Is PIN Blocked	No
Is PIN Change Required	No

6.2 Loading the Test Keys

It is a good security practice to ensure that the LMK pairs used in the operational system are not used during test operations. It is useful to have a set of known Test LMKs to simplify cryptographic fault-finding. It also helps the manufacturer to diagnose cryptographic problems if they know the LMK pairs.

Customers are provided with a means to generate three test LMK cards.




The payShield is in the Secure state.

To generate and install a test LMK using payShield Manager,


- Navigate to: Operational > LMK Operations
- Select Generate
- Expand Generate LMK and select Generate Standard Thales Test LMK
- Select the type from the drop down follow prompts
- Select Generate LMK follow prompts
- Select Install follow prompts



(The **LK** console command provides the equivalent functionality.)







Refer to the *payShield 10K Installation and User Guide* and to the *payShield 10K Host Programmer's Manual* for additional information regarding loading and managing LMK cards.

7 The Audit Log

7.1 Introduction

The payShield 10K provides an audit logging capability, enabling security officers to select a number of activities and functions whose usage is recorded in an audit log. Certain items are always recorded in the Audit Log, and this cannot be disabled.

The purpose of the Audit Log is to enable security officers to make regular checks on security-related actions that the payShield 10K is being asked to perform, and to assist in forensic examination of any suspected security breaches.

The Audit Log also provides facilities for its entries to be viewed, printed, and archived to a host computer.

This chapter describes the capabilities and usage of the payShield 10K Audit Log. Information on managing and using the Audit Log are given in the *payShield 10K Installation for and User Guide* and the *payShield 10K Console Guide*.

With Semantic Versioning changes in 1.0e, there is a change to the firmware upgrade audit log.



When upgrading from 1.0d to 1.0e, the following audit log is generated:

0000000141 13:38:54 12/Mar/2020 Firmware update to 1500.0021.0000 (uboot 0001.0001.0040) successful

Note that the above log is generated by the 1.0d firmware prior to the reboot and revision number is used for the audit log.

With 1.0e and later, the audit log is generated using the firmware version with 1.0e and later.

7.2 Overview

The Audit Log is held securely in non-volatile memory in the payShield 10K; it survives power cycling, payShield 10K restarts, tamper attempts, and software upgrades. It always records certain events and use of functions. In


It always records certain events and use of functions. In addition, security officers can elect to log other events and functions.

The Audit Log can be viewed, printed, erased, and retrieved or archived to a host computer. It can record 100,000 items. When the audit log is filled, the earliest entry is deleted to allow the most recent entry to be added. It is therefore important that entries are archived to a host computer frequently enough such that the Audit Log does not get filled. The frequency with which this needs to be performed will depend on how many items are being recorded.

A message authentication code (MAC) is associated with each individual audit entry, enabling easy detection of any fraudulent attempt to modify the audit record.



Follow this link for an analysis of log messages: Appendix D – Audit Log Messages.



7.3 Correct Use of the Audit Log

The audit log has been designed to capture information which will be examined when investigating any potential security issues; it is not intended for use as a general log of what the HSM is being used for, for example by logging all host commands (which can impact on performance). Audit Log entries should be reviewed at regular and frequent intervals to allow:

- Any necessary actions to be taken
- Any records that need to be retained for future reference to be printed or archived to the host system
- · The Audit Log to be cleared



It is important that the Audit Log is kept as small as possible to optimize performance. It is particularly important that the Audit Log is not allowed to reach its maximum size.

Logging high-frequency events which correspond to normal usage of the HSM and which have no significance in terms of security introduces a number of problems:

- Creating too many records to allow significant records to be found and interpreted
- Causing loss of audit records if the audit log capacity is exhausted before the audit records have been archived
- Negatively impacting performance, because of the additional processing required to create and
 record audit records, especially when the audit log capacity is exhausted and the log needs to be
 "rotated" (i.e., the oldest record deleted to allow the new record to be added).

It is recommended that as few host commands as possible are audited; error responses to host commands may well be indicative of a security threat, and the audit options allow such responses to be logged without having to audit normally executing host commands.

7.4 Forcibly recorded items

A number of items are always recorded in the Audit Log; this cannot be disabled.

7.5 PCI HSM Compliance

Most of these forcible recorded items were introduced to meet requirements of PCI HSM certification. These items are:

- Use of smartcards to authenticate users to the payShield 10K or payShield Manager. The serial number of the smartcard is recorded as part of the Audit Log record.
- Use of the A and C console commands to initiate and cancel authorization of activities. The Audit Log entry shows for how long the activity was authorized.
- Use of the following console commands or the equivalent payShield Manager actions. The Audit Log records made in this way will indicate the successful completion of the command:

Console (Command
CV	Generate a Card Verification Value
FK	Form Key from Components
IK	Import a Key
LK	Load LMK
LO	Load 'Old' LMK into Key Change Storage
LN	Load 'New' LMK into Key Change Storage
PV	Generate a Visa PIN Verification Value
UPLOAD	Upload new firmware/license
BK	Form a Key from Components
D	Form a ZMK from Encrypted Components
DE	Form a ZMK from Clear Components
IV	Import a CVK or PVK

7.6 Recording Deletion of Audit Log

The Audit Log will include a record to indicate that the Audit Log has been erased.

7.7 Discretionary Audit Log entries

It is possible to request that any of the following events are recorded in the Audit Log:

Use of combination of any console commands or payShield Manager actions. The Audit Log records
made in this way will indicate the initiation of the command rather than its successful completion.
This is different to the way that a forcibly audited command would be recorded, where the successful
completion of the command/action is recorded.

Auditing activity on host ports:

- Use of any desired selection of host commands. As discussed, this facility should be used carefully to avoid logging of high volumes of host commands which are executing normally; it is generally better to log just error responses, as these may well be indicative of a security issue.
- · Receipt of an error response to a host command
- Failures to establish host connections arising from the Access Control List (ACL)
- Attempts to use out-of-date certificates when trying to establish Secure Host Communication sessions

User actions:

- · Clearing of Audit Log
- Loading an LMK or an Old/New LMK
- Erasing an LMK or an Old/New LMK
- · Loading a license file successful
- Loading a license file failed
- · Change of state
- Power cycle
- Resetting of Utilization Data
- Results of automatic daily self-tests indicating whether the tests were successful or identifying any specific tests that failed

7.8 Protection of the Audit Log

The payShield 10K provides a number of features specifically aimed at protecting the Audit Log:

- Each Audit Log record is MAC'd using a unique MACing key protected by the LMK. A host command is available to allow the MAC to be verified at a later time.
- Audit log entries can be archived by printing to a printer attached to the payShield 10K
- Audit Log entries can be retrieved to the host system for secure electronic archiving
- Console actions to configure or delete the Audit Log require Authorization using the Management LMK. Equivalent actions on payShield Manager require Security Officers to be logged on.
- Host Commands to delete Audit Log records must be authorized
- Deletion of the Audit Log always results in a record of this event being added into the otherwise now blank Audit Log.

8 Shipping and Product Handling

This section describes Thales' understanding of the PCI HSM Version 3.0 standard and its impact on shipping and receipt by the user.

Thales is not qualified to provide advice on PCI standards and so readers must make their own judgements as to proper courses of action to take or discuss their intentions with a PCI QSA.

This section also provides suggestions as to how users should manage the payShield 10K after it has been delivered to them. The PCI HSM standard is not explicit in this area, but certain clarifications have been received and are included in the information provided below.



Warning: The information in this section is not intended to constitute security or standards compliance advice and should not be relied upon in lieu of consultation with appropriate technical security and audit compliance advisors in your own area of operations.

8.1 Responsibilities

Any organization, which is involved in arranging the shipping (whether for the whole journey, or a "leg" of a multi-part journey) of an HSM which is to be PCI HSM compliant, must ensure that the shipping is conducted in a manner which is compliant with the requirements of the PCI HSM standard as described here in.

The table below outlines a number of common delivery scenarios and shows which party has responsibility for which section of the payShield 10K's journey. It is important to understand that Thales' resellers are distinct organizations from Thales, and that Thales does not have responsibility for the shipping "legs" organized by the resellers.

Scenario	Responsible party	Extent of reesponsibility
Thales arranges shipping from manufacturing facility direct to end user	Thales Manufacturing Facility	Complete journey, until receipt of payShield 10K is signed for by the end user.
Thales arranges shipping from its manufacturing facility to a Thales regional office, and that Thales regional office	Thales Manufacturing Facility	Up to receipt of payShield 10K by the Thales regional office.
arranges shipping to the end user.	Thales regional office	From receipt of the payShield 10K until receipt of the payShield 10K by the end user.
Thales arranges shipping from its manufacturing facility to another Thales regional office, then that Thales regional office arranges shipping to a reseller, and	Thales Manufacturing Facility	Up to receipt of payShield 10K by the Thales regional office.
	Thales regional office	From receipt of the payShield 10K until receipt of the payShield 10K by the reseller.

Scenario	Responsible party	Extent of reesponsibility
the reseller arranges shipping to the end user.	Thales reseller	From receipt of the payShield 10K until receipt of the payShield 10K by the end user.
Thales arranges shipping from its manufacturing facility to a reseller, and that reseller arranges shipping to the end user.	Thales Manufacturing Facility	Up to receipt of payShield 10K by the Thales reseller.
	Thales regional office	From receipt of the payShield 10K until receipt of the payShield 10K by the end user.
Reseller arranges collection of payShield 10K from Thales manufacturing facility and then onward-ships to the end user.	Thales reseller	Complete journey, until receipt of payShield 10K is signed for by the end user.
End user arranges collection of payShield 10K from Thales manufacturing facility.	End user	Complete journey.

The PCI HSM standard discusses delivery of the HSM to the "facility of initial deployment". (The version 1.0 requirements used the term "initial key loading facility".) It does not explicitly place any requirements on the end user where the point of receipt by the end user organization is not the place where the first LMK will be loaded. However, Thales recommends that the end user organization implements the controls described later in this section.

8.2 PCI shipping requirements

The PCI Security Standards Council HSM standard for shipping of payment HSMs is described in the following document:

Payment Card Industry (PCI) Hardware Security Module (HSM) Security Requirements
 Version 4.0 Section: M – Device Security Requirements Between Manufacturer and Point of
 Initial Deployment.

Links to this document can be found in the following PCI press release:

https://www.pcisecuritystandards.org/about_us/press_releases/pci-security-standards-council-updates-hardware-security-module-standard/

9 Information for Security Auditors

9.1 Certifications

9.1.1 NIST Cryptographic Module Validation Program (CMVP) – FIPS 140-2

The payShield 10K incorporates a secure cryptographic module - the Thales Advanced Security Platform (TASP). Processing and storage of sensitive material is undertaken by the TASP which has completed certification at Level 3 of the FIPS 140-2 security standard. Details of the certificate is provided below:

- Link to FIPS 140-2 Level 3 certificate: https://csrc.nist.gov/projects/cryptographic-module-validation-program/certificate/3610
- Module Name: Thales Advanced Security Platform (TASP), certificate number 3610
 The versions approved are as follows. The Hardware version is shown on the product label and the Firmware version is displayed in payShield Manager or using the 'VR' Console Command:
- Hardware: FIPS Rev: 1.1 and FIPS Rev: 1.2
- Firmware: Bootstrap Versions 1.1.22, 1.1.29 and 1.1.40

Note that one of the versions of firmware listed above is included in each payShield 10K base software base or custom software release.

See: Section 9.2, References.

9.1.2 NIST Cryptographic Algorithm Validation Program CAVP

The random number generator and cryptographic algorithms implemented in payShield 10K are NIST CAVP approved. The approved implementations are included in payShield 10K Software and are listed below together with the certificate number. The versions can be verified by using the 'VR' Console Command from payShield Manager or when using the local Console.

• Link to certificates: <a href="https://csrc.nist.gov/projects/cryptographic-algorithm-validation-program/v

The certificates for all payShield 10K models except payShield 10K Special Edition are:

Algorithm	Validation Number
TASP-DRBG and ECC	A1991
TASP-GCM	C445
TASP-SHA	C446
TASP-AES	C444
TASP-AES-ACCELERATED	C450
TASP-TDES	C451
TASP-TDES-ACCELERATED	C452

Algorithm	Validation Number
TASP-RSA	C453
TASP-CMAC	C455
TASP-CCM	C456
TASP-HMAC	C457

The certificates for all payShield 10K Special Edition (Ref. 971-000109-001) are:

Implementation	Validation Number
TASP-ECC-SE, TASP-DRBG-	A1992
SE and TASP-RSA-SE	
TASP-GCM	C445
TASP-SHA	C446
TASP-AES	C444
TASP-AES-ACCELERATED	C450
TASP-TDES	C451
TASP-TDES-ACCELERATED	C452
TASP-CMAC	C455
TASP-CCM	C456
TASP-HMAC	C457

See: Section 9.2. References.

9.1.3 PCI HSM

payShield 10K hardware and specific software versions have undergone certification to the PCI HSM Version 3 standard. The versions of the hardware that are certified are given below and the hardware versions can be verified on the product label – the version is also shown using payShield Manager or by using the VR Console Command. The hardware versions approved are given below:

Versions of hardware approved:
 PCI Rev: 01, 1.0 and 1.1

• Approval number: 4-40266

The certificate identifies the specific hardware and software (i.e., firmware) versions which are covered by the certificate. See: *Section 9.2, References*.

9.1.4 Australian Payments Network (AusPayNet)

payShield 10K hardware and specific versions of software are AusPayNet approved. Details are shown on the AusPayNet website. See: *Section 9.2, References*. Note that AusPayNet was previously referred to as APCA.

9.1.5 Cartes Bancaires SAFIRE Evaluation

payShield 10K is currently undergoing evaluation for approval for connection to the Cartes Bancaires payment network in France. The new "SAFIRE" evaluation method is now used (Security Assurance through FIRmware Evaluation). This replaces the MEPS2 method used historically.

9.1.6 GBIC (German Banking Industry Committee) / ZKA (Zentraler Kreditausschuss)

Systems processing German domestic payment cards using the Girocard network must be approved by the security committee of the German Banking Industry Committee (GBIC). Note that GBIC was formerly referred to as ZKA.

payShield 10K has now been evaluated by GBIC and is now approved for use with a in the Girocard Network as follows:

- When using a TDES Master Key, payShield 10K Software v1.6a or above is required.
- When using an AES Master Key, payShield 10K Software Firmware Version 1.11.4 (1.7b) is required.

In addition the following specific conditions must be met:

- 1. The HSM has to be operated in a server safe or robust rack which is installed in a secure environment according to [ISO 13491-1] controlled by an alarm system. The server safe or rack must be equipped with two independent locking mechanisms to ensure the dual control access.
- 2. The HSM is fixed in the server safe or rack using the two lockers at the front panel. The necessary keys have to be given to separate security officers.
- 3. A subsequent and unauthorised installation of software into the HSM has to be excluded.
- 4. The two smart cards, used to activate the administration service by the security officers, have to be stored in separate safes or safe deposit boxes to guarantee access control according to the principles of at least dual control and split knowledge.
- 5. The remote system (HSM Manager) used for the input of keys has to be kept locked in a safe in a secure environment.
- 6. The LMK of the HSM has to be an AES key and to be deleted reliably whenever the HSM is removed from its secure environment for purpose of repair or maintenance.
- 7. The HSM has to be operated within a separated network segment, either physical or logical.
- 8. The security officers are responsible for the correct installation and for setting the correct usage of cryptographic keys.
- 9. The security settings command "Restrict Key Check Values to 6 hex chars" has to be activated.
- 10. The security setting "Return PIN Length in PIN Translation Response" must be set to NO.
- 11. The security setting "Enable PIN Translation to BDK Encryption" must be set to NO.
- 12. For Command G0 a fixed/static key must not be used as Destination Key.

In addition it is important to note that in order to comply with the GBIC requirements in v1.6a Host Command 'A0' has been updated to restrict the mode of use that can be specified for the keys that are derived from the ZKA Master Key as described in the Release Note and in the Core Host Command Manual. This change is NOT backward compatible and therefore host applications MUST be updated if necessary to support the new restrictions.

The security report on payShield 10K for use with a TDES Master Key is listed by GBIC under the number 3545.

Note also that in order to comply with the requirements of GBIC, a separate evaluation is typically required of the system in which the payShield 10K is installed.

9.1.7 Bancontact (Belgium)

Bancontact in Belgium provide payments solutions for individuals and businesses in Belgium. They manage the standards for the Bancontact debit card used widely in Belgium and specify their own standards for key management. payShield 10K provides the host commands required to support these standards. The host commands are N6 (Import Bancontact Session Key) and N8 (Export Bancontact Session Key) - these are detailed in the Core Host Command Manual. These have been approved by Bancontact and payShield 10K holds a certificate as an HSM provider and is listed on the Bancontact website. For details please see the link in *Section 9.2, References*.

9.2 References

Follow the links in the table below to find additional support documentation.

To find:	Link	Notes
NIST CMVP FIPS 140-2 certificate	https://csrc.nist.gov/projects/cryptographic-module-validation-program/certificate/3610	National Institute of Standards and Technology (NIST) Computer Security Resource Center
NIST CAVP Algorithm certificates	https://csrc.nist.gov/projects/cryptographi c-algorithm-validation- program/validation- search?searchMode=implementation≺ oduct=TASP&productType=-1&ipp=25	PCI Security Standards Council
PCI HSM Version 3	https://www.pcisecuritystandards.org/popups/pts_device.php?appnum=4-40266	PCI Security Standards Council
APCA IAC Approved devices list	https://approved- devices.auspaynet.com.au/registereddev iceslist?cmd=search&x Company=&x S tandard=&x ApprovalClass2=&x Device Name=&x Version=&psearch=Thales&p searchtype=OR	Scroll down the displayed page to locate Thales
Bancontact HSM Provider Certificate Holder confirmation	https://www.bancontact.com/en/partners	Scroll down the displayed page to locate Thales under the "Certificate holders – HSM Provider" section

10 Appendix A - Security Recommendations

10.1 Introduction

This appendix is provided as guidance for the development of policies and systems, including countermeasures to threats and the mitigation of risks. These must exist in order to provide an appropriate environment for PayShield 10Ks. In some cases these are related to the functionality provided by the HSM itself.

This appendix is not intended to provide a definitive list of requirements for HSM operation. It should be read in conjunction with audit requirements and mandates from organizations and authorities relevant to the specific application and environment in which a HSM is being used.

This appendix uses the terms:

MUST This word means that the definition is an absolute requirement to achieve an acceptable overall level of risk;

MUST NOT This phrase means that the definition is an absolute prohibition of the specification to achieve an acceptable overall level of risk;

SHOULD This word means that there may exist valid reasons in particular circumstances to ignore a particular item, but the full implications must be understood and carefully weighed before choosing a different course;

SHOULD NOT This phrase means that there may exist valid reasons in particular circumstances when the particular behavior is acceptable or even useful, but the full implications should be understood and the case carefully weighed before being implemented.

10.2 Procedural Security

A system employing an HSM can only operate securely if the HSM's environment provides the procedural security that it requires, and if the HSM's security enforcing functions are utilized appropriately. Careful consideration needs to be given to the tasks for which individual HSMs are configured and used to ensure that contradictory security requirements are avoided.

Note the requirements for procedural security are likely to extend beyond the Secure Area within which the HSM is used operationally (see the section "<u>Measures to Protect HSM Secure Area</u>), and are likely to include every aspect of an operation that contributes to the continuous secure management of HSMs and the mitigation of associated risks. Recommendations for procedural security are as follows:

- 1. A management process MUST be in place for the overall management and configuration of HSMs to define the acceptable configuration settings and enabled commands for each device mainly to ensure that the risk-exposure of cryptographic keys and secret data is always within acceptable limits.
- Remark: Particular care must be taken when an HSM is required to have multiple or changing roles within a system, or for compatibility with legacy systems, or system elements that are not capable of supporting the full range of security features such as longer cryptographic keys or stronger PIN block formats.
 - 2. Documentation regarding the security and operation of the system SHOULD be distributed on a "need-to-know" basis.

- 3. A management process MUST be in place for the system, to enable corrective action to be taken if any security elements, including procedures, are e.g., not being observed, failing their objectives, or could be efficiently improved.
- 4. Procedures regarding the security and operation of the system MUST be regularly reviewed and updated when necessary.
- 5. An incident management process MUST be in place for the system, e.g., to enable action to be taken if any compromise to the security of the system is detected or suspected, or if any security elements of the system is in an unplanned or uncontrolled state.
- 6. The system MUST be audited regularly to help ensure that the intended overall level of risk is being achieved, by checking that the chosen security elements of the system (e.g., satisfying the requirements laid down in this Appendix) are in place and are being used correctly.
- 7. The auditor MUST be independent of the operators of the security elements within the system.

10.2.1 Audit and records

Audits are required to help determine whether or not HSMs are being used appropriately. In this context, an audit is a review of records and procedures.

- 1. A management process MUST be in place to define the scope and on-going management of audit records i.e., to define the nature of all auditable events, to define the form or method for capturing audit information (including their storage and transfer arrangements), the system for reviewing and reconciling audit records, plus their backup and retention periods.
- 2. Audits MUST NOT themselves necessitate the recording of any sensitive information, (e.g., key material).
- 3. Whenever a maintenance function or authorized function is used, this fact MUST be recorded, with details of the function used, and the reason for its use.
- 4. Whenever the product is put into a new operating state, this MUST be recorded.
- 5. It MUST always be possible to determine the current operating state of the HSM by viewing the records.
- 6. Every movement of a HSM from one location to another MUST be recorded, together with reason for movement.
- 7. Every access to the HSM Secure Area or PIN printing areas MUST be recorded, including details of damaged and destroyed PIN mailer material.
- **Remark:** Particular care must be taken when using the HSM in a PIN issuing operation so that the physical security of the printer and its cable connections is given equivalent consideration to that of the HSM.
 - 1. Every access to an authorizing smartcard, LMK or HSM settings smartcard MUST be recorded and include the name of every officer involved and the reason for access.
 - 2. Where key material or smartcard PINs are written down, every access MUST be recorded and include the name of every officer involved and the reason for access.
 - 3. Every access to metal keys MUST be recorded and include the name of every officer involved.
 - 4. The records MUST be regularly reviewed to aid discovery of any hostile action that may have occurred.
 - Incident management procedures MUST exist to react to and counter hostile actions however discovered.
 - 6. The records SHOULD be easy to understand and organized in such a way as to make analysis both straightforward and useful.
 - 7. Records SHOULD be regularly backed up and copies stored off-site in such a way that they can be easily restored if necessary.
 - 8. All record entries MUST include a time and date.

- 9. All record entries MUST include a traceable signature. Where an entry involves more than one individual, e.g., the granting of access, all the individuals MUST sign the entry.
- 10. Sufficient resource MUST be available to allow complete records to be created.
- 11. The records MUST be protected against unauthorized modification.
- 12. There MUST be a record of all training activities relevant to the security system, and including any training exercises involving the facilities and equipment of the HSM Secure Area.
- 13. Before any deletions are made from the HSM's electronic log (e.g., using the CLEARAUDIT command from the Console to empty the Audit Log) the log MUST be correlated with the other record(s) of that HSM, and any differences fully investigated.
- Note: It is important to check that the first entries in the AUDITLOG correspond exactly with the last time the AUDITLOG was cleared. It is also important to check that each change to the Secure state was in support of a legitimate activity.

10.2.2 Identification and Authentication

The following requirements will be applied when a change of state is affected for an HSM with an online connection to the host. A more stringent process would be applicable in situations where the overall design or configuration of the system is being altered. However, the following requirements should be adequate to cover the day-to-day aspects of key management and both the planned and unplanned physical replacement of a HSM.

- 1. The persistent state (i.e. Online, Offline, Secure and/or Authorized) and physical condition of every HSM within the system MUST always be determinable from the records.
- 2. Necessary transitory states can be assumed but MUST be recorded if they are to be utilized in addition to their role in the transition to other operating states.
- 3. If an individual is no longer an Authorizing Officer, procedures MUST be put in place to prevent him from acting subsequently as an Authorizing Officer e.g., by changing or replacing the sensitive items to which the officer was exposed e.g., LMK key components, smartcards and PINS/passwords.
- **Remark:** The HSM is capable of uniquely identifying any smartcard whose format includes a serial number; and it is recommended that this feature be used to support the goal of managing authorized activities. The serial numbers of cards must therefore be recorded as they are issued to individuals.

10.2.3 Use of Authorized State

- 1. At least 2 separate Authorizing Officers MUST be required to put the HSM into Authorized state.
- 2. Before the HSM is put into the Authorized state, the identities and authority of both Authorizing Officers MUST be checked and logged, with audit entries signed by both Authorizing Officers.
- 3. Before either one or both Authorizing Officers leave the HSM Secure Area (even temporarily) or the payShield Manager application, the HSM MUST be taken out of Authorized state and the appropriate payShield Manager smartcard logged out.
- 4. HSMs MUST NOT be placed in Authorized state for any longer than is absolutely necessary to complete the required activity.
- 5. A time-out for Authorized state SHOULD be specified.
- 6. If Multiple Authorized Activities has been configured for the HSMs, then activities that are not being used MUST NOT be authorized.

10.2.4 Use of Secure State

1. At least 2 separate operators MUST be required to switch the HSM into Secure state.

Thales Group All Rights Reserved

- 2. Before the HSM is switched into Secure state, the identities of both operators MUST be checked and logged, with audit entries signed by both operators.
- Before either one or both operators leave the HSM Secure Area (even temporarily) or the payShield Manager application, the HSM MUST be switched out of Secure state and the appropriate payShield Manager smartcard logged out.

10.2.5 Use of Offline State

- 1. Before the HSM is switched into the Offline state, the identity of the operator(s) MUST be checked and logged.
- Before the operator(s) leave the HSM Secure Area (even temporarily) or the payShield Manager application, any key/smartcard under their control MUST be removed/logged out from the HSM and secured.

10.2.6 Use of the restricted role of the payShield Manager

- 1. The use of the payShield Manager in the restricted role requires an authorized smartcard allowed to communicate with the specific HSM.
- 2. If an individual is no longer authorized to work an HSM, procedures SHOULD be put in place to prevent him (or her) from accessing that HSM via the payShield Manager, e.g., by revoking their smartcards' authorization to communicate with that HSM.
- 3. Before any individual(s) leave the payShield Manager application, they MUST log their smartcard out of the application.

10.3 Command Security


There are a number of standard features provided by the payShield 10K that can help "lock down" the HSM to perform only the functions that are required by the host application.

Users of payShield Manager should refer to the payShield Manager manuals to perform the equivalent functions.

- Use the CONFIGCMDS console command to enable commands necessary for operation of the HSM and to disable all unused Console commands.
- 2. Use the CONFIGPB Console command to disable all unused PIN block formats.
- 3. Use Multiple Authorized Activities instead of the global Authorized state, thus permitting specific authorized commands, rather than all authorized commands.
- 4. All Authorized Activities SHOULD be time limited to reduce the risk of abuse.
- 5. Use the auditing capabilities to record and detect unexpected commands or events:
 - All HSM commands that require the HSM to be in the Authorized or Secure state must be audited by the HSM itself. This is achieved using the Console command AUDITOPTIONS.
 - The host system must extract the audit records from inside the HSM, and store them securely. The audit records can be extracted from the HSM using the host command 'Q2'.
 - Prior to viewing the audit records extracted by the host, they should be validated by the HSM. This is achieved using the host command 'Q8'.

10.4 Measures to Protect HSM Secure Area

The figure below shows an HSM, printer, and console in a "secure area with limited access". The Host Computer and the HSM are on a secure private network – separate from any user-orientated network and any connection to the Internet, even via a firewall and DMZ, etc. When necessary, the Console terminal is connected directly to the HSM e.g., via a suitable USB-to-serial cable (supplied by Thales).



Recommendations for the HSM secure area are as follows:

- 1. The operating procedures associated with the HSM Secure Area plus all the equipment and the interconnections between them MUST be subject to a management process that will deliver the required system functionality and achieve an acceptable level of overall risk.
- 2. The HSM, payShield Manager, Console terminal, and printer (if attached) MUST be located in a physically secure area during all operational use.
- 3. The HSM's Host and Management ports SHOULD be configured to communicate over separate subnets. This recommendation supports the electrical separation of networks by function i.e., operational, or managerial.
- 4. Access to the HSM Secure Area MUST only be provided when necessary.
- 5. Access to the HSM Secure Area MUST be recorded.
- 6. The HSM Secure Area MUST NOT ever be occupied by a lone individual.
- 7. The HSM Secure Area MUST be subject to protection against electromagnetic emanation, if this is deemed to be a threat.
- 8. The use of non-CRT monitors MUST be used to prevent the monitoring of electromagnetic emanation.
- 9. HSM peripherals (e.g., printer) MUST only be attached when required.
- 10. A HSM MUST be inspected, or subject to equivalent checks on its identity and integrity, when it enters or leaves the HSM Secure Area.
- 11. All staff associated with the security system MUST be instructed in their responsibilities and adequately trained in the use of relevant equipment, processes, and procedures.

In the case of an HSM attached to a host via an Ethernet network, the following note applies:

- Important Note: If Secure Host Communications (i.e., TLS) are not used, in order to ensure that a HSM only processes commands on behalf of the legitimate host computer, it is strongly recommended that a private Ethernet network segment is used. The only devices on this network should be the host and its associated HSM(s).
- Note: Refer to Section 2, "Installation Deployment", for additional information.

10.5 HSM Configuration Functions

1. Appropriate network protection mechanisms SHOUD be in place and the associated risks understood before enabling Dynamic Host Configuration Protocol (DHCP) on any of the host interfaces.

Thales Group
All Rights Reserved

- 2. Access Control Lists can be configured, for each of the host interfaces. This will restrict the IP addresses that can access each of the host interfaces.
 - The Access Control list can be enabled or disabled.
 - o The ACL only applies to the host port, not the auxiliary or management ports.

10.6 Host Application Functions

- 1. The host application MUST be written such that cryptographic requests are made as appropriate to the HSM.
- 2. The host application MUST be written such that cryptographic responses from the HSM are acted on as appropriate.
- 3. The host application MUST react appropriately in the event that an error is received from the HSM.
- 4. There MUST be procedures in place to detect if the host application is operating incorrectly.

10.7 Local payShield Manager Functions

payShield Manager users should refer to the payShield 10K Installation and User Guide for additional information, as needed.

The payShield Manager can be run in local mode on a directly connected, secured computer and is an alternative to managing an HSM from a Console terminal.

Refer to the relevant *payShield 10K Installation and User Guide* for more details of the preferred Security Environment for the payShield Manager.

- 1. The user MUST define and implement suitable management procedures.
- 2. The user's management procedures MUST mandate the use of the correct software to reduce the possibility of intercepting PINs or passwords.
- 3. Efforts to operate the payShield Manager securely SHOULD be enhanced by minimizing the presence of unnecessary hardware and other software.
- 4. All hardware and software within the computer hosting the payShield Manager MUST be operated and maintained according to the vendor's recommendations.

10.8 Cryptographic Key Management

In some cases, key management requirements are dictated by card schemes or other authorities such as a central bank. Also some aspects of key management, such as the replacement of terminal keys, may be automated within an application.

- 1. The user MUST define and implement suitable key management procedures.
- 2. For every cryptographic key, a suitable lifetime and key length MUST be chosen, as appropriate given:
 - Card scheme mandates or other requirements relevant to the application and environment in which
 the key is used
 - The effective strength of the associated cryptographic algorithm
 - The function of the key (e.g., key encryption, data encryption, data authentication)
 - The volume of use
 - The propensity to attack or unauthorized disclosure
 - The full implications of actual or possible compromise both during and after active use.

- 3. All cryptographic keys used within the system MUST be updated on a regular basis in an appropriate manner.
- 4. When a cryptographic key (in particular the LMK) is updated, data protected by that key will need to be translated from the 'old' key to the 'new' key. Once this translation process is complete, the 'old' key SHOULD be removed from the HSM.

10.8.1 Cryptographic Key Generation

- 1. When generating an LMK Component Set for use in the HSM, the secret values SHOULD be generated randomly by the HSM rather than entered manually.
- 2. Keys that are not generated by the HSM MUST be generated using a good random number generator.
- 3. The random number generator used for external key generation MUST be subject to statistical testing.

10.8.2 Protection of Cryptographic Key Material

Protection of keys is critical to the security of the system in which the HSM operates.

- 1. Keys and key components MUST NOT be disclosed to unauthorized individuals. This is particularly important for the LMK.
- 2. The management of key components MUST fully and continuously support the requirements of the "split knowledge" approach, helping to protect the system and its staff.
- 3. Untrusted keys MUST NOT be loaded or used. This is particularly important for the LMK.
- 4. Key material MUST NOT be loaded or used with untrusted equipment.
- 5. Unencrypted key material (such as ZMK components) MUST be distributed in a physically secure manner.
- 6. The secure management of each unencrypted key used in a HSM system MUST be the responsibility of a trusted individual.
- 7. Key material SHOULD NOT be written down.
- 8. A plaintext key component displayed on the PC/laptop screen MUST NOT be viewed by anybody other than the user who generated the component.
- 9. Plaintext key components SHOULD NOT be saved to file, except for the purpose of printing the components, after which the file MUST be deleted.
- 10. Encryption of key material, that is not subsequently subject to physical protection, MUST be performed using an appropriately secure algorithm with a sufficiently large key length.
- 11. Encryption of key material, that is not subsequently subject to physical protection, MUST be performed using a physically secure key or one that is itself encrypted.
- 12. Procedures MUST exist such that in the event of key material compromise, keys are replaced as necessary.
- **Remark:** Where a key suspected of compromise is a key encipherment key, all keys which are hierarchically under it shall be replaced.
 - 1. The utilization of each key component MUST be controlled by separate Authorizing Officers.
 - 2. Where keys or key components are stored on smartcards, the smartcards MUST be treated with an adequate degree of physical security to prevent unauthorized access.

10.8.3 Key Material Usage

- 1. Test key material MUST NOT be used in the live operation.
- 2. Keys MUST only be used for their defined purpose.

10.8.4 HSM PIN and Password Security

- 1. The user MUST define and implement suitable management procedures.
- 2. The PIN associated with each smartcard MUST be created securely e.g., created at random. Obvious, common, predictable or previously used values MUST NOT be used intentionally.
- 3. PINs MUST be at least 8 digits in length.
- 4. Strong passwords SHOULD be used. Good properties for strong passwords are that they:
 - Contain upper and lower case characters
 - Contain numbers, letters and punctuation characters
 - Contain at least 8 random characters
 - Do not contain dictionary words
 - Do not use spouse's/children's names
 - Do not intentionally re-use old passwords
- 5. The frequency for changing passwords SHOULD be stated and be sufficient for the role.
- 6. Passwords SHOULD NOT be disclosed to others.
- 7. The process for managing forgotten passwords SHOULD be set out in the user's security management procedures.
- 8. If the PINs or passwords are written down, they MUST be stored securely and separately.
- 9. If a PIN or password is compromised (including a previously authorized individual becoming unauthorized), it MUST be invalidated and a replacement issued.
- 10. Everyone, and especially operators and Authorizing Officers, MUST have no unauthorized knowledge of any PIN or password.

10.8.5 Smartcard Security

Smartcards are used for storing three distinct types of sensitive information:

- Storage of key components particularly the LMK;
- Storage of Authorizing Officer credentials;
- Storage of HSM alarm, security and host settings.

Security precautions for the cards are as follows:

- The user MUST define and implement suitable management procedures.
- All smartcards containing sensitive information MUST be stored securely.
- Smartcards containing sensitive information MUST be stored separately from each other.
- Access to any smartcard containing sensitive information MUST be recorded.
- Smartcards containing LMK Component Sets MUST only be made available to Authorizing Officers, and only when necessary.
- If a smartcard containing sensitive information is compromised (including a previously authorized individual becoming unauthorized), suitable measures MUST be taken to re-establish adequate security for the system e.g., by changing the LMK.
- Copies of the smartcards containing sensitive information SHOULD be kept separately, off-site. These copies MUST be subject to equivalent access controls as the original smartcards.
- All smartcards containing sensitive information SHOULD be periodically checked to ensure that they are functional and have not been corrupted or compromised.
- There MUST NOT be any unauthorized access to smartcards containing sensitive information especially by operators and Authorizing Officers.
- Only limited reliance MUST be placed on the security afforded by a smartcard's PIN in controlling access to its
 contents.



Note that the individual components of a cryptographic key (such as the LMK), each of which is normally stored on a separate smartcard, are not equivalent to each other.

10.8.6 Physical Key Security

The payShield 10K HSM is supplied with two physical keys for the front panel. These have three functions:

- Both locks must be opened in order to remove the HSM from the cabinet.
- Both locks must be opened to put the HSM into the Secure state.
- One lock (either one) must be opened to put the HSM into the Offline state.

Security precautions for the keys are as follows:

- 1. The user MUST define and implement suitable key management procedures.
- 2. The metal lock keys MUST be stored securely and separately.
- 3. Each metal lock key MUST only be made available when necessary.
- 4. If a previously authorized individual becomes unauthorized, measures MUST be taken to ensure that the individual no longer has access to the key.
- 5. Each use of the physical key on a HSM in operational use MUST be recorded.
- 6. There MUST NOT be any unauthorized access to a physical key especially by operators and Authorizing Officers.

10.8.7 HSM Recovery Key (HRK)

In the event that an HSM erases its secure memory and loses its Secure Host Communications & Remote Management key material, it would be a major operational headache to re-initialize the HSM and generate new key material. Hence, a supplementary mechanism has been devised to allow a relatively simple means of recovering the situation. This involves the use of an AES-256 bit *HSM Recovery Key* (HRK).

The HSM will erase its secure memory upon a Medium tamper event, the user pressing the erase button and a factory reset. Prior to restoring any key material to the HSM after an unexplained tamper event the Routine Inspection Procedure SHOULD be performed to ensure the HSM has not been maliciously tampered with. (See Appendix A.)



Key material protected under the HRK will not be recoverable after a factory reset.

The HRK is generated securely within each HSM using payShield Manager or the SK Console command. The HRK is cryptographically protected using a separate key which is protected by two, user-generated passphrases. To restore the HRK both passphrases are required using the SL Console command; this recovers the Secure Host Communications and Remote Management key material.

Note that the recovery mechanism stores encrypted copies of the Secure Host Communications and Remote Management key material in persistent storage within the HSM, and that this is not erased if the HSM erases its secure memory. It is therefore essential to ensure that the HRK passphrases are kept secret to prevent a compromise of the HRK and possible recovery of the Secure Host Communications and Remote Management key material.

Further details of the HRK and its use are provided in the payShield 10K Installation and User Guide.



The HRK can only be generated and restored via the HSM's console interface. No payShield Manager function exists to restore the HRK.

- 1. HRK-related activities SHOULD take place in a secure area.
- 2. The Security Manager MUST take overall responsibility for all HRK activities and MUST ensure that all HRK-related procedures are followed correctly.

- 3. The Security Manager MUST maintain a log of the names of the HRK passphrase holders; the log SHOULD be stored securely.
- 4. HRK component holders MUST be fully briefed by the Security Manager with regard to their roles and responsibilities.
- 5. All HRK passphrase holders SHOULD sign affidavits stating that they understand their roles and responsibilities with respect to their HRK passphrases and that they will carry out their duties to the best of their abilities.
- 6. HRK passphrase holders MUST NOT ever have access to more than one HRK passphrase.
- 7. HRK passphrase holders MUST NOT divulge their passphrase to any other party.
- 8. HRK passphrase holders SHOULD change their passphrase on a regular basis.
- 9. The Security Manager SHOULD perform the Routine Inspection Procedure prior to restoring the HRK if the key material erasure was caused by an unexplained event (i.e., not the erase button or an explainable tamper event).
- 10. The Security Manager MUST log all usages of the HRK including name of the passphrase holders, the log SHOULD be stored securely.
- 11. A person who leaves the organisation or ceases to hold the role of HRK passphrase holder MUST have their access rights to the HRK revoked immediately, and the Security Manager MUST arrange for a new HRK passphrase holder to take on the vacant role (this MUST include changing the role's passphrase to a new passphrase), in order to replace the existing HRK.

10.9 HSM Integrity

10.9.1 HSM Traceability

- 1. Procedures MUST exist so that movement of PayShield 10Ks from one location to another is controlled and recorded.
- 2. This record SHOULD be verified periodically to provide a high level of confidence in the location of all HSMs in the system.
- 3. If records show any discrepancy in the location of HSMs, this MUST be investigated, and immediate consideration SHOULD be given to withdrawing the HSM from service.

10.9.2 HSM Physical Integrity

- 1. When in use by the host application, the HSM MUST be in a secure environment.
- 2. When being transported to or from a user's premises, trusted couriers MUST be used.
- 3. If integrity of transport procedures is in doubt (for example if the HSM arrives substantially late without explanation), this MUST be investigated.
- 4. On arrival at a secure location, the HSM and its packaging MUST be inspected for signs of tampering prior to installation (see Inspection Procedure below).
- 5. Anything, such as additional labels, that would alter the external appearance of the HSM SHOULD be discouraged.
- 6. If the HSM is PCI-HSM certified and was delivered to a location that is <u>NOT</u> the initial key loading facility; the HSM MUST be kept under auditable controls that can account for the location of the HSM at every point in time until the initial keys are loaded. This will ensure continued PCI-HSM compliance.
- 7. If the HSM is PCI-HSM certified and is being transferred between internal departments within the customer's facilities; an audit record MUST be created to track the transfer of accountability for the HSM between those internal departments.


- 8. In normal usage, the HSM MUST periodically have a routine inspection for signs of tampering (See Inspection Procedure below).
- 9. Any HSM that appears to have been tampered with MUST NOT be loaded with keys or connected to the host application.
- 10. Any HSM that appears to have been tampered whilst connected to the host application MUST be withdrawn from service as soon as possible; and the system MUST become subject to the incident management process.

10.9.3 HSM Maintenance

The HSM contains a long-life battery that can be replaced only by Thales at their premises.

- HSM maintenance and repair, other than replacement of FRU components, MUST only be performed only by Thales; and if Thales found any evidence of tampering it would be preserved and reported appropriately.
- 2. Before a HSM is returned to Thales it SHOULD be given a routine inspection.
- 3. The HSM SHOULD be removed from the Secure Area for maintenance.
- 4. All maintenance operations MUST be recorded.
- 5. Before a HSM is given to Thales for maintenance, the LMKs MUST be erased e.g., by using the ERASE button.
- 6. Before an HSM is given to Thales for maintenance, follow the relevant instructions in the payShield 10K Decommissioning Guide (PPIF0552).
- 7. The return of faulty HSMs to the manufacturer MUST take place under the control of the incident management process.

Note that this approach is designed to help ensure that a faulty HSM, e.g., one on which the deletion of all LMKs cannot be confirmed or from which the audit log cannot be inspected, is handled appropriately and within an acceptable level of risk. The necessary decisions are likely to be more appropriate to the incident management process than to normal operations – as these may not be suitable for handling unusual risks and issues.



10.10 Normal Operations

These measures are applicable while the HSM is being held or used within the users Secure Area. If a functional HSM is to leave the Secure Area, this is considered to be a maintenance activity, e.g., the LMK SHOULD be deleted or replaced by the Test LMK.

The HSM contains an intrusion detection mechanism that is always armed.

- 1. When the HSM is to have an online connection to the host application it MUST be locked in position and put into the Online state.
- 2. When the HSM contains an LMK, the motion alarm SHOULD be enabled.
- 3. The payShield 10K temperature sensor is always enabled.
- 4. Fraud detection SHOULD be enabled. The fraud detection parameters SHOULD be monitored to ensure that they are, and continue to be, appropriate for the HSM environment.
- 5. Only host commands required for operations SHOULD be enabled, and Host commands not required for operations MUST be disabled.
- 6. PIN block formats that are not required for operations SHOULD be disabled. In particular, PIN block formats that do not involve an account number MUST be disabled unless needed.

Thales Group
All Rights Reserved

- 7. Any HSM that develops a fault whilst it contains an LMK MUST become subject to the incident management process if deletion of the LMK cannot be confirmed or the audit log cannot be inspected.
- 8. A faulty HSM MUST NOT be given an online connection to the host application.
- 9. The system design SHOULD include adequate contingencies for system failures, e.g. specific, isolated, localized, geographical or systemic.
- 10. Where the system design implies continuous availability of a HSM, in the event of failure of a HSM, a means of quickly switching operation to another HSM SHOULD be available at all times. (An automated load-balancing mechanism or Thales Security Resource Manager software may be useful for this purpose.)
- 11. At least two Authorizing Officers MUST control the initialization of a new HSM.
- 12. All online HSMs MUST be subject to regular monitoring, particularly with respect to the management of any HSM where the "Health" LED is illuminated red, or the "Tamper" LED has become illuminated.
- Note that normal operations can only continue with an HSM if a benign explanation can be established for a resettable error or alarm condition.

10.10.1 Timely Return to the Online State

The device MUST NOT be left in Authorized state or Secure state inadvertently. If either state is active when it is not required to be active, the HSM MUST immediately either be switched off or returned to the Online state.

10.11 Inspection Procedures

This section describes procedures that are carried out to confirm that the HSM has not been subject to accidental or deliberate tampering that may lead to insecure operation.

- 1. The inspection procedures MUST be performed by trusted personnel.
- 2. Details of the personnel performing the inspection procedures MUST be recorded.
- 3. The results of each step of the inspection procedures MUST be recorded.

10.11.1 Frequency of Inspection

Both the "Initial Inspection Procedure" and the "Routine Inspection Procedure" MUST be carried out whenever the HSM is received from an external source. That is:

- on initial receipt of the HSM;
- at any time after the HSM has traveled outside of the HSM Secure Area.

Additionally, the "Routine Inspection Procedure" SHOULD be carried out:


- after any known unauthorized entry to the HSM Secure Area;
- periodically, e.g. on a three-monthly basis, to confirm continued secure operation of the device in case of unknown unauthorized entry into the HSM Secure Area or accidental damage to the HSM.

10.11.2 Initial Inspection Procedure

The initial inspection procedure is as follows:

- The arrival of the HSM MUST match expectations in respect of model type, delivery mechanism, and delivery timing.
- 2. The delivery details MUST correspond to information provided by the originator e.g. with respect to courier used and the delivery tracking number.

- 3. Any opening of the HSM delivery packaging other than by the intended addressee MUST be traceable to an acceptable source e.g. the result of a customs check.
- 4. A detailed record of the HSM MUST be established for reference during audits and routine inspections.



10.11.3 Routine Inspection Procedure

The inspection procedure is as follows:

- 1. The serial number of the HSM, as stated on the labels on the front and back of the HSM, MUST correspond correctly with the record created during the initial inspection.
- 2. If the HSM is being inspected within the Secure Area, the operational mode of the HSM MUST be as expected. This MUST include verification of the HSM's operating state (Authorized state, Secure state or Online state) and examination of the "Health" and "Tamper" LEDs.
- 3. The identification numbers of the physical keys MUST correspond correctly with the record created during the initial inspection.
- 4. All physical keys associated with the HSM MUST operate correctly.
- 5. The HSM MUST NOT report any permanent, significant or unexplained faults i.e., it is only acceptable for the "Health" LED to be illuminated red. When looking for evidence of tampering, consideration should be given to the possibility that the tamper-evident lid has been opened or replaced with counterfeits. Such suspicions may be corroborated by errors or log entries indicating removal of the unit's lid. If the unit reports tampering of the internal cryptographic module this results in a High Tamper that is unrecoverable and the unit should be removed from operation and destroyed or returned to Thales.
- Remark: The inspection should check that the tamper lid is still intact and that the lid has not been drilled into.

The HSM's diagnostic test console DT command, as described in the *payShield 10K Console Reference Manual*, MUST demonstrate the correct basic operation of the HSM. The result of each test MUST be "OK". The final test MUST be followed by the phrase:

Diagnostics complete

- Users of payShield Manager should refer to the payShield 10K Installation and User Guide to perform the equivalent functions.
 - The HSM's self test console ST command, as described in the *payShield 10K Console Reference Manual*, MUST confirm that the self tests are running at the expected time.
- Users of payShield Manager should refer to the payShield 10K Installation and User Guide to perform the equivalent functions.
 - The HSM VR Console command, as described in the payShield 10K Installation and User Guide, Appendix A, MUST confirm that the version number reported agrees with the record created during the initial inspection. If the HSM is required to be operating in a PCI HSM compliant manner the user MUST

check that the Revision number is of the format XXXX-19XX, that the Revision number appears on the certificate on the PCI website, and that the following phrase is present:

PCI HSM Compliance: Refer to the PCI web site

(https://www.pcisecuritystandards.org/approved companies providers/approved pin transaction security.php) for current certification status of this version of payShield 10K software.

- Security settings are consistent with the requirements of PCI HSM.
- Users of payShield Manager should refer to the payShield 10K Installation and User Guide to perform the equivalent functions.
 - If the HSM is being inspected within the Secure Area, any cables connected to the HSM MUST terminate at the expected location/equipment; and there MUST be no signs of physical damage to the cables themselves.
 - The HSM MUST have no unrecorded physical changes or damage.

Remark: Potential attacks against an HSM can include subtle attempts to create small holes through which bugs or temporary probes may have been passed. Therefore some consideration must be given to the condition of removable fixings such as screws and brackets, in case these have been used as the point of entry. Particular consideration should be given to scratches and marks that may have been caused during unauthorized activities, and therefore cannot be traced in the records of legitimate activities and inspections. There must be no opaque labels on the HSM that could obscure holes or other damage to the casing.

• Any HSM whose authenticity and integrity cannot be adequately established MUST become subject to the incident management process.

10.12 Security Guidelines for SNMP Configuration

For SNMP configurations, following are the recommended security guidelines:

- 1. Configure SNMP with authPriv.
- 2. Choose SHA as the Authentication algorithm.
- 3. Choose AES as Privacy algorithm.
- 4. Set strong and distinct passwords for Auth and Priv algorithms. The passwords should not be the same. The passwords must be 8 to 19 characters, and should be made up of a combination of alpha-numeric and permitted special character values.

11 Appendix B – payShield Manager Recommendations Background

payShield Manager is a web-based product that allows communication with, and management of, a payShield 10K unit over a wide area network. As such, it permits "remote" users to perform almost all console activity without requiring physical access to the HSM.

In order to provide secure communications between a remote user and an HSM:

- All management traffic is protected by a TLS v1.2 server-only authenticated session.
- All critical security parameters are further protected by an end-to-end encrypted channel between the payShield 10K and the currently authenticated remote management smartcards.

11.1.1 Remote Management States

payShield Manager allows the same states that exist when using the payShield Manager locally: Online, Offline and Secure.

11.1.2 Remote Management Roles & Limitations

payShield Manager smartcards can operate in one or more of the following roles:

Based on the following restrictions:

- · A smartcard can only exist in one customer security domain;
- A smartcard cannot represent both the left and right key RACC (roles 3a and 3b) for the same HSM;
- A smartcard cannot contain more than one LMK share /RLMK role (roles 4a, 4b or 4c);
- A smartcard cannot contain more than one CTA share (role 1).



Comment on Terminology: Organizations using the payShield Manager may well use different names to describe the above roles and so must ensure that the relationship between Thales terminology and their own personnel structure is properly understood.

11.1.2.1 Customer Trust Authority

Every commissioned HSM or smartcard contains an ECDSA public/private key pair. In order to have confidence in the authenticity of the various public keys, each such key is held in the form of a certificate, signed by a private key that is also created by the user on an HSM. This root private key is normally described as a *Customer Trust Authority* (CTA).

The CTA is split across a number of CTA cards. The CTA is temporarily loaded into an HSM prior to signing the smartcard or HSM public key certificates. The corresponding CTA public key (used to verify the certificates) is stored in each smartcard and HSM.

The CTA functionality is standard in all payShield 10Ks that support payShield Manager. All user interaction with the CTA functionality is via either the HSM's console interface or the payShield Manager.

11.1.2.2 Customer Security Domain

The term "customer security domain" is used to describe the set of smartcards and HSMs, such that (secure) remote communication between the cards and the HSM in the group is permitted.

A necessary condition for a smartcard and an HSM to communicate is that their public keys are both signed by the same CTA. However, this is not a sufficient condition, and it is quite possible to have non-overlapping security groups created via the same CTA.

In addition to having matching CTAs, whitelists within each HSM define which smartcards can communicate with that HSM and what role they possess.

11.1.2.3 **Recovery**

One concern relating to the HSMs used in the remote management solution is that if an HSM is tampered, then it will lose its public and private keys from memory and it will be necessary to generate a new key pair. This could involve considerable operational inconvenience.

Therefore, a recovery mechanism involving an HSM Recovery Key (HRK) is available that simplifies the task of restoring a public/private key pair to the HSM's secure memory and re-establishing the previous security group following a tamper caused by some innocuous event.

11.2 PayShield Manager Best Practice

11.2.1 Introduction

The following security guidelines should be used to complement *Appendix A - Security Recommendations*. Both appendices should be read in conjunction with existing security policies and procedures, audit requirements and mandates from organizations and authorities relevant to the specific application and environment in which the HSMs are being used.

11.2.2 Assumptions

This Appendix assumes that the reader is familiar with the operation of the HSM (including console functionality) and with payShield Manager.

11.2.2.1 Terminology

In accordance with Appendix A - Security Recommendations, the terms "MUST", "MUST NOT", "SHOULD" and "SHOULD NOT" have the following meanings in this appendix:

- MUST: this indicates an absolute requirement to achieve an acceptable overall level of risk;
- MUST NOT: this indicates an absolute prohibition of the specified activity in order to achieve an acceptable overall level of risk;
- SHOULD: this means that there may exist valid reasons in particular circumstances to ignore a particular item, but the full implications must be understood and carefully evaluated before choosing a different course;
- SHOULD NOT: this means that there may exist valid reasons in particular circumstances when the specified
 activity is acceptable or even useful, but the full implications must be understood and evaluated before the
 activity is implemented.

11.2.3 Personnel

An individual responsible for the overall operation and security of payShield Manager needs to be identified. For the purposes of this appendix, this person will be designated as the *Security Manager*.

The Security Manager MUST have access to a secure storage area (such as a safe) for the storage of payShield Manager:

- Laptop
- · Card reader
- Smart cards
- Audit records

Other sensitive items as defined in remainder of this appendix.

- Other payShield Manager users MUST NOT have access to this area.
- The Security Manager SHOULD NOT possess any other role within the system.
- Users of the payShield Manager SHOULD NOT have more than one smartcard per customer security domain.
- Written justification SHOULD be provided by the Security Manager if it is deemed necessary for a user to carry out more than one of the roles.
- A user with a left key RACC MUST NOT be allowed to possess (even temporarily) a right key RACC, and vice versa.
- Every payShield Manager user, including the Security Manager, SHOULD have a named deputy, with the same level of access and responsibility.
- All users MUST be given adequate training to allow them to carry out their roles.
- All users MUST be made fully aware of their responsibilities regarding the security of payShield Manager.
- All users SHOULD sign affidavits stating that they understand their roles and responsibilities with respect to payShield Manager and that they will carry out their duties to the best of their abilities.
- Users who no longer need access to the payShield Manager (e.g., have left the organization, have been assigned to a new department or are on extended leave, etc.) MUST be deleted immediately from the system (and all whitelists) and their smartcards MUST have all contents deleted, using the functionality of either the HSM console, payShield Manager, or by physically destroying the card.

11.2.4 Procedural Security

In addition to the procedural security recommendations in Appendix A - Security Recommendations, all processes and procedures relating to the security and operation of the payShield Manager MUST be fully documented.

11.2.5 Audit

In addition to the audit recommendations in Appendix A - Security Recommendations, records of all payShield Manager activity MUST be made; this MUST include:

- · HSM management and user events
- Personnel
- · Security incidents
- Details of all personalized smartcards and HSMs
- Access to the payShield Manager operations room (access logs and CCTV images)
- Access to the safe in the operations room

- Access to various passphrases, smartcards and PINs (e.g. Key RACC smartcards, RLMK smartcards, CTA smartcards, HRK passphrases, etc.)
- Access to documents relating to the payShield Manager, including audit and error logs

11.2.6 Physical Security

Many payShield Manager activities are extremely sensitive and need to be carried out in a secure environment. In particular, compromising a computer from which remote management operations are carried out could lead an authorized user to unwittingly carry out malicious actions.

- The browser extension MUST only be obtained from genuine Thales sources (i.e., the payShield 10K itself through the management interface, the Thales website or the installation CD).
- The obtained browser extension SHOULD be hashed (using SHA-256) and compared to the expected message digest as provided by the Thales website, documentation and/or Support team.
- When commissioning a payShield 10K for payShield Manager, to avoid a possible man-in-the-middle attack, the network connection between the payShield 10K and the management client MUST be trusted;
- The recommended method of achieving this is to connect to the payShield 10K locally.
- IMPORTANT: FAILURE TO SECURE THE INITIAL CONNECTION TO THE HSM COULD LEAD TO COMPROMISE OF THE ENTIRE CUSTOMER SECURITY DOMAIN.
 - Remote access to the payShield Manager interface MUST be performed from an Operations Room, which is a physically secure environment.
 - Access to the Operations Room MUST be controlled and personnel who do not need access MUST NOT be given access.
 - Users who previously had access to the Operations Room but no longer need access MUST be revoked on the access control system.
 - Access to the Operations Room SHOULD require a 2-factor mechanism (i.e., "something you have", such as a physical token, and "something you know" or "something you are", such as a PIN/password or a biometric).
 - If the Operations Room is occupied, there SHOULD be a minimum of 2 personnel present.
 - The loss or theft of an Operations Room physical access token MUST be reported immediately to the Security Manager and the token revoked on the access control system; and the circumstances of the loss/theft MUST be investigated.
 - It MUST NOT be possible to leave the door to the Operations Room open for longer than a specified period of time without an alarm being raised; such an alarm MUST be investigated immediately.
 - All access to the Operations Room MUST be logged; each record MUST contain, as a minimum, a date/time stamp and a user identifier.
 - Exit from the Operations Room SHOULD be recorded by the access control system.
 - All failed access to the Operations Room MUST be recorded in the access log.
 - Failed access attempts MUST be investigated.
 - The door to the Operations Room SHOULD be covered by a CCTV camera.
 - Authorized users of the Operations Room SHOULD NOT have access to the access logs or CCTV images.
 - Access logs and CCTV images MUST be retained for inspection for a period of time that is compatible with organizational policies, but SHOULD be at least 6 months.
 - The Operations Room SHOULD be alarmed outside "normal" operating hours.
 - CCTV MUST NOT be used inside the Operations Room, to avoid compromising user passwords.

- All cabling inside the Operations Room SHOULD be clearly visible.
- There SHOULD be no network access to the Operations Room, except as necessary to allow communication with the HSMs.
- The Operations Room MUST contain a "dual access" safe for the storage of sensitive items; dual access could be (for example) a physical key and a PIN/password.
- · Access to the safe SHOULD require two people.
- All access to the safe SHOULD be logged and SHOULD include, as a minimum, a date/time stamp, user name and the reason for access.
- Smartcard readers SHOULD be stored in the safe when not in use.
- The computing equipment used to access the payShield Manager SHOULD be stored in the safe when not in
- If a desktop computer (PC) is used to run the payShield Manager then it SHOULD be locked to prevent access to the internal circuitry.
- The computer MUST be kept up to date with any applicable security updates (including OS and browser).
- The computer, smartcard readers and all cabling MUST be checked for signs of tampering before each payShield Manager session.
- The computer SHOULD NOT be used for any purpose other than remote management of payShield device, to reduce the risk of compromise of the computer.
- Equipment that is not required for the operation of payShield Manager MUST NOT be brought into the Operations Room. Such equipment includes, e.g.,: data analyzers, cameras, cell phones, etc.
- Loss or theft of any payShield Manager equipment MUST be investigated by the Security Manager and any necessary remedial action MUST be immediately instigated.
- The network communications link between the Operations Room and the secure area housing the physical HSM MUST be secured to provide further protection for the system. Examples of such protection include virtual private networks, firewalls, encrypted links, etc.
- The network communications link between the Operations Room and the secure area housing the physical HSM MUST be regularly inspected and tested to ensure that it provides sufficient protection against intrusion and unauthorized access.

11.2.7 HSM Security Configuration

- 1. HSM configuration is described in the *payShield 10K Installation and User Manual*, and includes a number of security related activities. Security configuration SHOULD retain the default settings unless there is a good operational reason to do otherwise.
- 2. All payShield Manager activities and User Events SHOULD be audited by the HSM. As noted in *payShield* 10K Installation and User Manual, this may impact HSM performance and so the extent of auditable activity SHOULD be reviewed from time to time.

Decisions regarding those payShield Manager activities and User Events that are not to be audited by the HSM MUST be approved, in writing, by the Security Manager. Such approval SHOULD include a justification for the decision.

11.2.8 Customer Trust Authority

The Customer Trust Authority (CTA) is critical to the security of the payShield Manager. All HSMs and smartcards used in the remote management solution possess a public/private key pair, with the public key held in the form of a certificate signed by the CTA's private key. If the CTA private key is compromised, an attacker can impersonate any member of the Customer Security Domain.

A one-off process to generate the CTA public/private key pair is performed on an HSM whose firmware supports the remote management solution. This is achieved via the GUI or the XI Console command and is described in detail in the payShield 10K Installation and User Manual.

Thereafter, individual HSMs generate a public/private key pair and the public key is signed using the CTA private key, this process is known as commissioning Similarly, any of the HSMs can be used to commission smartcards. Commissioning of HSMs and Smartcards uses the GUI, the XH console command (for HSM commissioning), or the XR Console command (for smartcard commissioning) and is described in detail in the *payShield 10K Installation and User Manual*.

The CTA public key, in the form of a self-signed certificate, is loaded into each HSM and onto each smartcard as part of the above processes.

The use of the various public/private keys allows the creation of the Customer Security Domain and forms the basis of secure communication between the payShield Manager and the HSM(s).

The CTA private key is stored on a group of smartcards via a (k, n)-threshold scheme.

The only restrictions on the values of the parameters "k" and "n" that are enforced by the HSM are that $3 \le k \le n \le 9$. The people responsible for the CTA private key shares are called "shareholders".



Note that a threshold scheme (also known as a "secret sharing scheme") is a mechanism that allows a "secret" to be broken into "shares", so that the secret can be recovered provided a defined number of shares are available, yet no information about the secret can be obtained if fewer than the required number of shares are presented. Threshold schemes provide a flexible management solution for sensitive data, whilst at the same time providing an automatic back-up facility. In the case of the Remote HSM Manager solution, the "secret" is the CA private key. A "(k, n)-threshold scheme" means that the secret is broken into n shares and that the secret can be recovered provided k (different) shares are presented.

payShield Manager users may act as shareholders, but there is no requirement for them to do so. In general, the choice of shareholders will depend on the organizational structure.

CTA-related activities SHOULD take place in a secure area.

The Security Manager MUST take overall responsibility for all CTA activities and MUST ensure that all CTA-related procedures are followed correctly.

The Security Manager MUST maintain a log of shareholder names and the corresponding card number and smartcard fingerprint. The log SHOULD be stored securely.

Shareholders MUST be fully briefed by the Security Manager with regard to their roles and responsibilities.

Shareholders SHOULD sign affidavits stating that they understand their roles and responsibilities with respect to their CTA private key shares and that they will carry out their duties to the best of their abilities.

The number of CTA private key "shares" (the parameter "n") MUST be such that adequate contingency is provided in the event of a share card being lost or damaged. The parameters "k" and "n" SHOULD satisfy $2k \le n$ and there may be operational benefit in allowing "teams" of shareholders to be established.

When creating the CTA, the CTA parameters that provide the highest level of security SHOULD be used.

Remark: Where a choice exists, the default selection provides the highest level security.

- Shareholders MUST NOT have access to more than one CTA private key share/card.
- All shareholder smartcards SHOULD be protected by strong PINs. For example:
 - PINs SHOULD be at least 8 digits in length
 - PINs SHOULD be randomly generated

- "obvious" PINs MUST NOT be chosen (e.g., "12345678" or "99999999")
- shareholders MUST NOT choose PINs that may be easily guessed by somebody else (e.g., date of birth, telephone number, etc.)

Shareholders MUST NOT divulge their smartcard PINs to any other party.

Shareholders SHOULD change their PINs on a regular basis.

New shareholders who take ownership of an existing shareholder card MUST change the shareholder card's PIN as soon as is practical.

All shareholder cards MUST be clearly labeled; and, as a minimum, the label SHOULD identify the card as a shareholder card.

All shareholder cards MUST be stored securely when not in use.

Shareholder cards SHOULD NOT be stored in the same location as one-another.

Shareholder card PINs SHOULD be written down and stored securely, separate from the cards, and separate from other shareholder card PINs. The Security Manager SHOULD know the location of all shareholder cards and the corresponding PINs but MUST NOT have access to any of these items (unless, of course, he or she is a shareholder).



Once the CTA private key shares are created there is no facility to create extra shares. Should a shareholder leave the organization, the existing shares can continue to be used if this is deemed to be an acceptable risk. However, the new shareholder MUST change the shareholder card PIN as soon as is practical.

- A person who ceases to hold the role of shareholder MUST have their access to the share card revoked immediately.
- Shareholder cards MUST be tested regularly to ensure that they still function correctly.
- A shareholder card that is no longer usable MUST be destroyed in a secure manner and a record of such destruction MUST be retained by the Security Manager.

11.2.9 Smartcard Security

- payShield Manager users authenticate to the system using smartcards that are protected by PINs. Initially the PIN is the transport PIN created when the card was issued. Users are forced to change the PIN before subsequent use of the card.
- Smartcards MUST be stored securely when not in use.
- Smartcard PINs SHOULD be written down and stored securely, separate from the smartcards.
- The Security Manager SHOULD NOT need to know the secure storage location of smartcards and the corresponding PINs and MUST NOT have access to any of these items.



<u>Unlike</u> the situation with CTA private key share cards, additional smartcards can be created in the event that an existing cardholder leaves the organization or if a card becomes unusable.

- A person who ceases to hold their role within the payShield Manager system MUST surrender their cards immediately, and have their access rights to both their card and to the relevant secure areas revoked immediately.
- Smartcards MUST be removed from the payShield Manager attached smartcard reader as soon as authentication has completed.
- All smartcards SHOULD be clearly labeled (for example whether the card is a left or right key card or a restricted card).

- Smart cards SHOULD be protected by strong PINs. For example:
 - PINs MUST be at least 8 digits in length
 - "random" PINs SHOULD be chosen
 - o "obvious" PINs MUST NOT be chosen (e.g. "12345678" or "99999999")
 - Shareholders MUST NOT choose PINs that may be easily guessed by somebody else (e.g., date of birth, telephone number, etc.)
- Users MUST use a tamper-resistant PIN entry device in conjunction with the payShield Manager.
- Users MUST NOT divulge their smartcard PINs to any other party.
- Users SHOULD change their PINs on a regular basis.
- All access to smartcards and PINs SHOULD be recorded by the Security Manager.
- Smartcards SHOULD be tested regularly to ensure that they still function correctly.
- A Smartcard that is no longer usable MUST be destroyed in a secure manner and a record of such destruction MUST be retained by the Security Manager.
- Smartcards MUST be distributed securely to the relevant user and the recipients MUST acknowledge receipt
 of the cards.
- The transport PIN for the smart cards SHOULD be distributed separately from the cards and, ideally, SHOULD NOT be sent until card receipt has been acknowledged.
- The Security Manager MUST retain a record of all HSMs and smartcards that have been issued (i.e., a public/private key pair has been generated and the public key signed by the CTA private key).

11.2.10 RLMK Smartcards

- RLMK users of the payShield Manager carry out a range of sensitive functions, including key management
 activities and functions that require the HSM to be in Authorized State. RLMK smartcards store Local Master
 Key (LMK) shares and/or authorization passwords. As such, the security of the RLMK smartcards is critical to
 the security of the payShield Manager.
- In addition to the general security guidelines relating to smartcards, the following guidelines apply specifically to RLMK cards:
- RLMK cards MUST be clearly labeled; and, as a minimum, the label MUST identify the LMK.
- RLMK Authorizing Password smartcards SHOULD be created and used for day-to-day operations; and cards
 containing LMK shares SHOULD NOT be used for day-to-day operations.
- RLMK Authorizing Password smartcards MUST be clearly labeled; and, as a minimum, the label MUST identify the LMK and the password number (1 or 2).



RLMK and RLMK Authorizing Password smartcards are specific to a particular LMK and so when multiple LMKs are used, the labeling of the cards is crucial. It may therefore be convenient if the authorizing password card's label also includes the relevant LMK identifier although this can be changed when the LMK is loaded. The LMK identifying is less likely to change in systems where the same LMK is loaded on to multiple HSMs.

11.2.11 Customer Security Domain

• The term "Customer Security Domain" describes a set of smartcards and HSMs, such that (secure) remote communication between a card in the group and the HSM in the group is permitted. A necessary pre-requisite for a card and a HSM to be in the same Security Group is that both must possess their own key pair, with the public key signed by the same CTA private key.

- In addition to the Customer Security Domain each HSM maintains its own whitelist, into which smartcard details (including public key certificate and serial number) are loaded and associated with their designated role. If an HSM does not contain details of a particular smartcard then communication between the two devices is not possible.
- Details of the initialization and management of the Customer Security Domain can be found in the *payShield* 10K Installation and User Guide.
- The Security Manager MUST keep a record of all smartcards and HSMs that belong to each Customer Security Domain; the record MUST be updated as new devices are added to, or deleted from any Customer Security Domain.
- The Security Manager MUST keep a record of all smartcards and their associated roles allowed to communicate to each HSM; the record MUST be updated as new devices are added to, or deleted from the HSM.
- Details of a lost or stolen card MUST be deleted from all HSM whitelists in the card's Customer Security Domain as soon as possible.

11.2.12 Back-Up

- All equipment and audit records relating to the payShield Manager must be backed-up.
- All RLMK smartcards and corresponding PINs SHOULD be backed-up and stored securely, separate from the primary cards; at least one back-up copy of each share SHOULD be stored off-site.
- At least one set of CTA private key share cards that can be used to re-generate the CTA private key (i.e., "k" such cards) and the corresponding PINs SHOULD be stored separately and securely off-site.
- All audit records relating to the payShield Manager MUST be backed-up and at least one copy SHOULD be stored off-site.
- Access control relating to all back-up equipment and audit records MUST be equivalent in strength to the controls surrounding the primary items.

11.2.13 Operational Security

- Details of payShield Manager operations are given in *payShield 10K Installation and User Guide*. These should be complemented by an organizational security and operations document based on this guide. The following guidelines should be used in conjunction with other guidelines in this document.
- **Remark:** The "key" guidelines listed below do not attempt to define a key management policy (e.g., key generation, distribution, update, archive, destruction, etc.). Such a policy should already exist within the organization and so any of the particular guidelines below that relate to keys should be used to complement this policy.
- Users MUST be fully aware of, and follow, security procedures relating to the operation of the payShield Manager.
- The Security Manager MUST ensure that all security procedures relating to the operation of the payShield Manager are followed correctly.
- Users MUST logout and take their smartcards with them if they exit the Operations Room.
- Users MUST ensure that nobody else can observe the entry of a PIN at a smartcard reader.
- HSMs MUST NOT be placed in the Offline state, Secure mode, or Authorized state for any longer than is absolutely necessary to complete the required activity.
- Users MUST NOT be logged into HSMs for any longer than is absolutely necessary.
- A time-out for user sessions SHOULD be specified.
- A Web Application Firewall may be employed to offer additional defense in depth against attacks on the payShield Manager interface.

12 Appendix C –TLS Security Recommendations

12.1 Background

The payShield 10K allows for secure host communications via the TLS protocol. These connections are secured using a Public Key Infrastructure (PKI) trust system.

12.1.1 payShield 10K TLS Server

The payShield 10K provides the TLS server for secure host communications. To enhance the security of the connections, the server has been configured with options described in the sections that follow.

12.1.2 Protocol Support

The TLS server only supports the TLS v1.2 protocol.

12.1.3 Cipher Suite Support

The server will only support connections with one of the following cipher suites; with preference being given in descending order:

Cipher ID	Cipher Suite Name	Protocol version
1	TLS_ECDHE_ECDSA_WITH_AES_256_GCM_SHA384	TLS v1.2
2	TLS_ECDHE_ECDSA_WITH_AES_256_CBC_SHA384	TLS v1.2
3	TLS_ECDHE_ECDSA_WITH_AES_128_GCM_SHA256	TLS v1.2
4	TLS_ECDHE_ECDSA_WITH_AES_128_CBC_SHA256	TLS v1.2
5	TLS_ECDHE_RSA_WITH_AES_128_GCM_SHA256	TLS v1.2
6	TLS_ECDHE_RSA_WITH_AES_128_CBC_SHA256	TLS v1.2
7	TLS_DHE_RSA_WITH_AES_256_GCM_SHA384	TLS v1.2
8	TLS_DHE_RSA_WITH_AES_256_CBC_SHA256	TLS v1.2
9	TLS_DHE_RSA_WITH_AES_128_GCM_SHA256	TLS v1.2
10	TLS_DHE_RSA_WITH_AES_128_CBC_SHA256	TLS v1.2

Elliptic Curve Cryptography (ECC) asymmetric key pairs SHOULD be preferred over RSA key pairs whenever possible due to the increased security strength they provide.

For software version 1.9a and later, the following restrictions are no longer applied to adhere to the latest standards. This is because RFC 8422 has replaced RFC 4492:

- An ECC key can be included in a certificate signed by an RSA CA
- An RSA key can be included in a certificate signed by an ECC CA
- · Client and Server ECC keys no longer need to be the same length
- Client and Server keys no longer need to be the same type, i.e., the Client can be RSA and the Server ECC and vice versa

Note that only ECC key curves and lengths of P256, P-384 and P-521 are supported.

12.1.4 TLS Configuration Options

The server also has the following options configured:

- When negotiating a cipher, the server's cipher preferences will be used as opposed to the client's cipher preferences.
- Ephemeral key cipher suites are preferred by the server. When selected, every new handshake will require new ephemeral keys be generated; this provides perfect forward secrecy.
- When performing a renegotiation of an existing connection, the server will always force a new session to be negotiated; this protects against a known renegotiation vulnerability.
- Connections will not use data compression, protecting against the CRIME vulnerability.

12.1.5 Man-In-The-Middle Mitigation

The payShield 10K TLS server implements a client whitelist mechanism to help prevent man-in-the-middle attacks; this prevents any unspecified clients from successfully connecting to the HSM. Any TLS client that wishes to communicate with the server must first have their public key certificate installed in the HSM (performed using the console command SI).

It should be noted that the TLS protocols do not intrinsically provide protection against man-in-the-middle attacks. Therefore clients MUST authenticate the TLS server they are connecting to by checking the information in the server's public key certificate.

To facilitate this validation check, server certificates MUST contain a reference to the entity they belong to; in this case the payShield 10K Host IP address. This can be achieved through the Subject Alternative Name field of X.509 public key certificates or through an internal PKI and Certificate Authority (CA).

12.1.6 TLS Clients

The payShield 10K TLS server enforces mutual authentication. This requires the client to authenticate itself to the server as part of the handshake.

To successfully connect to the payShield 10K clients must have their own asymmetric key pair; the public key of which will be provided to the server during the handshake in the form of a public key certificate.

Thales recommend that industry best practices are followed for the generation, storage and usage of these asymmetric key pairs.

12.1.7 Client Mitigations

The payShield 10K TLS server includes mitigations for the BEAST attack (CVE-2011-3389); however, due to the nature of this attack a TLS session can still be vulnerable if the TLS client does not also implement similar mitigations.

Thales recommend that TLS clients with BEAST mitigations are used to establish secure host communications with the payShield 10K.

13 Appendix D – Audit Log Messages

Category	Audit Log	Com- mand Code Type	Com- mand Code	Res- ponse Code	Notes
Access Control List (ACL)	TCP/TLS connection from x.x.x.x to y.y.y.y refused due to ACL UDP traffic from x.x.x.x to y.y.y.y refused due to ACL	A	00	00	Optional (controlled by "Audit ACL connection failures" audit option; Disabled by default) x.x.x.x - source IP address y.y.y.y - destination IP address (host 1 or host 2)
Audit log	Audit log was cleared Cleared all retrieved audit logs Cleared all archived audit logs	A	CL	00	
Authentica tion	Authentication cmd XX executed	А	00	00	"XX" is the authentication related console command (such as CO, KD, SP, XD, XH, XR) that was executed
Authorizati on	Activity A was authorized for LMK id 0-19 Activity A:T was authorized for LMK id 0-19 Authorization activity A:T was cancelled Authorization activity A was cancelled for LMK id 0-19 Authorization activity A:T has expired for LMK id 0-19 HSM was authorized for LMK id 0-19 HSM authorization was cancelled for LMK id 0-19Le	A	AA	00	A - activity list, T - timeout
Bootup	System Restarted	А	PW	00	
Console command	Console command XX	С	Console Command Code	00	"XX" is the console command that was executed Audit of desired console commands is done via "auditoptions" console command or via payShield manager Security sensitive console commands are always audited
Commissi oning	HSM commissioned HSM decommissioned HSM commission failed; error "error message"	A	CS DC CF	00	
Diagnostic s	Diagnostic self tests passed Diagnostic self test failure: "test name"	A	DE	00	Optional (controlled by "Audit diagnostic self tests" audit option; Disabled by default) "test name" is name of the failed diagnostic self test

Category	Audit Log	Com- mand Code Type	Com- mand Code	Res- ponse Code	Notes
Firmware update	Firmware update attempted Firmware update package validation failed Firmware update failed Firmware update to revision XXXX-YYYY and bootstrap version u.u.u successful / failed	A	FA FF FF FS	00	"Firmware update failed" is generated when firmware update fails and version info is not available (such as package validation failure) XXXX-YYYY is the revision If uboot was present in the update package, "and bootstrap version u.u.u" is included in the log message (where u.u.u is the uboot version)
Fraud	Fraud event detected executing host command XX - Limit of number of PIN verification failures per minute exceeded Fraud event detected executing host command XX - Limit of number of PIN verification failures per hour exceeded Fraud event detected executing host command XX - PIN attack limit exceeded	F	FE	01 02 03	"XX" is the host command that was executed
FRU (Field Replaceab le Units - fans, PSUs)	FAN 1/2 removed FAN 1/2 restored Fan 1/2 replaced: "fru serial number" Power Supply 1/2 removed Power Supply 1/2 restored Power Supply 1/2 replaced: "fru serial number" Power Supply 1/2 AC outage Power Supply 1/2 AC restored	A	НМ	00	"fru serial number" is the FRU serial number
Health Host command	Health Check Statistics reset to 0 Host command XX Host command XX, response EE	A H	UT Host Command Code	Host Comm and Respo nse Code	Audit of desired host commands is done via "auditoptions" console command or via payShield manager Optional (controlled by "Audit Error Responses to Host Commands" audit option; Disabled by default) XX is the host command EE is the error response to the host command
Key Managem ent	Smartcard activated: "card serial number" Smartcard PIN changed Key management command XX executed Loaded CTA share from smartcard Stored CTA share on smartcard Smartcard serial number read error	A	KE	00	"card serial number" is the smartcard serial number XX is the key management command that was executed On 9K, this was "Key I/O command XX executed"

Category	Audit Log	Com- mand Code Type	Com- mand Code	Res- ponse Code	Notes
Keylock	Keylock turned to Online/Offline/Secure	А	ON/OF/SE	00	
Licensing	New license file loaded License file load failed	А	LS	00	
	License lile load falled		LF		
LMK	LMKs loaded	A	LL	00	
	LMKs erased		LE		
	Keychange LMKs loaded		OL		
	Keychange LMKs erased		OE		
Maintenan ce	payShield "device serial number" maintenance light switch ON/OFF	A	00	00	"device serial number" is the 10K device serial number
Managem ent	Format of the audit logs for payShield manager commands is as follows:	A		00	Security sensitive management actions/commands are always audited
	Remote (xxxxxxxx) - "command string" - Current users: (None / Left: SSSS / Right: SSSS / Guest: SSSS)				Current Users will list all the logged in users;
	xxxxxxxx is the session cookie id				
	SSSS is the card serial number				
	Below are the various management command strings/messages when the				
	command is successful. A few of these are configurable (enabled/disabled via payShield manager Audit Settings).		ON/OF/SE 02/03		
	HSM state changed to Online/Offline/Secure		04		
	(Client: xxx.xxx.xxx) - Login / Logout		05		
	Session terminated		06		
	Single authorized state entered		07		
	Single authorized state cancelled		08		
	CTA generated		09		
	CTA share created on smartcard		10		
	CTA share read from smartcard (optional - disabled by default)		11		
	RACC commissioned				
	Left RACC prepared for commissioning		13		
	HSM commissioned		14		
	CTA share loaded from smartcard(optional - disabled by default)		15 16		
	CTA share stored on smartcard		17		
	Right RACC prepared for commissioning		18		
	Periodic diagnostic self tests schedule		19		
	changed		22		
	Diagnostic tests executed		23		
	Alarm settings modified		24		

Category	Audit Log	Com- mand Code Type	Com- mand Code	Res- ponse Code	Notes
	HSM date and time updated		25		
	PIN block settings modified		26		
	Fraud settings modified		27		
	Fraud detection re-enabled		28		
	Enabled host commands modified		29		
	Enabled console commands modified		30		
	Audit settings modified		31		
	Host commands audit modified		32		
	Console commands audit modified		33		
	Remote management commands audit modified		34		
			35		
	Health statistics report generated (optional - disabled by default)		36		
	Health statistics reset (optional - disabled by default)		37 39		
	HRK passphrases set		40		
	HRK passphrase 1 changed		41		
	HRK passphrase 2 changed		42		
	General host settings modified		43		
	Ethernet host settings modified		44		
	ACL host settings modified		45		
	Error log cleared		46		
	Error log retrieved (optional - disabled by default)		47		
	Error log downloaded (optional - disabled by default)		48		
	Audit log cleared		50		
	Audit log retrieved (optional - disabled by default)		51		
	Audit log downloaded (optional - disabled by default)		52 53		
	New LMK installed		54		
	Keychange old LMK installed		55		
	New LMK deleted		56		
	Keychange LMK deleted		57		
	LMK generated		58		
	LMK copied		59		
	LMK verified		60		
	Authorizing officer card created		63		
	Management interface settings modified		64		
			65		

Category	Audit Log	Com- mand Code Type	Com- mand Code	Res- ponse Code	Notes
	Printer settings modified (optional - disabled by default)		66		
	Test page printed (optional - disabled by default)		67 68		
	General security settings modified		69		
	Initial security settings modified		70		
	SNMP state changed (optional - enabled by default)		71 72		
	SNMP port changed (optional - disabled by default)		73		
	SNMP user added (optional - disabled by default)		74 75		
	SNMP user deleted		76		
	VR info retrieved (optional - enabled by default)		77		
	Licensing info retrieved (optional - disabled by default)		78 79		
	Firmware update attempted		80		
	License updated (optional - enabled by default)		81		
	Utilstats settings modified (optional - disabled by default)		82		
	Utilstats state changed (optional - disabled by default)		84		
	Utilstats reset (optional - disabled by default)		85 86		
	Miscellaneous settings modified (optional - disabled by default)		87		
	Multiple authorized state changed		88		
	Whitelist modified		89		
	Session timeout settings modified				
	Keychange new LMK installed				
	Management TLS certificate imported				
	Host TLS certificate imported				
	LMK share loaded				
	LMK share stored				
	LMK split				
	LMK reassembled				
	LMK password loaded				
	LMK password stored				
	HSM settings loaded from smartcard				
	HSM settings saved to smartcard (optional - enabled by default)				
	HSM settings reset to factory state				

Category	Audit Log	Com- mand Code Type	Com- mand Code	Res- ponse Code	Notes
	HSM reboot requested				
	Invalid request				
	Failure audit logs are generated for most of the above commands/actions when the command fails:				
	(Client: xxx.xxx.xxx.xxx) - Login failed / Logout failed				
	Failed to generate CTA				
	Failed to read CTA share from smartcard				
	Failed to load CTA share from smartcard				
	Failed to create CTA share on smartcard				
	Failed to store CTA share on smartcard				
	Failed to commission RACC				
	Failed to prepare left RACC for commissioning				
	Failed to prepare right RACC for commissioning				
	Failed to commission HSM				
	Failed to update license				
	Failed to set HRK passphrases				
	Failed to change HRK passphrase 1				
	Failed to change HRK passphrase 2				
	Failed to update HSM date and time				
	Failed to install keychange old LMK				
	Failed to delete new LMK				
	Failed to generate LMK				
	Failed to copy LMK				
	Failed to verify LMK				
	Failed to load LMK share				
	Failed to store LMK share				
	Failed to split LMK				
	Failed to reassemble LMK				
	Failed to create authorizing officer card				
	Failed to import management TLS certificate				
	Failed to import host TLS certificate				
	Failed to load HSM settings from smartcard				
	Failed to save HSM settings to smartcard				
	Failed to reset to HSM settings to factory state				
	Failed to enter single authorized state				
	Failed to enter cancel authorized state				

Category	Audit Log	Com- mand Code Type	Com- mand Code	Res- ponse Code	Notes
	Failed to modify whitelist				
Reboot	System rebooted due to firmware update System rebooted due to management request System rebooted due to critical diagnostic test failure - "failed test name"	A	SH	00	
Secure Host Comms	Certificate not yet valid. Unique ID: "Cert ID" Certificate has expired. Unique ID: "Cert ID" Error in Cert. Not Before Field. Unique ID: "Cert ID" Error in Cert. Not After Field. Unique ID: "Cert ID"	A	CN CE CB CA	00	"Cert ID" is the certificate's unique ID
Settings	HSM settings saved to smartcard HSM settings loaded from smartcard HSM settings saved to smartcard (remote) HSM settings loaded from smartcard (remote)	A	SC	00	"(remote)" refers to settings save/restore from payShield manager
SNMP	SNMP user added/deleted SNMP trap receiver added/deleted	A	SN	00	
Tamper	Tamper Detected "tamper text" High Tamper Detected "tamper text" Tamper Cleared	A	НМ	00	"tamper text" provides tamper details
Utilization	Utilization Statistics reset to 0	А	UT	00	Optional (controlled by "Audit utilization data resets" audit option; Enabled by default)

Technical Support Contacts

Our team of knowledgeable and friendly support staff are available to help. If your product is under warranty or you hold a support contract with Thales, do not hesitate to contact us using the link below. For more information, consult our standard Terms and Conditions for Warranty and Support.

https://supportportal.thalesgroup.com/csm

THALES

Contact us

For all office locations and contact information, please visit cpl.thalesgroup.com/contact-us

> cpl.thalesgroup.com <









2.