

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Royal Enfield - CONTINENTAL-GT-OWNERS-MANUAL

1 Foreword

The Royal Enfield Continental GT is our lightest, fastest, and most powerful motorcycle in production. It's a machine with a story, a nod to motorcycling's finest hour, the best expression yet of a cultural phenomenon that has simply refused to fade away - the cafe racer.

And now you have one of your own. Congratulations!

Your meticulously re-engineered Continental GT debuts a twin downtube cradle frame chassis developed by the renowned Harris Performance from UK. A new engine displaces 535cc and dollops of torque, when you need it. With gas-charged rear shock absorbers from Paoli and Brembo disc brakes, you stay in charge. With an aerodynamic seating position, Pirelli Sports Demon tyres and a remapped ECU, the new Continental GT is part homage, part engineering tour-de-force.

This manual will help you to operate your motorcycle and guide you to wholly maintain it. We have also provided tips on safe riding and on minor adjustments for the care of your motorcycle. Please avail the four free services at the nearest Authorised Service Point at the appropriate time to maintain your motorcycle in top riding condition. We request you to carefully read the terms and conditions of warranty and other useful information given in this manual before starting to use your Continental GT. Log on to the exciting world of Royal Enfield on www.royalenfield.com to get to know more about the company, its products and news from time to time.

Welcome to the world of the Rockers, and enjoy your burn-ups atop this spectacular machine.

2

All information in this manual is based on the latest product information available at the time of publication. Due to continuous improvements or other changes, there may be discrepancies between information in this manual and your vehicle. Royal Enfield reserves the right to make production changes at any time without prior notice and without incurring any obligation to make same or similar changes to vehicles previously built or sold.

All images shown are for reference to explain and need not to be exactly the same on the model you own. Technical specifications are subject to change without prior notice.

© Copyright 2014 Royal Enfield (A unit of Eicher Motors Ltd.). All Rights Reserved. No part of this manual shall be copied, distributed or otherwise dealt with without the express permission in writing from Royal Enfield. Notice

Part No. 585441/A / Revision 1.0 / Qty. 500 / Apr. 2014 Disclaimer

* This model fitted with tubeless tyre is provided with an inner tube.

* Failure to use an inner tube in a spoked wheel will cause deflation of the tyre resulting in loss of motorcycle control.

* The approved tyres marked with TUBELESS are suitable for use with inner tube.

3

PERSONAL & VEHICLE INFORMATION 6

FREE SERVICE RECORD 7

SAFETY DEFINITIONS 8

TECHNICAL SPECIFICATIONS 9

Engine 9

Ignition System 10

Transmission 10

Electricals 11

Chassis 12

Dimensions 13

Weights 13

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

SAFE RIDING TIPS/GUIDELINES	14	SAFE & HAPPY RIDING	18
RULES OF THE ROAD	19		
VEHICLE IDENTI. NUMBER-DETAILS	21	KEY PARTS LOCATION	22
Right Side View	22		
Left Side View.....	23		
Top View	24		
OPERATION OF CONTROLS	25		
Ignition Switch	25		
Steering Lock	26		
Steering Unlock	26		
Fuel Tank Cap.....	27		
Side Panel LH / Battery Cover	27		
Utility Box	27		
Side PANEL RH	27		
Alpha-Numeric display unit.....	28		
Head Lamp Switch.....	30		
Head Lamp Day Flash.....	30		
Dip Switch	30		
Engine Start Switch	31		
Engine Stop Switch	31		
Turn Signal Switch	31		
Horn	32	Contents	
4 Contents			
Manual Bi Starter (choke)	32		
PRE OPERATIONAL CHECKS	33		
RUNNING IN PERIOD.....	34		
ELECTRONIC FUEL INJECTION (EFI)	35		
EFI	35		
The Advantages of EFI	35		
Malfunction Indicator Lamp (MIL)	35		
ROLL OVER SENSOR	36		
STARTING	37		
GEAR SHIFTING	40	PARKING	41
Center Stand	41		
Side Stand	41		
TOOLS & FIRST AID KIT.....	42		
RECOMMENDED LUBRICANTS	43		
PERIODICAL MAINTENANCE	44		
MINOR MAINTENANCE TIPS	48		
Control Cables, Hand lever,			
Center / Side Stand Pivots	48		
Oil Level Inspection	48		
Engine oil change	49		
Spark Plug	50		
Brake fluid (Front & Rear)	51		

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Inspection of tyres and wheels	51	
Tyre pressure.....	52	
Front W heel removal	52	
Front Wheel reassembly	53	
Rear wheel removal	54	
Rear wheel reassembly.....	55	
Adjustments-Clutch lever free play	57	
Rear brake light switch adjustment.....	57	
Drive Chain free play	58	
Chain lock fitment	59	
Adj. of gas filled shockabsorber	60	
Removal of Battery from the Vehicle.....	61	
5 Contents		
Battery Maintenance.....	61	
Reassembly of Battery on Vehicle	62	
CHANGING ELECTRICAL COMPONENTS....	64	
Head Lamp Bulb Replacement	64	
Tail Lamp bulb Replacement	65	
Trafficator bulb Replacement	65	
Fuse	66	
Blade fuse usage list	66	
Air Filter Paper element.....	67	
WASHING PROCEDURE.....	68	
Precautions	68	
After washing.....	68	
STORAGE PRECAUTION	70	
Preparing the motorcycle for re-use ...	71	
LONG TRIP PRECAUTIONS	72	
COMPLETE WIRING DIAGRAM (Domestic) .	73	
TROUBLE SHOOTING	74	
Engine fails to start	74	
Engine misfiring	75	
Poor pickup	75	
White / Blue smoke	76	
Engine overheating	76	
Excessive fuel consumption.....	76	
Brakes Poor	77	
Vehicle wobbles.....	77	
Electricals	77	
Electronic Fuel Injection (EFI)	78	
WARRANTY	79	
EMISSION WARRANTY.....	81	
FREE SERVICE COUPONS	86	
PAID SERVICE/MAINTENANCE RECORD	95 ALL INDIA ROAD SIGNS	103
LOG BOOK	104	

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

NOTES 108

TECHNICAL SPECIFICATIONS

Engine

Ignition System

Transmission

Electricals

Chassis

Dimensions

Weights