

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Husaberg - Husaberg_2006_Manual_de_intretinere

OWNERS MANUAL

MANUEL D'UTILISATION

Edition 2006

HUSABERG - a company of the KTM Group

Stallhofner Straße 3, A-5230 Mattighofen

E-mail: info @husaberg.cc, Internet: www.husaberg.cc

Cover: Büro 3 Communication, Photos: Florian Jaenicke. 08/2005 ART. NR. 3802007

TABLE OF CONTENTS

- 1 -

ENGLISH

Page

INTRODUCTION	2
Important LIMITED warranty and LIMITED guarantee information	4
SERIAL NUMBER LOCATIONS	5
Chassis number	5
Engine-Number	5
OPERATION INSTRUMENTS	6
Clutch lever	6
Hand decompression lever	6
Hand brake lever	6
Short circuit button	6
Combination switch	7
Flasher switch	7
Headlamp switch (USA)	7
Indicator lamps	7
Starter button	8
Emergency OFF switch (Australia)	8
Electronic speedometer	8
Kilometers or miles	13
Setting the clock	13
Filler cap	14
Fuel Taps	14
Choke	14
Hot start device	14
Shift lever	15
Kickstarter	15
Foot brake pedal	15
Side stand	15
Compression damping of fork	16
Rebound damping of fork	16

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Damping action during compression of shock absorber	17
Rebound damping of shock absorber	18
Steering lock.	18
Instructions for initial operation.	19
Running in the Husaberg models	19
TIPS AND WARNINGS FOR STARTING THE MOTORCYCLE.	19
DRIVING INSTRUCTIONS.	20
Check the following before each start	20
Starting when the engine is cold.	21
Starting when the engine is warm	21
What to do when the engine is flooded	21
Starting off	22
Shifting/Riding	22
Braking	22
Stopping and parking	23
Fuel	23
PERIODIC MAINTENANCE SCHEDULE.	24
MAINTENANCE WORK ON CHASSIS AND ENGINE	27
Checking and adjusting the steering head bearing	27
Breather plug front fork.	28
Cleaning the dust sleeves of the telescopic fork	28
Basic suspension setup for the weight of the driver	29
Checking the shock absorber and spring	29
Determining the static sag of the shock absorber	29
Determining the riding sag of the shock absorber	29
Checking the basic setup of the telescopic fork	30
Changing the spring preload on the telescopic fork	30
Replacing fork springs	30
Page	
Changing the fork offset (caster) (FS)	31
How to change the handlebar position	33
Changing the spring preloading of the shock absorber	33
Check chain tension	34
Correct chain tension	34
Chain maintenance	35
Chain wear	35
General information about Husaberg disc brakes	36
Changing the basic position the hand brake lever (FE)	37
Changing the basic position the hand brake lever (FS)	37
Checking the brake fluid level - front brake	37
Refilling the front brake fluid reservoir	37
Checking the front brake pads	38
Replacing the front brake pads (FE)	38
Replacing the front brake pads (FS)	38

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Changing the basic position of the foot brake pedal	39
Check the rear brake fluid level	39
Refilling the rear brake fluid reservoir.	39
Checking the rear brake pads	40
Replacing the rear brake pads	40
Dismounting and mounting the front wheel	41
Dismounting and mounting the rear wheel.	42
Checking the shock absorption rubbers in the rear hub. 43	
Checking spoke tension	43
Tires, air pressure.	44
Check/set distance of the magnetic sensor	44
Battery	45
Charging the battery.	45
Fuse (FE/FS)	46
Replacing headlight lamp/parking light lamp	46
Cooling system.	47
Checking the coolant level	47
Bleeding the cooling system.	48
Replacing the glassfiber yarn packing of the silencer	48
Cleaning the spark arrester	48
Cleaning the air filter	49
Checking the adjustment of the hand decompressionrelease cable	49
Adjusting the throttle cables	49
Changing the original position of the clutch lever.	50
Checking the oil level of the hydraulic clutch	50
Bleeding of the hydraulic clutch	50
Carburetor Adjust idling	51
Basic information on carburetor wear.	51
Adjusting the mixture control screw	51
Checking the float level (float height)	52
Draining the float chamber of the carburetor	52
Oil Circuit	52
Checking the engine oil level	53
Engine oil	53
Changing the engine oil	53
Cleaning the oil screen	53
Changing the oil filter	54
TROUBLESHOOTING	55
CLEANING, CONSERVATION, STORAGE	57
TECHNICAL DATA - ENGINE.	58
TECHNICAL DATA - CHASSIS.	61
HEAD WORD INDEX	63
WIRING DIAGRAMM. Appendix	

INTRODUCTION

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

- 2 -

ENGLISH

IMPORTANT

WE STRONGLY SUGGEST THAT YOU READ THIS MANUAL CAREFULLY AND COMPLETELY BEFORE GOING ON YOUR FIRST RIDE. IT CONTAINS A GREAT DEAL OF INFORMATION AND ADVICE WHICH WILL HELP YOU USE AND HANDLE YOUR BIKE PROPERLY.

IN YOUR OWN INTEREST, PLEASE PAY PARTICULAR ATTENTION TO NOTICES THAT ARE MARKED AS FOLLOWS:

WARNING: IGNORING THESE INSTRUCTIONS, CAN ENDANGER YOUR BODY AND YOUR LIFE.

CAUTION: IGNORING THESE INSTRUCTIONS COULD CAUSE DAMAGE TO PARTS OF YOUR MOTORCYCLE OR THAT THE MOTOR-CYCLE IS NOT ROAD-SAFE ANYMORE.

NOTE: USEFUL INFORMATION ON HANDLING AND SERVICING YOUR MOTORCYCLE.

Please insert the serial numbers of your motorcycle in the boxes below

Frame number:

Motor number:

Stamp of dealer:

HUSABERG RESERVES THE RIGHT TO MODIFY ANY EQUIPMENT , TECHNICAL SPECIFICATIONS , COLORS , MATERIALS ,

SERVICES OFFERED AND RENDERED , AND THE LIKE SO AS TO ADAPT THEM TO LOCAL CONDITIONS WITHOUT PREVIOUS ANNOUNCEMENT AND WITHOUT GIVING REASONS , OR TO CANCEL ANY OF THE ABOVE ITEMS WITHOUT SUBSTITUTING THEM WITH OTHERS . IT SHALL BE ACCEPTABLE TO STOP MANUFACTURING A CERTAIN MODEL