

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Husaberg - Husaberg_05_Owners_Manual

OWNERS MANUAL

MANUEL D'UTILISATION

Edition 2005

HUSABERG - a company of the KTM Group

Stallhofner Straße 3, A-5230 Mattighofen

E-mail: info @husaberg.cc, Internet: www.husaberg.cc

Cover: Büro 3 Communication, Photos: Florian Jaenicke. 05/2003 ART. NR. 3802003

TABLE OF CONTENTS

- 1 -

ENGLISH

Page

INTRODUCTION	2
Important LIMITED warranty and LIMITED guarantee information	4
SERIAL NUMBER LOCATIONS	5
Chassis number	5
Engine-Number	5
OPERATION INSTRUMENTS	6
Clutch lever	6
Hand decompression lever	6
Hand brake lever	6
Short circuit button	6
Combination switch	7
Flasher switch	7
Headlamp switch (USA)	7
Indicator lamps	7
Starter button	8
Emergency OFF switch (Australia)	8
Electronic speedometer	8
Kilometers or miles	13
Setting the clock	13
Filler cap	14
Fuel Taps	14
Choke	14
Hot start device	14
Shift lever	15
Kickstarter	15
Foot brake pedal	15
Side stand	15
Compression damping of fork	16
Rebound damping of fork	16

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Damping action during compression of shock absorber	17
Rebound damping of shock absorber	18
Steering lock	18
Instructions for initial operation	19
Running in the Husaberg models	19
TIPS AND WARNINGS FOR STARTING THE MOTORCYCLE	19
DRIVING INSTRUCTIONS	20
Check the following before each start	20
Starting when the engine is cold	21
Starting when the engine is warm	21
What to do when the engine is flooded	21
Starting off	21
Shifting/Riding	22
Braking	22
Stopping and parking	23
Fuel	23
PERIODIC MAINTENANCE SCHEDULE	24
MAINTENANCE WORK ON CHASSIS AND ENGINE	28
Checking and adjusting the steering head bearing	28
Breather plug front fork	29
Cleaning the dust sleeves of the telescopic fork	29
Basic suspension setup for the weight of the driver	30
Checking the shock absorber and spring	30
Determining the static sag of the shock absorber	30
Determining the riding sag of the shock absorber	30
Checking the basic setup of the telescopic fork	31
Changing the spring preload on the telescopic fork	31
Replacing fork springs	31

Page

Changing the fork offset (caster) (FS)	32
How to change the handlebar position	34
Changing the spring preloading of the shock absorber	34
Check chain tension	35
Correct chain tension	35
Chain maintenance	36
Chain wear	36
General information about Husaberg disc brakes	37
Changing the basic position the hand brake lever (FC, FE)	38
Changing the basic position the hand brake lever (FS)	38
Checking the brake fluid level - front brake	38
Refilling the front brake fluid reservoir	38
Checking the front brake pads	39
Replacing the front brake pads (FC/FE)	39

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Replacing the front brake pads (FS)	39
Changing the basic position of the foot brake pedal	40
Check the rear brake fluid level	40
Refilling the rear brake fluid reservoir	40
Checking the rear brake pads	41
Replacing the rear brake pads	41
Dismounting and mounting the front wheel	42
Dismounting and mounting the rear wheel	43
Checking the shock absorption rubbers in the rear hub	44
Checking spoke tension	44
Tires, air pressure	45
Check/set distance of the magnetic sensor	45
Battery	46
Charging the battery	46
Fuse (FE/FS)	47
Replacing headlight lamp/parking light lamp	47
Cooling system	48
Checking the coolant level	48
Bleeding the cooling system	49
Replacing the glassfiber yarn packing of the silencer . .	49
Cleaning the spark arrester	49
Cleaning the air filter	50
Checking the adjustment of the hand decompression release cable	50
Adjusting the throttle cables	50
Changing the original position of the clutch lever	51
Checking the oil level of the hydraulic clutch	51
Bleeding of the hydraulic clutch	51
Carburetor Adjust idling	52
Basic information on carburetor wear	52
Adjusting the mixture control screw	52
Checking the float level (float height)	53
Draining the float chamber of the carburetor	53
Oil Circuit	53
Checking the engine oil level	54
Engine oil	54
Changing the engine oil	54
Cleaning the oil screen	54
Changing the oil filter	55
TROUBLESHOOTING	56
CLEANING, CONSERVATION, STORAGE	58
TECHNICAL DATA - ENGINE	59
TECHNICAL DATA - CHASSIS	62
HEAD WORD INDEX	64
WIRING DIAGRAMM	Appendix

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

INTRODUCTION

- 2 -

ENGLISH

IMPORTANT

WE STRONGLY SUGGEST THAT YOU READ THIS MANUAL CAREFULLY AND COMPLETELY BEFORE GOING ON YOUR FIRST RIDE. IT CONTAINS A GREAT DEAL OF INFORMATION AND ADVICE WHICH WILL HELP YOU USE AND HANDLE YOUR BIKE PROPERLY.

IN YOUR OWN INTEREST, PLEASE PAY PARTICULAR ATTENTION TO NOTICES THAT ARE MARKED AS FOLLOWS:

WARNING: IGNORING THESE INSTRUCTIONS, CAN ENDANGER YOUR BODY AND YOUR LIFE.

CAUTION: IGNORING THESE INSTRUCTIONS COULD CAUSE DAMAGE TO PARTS OF YOUR MOTORCYCLE OR THAT THE MOTOR-CYCLE IS NOT ROAD-SAFE ANYMORE.

NOTE: USEFUL INFORMATION ON HANDLING AND SERVICING YOUR MOTORCYCLE.

Please insert the serial numbers of your motorcycle in the boxes below

Frame number:

Motor number:

Stamp of dealer:

HUSABERG RESERVES THE RIGHT TO MODIFY ANY EQUIPMENT, TECHNICAL SPECIFICATIONS, COLORS, MATERIALS,

SERVICES OFFERED AND RENDERED, AND THE LIKE SO AS TO ADAPT THEM TO LOCAL CONDITIONS WITHOUT PREVIOUS ANNOUNCE -

MENT AND WITHOUT GIVING REASONS, OR TO CANCEL ANY OF THE ABOVE ITEMS WITHOUT SUBSTITUTING THEM WITH OTHERS. IT

SHALL BE ACCEPTABLE TO STOP MANUFACTURING A CERTAIN MODEL WITH