

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Peugeot - jet_ctech

Sales division

Technical network leadership

WORKSHOP MANUAL

-
Downloaded from www.Manualslib.com manuals search engine

Sales division

Technical network leadership Reproduction or translation, even partial, is forbidden without the written consent of Peugeot Motocycles
Downloaded from www.Manualslib.com manuals search engine

TABLE OF CONTENTS

1

Reproduction or translation, even partial, is forbidden without the written consent of Peugeot Motocycles
TABLE OF CONTENTS

TABLE OF CONTENTS.....	1
CHARACTERISTICS.....	3
Engine.....	3
Capacities.....	3
Chassis.....	4
Dimensions and weight.....	4
Tyres.....	4
Chassis markings.....	4
Engine marking.....	4
SERVICE SCHEDULE AND COMMISSIONING.....	5
Check.....	5
Change.....	5
Check and lubricate.....	6
Clean and adjust.....	6
Test machine.....	6
Battery preparation (Except battery without maintenance)*.....	7
Checks before handing over to the customer.....	7
SPECIAL IMPORTANT POINTS.....	8
Oil and fuel.....	8
Starting up after overhauling the engine.....	8
TIGHTENING TORQUES.....	9
Body panels.....	9
Cycle part.....	9
Standard.....	9
SPECIAL TOOLS.....	10
LOCATION OF COMPONENTS.....	11
BODY PANELS.....	12
Removal of the front shield panel.....	12
Removal of front lower shield panels.....	12
Removing the footboard and the LH tunnel.....	12

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Removal of the storage compartment.....	13
Removal of the rear cover assembly and mudflap.....	14
Removal of the header tank.....	14
ELECTRIC COMPONENTS.....	15
Removal of the blinker unit.....	15
from www.Manualslib.com manuals search engine	Downloaded

TABLE OF CONTENTS

2

Reproduction or translation, even partial, is forbidden without the written consent of Peugeot Motorcycles
Removal of the ignition module.....15

Removal of the headlight bulbs.....	15
Removal of the horn.....	16
Removal of the oil pump control unit.....	16
Removal of the regulator.....	16
Removal of the engine temperature sensor.....	16
Removal of the oil pump.....	16
Removal of the high tension coil.....	17

PETROL CIRCUITS.....18

Removal of the fuel tank filter.....	18
Removal of the fuel pump.....	18
Removal of the carburettor.....	19
Procedure to position the carburettor.....	20
Removal of the inlet coupling and valves.....	21
Removal of the inlet coupling and valves.....	21
Removal of the throttle valve.....	21

WORKING ON THE ENGINE WITHOUT REMOVING THE ENGINE.....22

Removal of the air pump.....	22
Removal of the cylinder / piston.....	22
Removal of the water pump.....	23

MISCELLANEOUS OPERATIONS.....24

 Removal of the rear brake pad.....24
 from www.Manualslib.com manuals search engine

CHARACTERISTICS

3

Reproduction or translation, even partial, is forbidden without the written consent of Peugeot
Motorcycles

CHARACTERISTICS

Engine.

Capacities. Jet C-Tech 307 WRC

Type. 2-stroke single-cylinder.

Cooling. Liquid.

Bore x stroke. 39.9 x 39.8 mm.

Cubic capacity. 49.9cc.

Max. power output. 3.6 kW at 7300 rpm.

Max. torque rating. 7000 rpm.

Fuel supply. Carburettor Gurtner PY15.

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Lubrication. Electric oil pump.

Transmission. By 2 variable pulleys and V-type belt.

Clutch. Centrifugal automatic.

Spark plug. NGK CR7EB.

Exhaust. Catalytic.

Fuel tank. 7.8l 95 or 98 lead-free.

Oil tank. 1.2 l.

Semi synthetic for 2stroke engines with separate oiling.

Relay box. 0.12l SAE 80W90 life lubricated.

Coolant. 1.4 l.

Peugeot coolant part number 754614.

Fork. 0.12 l per tube (Esso Univis 46 or Agip