

# **BL Motorcycles Ltd**

*Professional Workshop Manual - English Translation*

## **Beta - Beta REV3-4t- Trial service manual**

REV 4T

Betamotor S.p.A. Pian dellIsola, 72 50067 Rignano SullArno (Firenze) Italia Tel +39 055 83 48 741 Fax +39 055 83 48 984 info@betamotor.com

COD 21.73243.000 ENG2007 OWNERS MANUAL

[betamotor.com](http://betamotor.com)

Thank you for choosing Betamotor. We hope you enjoy your motorcycle.

This booklet provides the information you will need to use and maintain your bike properly.

The details and specifications given in this manual do not commit BETAMOTOR S.p.A, who reserve the right to make changes to their models at any time.

OWNERS MANUAL

[betamotor.com](http://betamotor.com)

CAUTION

It is important, after the first hour of break-in, to check the tightness of all fasteners, paying particular attention to the following:

Footrest brackets

Front and rear brake discs

Wheel spokes

Shockabsorber bolt

Engine bolts

Rear sprocket

Exhaust bolts

ENGLISH

Index

CHAPTER 1: GENERAL INFORMATION

INDEX OF TOPICS

Principal	parts	
.....	6	
Vehicle	identification	details
.....	6	
Console	and	controls

# BL Motorcycles Ltd

Professional Workshop Manual - English Translation

.....	6	.....	details
Technical			
.....	7	.....	scheme
Wiring			
.....	8	.....	

## CHAPTER 2: OPERATION AND USE

### INDEX OF TOPICS

Filling	the	fuel	tank				
.....							
.....	10	.....					
Start-up							
.....	10	.....					
Break-in							
.....	12	.....					
Checks	and	maintenance	before	and	after	use	off-road
.....							
.....	12	.....					
Recommended		lubricants		and			liquids
.....							
... 13							

## CHAPTER 3: MAINTENANCE AND CHECKS

### INDEX OF TOPICS

Lubrication			circuit
.....			
.....	15	.....	
Engine			oil
.....			
.....	16	.....	
Brake	master	cylinder	fluid
.....			
.....	19	.....	
Brakes		circuit	bleeding
.....			
.....	21	.....	
Clutch	master	cylinder	fluid

# BL Motorcycles Ltd

*Professional Workshop Manual - English Translation*

..... 22		
Clutch	circuit	bleeding
..... 22		
Fork		oil
..... 23		
Air		filter
..... 24		
Sparkplug		
..... 25		
Front		brake
..... 26		
Rear		brake
..... 27		
Coolant		
..... 28		
Checks	after	cleaning
..... 28		
Scheduled		maintenance
..... 29		

## CHAPTER 4: ADJUSTMENTS

### INDEX OF TOPICS

Brake	adjustment
..... 31	
Clutch	adjustment
..... 31	
Carburettor	
..... 32	
Tickover	adjustment

# BL Motorcycles Ltd

*Professional Workshop Manual - English Translation*

.....	32			
Throttle	free	clearance		adjustment
.....	32			
Steering	paly	check	and	adjustment
.....	33			
Chain				tension
.....	33			
Front		suspension		adjustment
.....	34			
Rear		shockabsorber		adjustment
.....	34			

## CHAPTER 5: WHAT TO