

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Beta - Beta R107 minicross service manual

BETAMOTOR S.p.A.

Pian dellisola, 72

50067 Rignano SullArno (Firenze) Italy

Tel. +39-055-8348741 Fax +39-055-8348984

www.betamotor.com - info@betamotor.com

MINICROSS R107 cc 10/12"

BETAMOTOR S.p.A. congratulates you on choosing one of its products.

This manual contains all the information, advice and remarks which our technicians considered useful to properly operate your motorcycle. It also contains directions about periodical maintenance operation, in order that your motorcycle may always be kept in perfect working order.

Every vehicle is supplied with a copy of the manual. BETAMOTOR S.p.A. reserves the right to change the data and features described in this manual and to modify its products at any time.

2INFORMATIONS

ATTENTION

After the first training hour, check all the tightenings and in particular manner:

Footboard supports

Shock absorber cover

Wheel rims

Shock absorber

Engine bolts and nuts

Crown

3INFORMATIONS

REMEMBER THAT

The means you own is not a toy, you must use it with competence, attention and respect towards the others and towards yourself. Please always wear the advised apparels, the helmet (well closed), the suitable glasses, gloves and shoes. Do not try to show to yourself and to the others your driving capabilities.

WARNING

The vehicle must be in the proportions of the drivers sizes, the person must be able to comfortably lay his feet on the round when hes sitting on the

saddle. The vehicle was designed for a driver with a weight not higher than 75 kg. The vehicle, if used in a non correct way without paying attention to

the I manuals indication can cause you serious hurts, permanent and/or even mortal ones.

THE MANUAL

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

First, this must be carefully read by an adult who afterwards must inform and train the minor to correctly use the Minicross. The minor, if he can, must anyway read the manual to feel responsible. This manual contains useful information for the use and maintenance of the Minicross and the indications in order to keep it always at the top of its efficiency, so it is important to read this manual and learn the advise and suggestions that we feel are important for you to have.

4INFORMATIONS

BETAMOTOR S.p.A. reserves the right
to change the data and features described in this manual and to modify its products at any time.

5INFORMATIONS

Symbols	6
Description	6
Safety, advice and recommandations	7
Ecologic drive	12
SECTION 1: GENERAL INFORMATION	
Main parts	14
Vehicle identification data	15
Plates on the vehicle	16
Hand drive controls	17
Technical data	18
Electrical diagram	19
SECTION 2: OPERATION AND USE Checks and maintenance before and after use	
22	
How to fuel up into the Minicross	23
How to stock and manage fuel	25
Recommended lubricants and liquids ...	26
Breaking in	27
Startup	28
SECTION 3: MAINTENANCE AND CHECKS Maintenance, description	
30	
Maintenance and checking to perform	31
Gearbox oil	32
Air filter	33
Spark plug	34
Brakes	35
Checks after cleaning	36
Maintenance and schedule	37
How to transport the vehicle	38
How to dispose the vehicle	38
Suitable apparels	38
SECTION 4: ADJUSTMENTS Adjustment of brakes	
42	
Adjustment of clutch	43
Adjustment of gas clearance	43

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Adjustment of idling speed	44
Check and adjustment of steering gear ...	45
Tightening the chain	46
Adjustment of rear shock absorber	47
SECTION 5: WHAT TO DO IN AN EMERGENCY Troubleshooting	
50	
ALPHABETICAL INDEX Index	
53	

6INFORMATIONS

WARNING

The guarantee is considered null

and the manufacturer is released of all responsibility in the case of any intervention carried out by unauthorized personnel, technical modifications and/or tampering carried out on the Minicross during the guarantee period, or if non original spare parts are used.

Always wear your crash helmet, the suitable suit, shoes and glasses for a motorbiker and dont go over your capa

-
bilities. Being careful means
being intelligent.

SYMBOLS

SAFETY/WARNING

If the parts indicated with this symbol are not respected this could lead to danger for the driver.

VEHICLE INTEGRITY

If the parts indicated by this symbol are not respected, this can lead to serious damage to the vehicle and to the guarantee being null.

SAFEGUARDING

THE ENVIRONMENT

Behaviour to be adopted in order not to damage nature.

PROTECTION DEVICES

Use the protection devices shown.

BE INFORMED

Important information for the safety
of both owner and vehicle

DESCRIPTION

This manual is Your guide to the
use and simple maintenance of the Minicross.

We suggest that you follow
very closely the advise herewith contained because the good working order and durability in time of the Minicross
depend on its correct use and on the methodical application of the
maintenance rules mentioned.

We recommend that You read
this MANUAL carefully in all its parts before carrying out any USE operation or small MAINTENANCE, to be carried out
always and in any case with the help of an adult and under adult supervision.

In case of loss or deterioration

of this manual it is necessary to ask your dealer directly for a new copy.

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

7INFORMATIONS

SAFETY, ADVICE AND

RECOMMANDATIONS

Make an adult teach you how to correctly use your Minicross:

A. Progressive speeding up modalities.

B. Deceleration. C

. Braking.

D. How to behave correctly during the use of the means.

E. Read this manual along with an adult .

F. Proper use of gears.

Do not let aliens approach to the means driving when this is stopped on the stand. Danger of burning and falls of the means.

Do not seat and make nobody seat on the cross-bike when this is stopped and is laid on the stand.

If you wear sight glasses let an adult inspect they are clean and suitable to be used when driving the means.

This Minicross has been designed to carry a maximum weight of 75 Kg. It is forbidden to carry passengers.

Always keep your motorcycle in perfect working order. This will help you to keep it for a longer time, at its top efficiency and ready to satisfy your desire for fun.

Please remember to always use the helmet, suitable gloves, sunglasses and garments to drive the means. The apparel must be in leather with support patches on knees and elbows.

Never drive with naked feet.

WARNING

Other operations that are not described in this manual require the use of special equipment and technical know-how. Therefore we recommend that you go to a specialized garage.

8INFORMATIONS

Always tell an adult

if you notice anything strange while riding; for your safety, and to keep your Minicross in good condition, it is important to have even the smallest noise checked out.

The vehicle must always be used in the presence of a responsible

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

adult.

Before starting up always

check the brakes and the state and pressure of the tyres, the functioning of the gas throttle and of the fuel pipe integrity.

Any alteration or modification of the Minicross made to the original purchase makes the vehicle dangerous because it will no longer be in conformity.

In case small part should detach from the saddle or metal parts or plastic ones do not swallow and do not bite and in any case call for an adult to repair it.

When you start, make sure that

no people are nearby and that the children that are present, are kept at the right distance and under the control of an adult.

Always follow the indications by

an adult that is super-visioning how you are using the means.

Minicross is not equipped with a stationing stand so please make sure that you have stopped it in a suitable area (in flat and not

in a slant).

To park the vehicle (when getting off) turn off the engine, pull out

the kickstand, and make sure it is firmly resting on the ground. Before riding away, always make sure that the kickstand is all the way up (or down, depending on the model).

If the Minicross is stopped on the stand the motor must be switched off.

WHERE TO USE THE MINICROSS

Remember that the use of this motorcycle is allowed only in private areas.

Where however the ordinary circulation is not allowed

9INFORMATIONS

This vehicle is not authorized for use on public roads.

Do not make races or competitions.

Dont start the engine in closed places.

Do not drive close to rivers and do not cross water even if not too deep.

HOW TO BEHAVE DURING THE DRIVING

Do not speak on the mobile phone when driving, even if you wear an earphone.

Only drive with sufficient light

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

for your safety and the others
one.

Do not drive at night.

Always drive gripping tightly the handles at the side of the handlebars, and drive according to your capabilities and with care, to avoid danger both to yourself and to others.

Do not wander: always look
in front of you During the driving, your feet must always be comfortably laid on the specia