

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Piaggio - mp3_400ie_user_manual

PIAGGIO WOULD LIKE TO THANK YOU

for choosing one of its products. We have prepared this manual to help you to get the very best from your scooter.
Please read it carefully before riding
the scooter for the first time. It contains information, tips and precautions for using your scooter. It also describes features, details and devices to assure
you that you have made the right choice. We believe that if you follow our suggestions, you will soon get to know your new vehicle and it will serve you well for a long time to come. This booklet forms an integral part of the scooter; should the scooter be sold, it must be transferred to the new owner.

MP3 400ie

Ed. 2

The instructions given in this manual are intended to provide a clear, simple guide to using your scooter; this booklet also details routine maintenance procedures and regular checks that should be carried out on the vehicle at an authorised Dealer or Service Centre . The booklet also contains instructions for simple repairs. Any operations not specifically described in this manual require the use of special tools and/or particular technical knowledge: to carry out these operations refer to any authorised Dealer of Service Centres .

Personal safety

Failure to completely observe these instructions will result in serious risk of personal injury.

Safeguarding the environment

Sections marked with this symbol indicate the correct use of the vehicle to prevent damaging the environment.

Vehicle intactness

The incomplete or non-observance of these regulations leads to the risk of serious damage to the vehicle and sometimes even the invalidity of the guarantee.

The signs that you see on this page are very important. They are used to highlight those parts of the booklet that should be read with particular care. As you can see, each sign consists of a different graphic symbol, making it quick and easy to locate the various topics.

INDEX

VEHICLE	7
Dashboard	9
Analogue instrument panel	11
Clock	12
Digital Lcd display	12
Maintenance icons	13

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

MODE button	13
Key switch	14
Locking the steering wheel	14
Releasing the steering wheel	14
Switch direction indicators	15
Horn button	15
Light switch	16
Emergency flashing light button	16
Start-up button	17
Engine stop button	17
Front suspension unlock-lock switch	18
The immobilizer system	18
Keys	18
Immobilizerdevice enabled indicator led	19
Operation	19
Programming the immobilizer system	20
Saddle opening remote control	21
Remote control programming	22
Accessing the fuel tank	23
The saddle	24
Opening the saddle to access the helmet compartment by remote control	24
Opening the saddle to access the helmet compartment in an emergency	25
Opening of top box	26
Identification	26
USE.....	27Checks
Refuelling	28
Tyre pressure	30
Shock absorbers adjustment	31
Running in	32
Starting up the engine	33
Precautions	35
Difficult start up	35
Stopping the engine	36
Stand	36
Automatic transmission	37
Safe driving	37
Front suspension locking system	39
MAINTENANCE	45
Engine oil level	46
Engine oil level check	46
Engine oil top-up	46
Warning light (insufficient oil pressure)	46

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Engine oil change	47
Hub oil level	48
Tyres	50
Spark plug dismantlement	51
Removing the air filter	52
Air filter cleaning	52
Cooling fluid level	53
Checking the brake oil level	55
Braking system fluid top up	55
Battery	56
Use of a new battery	56
Long periods of inactivity	57
Fuses	57
Front light group	63
Headlight adjustment	63
Front direction indicators	66
Rear optical unit	67
Number plate light	68
Helmet compartment lighting bulb	69
Rear-view mirrors	69
Front and rear disc brake	69
Puncture	70
Periods of inactivity	71
Cleaning the vehicle	72
TECHNICAL DATA	77
Kit equipment	85
SPARE PARTS AND ACCESSORIES	87
Warnings	88
PROGRAMMED MAINTENANCE	91
Scheduled maintenance table	92

MP3 400ie

Chap. 01

Vehicle

Dashboard (01_01)

A = Ignition key-switch

B = Starter button

C = Throttle grip

D = Front brake lever

E = Turn indicator switch

F = Headlight switch

G = Rear brake lever

H = Horn button

I = Engine cut-off switch

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

L = Mode switch

M = Emergency turn indicator switch

N = Analogue instrument panel

O = Indicator unit

P = Bag hook

Q = Digital instrument panel