

ABI for the ARM Architecture: Support for Debugging Overlaid Programs

Document number: ARM IHI 0049A, current through ABI release 2.09

Date of Issue: 10th October 2008, reissued 30th November 2012

Abstract

This specification defines an extension to the *ABI for the ARM Architecture* to support debugging overlaid programs. No tool chain is required to support this extension but tools that support debugging overlaid programs should do so in one of the ways specified in §3.

Keywords

Debugging ABI for the ARM Architecture; debugging; ABI

How to find the latest release of this specification or report a defect in it

Please check the ARM Information Center (http://infocenter.arm.com/) for a later release if your copy is more than one year old (navigate to the ARM Software development tools section, ABI for the ARM Architecture subsection).

Please report defects in this specification to arm dot eabi at arm dot com.

Licence

THE TERMS OF YOUR ROYALTY FREE LIMITED LICENCE TO USE THIS ABI SPECIFICATION ARE GIVEN IN SECTION **1.4, Your licence to use this specification** (ARM contract reference **LEC-ELA-00081 V2.0**). PLEASE READ THEM CAREFULLY.

BY DOWNLOADING OR OTHERWISE USING THIS SPECIFICATION, YOU AGREE TO BE BOUND BY ALL OF ITS TERMS. IF YOU DO NOT AGREE TO THIS, DO NOT DOWNLOAD OR USE THIS SPECIFICATION.

THIS ABI SPECIFICATION IS PROVIDED "AS IS" WITH NO WARRANTIES (SEE SECTION 1.4 FOR DETAILS).

Proprietary notice

ARM, Thumb, RealView, ARM7TDMI and ARM9TDMI are registered trademarks of ARM Limited. The ARM logo is a trademark of ARM Limited. ARM9, ARM926EJ-S, ARM946E-S, ARM1136J-S ARM1156T2F-S ARM1176JZ-S Cortex, and Neon are trademarks of ARM Limited. All other products or services mentioned herein may be trademarks of their respective owners.

Contents

1 AB	OUT THIS DOCUMENT	3
1.1 1.1.1 1.1.2	Change control Current status and anticipated changes Change history	3 3 3
1.2	References	3
1.3	Terms and abbreviations	3
1.4	Your licence to use this specification	3
1.5	Acknowledgements	4
2 TH	E INTERFACE BETWEEN LINKERS AND DEBUGGERS	5
2.1	Summary	5
2.2	Terminology	5
2.3	Standard ELF views	5
2.4.1 2.4.2 2.4.3	Relating different views of target addresses Finding section and symbol load addresses Finding which overlay is currently executing Relating debug sections to program sections	6 6 7 7
3 TH	E ABI EXTENSION	9
3.1	Terminology	9
3.2 3.2.1	Linker obligations The debug-overlay section	9 10
3.3	Integration with GNU overlay management (speculative in r2.07)	11

1 ABOUT THIS DOCUMENT

1.1 Change control

1.1.1 Current status and anticipated changes

1.1.2 Change history

Issue	Date	By Change	
Α	10 th October 2008	LS	First public release.

1.2 References

This document refers to the following documents.

Ref	Author(s) or links	Title
ABI	http://infocenter.arm.com/help/index.jsp → ARM Software development tools → ABI for the ARM Architecture	Application Binary Interface for the ARM® Architecture
<u>ABI</u> <u>Addenda</u>	Ibid \rightarrow Addenda to, and Errata in, the ABI for the ARM Architecture	Addenda to, and Errata in, the ABI for the ARM Architecture
AADWARF	$\textit{Ibid} \rightarrow \textit{DWARF}$ for the ARM Architecture	DWARF for the ARM Architecture
AAELF	$\textit{Ibid} \rightarrow \textit{ELF}$ for the ARM Architecture	ELF for the ARM Architecture
GNU OV	http://sourceware.org/gdb/current/onlinedocs/gdb/Overlays.html#Overlays	Debugging Programs That Use Overlays (GDB documentation suite)

1.3 Terms and abbreviations

This document defines its terms and abbreviations in the document text.

1.4 Your licence to use this specification

IMPORTANT: THIS IS A LEGAL AGREEMENT ("LICENCE") BETWEEN YOU (AN INDIVIDUAL OR SINGLE ENTITY WHO IS RECEIVING THIS DOCUMENT DIRECTLY FROM ARM LIMITED) ("LICENSEE") AND ARM LIMITED ("ARM") FOR THE SPECIFICATION DEFINED IMMEDITATELY BELOW. BY DOWNLOADING OR OTHERWISE USING IT, YOU AGREE TO BE BOUND BY ALL OF THE TERMS OF THIS LICENCE. IF YOU DO NOT AGREE TO THIS, DO NOT DOWNLOAD OR USE THIS SPECIFICATION.

"Specification" means, and is limited to, the version of the specification for the Applications Binary Interface for the ARM Architecture comprised in this document. Notwithstanding the foregoing, "Specification" shall not include (i) the implementation of other published specifications referenced in this Specification; (ii) any enabling technologies that may be necessary to make or use any product or portion thereof that complies with this Specification, but are not themselves expressly set forth in this Specification (e.g. compiler front ends, code generators, back ends, libraries or other compiler, assembler or linker technologies; validation or debug software or hardware; applications, operating system or driver software; RISC architecture; processor microarchitecture); (iii) maskworks

and physical layouts of integrated circuit designs; or (iv) RTL or other high level representations of integrated circuit designs.

Use, copying or disclosure by the US Government is subject to the restrictions set out in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 or subparagraphs (c)(1) and (2) of the Commercial Computer Software – Restricted Rights at 48 C.F.R. 52.227-19, as applicable.

This Specification is owned by ARM or its licensors and is protected by copyright laws and international copyright treaties as well as other intellectual property laws and treaties. The Specification is licensed not sold.

- 1. Subject to the provisions of Clauses 2 and 3, ARM hereby grants to LICENSEE, under any intellectual property that is (i) owned or freely licensable by ARM without payment to unaffiliated third parties and (ii) either embodied in the Specification or Necessary to copy or implement an applications binary interface compliant with this Specification, a perpetual, non-exclusive, non-transferable, fully paid, worldwide limited licence (without the right to sublicense) to use and copy this Specification solely for the purpose of developing, having developed, manufacturing, having manufactured, offering to sell, selling, supplying or otherwise distributing products which comply with the Specification.
- 2. THIS SPECIFICATION IS PROVIDED "AS IS" WITH NO WARRANTIES EXPRESS, IMPLIED OR STATUTORY, INCLUDING BUT NOT LIMITED TO ANY WARRANTY OF SATISFACTORY QUALITY, MERCHANTABILITY, NONINFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. THE SPECIFICATION MAY INCLUDE ERRORS. ARM RESERVES THE RIGHT TO INCORPORATE MODIFICATIONS TO THE SPECIFICATION IN LATER REVISIONS OF IT, AND TO MAKE IMPROVEMENTS OR CHANGES IN THE SPECIFICATION OR THE PRODUCTS OR TECHNOLOGIES DESCRIBED THEREIN AT ANY TIME.
- 3. This Licence shall immediately terminate and shall be unavailable to LICENSEE if LICENSEE or any party affiliated to LICENSEE asserts any patents against ARM, ARM affiliates, third parties who have a valid licence from ARM for the Specification, or any customers or distributors of any of them based upon a claim that a LICENSEE (or LICENSEE affiliate) patent is Necessary to implement the Specification. In this Licence; (i) "affiliate" means any entity controlling, controlled by or under common control with a party (in fact or in law, via voting securities, management control or otherwise) and "affiliated" shall be construed accordingly; (ii) "assert" means to allege infringement in legal or administrative proceedings, or proceedings before any other competent trade, arbitral or international authority; (iii) "Necessary" means with respect to any claims of any patent, those claims which, without the appropriate permission of the patent owner, will be infringed when implementing the Specification because no alternative, commercially reasonable, non-infringing way of implementing the Specification is known; and (iv) English law and the jurisdiction of the English courts shall apply to all aspects of this Licence, its interpretation and enforcement. The total liability of ARM and any of its suppliers and licensors under or in relation to this Licence shall be limited to the greater of the amount actually paid by LICENSEE for the Specification or US\$10.00. The limitations, exclusions and disclaimers in this Licence shall apply to the maximum extent allowed by applicable law.

ARM Contract reference LEC-ELA-00081 V2.0 AB/LS (9 March 2005)

1.5 Acknowledgements

Lauterbach Datentechnik GmbH gave valuable review of earlier drafts of this specification.

2 THE INTERFACE BETWEEN LINKERS AND DEBUGGERS

2.1 Summary

The ABI for the ARM® Architecture [ABI] specifies ELF [AAELF] as the executable file format and DWARF 3.0 [AADWARF] as the debugging data format.

This note describes the obligations a producer of an executable ELF file (a linker) must meet to support debugging overlaid programs.

2.2 Terminology

In this note the terms *virtual address* and *address* are used interchangeably to describe addresses in a target system used by a program. This note is not concerned with the possibility that an external agent such as a debugger might 'see' addresses differently to an executing program.

A linker has two views of a program's address space that become distinct in the presence of *overlaid*, *position-independent*, and *relocatable* program fragments (code or data).

The load address of a program fragment is the target address to a linker expects an external agent such as a
program loader, dynamic linker, or debugger to copy the fragment from the ELF file. This is not necessarily the
address at which the fragment will execute.

The execution address of a program fragment is the target address at which a linker expects the fragment will
reside whenever it participates in the program's execution.

Of course, if a fragment is position-independent or relocatable, its execution address can vary during execution.

2.3 Standard ELF views

The ELF standard specifies two views of an executable ELF file.

In the program view, each program header of type PT_LOAD describes:

- □ A contiguous region of the file containing the initializing content for a *program segment*.
- A contiguous region of target address-space to which an external agent will copy that content.

In a program header, target addresses *should* be *load addresses* (§2.2) because an external agent is expected to load the program segment there.

In the section view, each section header describes:

- ☐ A contiguous region of the file occupied by the content of the section.
- □ And, if the section will appear in memory, a corresponding contiguous region of the target address-space. These addresses *must* be *execution addresses*.

The ELF standard permits the section view to be omitted from an executable ELF file and this is typically done when executable files are not intended to be debugged. The segment view suffices to support loading and execution.

In practice, the section view is *never* omitted when an ELF file is intended to be debugged.

DWARF debug tables and the section view of an ELF file can embody only one interpretation of target addresses. Because debuggers debug the *execution* of a program it is *logically necessary* for this to be the *execution address* view. By the same argument, ELF symbols must (almost always) define target execution addresses.

2.4 Relating different views of target addresses

In the absence of *relocatable*, *position-independent*, or *overlaid* program fragments, a debugger has no use for load addresses.

For example, a debugger stepping through a self-installing program will always 'see' execution addresses.

Load addresses might still have meaning to the user of a debugger, but their availability can be a *quality of implementation*. Non availability does not reduce a debugger's *necessary* functionality.

Relocatable and position-independent program fragments cause difficulties for debuggers that are beyond the scope of this note so we mention them no more.

Overlaid program fragments cause the following difficulty.

Multiple debug sections that should refer to distinct program fragments (and that *do* refer to distinct relocatable program fragments prior to static linking) actually refer to the same region of target memory that is time-multiplexed between multiple program fragments.

Stated simply, given a target execution address, several different debug sections might relate to it and there is no obvious way to choose among them.

The remainder of this section explains how to make the relationship between target addresses and debug sections unambiguous.

2.4.1 Finding section and symbol load addresses

Each program header PH of type PT_LOAD defines

- □ A half-open extent of the ELF file, [PH.p_offset, PH.p_offset + PH.p_filesz).
- □ A half-open extent of load-address space, [PH.p_paddr, PH.p_paddr + PH.p_memsz).

It is guaranteed that p_memsz ≥ p filesz.

- **Note** Strictly speaking the ELF standard guarantees that the memory interval [PH.p_vaddr + PH.p_filesz, PH.p_vaddr + PH.p_memsz) will be set to zero. Many embedded systems allow it to be uninitialized.
- **Note** Some linkers notably GNU ld use PH.p_**paddr** to hold the load address of a segment. We adopt that convention in this note and propose it as an extension to the ABI in §3.

Each section header SH defines:

- □ A half-open extent of the ELF file, [SH.sh_offset, SH.sh_offset + filesz), where filesz is SH.sh_size or 0 if SH.sh_type = SHT_NOBITS.
- □ A half-open extent of execution-address space, [SH.sh_addr, SH.sh_addr + SH.sh_size).

For any section SH whose file extent overlaps the file extent of a segment PH and any file offset off that lies in both file extents the load address LA and execution address EA corresponding to off are:

```
LA(off) = PH.p\_paddr + (off - PH.p\_offset)
```

Conditional on the corresponding file offset off lying in both the segment file extent and the section file extent

```
LA = EA + PH.p_paddr - SH.sh_addr + SH.sh_offset - PH.p offset
```

This gives the load address corresponding to each target execution address and, in the presence of overlaid program fragments will give multiple load addresses for the same execution address.

In particular, this allows the load address of every section that is part of the program to be computed from information already present in the ELF file.

Note Normally a program section cannot intersect more than one program segment.

When two or more segments are overlaid at the same *load address* and contain only sections of type SHT_NOBITS (zero-initialized or uninitialized data) and there is no intervening file content between the segments, the sections and the segments all have identical (empty) file extents. It is then impossible to match sections to a loaded segment via a unique file extent which makes it impossible to locate the

This obscure corner case can be avoided if a linker ensures that every program segment has a unique file offset, p_offset. This can be done by adding padding bytes between adjacent segments with empty file extents (§3.2).

Once a load address is known for each section, the load address of every section-relative symbol S can be found.

S.st shndx identifies the section header SH for the section in which S is defined.

S.st_value - SH.sh_addr is the offset of S in the section described by SH.

S.load address = SH.load address + (S.st value - SH.sh addr).

debugging sections appropriate to the loaded segment.

From above:

Note

```
SH.load_address = SH.sh_addr + PH.p_paddr - SH.sh_addr + SH.sh_offset - PH.p_offset
= PH.p_paddr + (SH.sh_offset - PH.p_offset)
```

2.4.2 Finding which overlay is currently executing

In a typical embedded application, each section S in a set {S} of sections with overlapping execution extents has a distinct extent in load-address space. The section executing is the one for which the content of the execution-address space extent is identical to the content in the corresponding load-address space extent ¹.

Note This definition only works for read-only segments that have not been accidentally corrupted. In other cases a debugger must observe or collude with the overlay manager to discover which segment is live.

If the overlay system uses a centralized overlay manager (rather than loading overlays in an ad-hoc, distributed manner) it might be possible for a debugger to observe the load address and execution address used by the overlay manager in a code fragment resembling

memcpy (execution address, load address, segment length)

The static structure of overlays is, of course, discernable from *execution address*, *load address*, and *section length* of each section that overlaps another in the execution-address space.

2.4.3 Relating debug sections to program sections

In a relocatable file, a debug section refers to a location in a program section via a relocated location.

A relocation directive refers to the debug section being relocated via the sh_info field in the relocation section header and the r_offset field in the relocation itself. It refers to the program section via a symbol (identified by ELF32_R_SYM(r_info)) that refers to the program section via st_shndx and st_value (an offset in the section).

At this stage of linking, a reference from a debug section to a location in a program section is a pair of pairs

<debug section index, debug section offset>, <program section index, program section offset>

During static linking the *program* pair is reduced to single value, the *execution address*. This is ambiguous in the presence of overlaid sections.

Resolving the ambiguity requires some of the original relocation information. We propose two ways to represent that in an ELF file.

¹ Assuming the program has not altered writable memory and that initializing contents are unique.

- □ Retain the relevant subset (or all) of the original relocations in the executable ELF file.
- ☐ Emit a new ELF section called .ARM.debug_overlay of type SHT_ARM_DEBUG_OVERLAY = SHT_LOUSER + 4 containing a table of entries as follows:

debug section offset, debug section index, program section index

The description earlier in this section shows that the second representation can be calculated from the relevant subset of the retained relocation data.

GNU Id has an option (--emit-relocs) to retain all relocations in the executable file. Clearly this is sufficient.

A better option is to retain only relocations of debug sections (those with names matching *debug*) with respect to overlaid program sections (--emit-overlay-debug-relocs). An overlay-aware linker will readily recognize these sections.

For some linkers it might be easier to build a .ARM.debug_overlay section directly, as each relocation directive is processed, than to emit the original relocations filtered for relevance.

3 THE ABI EXTENSION

We extend the *ABI for the ARM Architecture* (ABI) as noted in this section. The extension is optional and no tool chain is required to support in order to claim conformance to the ABI. However, tools that support debugging overlaid programs should do so in one of the ways specified here.

3.1 Terminology

A linker has two views of a program's address space that become distinct in the presence of *overlaid* program fragments (code or data).

- ☐ The *load address* of a program fragment is the address to which a linker expects an external agent such as a program loader, dynamic linker, or debugger to copy the fragment from the ELF file. This is not necessarily the address at which the fragment will execute.
- ☐ The execution address of a program fragment is the address at which a linker expects the fragment will reside whenever it participates in the program's execution.

3.2 Linker obligations

A linker claiming to support the debugging of overlaid programs shall ensure the following in the executable ELF files it produces.

- □ Each program fragment that overlaps another in the execution address space shall be described by a distinct ELF section header.
- □ Target addresses recorded in section header sh_addr fields and symbol st_value fields shall be execution addresses.
- □ Target addresses recorded in p_paddr fields of program headers of type PT_LOAD shall be *load addresses*.
- □ Each program segment described by a program header PH of type PT_LOAD shall occupy a different extent [PH.p_offset, PH.p_offset + PH.p_filesz) in the ELF file. (An empty extent shall not overlap any other extent).

In addition, a linker claiming to support debugging of overlaid programs shall do at least one of the following.

- □ Provide a means to retain all original relocations in the executable file. GNU *Id* does this using the command option --emit-relocs.
- Provide a means to retain just those original relocations that relocate debug sections with respect to overlaid program sections. A linker might provide a command option such as --emit-overlay-debug-relocs.
- □ Add a debug-overlay ELF section (specified in §3.2.1, below) to the executable file.

3.2.1 The debug-overlay section

Table 1, The debug-overlay section header

Field	Value
sh_name	.ARM.debug_overlay
sh_type	SHT_ARM_DEBUGOVERLAY = SHT_LOPROC + 4 = 0x70000004
sh_flags	0
sh_addr	0
sh_offset	The section's file offset.
sh_size	The byte size of the section, a multiple of sh_entsize.
sh_link	0
sh_info	0
sh_addralign	0
sh_entsize	8 or 12 (the size of an entry).

The debug-overlay section is a table of fixed size rows, each row containing three values.

Table 2, The debug-overlay section row format

Field	Offset	Size	Value
dbg_offset	0	4	The offset in the debug section of the field containing the execution address.
dbg_shndx	4	2 4	The index in the ELF file's section header table of a debug section that refers to an overlaid program section (via a potentially ambiguous execution address).
ov_shndx	6 8	2 4	The index in the ELF file's section header table of the overlaid section referred to by the debug section.
sh_entsize		8 12	If section indexes are smaller than SHN_XINDEX (0xffff). If any section index needs to be greater than SHN_XINDEX – 1.

Rationale

The size of many consolidated debug sections exceeds 2¹⁶ bytes so offsets need to be 4-byte quantities.

In reality, the indexes of consolidated sections will usually fit into 1 byte. However, a 6 byte entry does not fit well with the 4-byte alignment requirement of 4-byte offsets and saves little space compared with 8-byte entries.

A linker only needs to generate a section containing 12-byte entries when it would in any case need to generate a section of type SHT_SYMTAB_SHNDX in order to accommodate values of st_shndx greater than SHN_XINDEX – 1.

A linker should usually generate a debug-overlay section containing 8-byte entries.

3.3 Integration with GNU overlay management (speculative in r2.07)

The GNU debugger GDB features some support for debugging overlaid programs and defines a memory-resident table, identified by the _ovly_table symbol, for communicating between an overlay manager and GDB [GNU OV]. Each row in _ovly_table[] contains <execution address, size, load address, loaded> for an overlay segment.

From an embedded perspective there are a number of issues with this.

- ☐ The whole table must be writable (RAM) because the flag field *loaded* needs to be writable. In most embedded applications the other fields are read-only so they could reside in ROM.
- In a distributed overlay manager (e.g. each segment loads its successor explicitly) this data might need to replicated in _ovly_table[] just for the convenience of a debugger that could use a copy held on the host.
- □ It does not solve the problem of relating an overlaid program section to the debug sections that refer to it (for which --emit-relocs, a debug overlay section [§3.2.1], or similar, is needed).

To integrate this mechanism in a manner more useful to embedded systems we propose the following.

- □ Define a new .ARM.overlay_table section of type SHT_ARM_OVERLAYSECTION = 0x70000005 with contents exactly as defined by [GNU OV].
- ☐ The section header's sh_flags field contains SHF_ALLOC if the section resides in memory, otherwise the section is an offline section used by a debugger.
- □ If the sh_flags field contains SHF_ALLOC and *not* SHF_WRITE, the table resides in ROM.
 - Otherwise the section resides in RAM and is used exactly as described by [GNU OV]. This is also the interpretation when the symbol _ovly_table exists but there is no .ARM.overlay_table section.

When the .ARM.overlay_table section exists and is not resident in RAM

☐ The *loaded* field of each _ovly_table entry is unused and the symbol _ovly_loaded identifies a separate *byte* array in RAM recording the *loaded* status of the corresponding overlay segments.