TF

RNAV (GNSS) RWY 06

ITMIL 1A

ARR-04A

STANDARD ARRIVAL TO FALE RWY 06 FROM ITMIL							
FIX/WAYPOINT	LATITUDE	LONGITUDE	COURSE (°T)	DISTANCE (NM)	PATH TERMINATOR		
ITMIL	29°01'51.05"S	031°48'38.40"E	220.7	20.17	IF		
LE006	29°17'10.34"S	031°33'35.53"E	217.3	23.71	TF		
LE013	29°36'03.66"S	031°17'05.97"E	217.2	20.24	* TF		

031°03'01.44"E

LE1N3 29°52'12.43"S \* Communication Failure Way Point

ENR HOLDING						
FACILITY	INBOUND HEADING/RADIAL	MAX FL	FACILITY			
ITMIL						
29°01'51.05"S	0.4.4%8.4/0.0.4%8.4	FL280	Left hand racecourse pattern.			
031°48'38.40"E	244°M/064°M	FL150	13 NM Outbound leg.			
R070/50 DME TGV						