(KING SHAKA INTERNATIONAL)
RNAV (GNSS) RWY 06

MAN	(GINGS)	LAAL	UU
		ITMIL	1C
			\neg

STANDARD DEPARTURE FROM FALE RWY 06 TO ITMIL						
FIX/WAYPOINT	LATITUDE	LONGITUDE	COURSE (°T)	DISTANCE (NM)	PATH TERMINATOR	
RWY 06 DER	29°35'46.81"S	031°07'57.91"E	037.3	01.89	CF	
LE015	29°34'16.46"S	031°09'16.53"E	046.9	36.99	DF	
LE017	29°08'53.57"S	031°40'08.81"E	046.7	10.23	*TF	
ITMIL	29°01'51.05"S	031°48'38.40"E				

^{*} Communication Failure Way Point

ENR HOLDING						
FACILITY	INBOUND HEADING	MAX FL	FACILITY			
ITMIL						
29°01'51.05"S	244°M	FL280	Left hand racecourse pattern.			
031°48'38.40"E	244 IVI	FL150	13 NM Outbound leg.			
R070/50 DME TGV						