## Introduction

## **Package Contents**

Confirm that the package contains the following items:





- ☐ BS-1 accessory shoe cover
- DK-20 rubber eyecup



☐ BF-1B body cap







¬ AN-DC3 strap



UC-E6 USB cable



☐ D5100 digital camera

☐ EN-EL14 rechargeable Li-ion ☐ MH-24 battery charger (plug battery (with terminal cover)



adapter supplied in countries or regions where required; shape depends on country of sale)



 $\square$  EG-CP14 audio/video (A/V) cable

- ☐ ViewNX 2 CD
- ☐ Reference CD
- ☐ User's Manual (this booklet) ☐ Warranty
- ☐ Quick Start Guide

Purchasers of the lens kit option should confirm that the package also includes a lens. Memory cards are sold separately.

## Attaching the Strap

Attach the strap securely to the two eyelets on the camera body.







