## **Image Size**


Image size is measured in pixels. Choose from the following options:

lmage size	Size (pixels)	Print size (cm/in.)*
■ Large	4,928 × 3,264	41.7 × 27.6/16.4 × 11.4
M Medium	3,696× 2,448	31.3 × 20.7/12.3 × 8.2
S Small	2,464 × 1,632	20.9 × 13.8/8.2 × 5.4

<sup>\*</sup> Approximate size when printed at 300 dpi. Print size in inches equals image size in pixels divided by printer resolution in dots per inch (dpi; 1 inch = approximately 2.54 cm).

1 Place the cursor in the information display.

If shooting information is not displayed in the monitor, press the 4b button. Press the 4b button again to place the cursor in the information display.



**2** Display image size options. Highlight the current image size in the information display and press **⊛**.





**3** Choose an image size.

Highlight an option and press (\*\*). To return to shooting mode, press the shutter-release button halfway.





## File Names

Photographs are stored as image files with names of the form "DSC\_nnnn.xxx," where nnnn is a four-digit number between 0001 and 9999 assigned automatically in ascending order by the camera, and xxx is one of the following three letter extensions: "NEF" for NEF images, "JPG" for JPEG images, or "MOV" for movies. The NEF and JPEG files recorded at a setting of NEF (RAW)+JPEG have the same file names but different extensions.

