Other Accessories

At the time of writing, the following accessories were available for the D5100.

	• Rechargeable Li-ion Battery EN-EL14 (12): Additional EN-EL14 batteries are
	available from local retailers and Nikon-authorized service representatives.
Power sources	• Battery Charger MH-24 (CLL 12): Recharge EN-EL14 batteries.
	• Power Connector EP-5A, AC Adapter EH-5b: These accessories can be used to power the
	camera for extended periods (EH-5a and EH-5 AC adapters can also be used). A
	power connector EP-5A is required to connect the camera to the EH-5b, EH-5a,
	or EH-5.
	Filters intended for special-effects photography may interfere with autofocus
	or the electronic rangefinder.
	The D5100 can not be used with linear polarizing filters. Use C-PL or C-PL II
	circular polarizing filters instead.
	NC filters are recommended for protecting the lens.
Filters	To prevent ghosting, use of a filter is not recommended when the subject is
	framed against a bright light, or when a bright light source is in the frame.
	 Center-weighted metering is recommended with filters with exposure factors
	(filter factors) over 1 × (Y44, Y48, Y52, O56, R60, X0, X1, C-PL, ND2S, ND4, ND4S,
	ND8, ND85, ND400, A2, A12, B2, B8, B12). See the filter manual for details.
	• DK-20C Eyepiece Correction Lenses : Lenses are available with diopters of –5, –4, –3,
	-2, 0, +0.5, +1, +2, and +3 m ⁻¹ when the camera diopter adjustment control is
	in the neutral position (–1 m ⁻¹). Use eyepiece correction lenses only if the
	desired focus can not be achieved with the built in diopter adjustment control
	$(-1.7 \text{ to } +0.7 \text{ m}^{-1})$. Test eyepiece correction lenses before purchase to ensure
	that the desired focus can be achieved. The rubber eyecup can not be used
Viewfinder	with eyepiece correction lenses.
eyepiece	• Magnifier DG-2: The DG-2 magnifies the scene displayed in the center of the
accessories	viewfinder for greater precision during focusing. Eyepiece adapter required
	(available separately).
	• Eyepiece Adapter DK-22: The DK-22 is used when attaching the DG-2 magnifier.
	Right-Angle Viewing Attachment DR-6: The DR-6 attaches at a right angle to the
	viewfinder eyepiece, allowing the image in the viewfinder to be viewed at right
	angles to the lens (for example, from directly above when the camera is
	horizontal).
Software	• Capture NX 2: A complete photo editing package offering such features as white
	balance adjustment and color control points.
	• Camera Control Pro 2: Control the camera remotely from a computer and save
	photographs directly to the computer hard disk.
	Note : Use the latest versions of Nikon software. Most Nikon software offers an
	auto update feature when the computer is connected to the Internet. See the
	websites listed on page vi for the latest information on supported operating
	systems.
	BF-1B and BF-1A Body Caps: The body cap keeps the mirror, viewfinder screen, and
Body cap	low-pass filter free of dust when a lens is not in place.
	low pass filter free of dust when a lens is flot in place.