







Berkeley Buckler	REV: A
Author: Branden Ghena	
Date: 8/2/18 6:26 PM	Sheet: 1/3



Berkeley Buckler	REV: A
Author: Branden Ghena	
Date: 8/2/18 6:26 PM	Sheet: 2/3

SD Card Adapter



Push Buttons (Momentary)



2x16 LCD Screen



Switches



LEDs (Various Colors)



Power Indicator

Berkeley Buckler	REV: A
Author: Branden Ghena	
Date: 8/2/18 6:26 PM	Sheet: 3/3

Top and Bottom Layers



Top Layer


RESET
POWER
SD Card
I2C ACCELEROMETER
GYRO & MAGNETOMETER
ANALOG ACCELEROMETER
TEMPERATURE
HUMIDITY
LIGHT
PRESSURE
Berkeley Buckler
Branden Ghena
August 2018
SWITCH_0
SWITCH_1
BTN_0
BTN_1
LED0
LED1
LED2
3.3V
GND
NC
5V
SCL
SDA
GROVE_A0
SWITCH_1
SWITCH_0
BUTTON_1
BUTTON_0
SD_ENABLE
LED_2
GROVE_D1
LED_1
LED_0
SD_DETECT
SD_CS
LCD_CS
LIGHT_INT
IMU_INT
NFC2
NFC1
UART_RXD
UART_CTS
UART_TXD
UART_RTS
GROVE_A1
GROVE_D0
GROVE_A2
ACCEL_X
ACCEL_Y
ACCEL_Z
ACCEL SELF TEST
GROVE_D2
EXTERN_RX
QSPI_DIO3
QSPI_DIO1
QSPI_CLK
QSPI_CS
SD_MOSI
SD_MISO
SD_SCLK
SDGROVE
LCD_SCLK
LCD_MISO
LCD_MOSI
nRESET
QSPI_DIO0
QSPI_DIO2
EXTERN_TX
LCD_D/C
LCD_SCK
EXTERN_TX
EXTERN_RX
J1
J2
J3
J4
J5
J6
J7
J8


Bottom Layer

Top Copper Layer



Bottom Copper Layer



Top Paste Layer with Silkscreen







Top and Bottom Layers 1:1 Scale



Top Layer 1:1 Scale



Bottom Copper Layer 1:1 Scale