



SIM CARD USER MANUAL

Easy setup for your EvairSIM card

A complete setup guide for phones, tablets, MiFi devices, and supported cameras.

www.evairdigital.com

service@evairdigital.com

You are in. Welcome to EvairSIM.

Scan the QR code to visit www.evairdigital.com and start your seamless global connectivity experience.

**Check plan details instantly.**

View your plan validity and remaining data so you stay informed and in control.

Order new plans effortlessly.

Browse plans, renew, or switch with a tap wherever you are.

Get quick support.

Report issues and connect with our team for fast assistance.

For inquiries, please consult this manual or email service@evairdigital.com.

Table of contents

Top up / balance	04
iOS carrier switch	05
iOS APN setup	06
Android carrier switch	07
Android APN setup	08
MiFi setup	09
Reolink setup	10-11
Q&A	12-15

First things first

Check these before using your SIM card.

1. Check whether your phone is unlocked

If your phone is network-locked, contact the device retailer or carrier to unlock it.

2. Confirm device support

Make sure your device supports third-party SIM cards and has data roaming enabled.

Manual APN

Use APN plus. Leave username and password blank.

Top up, balance, and APN reference

Use EvairSIM online to view plan validity, remaining data, renewal options, and support.

1

Open EvairSIM

Visit www.evairdigital.com or scan the QR code.

2

Check plan details

Review validity and remaining data before changing settings.

3

Order new plans

Browse plans and choose the option that fits your device.

4


Contact support

Use the app or email service@evairdigital.com.

Preferred APN	plus	Other APNs	globaldata or internet
Username	Blank	Password	Blank
Roaming	Enable data roaming. After APN changes, save, wait about 2 minutes, then restart if needed.		

How to switch carriers on iOS devices


Use this if your iPhone or iPad does not automatically connect to a good network.



1

Insert SIM card


Insert the EvairSIM card and wait for the device to detect it.



2

Open Settings


Tap Cellular, then tap the SIM card that uses EvairSIM.



3

Enable roaming

Turn on Data Roaming, then tap Network Selection.




4

Select manually

Disable Automatic, wait 1-2 minutes, then select the strongest carrier.

How to configure APN for iOS devices


Most iOS devices connect automatically. If not, set APN manually.



1

Insert SIM card


Install the SIM and wait for the phone to recognize it.



2

Open Cellular


Open Settings, tap Cellular, then select the EvairSIM SIM card.



3

Open data network

Enable Data Roaming, then tap Cellular Data Network.



4

Set APN

Enter APN plus. Leave Username and Password blank, then save.

How to switch carriers on Android devices

Android menu names vary by brand, but the network selection flow is similar.




Settings

1

Insert SIM card

Insert the EvairSIM card and power on your device.



2

Open Settings


Tap Mobile Network, then tap SIM Card.



3

Enable roaming

Turn on Data Roaming and tap Carrier or Network Operator.




4

Select manually

Disable Automatic Selection, wait 1-2 minutes, then choose a carrier.

How to configure APN for Android devices


Use this if your device has no internet after data roaming is enabled.



1

Open APN settings


Go to Settings, Network or Mobile Network, then APN or Access Point Names.



2

Add a new APN


Tap +, Add New APN, or Manual Configuration.



3

Enter APN details

Set APN to plus. Leave Username and Password blank.




4

Save and select

Save the APN, select it as active, and wait for the connection.

How to set up APN on MiFi


For mobile Wi-Fi, hotspots, and routers, enter the APN from the admin panel.



1

Insert SIM card

Insert the SIM card into the MiFi, hotspot, or router.



2

Access admin panel


Open a browser and enter the Wi-Fi hotspot or router IP address.



3

Common IPs

The IP is often 192.168.0.1 or 192.168.1.1.
Some devices print it on the rear label.



4

Log in

Use your admin username and password.
Check your device manual if needed.

Finish MiFi APN and create Reolink APN file

Use these steps for MiFi APN setup and Reolink-style camera APN import.



5

Find MiFi APN settings

Go to Settings, Network, then APN. Enable roaming if available.



6

Add MiFi APN


Select Add New APN. Set APN to plus and leave username/password blank.



1

Create camera file

Create a TXT file named my_custom_apn.



2

Add APN information

Enter apn=plus, username=, and password=.

Reolink SD-card APN import

Based on Reolink camera settings. Some cameras require APN import by Micro SD card.



3

Transfer to SD card

Save `my_custom_apn.txt` to the root directory of a FAT32 Micro SD card.



4

Install cards

Turn off the camera, then install the SIM card and Micro SD card.



5

Trigger update

Power on the camera and press reset for a few seconds.



6

Reboot and verify

The camera imports settings automatically. A blue LED or voice prompt usually means success.

1. Why is there no network connection after inserting the SIM card?

Enable Data Roaming and wait about 2 minutes for the SIM card to activate and connect automatically. You can also restart your phone after enabling roaming.

3. Why does my SIM show as expired even though I have not used all the data?

Some MiFi and IoT devices have roaming enabled by default, which can trigger automatic activation once the SIM is inserted. The plan expires once the package duration ends.

2. Why is there still no network connection after enabling roaming?

Your device may not support automatic APN configuration. Manually set the APN to globaldata, plus, or internet.

4. Why does my device display Invalid SIM, SIM Locked, No Service, or SIM Network Unlock PIN?

The device is carrier-locked and does not support SIMs from other providers. Contact the device provider to unlock it. EvairSIM IoT cards work with unlocked devices.

5. No internet after roaming and APN setup on mobile Wi-Fi?

Check US network bands

Our SIM cards support these 4G/LTE bands: B2, B4, B12, B13, B14, B30, B66, and B71.

If your device supports these bands

Take screenshots of your Data Roaming and APN configuration pages and send them to EvairSIM support.

5G bands

Supported 5G bands include n5, n41, n71, n77, n258, n260, and n261.

Quick settings

Roaming should be on. APN should be plus, globaldata, or internet. Username and password should be blank.

6. How can I contact you?

You can reach us via the app or by emailing service@evairdigital.com.

8. Why did my internet stop working after I had been using it for a while?

Log in to the EvairSIM app or website and wait 15 minutes to check if your data package has been exhausted.

7. Why is my network speed only 50 Mbps?

Speed depends on the carrier selected and signal strength in your area. Try manually switching providers and choosing the strongest signal among AT&T, Verizon, or T-Mobile.

9. Do I need to buy a new SIM card once my data is used up?

No. Download the EvairSIM app or visit the top-up page to subscribe to a new plan. You can keep using the same SIM card.

10. Why is my security camera unable to connect after inserting the SIM card?

Your device may not support automatic APN configuration. Contact the camera support team to ask how to manually configure APN. The EvairSIM APN is globaldata, plus, or internet.

12. Does the SIM card provide a static US IP address?

Not exactly. The EvairSIM IoT card provides a local US IP for US-based apps and streaming services. Because it supports all three major US carriers, the IP may change during network fluctuations or carrier switching.

11. Can the US SIM card be used in Mexico or Europe?

No. For multiple regions, such as US and Europe, or US, Mexico, and Canada, purchase our Multi-Region SIM card.

13. Can I use the SIM card in American Samoa?

No. The EvairSIM card is supported in the Mainland US, Alaska, and Hawaii. It is not currently supported in other US overseas territories or islands.



Manage your SIM online

Check data, top up, and contact support at www.evairdigital.com.

www.evairdigital.com

service@evairdigital.com