DLI EPCR5 Object Model Reference

Generated by Doxygen

20180420T190047Z

ii CONTENTS

Contents

1	DLI Controller API				
2	2 Relay object				
	2.1	Name	4		
	2.2	Online status	5		
	2.3	Model	5		
	2.4	Relay version number	6		
	2.5	Outlets	6		
		2.5.1 Outlet	7		
	2.6	Outlet: Name	8		
	2.7	Outlet: Configured state	9		
	2.8	Outlet: Transient state	10		
	2.9	Outlet: Physical state	11		
	2.10	Outlet: Lock state	12		
	2.11	Outlet: Critical	13		
	2.12	Outlet: Outlet cycle delay, if any	13		
		2.12.1 Outlet cycle delay	14		
	2.13	Outlet: Cycle	14		
		2.13.1 Action performed	15		
	2.14	Outlet ON sequence delay	15		
	2.15	Minimal ON sequence delay	16		
	2.16	Default outlet cycle delay	16		
	2.17	Brown-out re-latch delay	16		
	2.18	Recovery mode	17		
	2.19	Buses	18		
		2.19.1 Bus	18		
	2.20	Bus: Outlet list	20		
		2.20.1 Outlet index	21		
	2.21	Bus: Voltage-affected outlets	21		

	2.21.1 Outlet list index	22
2.22	Bus: Minimum voltage, if any	23
	2.22.1 Minimum voltage	23
2.23	Bus: Maximum voltage, if any	24
	2.23.1 Maximum voltage	24
2.24	Bus: Current-affected outlets	25
	2.24.1 Outlet list index	25
2.25	Bus: Maximum current, if any	26
	2.25.1 Maximum current	27
2.26	Pins	27
	2.26.1 GPIO pin	28
2.27	GPIO pin: Name	29
2.28	GPIO pin: Mode driver	30
	2.28.1 Net name	30
	2.28.2 Invalid net placeholder	31
2.29	GPIO pin: Mode driver locked	31
2.30	GPIO pin: Level driver	32
	2.30.1 Net name	33
	2.30.2 Invalid net placeholder	33
2.31	GPIO pin: Level driver locked	33
2.32	Nets	34
	2.32.1 Net	35
2.33	Net: Name	36
2.34	Net: Expression, if any	37
	2.34.1 Expression	37
2.35	Net: Tracking	38
2.36	Net: Value	38
2.37	Enable measurement-driven outlet control	39
2.38	Minimum relay voltage, if any	40
	2.38.1 Minimum relay voltage	40

2.39	Measurement-driven relatch timeout, if any	41
	2.39.1 Measurement-driven relatch timeout	41
2.40	Keypad state	42
2.41	LCD all-caps filter	42
2.42	Beep sequence	43
2.43	Backlight sequence	43
2.44	LCD column count	44
2.45	LCD row count	44
2.46	User LCD lines	45
2.47	User LCD lines: User LCD line, if any	46
	2.47.1 User LCD line	46
2.48	User message force display timeout, if any	47
	2.48.1 User message force display timeout	47
2.49	User message display timeout, if any	48
	2.49.1 User message display timeout	48
2.50	Notifications	48
	2.50.1 Events	49
2.51	Message template: Message template element	50
	2.51.1 String	51
	2.51.2 Parameter	51
2.52	Event parameter: Fixed value	51
	2.52.1 String	51
	2.52.2 Number	52
2.53	Event parameter: Fixed value flag	52
2.54	Event parameter: Identifier	52
2.55	Events: Event	53
	2.55.1 Message template	54
	2.55.2 Event parameters	54
	2.55.3 Severity	57
2.56	Notifications: Parameter kinds	58
	2.56.1 Lock state	58
	2.56.2 Outlet	59
	2.56.3 Physical state	59
	2.56.4 Configured state	60
	2.56.5 Transient state	60

3	Auth	thentication server object				
	3.1	Users list	62			
		3.1.1 User account	63			
	3.2	User account: Username	64			
	3.3	User account: Password	65			
	3.4	User account: User allowed	66			
	3.5	User account: Administrative user	66			
	3.6	User account: Outlet access levels	67			
		3.6.1 Outlet access	68			
	3.7	Cookie timeout	69			
	3.8	Notifications	69			
		3.8.1 Events	70			
	3.9	Message template: Message template element	71			
		3.9.1 String	72			
		3.9.2 Parameter	72			
	3.10	Event parameter: Fixed value	72			
		3.10.1 String	72			
		3.10.2 Number	73			
	3.11	Event parameter: Fixed value flag	73			
	3.12	Event parameter: Identifier	73			
	3.13	Events: Event	74			
		3.13.1 Message template	74			
		3.13.2 Event parameters	75			
		3.13.3 Severity	77			
	3.14	Notifications: Parameter kinds	77			
		3.14.1 Authentication allowed	77			
		3.14.2 IP address	78			
		3.14.3 Username	78			
		3.14.4 Method	79			
		3.14.5 Reason	79			
		3.14.6 User state	79			

4	Cont	nfiguration server object				
	4.1	Links list	83			
	4.2	Links list: Link	84			
		4.2.1 URI	85			
		4.2.2 Description	85			
	4.3	Plots list	86			
		4.3.1 Plot	87			
	4.4	Plot: Title	89			
	4.5	Plot: Display	89			
	4.6	Plot: Width	90			
	4.7	Plot: Height	91			
	4.8	Plot: X1 axis settings	91			
		4.8.1 Minimum, if any	92			
		4.8.2 Maximum, if any	93			
		4.8.3 Soft minimum, if any	94			
		4.8.4 Soft maximum, if any	95			
		4.8.5 Major tick interval, if any	96			
		4.8.6 Minor ticks per major tick, if any	96			
	4.9	Plot: X2 axis settings	97			
		4.9.1 Minimum, if any	98			
		4.9.2 Maximum, if any	99			
		4.9.3 Soft minimum, if any	100			
		4.9.4 Soft maximum, if any	101			
		4.9.5 Major tick interval, if any	102			
		4.9.6 Minor ticks per major tick, if any	102			
	4.10	Plot: Y1 axis settings	103			
		4.10.1 Minimum, if any	104			
		4.10.2 Maximum, if any	105			
		4.10.3 Soft minimum, if any	106			
		4.10.4 Soft maximum, if any	107			

CONTENTS vii

	4.10.5 Major tick interval, if any	108
	4.10.6 Minor ticks per major tick, if any	108
4.11	Plot: Y2 axis settings	109
	4.11.1 Minimum, if any	110
	4.11.2 Maximum, if any	111
	4.11.3 Soft minimum, if any	112
	4.11.4 Soft maximum, if any	113
	4.11.5 Major tick interval, if any	114
	4.11.6 Minor ticks per major tick, if any	114
4.12	Plot line configuration: Style	115
	4.12.1 Line style	116
	4.12.2 Line type	117
	4.12.3 Line color	117
	4.12.4 Line width	118
	4.12.5 Marker size	119
	4.12.6 Base axes	119
	4.12.7 Marker type	120
4.13	Plot: Plot lines	120
	4.13.1 Plot line configuration	121
4.14	Meters list	124
	4.14.1 Meter configuration	125
4.15	Meter configuration: Title	127
4.16	Meter configuration: Display	128
4.17	Meter configuration: Data source	128
4.18	Meter configuration: Width	129
4.19	Meter configuration: Height	129
4.20	Meter configuration: Display scale	130
4.21	Meter configuration: Decimals	131
4.22	Meter configuration: Arrow color	131
4.23	Meter configuration: Minimum value	132

4.24	Meter configuration: Meter sectors	132
	4.24.1 Sector configuration	134
4.25	Primary unit contact	136
4.26	Related contacts	137
	4.26.1 Contact	138
4.27	Contact: Name	139
4.28	Contact: Email, if any	140
	4.28.1 Email	141
4.29	Contact: Phone number, if any	141
	4.29.1 Phone number	141
4.30	Contact: Fax number, if any	142
	4.30.1 Fax number	142
4.31	Unit location	143
4.32	Model OID	143
4.33	Version number	144
4.34	Hardware ID	144
4.35	Serial number	144
4.36	Outlet label	145
4.37	Brand company name	145
4.38	Brand name	145
4.39	Brand URL	146
4.40	Brand manual URL	146
4.41	Brand FAQ URL	147
4.42	Brand product information URL	147
4.43	Support email	147
4.44	Registration URL	148
4.45	Support URL	148
4.46	Update URL	149
4.47	Custom brand company name, if any	149
	4.47.1 Custom brand company name	150

4.48	Custom brand name, if any	150
	4.48.1 Custom brand name	151
4.49	Custom brand URL, if any	151
	4.49.1 Custom brand URL	151
4.50	Custom brand logo URL, if any	152
	4.50.1 Custom brand logo URL	152
4.51	Custom brand logo width, if any	153
	4.51.1 Custom brand logo width	153
4.52	Custom brand logo height, if any	153
	4.52.1 Custom brand logo height	154
4.53	Custom support email, if any	154
	4.53.1 Custom support email	155
4.54	Custom registration URL, if any	155
	4.54.1 Custom registration URL	156
4.55	Custom support URL, if any	156
	4.55.1 Custom support URL	157
4.56	Custom update URL, if any	157
	4.56.1 Custom update URL	157
4.57	Custom help URL, if any	158
	4.57.1 Custom help URL	158
4.58	Registration status	159
4.59	Enable page refresh	159
4.60	Page refresh delay	160
4.61	Preferred image format	160
4.62	Unit hostname	161
4.63	Time zone	161
4.64	HTTP ports	162
4.65	HTTP ports: Port binding	163
	4.65.1 Address	164
	4.65.2 Port	165

4.66	HTTPS ports	165
4.67	HTTPS ports: Port binding	167
	4.67.1 Address	168
	4.67.2 Port	168
4.68	HTTPS certificate settings	169
	4.68.1 Bits	171
	4.68.2 Domain names override, if any	171
	4.68.3 Addresses override, if any	172
	4.68.4 Automatic renewal	173
	4.68.5 Certificate renewal method	174
	4.68.6 HTTPS certificate signing request	174
	4.68.7 HTTPS certificate chain	175
	4.68.8 HTTPS certificate key	176
	4.68.9 Renew certificate	176
	4.68.10 Generate key	177
	4.68.11 Renewal methods	177
	4.68.12 Distinguished name	178
	4.68.13 String mask	179
4.69	Domain names override, if any: Domain names override	180
	4.69.1 Hostname	180
4.70	Addresses override, if any: Addresses override	181
	4.70.1 IPv4 address	181
4.71	HTTPS certificate settings: Data	182
	4.71.1 Data item	182
4.72	Supported data items: Data item properties	183
	4.72.1 Name	184
	4.72.2 Regular expression	185
	4.72.3 Secret	185
4.73	Renewal methods: Renewal method	185
	4.73.1 Supported data items	186

CONTENTS xi

	4.73.2 Name	187
4.74	Distinguished name: Values	188
	4.74.1 Value	188
4.75	HTTPS certificate settings: Known DN OIDs	189
	4.75.1 OID	190
4.76	SSH enabled	190
4.77	SSH port number	191
4.78	SSH authorized keys	191
4.79	SSH authorized keys: SSH authorized key	193
	4.79.1 Data	193
	4.79.2 Options	194
	4.79.3 Comment	195
4.80	NTP server enabled	195
4.81	NTP peers	196
4.82	NTP peers: NTP peer	197
	4.82.1 Hostname	198
	4.82.2 IPv4 address	198
4.83	Syslog threshold severity	199
4.84	Syslog server address, if any	200
	4.84.1 Hostname	201
	4.84.2 IPv4 address	201
4.85	Allow JSONRPC	201
4.86	Allow REST-like API	202
4.87	Allowed REST-like API client origins	202
	4.87.1 Allowed REST-like API client origin	203
4.88	Relax non-HTML method CSRF checks	204
4.89	Relax non-HTML content type CSRF checks	205
4.90	Allow plaintext logins	205
4.91	Relay name visibility	206
	Hide user passwords	

4.93 Hide WiFi key
4.94 Security lockout duration
4.95 Protect firmware
4.96 Protect admin login
4.97 Protect network settings
4.98 Protect private settings
4.99 Protect from restore
4.100 Protect from maintenance
4.101 Protect notification settings
4.102Beep on upgrade
4.103Blink on upgrade
4.104Known quantities
4.104.1 Quantity
4.105Quantity: Name
4.106Quantity: Preferred unit, if any
4.106.1 Preferred unit
4.107Quantity: Known units
4.107.1 Unit
4.108 Known timezones
4.108.1 Timezone
4.109Known protection bits
4.109.1 Protection bit
4.110 Protection bit: Name
4.111 Protection bit: Protection status
4.111.1 Ineffective
4.112Relay ports
4.112.1 Relay port

χij

CONTENTS xiii

5	Network configuration data					
	5.1	Wired	network data	228		
		5.1.1	MAC address	230		
		5.1.2	Online	230		
		5.1.3	IP address assignment protocol	231		
		5.1.4	IP address	231		
		5.1.5	Network mask	232		
		5.1.6	DNS server	233		
	5.2	Wired	network data: Default gateway IP address, if any	233		
		5.2.1	Default gateway IP address	234		
	5.3	Wired	network data: DNS servers	235		
		5.3.1	DNS server	235		
	5.4	Wirele	ss network data	236		
		5.4.1	Enable wireless module	237		
		5.4.2	Online	238		
		5.4.3	MAC address	238		
		5.4.4	IP address assignment protocol	239		
		5.4.5	IP address	239		
		5.4.6	Network mask	240		
		5.4.7	DNS server	241		
		5.4.8	Mode	241		
		5.4.9	SSID	242		
		5.4.10	Wireless channel	242		
		5.4.11	Encryption	243		
		5.4.12	Key	244		
		5.4.13	Wireless Accessory Configuration supported	244		
		5.4.14	Wireless Accessory Configuration enabled	245		
	5.5	Wirele	ss network data: Default gateway IP address, if any	246		
		5.5.1	Default gateway IP address	246		
	5.6	Wireles	ss network data: DNS servers	247		

	5.6.1	DNS server	47
5.7	Wireles	ss network data: Known modes	48
	5.7.1	Mode	48
5.8	Wireles	ss network data: Known channels	49
	5.8.1	Channel	49
5.9	Wireles	ss network data: Known encryptions	50
	5.9.1	Encryption	50
5.10	Same s	subnet restriction	:51
5.11	Known	protocols	:51
	5.11.1	Protocol	52
5.12	Interfac	pe priority order	52
	5.12.1	Interface order element	:53
5.13	Notifica	utions	53
	5.13.1	Events	54
5.14	Messag	ge template: Message template element	:55
	5.14.1	String	56
	5.14.2	Parameter	56
5.15	Event p	parameter: Fixed value	56
	5.15.1	String	56
	5.15.2	Number	57
5.16	Event p	parameter: Fixed value flag	:57
5.17	Event p	parameter: Identifier	57
5.18	Events	: Event	58
	5.18.1	Message template	58
	5.18.2	Event parameters	:59
	5.18.3	Severity	61
5.19	Notifica	ations: Parameter kinds	61
	5.19.1	Device name	62
	5.19.2	Device index	62
	5.19.3	Status	62

CONTENTS xv

6	Even	nt notification server object	263
	6.1	Sinks	264
		6.1.1 Sink	266
	6.2	Sink: Data	267
		6.2.1 Data item	268
	6.3	Sink: Name	269
	6.4	Sink: Test	270
	6.5	Sink: Type	270
	6.6	Rules	271
	6.7	Rules: Rule	273
		6.7.1 Rule condition	274
		6.7.2 Rule action	274
	6.8	Sink types	275
		6.8.1 Sink type	275
	6.9	Sink type: Supported data items	277
		6.9.1 Data item properties	277
	6.10	Sink type: Name	279
	6.11	Sink data item groups	280
	6.12	Sink data item groups: Sink data item group	281
		6.12.1 Immutable	282
		6.12.2 Name	283
		6.12.3 Secret	283
		6.12.4 Unreadable	284

7	Auto	ping server object	284
	7.1	Enabled	285
	7.2	ltems	286
		7.2.1 Autoping item data	287
	7.3	Autoping item data: Enabled status	289
	7.4	Autoping item data: Address list	290
		7.4.1 Address	290
	7.5	Autoping item data: Controlled outlets	291
		7.5.1 Outlet index	292
	7.6	Autoping item data: Script command, if any	292
		7.6.1 Script command	293
		7.6.2 Invalid action placeholder	294
	7.7	Autoping item data: Request item state change	294
		7.7.1 Desired item state	294
	7.8	Target states: Target state	295
		7.8.1 Address	295
		7.8.2 State	296
		7.8.3 Success count	296
		7.8.4 Failure count	297
		7.8.5 Queue size	297
	7.9	Autoping item data: Autoping item status	298
		7.9.1 Target states	299
		7.9.2 Reboot count	301
	7.10	Autoping item data: Pings remaining to enable, if any	301
		7.10.1 Pings remaining to enable	302
	7.11	Autoping item data: Recently failed	302
	7.12	Autoping item data: In resumption trial	303
	7.13	Ping interval	303
	7.14	Ping timeout	304
	7.15	Post-reboot delay	304

CONTENTS xvii

7.16	Default maximum total reboot count, if any	305
	7.16.1 Maximum total reboot count	306
7.17	Pings before enabling	306
7.18	Resume without retrial	306
7.19	Handle failures immediately	307
7.20	Reset statistics	308
7.21	Notifications	308
	7.21.1 Events	309
	7.21.2 Parameter kinds	310
7.22	Message template: Message template element	311
	7.22.1 String	312
	7.22.2 Parameter	312
7.23	Event parameter: Fixed value	312
	7.23.1 String	312
	7.23.2 Number	313
7.24	Event parameter: Fixed value flag	313
7.25	Event parameter: Identifier	313
7.26	Events: Event	313
	7.26.1 Message template	315
	7.26.2 Event parameters	315
	7.26.3 Severity	317
7.27	Parameter kinds: Address	317
7.28	Parameter kinds: Item addresses	318
7.29	Parameter kinds: Consecutive failure count	318
7.30	Parameter kinds: Maximum consecutive failure count, if any	319
	7.30.1 Maximum consecutive failure count	319
7.31	Parameter kinds: Maximum total failure count, if any	320
	7.31.1 Maximum total failure count	320
7.32	Parameter kinds: Item name	321
7.33	Parameter kinds: Pings before enabling	321
7.34	Parameter kinds: Item script name	322
7.35	Parameter kinds: Item state	322
7.36	Parameter kinds: Total failure count	323
7.37	Parameter kinds: Ping time	323
7.38	Parameter kinds: Ping timeout	323
7.39	Parameter kinds: Ping state	324
7.40	Default maximum consecutive reboot count, if any	324
	7.40.1 Maximum consecutive reboot count	325

8	Scrip	oting server object	326
	8.1	User script source	327
	8.2	User functions	327
		8.2.1 User script function signature	328
	8.3	Script to start at boot, if any	328
		8.3.1 Script to start at boot	329
	8.4	Thread map	329
	8.5	Thread map: Scripting thread	330
		8.5.1 Label	331
	8.6	Start a script thread	331
		8.6.1 Code source	332
		8.6.2 Resulting thread ID	332
	8.7	Code source: User function, if any	333
		8.7.1 User function	333
	8.8	Code source: User code, if any	333
		8.8.1 User code	333
	8.9	Code source: Displayed source code, if any	333
		8.9.1 Displayed source code	334
	8.10	Stop a script thread	334
	8.11	Stop a script thread: Thread(s) to stop	334
		8.11.1 Thread ID	335
	8.12	Script tracing	335
	8.13	Script step delay	335
	8.14	Script step time limit	336
	8.15	Notifications	336
		8.15.1 Events	337
		8.15.2 Parameter kinds	338
	8.16	Message template: Message template element	339
		8.16.1 String	339
		8.16.2 Parameter	339

CONTENTS xix

8.17	Event parameter: Fixed value	340
	8.17.1 String	340
	8.17.2 Number	340
8.18	Event parameter: Fixed value flag	340
8.19	Event parameter: Identifier	341
8.20	Events: Event	341
	8.20.1 Message template	342
	8.20.2 Event parameters	343
	8.20.3 Severity	345
8.21	Parameter kinds: Thread error	345
8.22	Parameter kinds: Thread ID	346
8.23	Parameter kinds: Thread name	346
8.24	Parameter kinds: Thread origin, if any	347
	8.24.1 Thread origin	347
8.25	Parameter kinds: Thread start reason, if any	347
	8.25.1 Thread start reason	348
8.26	Parameter kinds: Thread state	348
8.27	Parameter kinds: Thread stop reason	349
8.28	Script snippets	349
8.29	Script snippets: Script snippet	350
	8.29.1 Snippet source	351
8.30	User function UI order	352
	8.30.1 User script function name for index	352

9	SNM	P server object	352
	9.1	Allow SNMP	354
	9.2	Engine ID	354
	9.3	OID subtrees	355
	9.4	OID subtrees: OID subtree	356
		9.4.1 Title	357
		9.4.2 Root mask	358
		9.4.3 Read security level	358
		9.4.4 Write security level	359
	9.5	Users	360
		9.5.1 User	361
	9.6	User: User allowed	363
	9.7	User: Authentication method	364
	9.8	User: Authentication password configured	365
	9.9	User: Authentication password	366
	9.10	User: Privacy method	367
	9.11	User: Privacy password configured	367
	9.12	User: Privacy password	368
	9.13	User: Subtree access levels	369
		9.13.1 Subtree access	369
	9.14	Community mappings	370
	9.15	Community mappings: Community mapping	371
		9.15.1 Community	372
		9.15.2 User	373
		9.15.3 IP address	374
		9.15.4 Network mask	374
	9.16	Known authentication methods	375
		9.16.1 Authentication method	376
	9.17	Known privacy methods	376
		9.17.1 Privacy method	377

CONTENTS xxi

10	UPnP server object	377
	10.1 Enabled	378
	10.2 Outlet UPnP configuration settings	379
	10.2.1 Outlet UPnP configuration	380
	10.3 Outlet UPnP configuration: Alternate name, if any	381
	10.3.1 Alternate name	382
	10.4 Outlet UPnP configuration: Exposed	382
	10.5 Outlet UPnP configuration: Identifier	383
	10.6 Outlet UPnP configuration: Profile	383
	10.7 UPnP device profiles	384
	10.7.1 UPnP device profile	386
	10.8 Arguments: Argument	388
	10.8.1 Output/return value flag	389
	10.8.2 Argument name	390
	10.8.3 Related state variable identifier, if any	391
	10.8.4 Argument type	392
	10.9 UPnP device profile: Action map	392
	10.9.1 Action	393
	10.10UPnP device profile: Device type	396
	10.11UPnP device profile: Device version	397
	10.12UPnP device profile: Device namespace	398
	10.13UPnP device profile: Manufacturer	398
	10.14UPnP device profile: Model	399
	10.15UPnP device profile: Model number	399
	10.16UPnP device profile: Namespace identifier	400
	10.17UPnP device profile: Service control URL	401
	10.18UPnP device profile: Service event subscription URL	401
	10.19UPnP device profile: Service ID	402
	10.20UPnP device profile: Service SCPD URL	402
	10.21 UPnP device profile: Service type	403

10.22UPnP device profile: Service version	4
10.23UPnP device profile: Service namespace	4
10.24UPnP device profile: State variables	5
10.24.1 State variable binding	6
10.25UPnP device profile: Variable types	0
10.25.1 Variable type	1
10.26UPnP device profile: UUID prefix	3
10.27Notifications	4
10.27.1 Events	5
10.27.2 Parameter kinds	5
10.28Message template: Message template element	6
10.28.1 String	6
10.28.2 Parameter	6
10.29 Event parameter: Fixed value	6
10.29.1 String	7
10.29.2 Number	7
10.30 Event parameter: Fixed value flag	7
10.31 Event parameter: Identifier	8
10.32Events: Event	8
10.32.1 Message template	9
10.32.2 Event parameters	0.
10.32.3 Severity	2

CONTENTS xxiii

11	MQTT client object	422
	11.1 Enabled	424
	11.2 Outlet MQTT configuration settings	425
	11.2.1 Outlet MQTT configuration	427
	11.3 Outlet MQTT configuration: Allow read	428
	11.4 Outlet MQTT configuration: Allow write	428
	11.5 Outlet MQTT configuration: State subscription and report QoS	429
	11.6 Outlet MQTT configuration: Topic subtree, if any	430
	11.6.1 Topic subtree	431
	11.7 MQTT broker address	431
	11.7.1 Hostname	432
	11.7.2 IPv4 address	432
	11.8 Use SSL	432
	11.9 Username	433
	11.10 Password	433
	11.11 Topic root	434
	11.12Last Will and Testament topic	434
	11.13Last Will and Testament payload	435
	11.14Last Will and Testament QoS	436
	11.15 Notifications	436
	11.15.1 Events	437
	11.16Message template: Message template element	438
	11.16.1 String	439
	11.16.2 Parameter	439
	11.17Event parameter: Fixed value	439
	11.17.1 String	439
	11.17.2 Number	440
	11.18 Event parameter: Fixed value flag	440
	11.19Event parameter: Identifier	440
	11.20 Events: Event	441
	11.20.1 Message template	442
	11.20.2 Event parameters	442
	11.20.3 Severity	444
	11.21 Notifications: Parameter kinds	445
	11.21.1 Connection status	445
	11.22MQTT broker port, if any	445
	11.22.1 MQTT broker port	446

12	Meter server object	446
	12.1 Measured values	448
	12.1.1 Measured value	449
	12.2 Measured value: Value name	451
	12.3 Measured value: Value, if any	451
	12.3.1 Value	452
	12.4 Measured value: Expression, if any	452
	12.4.1 Expression	453
	12.5 Measured value: Custom flag	453
	12.6 Measured value: Calibration flag	454
	12.7 Measured value: Calibration support flag	455
	12.8 Measured value: Quantity	455
	12.9 Measured value: Bus index, if any	456
	12.9.1 Bus index	456
	12.10Measured value: Internal	457
	12.11 Measured value: Log history	457
	12.12Measured value: History log parameters	458
	12.12.1 History log	459
	12.13 Value history: Data point, if any	461
	12.13.1 Data point	462
	12.14Measured value: Get value history	462
	12.14.1 Data start time	462
	12.14.2 Data end time	462
	12.14.3 Data time step	463
	12.14.4 Value history record	463
	12.15Measured value: Clear value history	464
	12.16Measured value: Data absence alarm level, if any	464
	12.16.1 Data absence alarm level	465
	12.17Measured value: Data absence alarm period, if any	465
	12.17.1 Data absence alarm period	466

12.18Measured value: Lowest interval alarm level, if any
12.18.1 Lowest interval alarm level
12.19Measured value: Lowest interval alarm period, if any
12.19.1 Lowest interval alarm period
12.20 Interval configuration: Alarm level, if any
12.20.1 Alarm level
12.21 Interval configuration: Alarm period, if any
12.21.1 Alarm period
12.22Measured value: Value interval properties
12.22.1 Interval configuration
12.23Measured value: Commit calibration
12.24Measured value: History subsample count
12.25Measured value: History time step
12.26Measured value: Insert calibration point
12.26.1 Kind
12.26.2 Value
12.26.3 Weight
12.26.4 Derivative
12.26.5 Derivative weight
12.27Bus list
12.28Bus list: Bus attributes
12.28.1 Name
12.28.2 Power status
12.28.3 Power factor
12.29 Power status
12.30Emergency shutoff status
12.31 Notifications
12.31.1 Events
12.31.2 Parameter kinds
12.32Message template: Message template element

12.32.1 String	485
12.32.2 Parameter	486
12.33 Event parameter: Fixed value	486
12.33.1 String	486
12.33.2 Number	486
12.34Event parameter: Fixed value flag	486
12.35 Event parameter: Identifier	487
12.36Events: Event	487
12.36.1 Message template	489
12.36.2 Event parameters	489
12.36.3 Severity	491
12.37 Parameter kinds: Bus index	492
12.38 Parameter kinds: Bus name	492
12.39 Parameter kinds: Bus power status	492
12.40 Parameter kinds: Emergency shutoff status	493
12.41 Parameter kinds: Power status	493
12.42 Parameter kinds: Value alarm duration	494
12.43 Parameter kinds: Value alarm level	494
12.44 Parameter kinds: Value alarm repeat count, if any	495
12.44.1 Value alarm repeat count	495
12.45 Parameter kinds: Value identifier	496
12.46 Parameter kinds: Value name	496

CONTENTS xxvii

13	Rend	derer object	496
	13.1	Draw a message	498
		13.1.1 Format	498
		13.1.2 Width	498
		13.1.3 Height	499
		13.1.4 Message	499
		13.1.5 Content type	499
		13.1.6 Image data	499
	13.2	Draw a pie meter	500
		13.2.1 Format	501
		13.2.2 Width	501
		13.2.3 Height	501
		13.2.4 Properties	502
		13.2.5 Value	502
		13.2.6 Content type	503
		13.2.7 Image data	503
	13.3	Properties: Arrow color	503
	13.4	Properties: Decimals	503
	13.5	Properties: Minimum value	503
	13.6	Properties: Display scale	504
	13.7	Properties: Meter sectors	504
		13.7.1 Sector parameters	504
	13.8	Draw a pie meter: Value quantity and unit	505
		13.8.1 Value quantity	505
		13.8.2 Value unit	506
	13.9	Draw a plot	506
		13.9.1 Format	507
		13.9.2 Width	507
		13.9.3 Height	508
		13.9.4 Properties	508

13.9.5 Lines
13.9.6 Content type
13.9.7 Image data
13.10 Properties: Custom time format, if any
13.10.1 Custom time format
13.11 Properties: X1 axis settings
13.11.1 Minimum, if any
13.11.2 Maximum, if any
13.11.3 Soft minimum, if any
13.11.4 Soft maximum, if any
13.11.5 Major tick interval, if any
13.11.6 Minor ticks per major tick, if any
13.12Properties: X2 axis settings
13.12.1 Minimum, if any
13.12.2 Maximum, if any
13.12.3 Soft minimum, if any
13.12.4 Soft maximum, if any
13.12.5 Major tick interval, if any
13.12.6 Minor ticks per major tick, if any
13.13Properties: Y1 axis settings
13.13.1 Minimum, if any
13.13.2 Maximum, if any
13.13.3 Soft minimum, if any
13.13.4 Soft maximum, if any
13.13.5 Major tick interval, if any
13.13.6 Minor ticks per major tick, if any
13.14Properties: Y2 axis settings
13.14.1 Minimum, if any
13.14.2 Maximum, if any
13.14.3 Soft minimum, if any


1 DLI Controller API

	13.14.4 Soft maximum, if any	521
	13.14.5 Major tick interval, if any	522
	13.14.6 Minor ticks per major tick, if any	522
	13.15Plot point: X	523
	13.16Plot point: Y, if any	523
	13.16.1 Y	523
	13.17Plotted quantities and units: X axis quantity and unit	524
	13.17.1 X axis quantity	524
	13.17.2 X axis unit	524
	13.18 Plotted quantities and units: Y axis quantity and unit	524
	13.18.1 Y axis quantity	525
	13.18.2 Y axis unit	525
	13.19Lines: Line	525
	13.19.1 Title	526
	13.19.2 Plot data	526
	13.19.3 Style	527
	13.19.4 Plotted quantities and units	530
	13.20Axes	531
	13.20.1 Name	532
	13.21 Image formats	532
	13.21.1 Name	533
	13.22Line types	533
	13.22.1 Name	534
	13.23Marker types	534
	13.23.1 Name	534
	13.24Plot styles	535
	13.24.1 Name	535
	13.25 Plot scales	536
	13.25.1 Name	537
1/1	Credentials	537
	14.1 Client username, if any	538
	14.1.1 Client username	
	14.2 Administrative user	
	14.3 Outlet access permissions	
	14.4 Outlet access permissions: Outlet access levels	
	14.4.1 Outlet access	
	14.5 Agent identifier	
	14.6 Client IP address, if any	
	14.6.1 Client IP address	
	The state of the s	J 1/2

1 DLI Controller API

object

The set of objects that comprise the controller's API



This object contains the following items:

relay	Relay object	
auth	Authentication server object	
config	Configuration server object	
network Network configuration data		
notification	Event notification server object	
autoping	Autoping server object	
script	Scripting server object	
snmp SNMP server object		
upnp	UPnP server object	
mqtt	MQTT client object	
meter	Meter server object	
renderer	Renderer object	
cred	Credentials	

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/"
```

2 Relay object

```
\Rightarrow
```


. . .

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept ← 
→ : application/json" --data-binary "..." "https://192.168.0.100/restapi/"
```

2 Relay object

object	relay/
Object i	representing relay state and configuration



Retrieving the value is denied if not administrative user

This object contains the following items:

name	Name
online	Online status
model	Model
version	Relay version number
outlets	Outlets

sequence_delay	Outlet ON sequence delay
min_sequence_delay	Minimal ON sequence delay
cycle_delay	Default outlet cycle delay
relatch	Brown-out re-latch delay
recovery_mode	Recovery mode
buses	Buses
pins	Pins
nets	Nets
fuses_enabled	Enable measurement-driven outlet control
min_relay_voltage	Minimum relay voltage, if any
fuse_relatch	Measurement-driven relatch timeout, if any
keypad_enabled	Keypad state
all_caps	LCD all-caps filter
beep_sequence	Beep sequence
backlight_sequence	Backlight sequence
lcd_columns	LCD column count
lcd_rows	LCD row count
user_lines	User LCD lines
user_message_force_timeout	User message force display timeout, if any
user_message_timeout	User message display timeout, if any
notifications	Notifications

Sample read command:

Sample write command:

2.1 Name

string	relay/name/	
User-vi	User-visible relay name	

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/relay/name/"
```

2.3 Model 5

```
⇒
"Sample value"
```

Sample write command:

2.2 Online status

sum (variant)	relay/online/
Relay module	online status

Retrieving the value is denied if not administrative user

This sum does not support direct modification if agent identifier is not equal to relay.

This sum can assume the following values:

constant true	Online	The relay module is online and fully operational, out-
		lets can be switched on unless emergency shutoff is
		activated
constant "degraded"	Degraded	The relay module is online but outlets cannot be
		switched on due to low-power conditions
constant false	Offline	The relay module is offline, outlets cannot be switched
		on

Sample read command:

\Rightarrow (possible variant)

false

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "\"Sample value\"" "https \leftrightarrow ://192.168.0.100/restapi/relay/online/"
```

2.3 Model

string	relay/model/	
Relay n	Relay model name	

Retrieving the value is denied if not administrative user

This string does not support direct modification.

This string represents a value in persistent storage.

Sample read command:

2.4 Relay version number

```
string relay/version/
Relay core firmware version number
```

Retrieving the value is denied if not administrative user

This string does not support direct modification if agent identifier is not equal to relay.


Sample read command:

Sample write command:

2.5 Outlets

```
array relay/outlets/
Outlets controlled by the relay
```

2.5 Outlets 7



Retrieving the value is denied if not administrative user

This array does not support direct modification.

This array represents a value in persistent storage.

This array contains Outlet elements.

Sample read command:

Creating elements in this collection is not supported.

2.5.1 Outlet

object	relay/outlets/N/
Object representing outlet state and configuration	

This object contains the following items:

name	Name
state	Configured state
transient_state	Transient state
physical_state	Physical state
locked	Lock state
critical	Critical
cycle_delay	Outlet cycle delay, if any
cycle	Cycle

Sample read command (note that :outlet is a URL template argument and needs to be replaced before trying):

Sample write command (note that :outlet is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"state\":false,\"physical_state\":true,\"cycle_delay\":3,\" \( \to \) locked\":true,\"transient_state\":true,\"critical\":true,\"name\":\"Sample \( \to \) value of name\"}"\
"https://192.168.0.100/restapi/relay/outlets/:outlet/"
```

See also Outlet: Name

See also Outlet: Configured state

See also Outlet: Transient state

See also Outlet: Physical state

See also Outlet: Lock state

See also Outlet: Critical

See also Outlet: Outlet cycle delay, if any

See also Outlet: Cycle

2.6 Outlet: Name

```
string relay/outlets/N/name/
User-visible outlet name
```

Retrieving the value is denied if any of the following is true:

- · outlet access permissions is equal to false
- all of the following is true:
 - outlet access permissions is not equal to true
 - not outlet access permissions[index of outlet]

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Sample read command (note that :outlet is a URL template argument and needs to be replaced before trying):

Sample write command (note that :outlet is a URL template argument and needs to be replaced before trying):

2.7 Outlet: Configured state

```
sum (boolean) relay/outlets/N/state/
Saved configured state of the outlet. Cannot be changed if the outlet is locked
```

Retrieving the value is denied if any of the following is true:

- · outlet access permissions is equal to false
- · all of the following is true:
 - outlet access permissions is not equal to true
 - not outlet access permissions[index of outlet]

Changing the value is denied if any of the following is true:

- any of the following is true:
 - outlet access permissions is equal to false

- all of the following is true:
 - * outlet access permissions is not equal to true
 - * not outlet access permissions[index of outlet]
- · lock state

This sum represents a value in persistent storage.

Changes to this sum may have an effect besides setting value.

This sum can assume the following values:

constant true	On	The outlet is powered	
constant false	Off	The outlet is not powered	

Sample read command (note that :outlet is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/relay/outlets/:outlet/state/"
```

 \Rightarrow (possible variant)

false

Sample (possible variant) write command (note that :outlet is a URL template argument and needs to be replaced before trying):

2.8 Outlet: Transient state

sum (boolean)	relay/outlets/N/transient_state/
Current expecte	ed state of the outlet. Cannot be changed if the outlet is locked

Retrieving the value is denied if any of the following is true:

- · outlet access permissions is equal to false
- all of the following is true:
 - outlet access permissions is not equal to true
 - not outlet access permissions[index of outlet]

Changing the value is denied if any of the following is true:

- · any of the following is true:
 - outlet access permissions is equal to false
 - all of the following is true:

- * outlet access permissions is not equal to true
- * not outlet access permissions[index of outlet]
- · lock state

This sum can change as if by itself or indirectly because of other actions.

This sum can assume the following values:

constant true	On	The outlet is powered	
constant false	Off	The outlet is not powered	

Sample read command (note that :outlet is a URL template argument and needs to be replaced before trying):

 \Rightarrow (possible variant)

false

Sample (possible variant) write command (note that :outlet is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "true" "https://192.168.0.100/restapi/ \hookrightarrow relay/outlets/:outlet/transient_state/"
```

2.9 Outlet: Physical state

sum (boolean)	relay/outlets/N/physical_state/	
Current actual s	Current actual state of the outlet	

Retrieving the value is denied if any of the following is true:

- · outlet access permissions is equal to false
- all of the following is true:
 - outlet access permissions is not equal to true
 - not outlet access permissions[index of outlet]

Changing the value is denied if agent identifier is not equal to relay

This sum does not support direct modification if agent identifier is not equal to relay.

This sum can assume the following values:

constant true	On	The outlet is powered	
constant false	Off	The outlet is not powered	

Sample read command (note that :outlet is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :outlet is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "false" "https://192.168.0.100/restapi/ \hookleftarrow: relay/outlets/:outlet/physical_state/"
```

2.10 Outlet: Lock state

sum (boolean)	relay/outlets/N/locked/	
Indicates wheth	Indicates whether the outlet state is locked from keypad	

Retrieving the value is denied if any of the following is true:

- · outlet access permissions is equal to false
- · all of the following is true:
 - outlet access permissions is not equal to true
 - not outlet access permissions[index of outlet]

Changing the value is denied if agent identifier is not equal to relay

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Locked	The outlet state cannot be changed
constant false	Unlocked	The outlet state can be changed

Sample read command (note that :outlet is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :outlet is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "false" "https://192.168.0.100/restapi/ \hookleftarrow: relay/outlets/:outlet/locked/"
```

2.11 Outlet: Critical

sum (boolean)	relay/outlets/N/critical/
Flag indicating	whether the outlet is critical, and turning it off should ask for confirmation

Retrieving the value is denied if any of the following is true:

- · outlet access permissions is equal to false
- all of the following is true:
 - outlet access permissions is not equal to true
 - not outlet access permissions[index of outlet]

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Critical	Confirmation requested to change the outlet state
constant false	Noncritical	No confirmation is needed to change the outlet state

Sample read command (note that :outlet is a URL template argument and needs to be replaced before trying):

 \Rightarrow (possible variant)

true

Sample (possible variant) write command (note that :outlet is a URL template argument and needs to be replaced before trying):

2.12 Outlet: Outlet cycle delay, if any

sum (optional number)	relay/outlets/N/cycle_delay/	
Outlet cycle delay, in sec	conds, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Use default cycle delay	Use unit default cycle delay	
number	Outlet cycle delay	Outlet cycle delay, in seconds	the value is greater than 0

Sample read command (note that :outlet is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :outlet is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "7" "https://192.168.0.100/restapi/relay/ \leftrightarrow outlets/:outlet/cycle_delay/"
```

2.12.1 Outlet cycle delay

(possibly) number	relay/outlets/N/cycle_delay/	
Outlet cycle delay, in seconds		

The value is subject to the following constraints: the value is greater than 0

Sample write command (note that :outlet is a URL template argument and needs to be replaced before trying):

2.13 Outlet: Cycle

call	relay/outlets/N/cycle/
------	------------------------

Turns the outlet off, then on again after the cycle delay passes. Has no effect when the outlet is already off. Signals an error if the outlet is locked. Does not turn the outlet back on if it becomes locked

Performing the function call is denied if any of the following is true:

- · any of the following is true:
 - outlet access permissions is equal to false
 - all of the following is true:
 - * outlet access permissions is not equal to true
 - * not outlet access permissions[index of outlet]
- · lock state

The call has no arguments (supply empty tuple).

The call returns the following results:

1. Started or No action taken

Sample invocation (note that :outlet is a URL template argument and needs to be replaced before trying):

2.13.1 Action performed

sum (boolean)	relay/outlets/N/cycle/results: 1/
Flag indicating whether the call affected the outlet state	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant false	No action taken	The outlet was off or already in a cycle, so the call had no effect
constant true	Started	The outlet was on and the cycle has started

2.14 Outlet ON sequence delay

```
number relay/sequence_delay/

Time after switching an outlet on during which switching outlets on is delayed to prevent simultaneous inrush currents on power-on
```

The value is subject to the following constraints: the value is greater or equal to minimal on sequence delay

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command:

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "1" "https://192.168.0.100/restapi/relay/ \leftrightarrow sequence_delay/"
```

2.15 Minimal ON sequence delay

number	relay/min_sequence_delay/
The minimal time after switching an outlet on during which switching outlets on is delayed	

The value is subject to the following constraints: the value is greater or equal to 0

This number does not support direct modification.

This number represents a value in persistent storage.

Sample read command:

2.16 Default outlet cycle delay

```
number relay/cycle_delay/
```

Time between switching an outlet off and turning it back on during cycling, which allows the controlled device to really power down

The value is subject to the following constraints: the value is greater than 0

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command:

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "10" "https://192.168.0.100/restapi/relay \leftarrow \leftrightarrow /cycle_delay/"
```

2.17 Brown-out re-latch delay

number	relay/relatch/
Time to wait before relatching relays on brown-out	

2.18 Recovery mode 17

The value is subject to the following constraints: the value is greater than 0

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

```
Sample read command:
```

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←
   → restapi/relay/relatch/"
\Rightarrow
8
```

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept ←
   → : application/json" --data-binary "3" "https://192.168.0.100/restapi/relay/ ←
   → relatch/"
```

2.18 Recovery mode

sum (enumerated number)	relay/recovery_mode/
Outlet power-off recovery state policy	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant 0	All outlets off	All outlets remain powered off at power-up
constant 1	All outlets on	All outlets are switched on in sequence during power-
		up
constant 2	Pre-powerloss state	Outlets are returned to configured pre-powerloss state
		during power-up

```
Sample read command:
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←

→ restapi/relay/recovery_mode/"


\Rightarrow (possible variant)
7
Sample (possible variant) write command:
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept ←
```

→ : application/json" --data-binary "7" "https://192.168.0.100/restapi/relay/ ←

→ recovery_mode/"

2.19 Buses

array	relay/buses/	
Buses	Buses powering the relay	



This array does not support direct modification.

This array represents a value in persistent storage.

This array contains Bus elements.


Sample read command:

Creating elements in this collection is not supported.

2.19.1 Bus

object	relay/buses/N/
Object representing bus state and configuration	

2.19 Buses 19



This object contains the following items:

outlet_indices	Outlet list
voltage_affects_outlets	Voltage-affected outlets
min_voltage	Minimum voltage, if any
max_voltage	Maximum voltage, if any
current_affects_outlets	Current-affected outlets
max_current	Maximum current, if any

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \( \rightarrow\) restapi/relay/buses/:bus/"

$\Rightarrow\ \{\text{"outlet_indices":[} \\ 2, \\ 8, \\ 2, \\ 8, \\ 1, \\ 10, \\ 1, \\ 6 \\ ], \\ "voltage_affects_outlets":[$\]
```

```
3,
8
],
"min_voltage":7,
"current_affects_outlets":[
1,
2,
6,
1,
1,
3,
5,
9
],
"max_voltage":7,
"max_current":8
```

Sample write command (note that :bus is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"outlet_indices\":[2],\"voltage_affects_outlets \( \to \) \":[3,9,2,10,1,9,1,1,10,6],\"min_voltage\":null,\"current_affects_outlets \( \to \) \":[10,9,4,6],\"max_voltage\":null,\"max_current\":5}"\
"https://192.168.0.100/restapi/relay/buses/:bus/"
```

See also Bus: Outlet list

See also Bus: Voltage-affected outlets

See also Bus: Minimum voltage, if any

See also Bus: Maximum voltage, if any

See also Bus: Current-affected outlets

See also Bus: Maximum current, if any

2.20 Bus: Outlet list

```
array relay/buses/N/outlet_indices/
List of outlets connected to the bus
```

This array does not support direct modification.

This array contains Outlet index elements.

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/relay/buses/:bus/outlet_indices/"
```

```
⇒
[
9,
9,
4,
3,
9
1
```

Creating elements in this collection is not supported.

2.20.1 Outlet index

numbe	r relay/buses/N/outlet_indices/N/
Index of outlet connected to the bus	

The value is subject to the following constraints: all of the following is true:

- · outlets[the value]
- · outlet list are distinct

This number does not support direct modification.

This number represents a value in persistent storage.

Sample read command (note that :bus and :outlet_index are URL template arguments and need to be replaced before trying):

2.21 Bus: Voltage-affected outlets

```
array relay/buses/N/voltage_affects_outlets/
List of outlets affected by over/undervoltage
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This array represents a value in persistent storage.

This array represents an unordered set (order of its elements doesn't matter, and each value should not be supplied more than once).

This array contains Outlet list index elements.

Sample write command (note that :bus is a URL template argument and needs to be replaced before trying):

Sample outlet list index creation command (note that :bus is a URL template argument and needs to be replaced before trying):

2.21.1 Outlet list index

```
number relay/buses/N/voltage_affects_outlets/N/
Index of outlet in the bus outlet list
```

The value is subject to the following constraints: all of the following is true:

- outlet list[the value]
- · voltage-affected outlets are distinct

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

Sample read command (note that :bus and :outlet_list_index are URL template arguments and need to be replaced before trying):

Sample write command (note that :bus and :outlet_list_index are URL template arguments and need to be replaced before trying):

Sample deletion command (note that :bus and :outlet_list_index are URL template arguments and need to be replaced before trying):

2.22 Bus: Minimum voltage, if any

sum (optional number)	relay/buses/N/min_voltage/
The minimum voltage, below which the affected bus outlets are switched off, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	No minimum voltage	Undervoltage doesn't affect any outlets	
number	Minimum voltage	The minimum voltage, below which the affected bus outlets are switched off	

Sample read command (note that :bus is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :bus is a URL template argument and needs to be replaced before trying):

2.22.1 Minimum voltage

```
(possibly) number relay/buses/N/min_voltage/
The minimum voltage, below which the affected bus outlets are switched off
```

The value is subject to the following constraints: the value is greater or equal to 0

Sample write command (note that :bus is a URL template argument and needs to be replaced before trying):

2.23 Bus: Maximum voltage, if any

sum (optional number)	relay/buses/N/max_voltage/
The maximum voltage, above which the affected bus outlets are switched off, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	No maximum voltage	Overvoltage doesn't affect any outlets	
number	Maximum voltage	The maximum voltage, above which the affected bus outlets are switched off	

Sample read command (note that :bus is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :bus is a URL template argument and needs to be replaced before trying):

2.23.1 Maximum voltage

(possibly) number	relay/buses/N/max_voltage/
The maximum voltage, above which the affected bus outlets are switched off	

The value is subject to the following constraints: the value is greater or equal to 0

2.24 Bus: Current-affected outlets

```
array relay/buses/N/current_affects_outlets/
List of outlets affected by overcurrent
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This array represents a value in persistent storage.

This array represents an unordered set (order of its elements doesn't matter, and each value should not be supplied more than once).

This array contains Outlet list index elements.

Sample read command (note that :bus is a URL template argument and needs to be replaced before trying):

Sample write command (note that :bus is a URL template argument and needs to be replaced before trying):

Sample outlet list index creation command (note that :bus is a URL template argument and needs to be replaced before trying):

2.24.1 Outlet list index

```
number relay/buses/N/current_affects_outlets/N/
Index of outlet in the bus outlet list
```

The value is subject to the following constraints: all of the following is true:

- · outlet list[the value]
- · current-affected outlets are distinct

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

Sample read command (note that :bus and :outlet_list_index are URL template arguments and need to be replaced before trying):

Sample write command (note that :bus and :outlet_list_index are URL template arguments and need to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "2" "https://192.168.0.100/restapi/relay/ \leftrightarrow buses/:bus/current_affects_outlets/:outlet_list_index/"
```

Sample deletion command (note that :bus and :outlet_list_index are URL template arguments and need to be replaced before trying):

2.25 Bus: Maximum current, if any

sum (optional number)	relay/buses/N/max_current/
The maximum current, above which the affected bus outlets are switched off, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	No maximum current	Overcurrent doesn't affect any outlets	
number	Maximum current	The maximum current, above which the affected bus outlets are switched off	

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/relay/buses/:bus/max_current/"
```

2.26 Pins 27

```
⇒ (possible variant)
```

Sample (possible variant) write command (note that :bus is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow : application/json" --data-binary "null" "https://192.168.0.100/restapi/ \hookrightarrow relay/buses/:bus/max_current/"
```

2.25.1 Maximum current

(possibly) number	relay/buses/N/max_current/
The maximum current, above which the affected bus outlets are switched off	


The value is subject to the following constraints: the value is greater or equal to 0

Sample write command (note that :bus is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "3" "https://192.168.0.100/restapi/relay/ \leftrightarrow buses/:bus/max_current/"
```

2.26 Pins

map	relay/pins/	
GPIO	GPIO pins attached to the relay	



This map does not support direct modification if agent identifier is not equal to relay.

This map contains GPIO pin elements.

Sample read command:

Sample write command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/relay/pins/"
```

Sample gpio pin creation command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"mode_driver\":true,\"name\":\"Sample value of gpio pin pins_5 \( \to \)
\( \to \) of name\",\"mode_driver_locked\":true,\"level_driver\":\"Sample value of \( \to \)
\( \to \) gpio pin pins_5 of level driver\",\"level_driver_locked\":true}\"\
"https://192.168.0.100/restapi/relay/pins/pins_5/"
```

2.26.1 GPIO pin

object	relay/pins/S/
Object representing state and configuration of a GPIO pin	

This object contains the following items:

name	Name
mode_driver	Mode driver
mode_driver_locked	Mode driver locked
level_driver	Level driver
level_driver_locked	Level driver locked

Sample read command (note that :gpio_pin is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/relay/pins/:gpio_pin/"
```

 \Rightarrow

```
{
"mode_driver":"Sample value of mode driver",
"name":"Sample value of name",
"mode_driver_locked":true,
"level_driver":"Sample value of level driver",
"level_driver_locked":true
}
```

Sample write command (note that :gpio_pin is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :gpio_pin is a URL template argument and needs to be replaced before trying):

See also GPIO pin: Name

See also GPIO pin: Mode driver

See also GPIO pin: Mode driver locked

See also GPIO pin: Level driver

See also GPIO pin: Level driver locked

2.27 GPIO pin: Name

string	relay/pins/S/name/
User-visible pin name	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Sample write command (note that :gpio_pin is a URL template argument and needs to be replaced before trying):

2.28 GPIO pin: Mode driver

sum (variant)	relay/pins/S/mode_driver/
Configured signal driving the pin's mode (input or output)	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can change as if by itself or indirectly because of other actions.

This sum can assume the following values:

constant true	Active	The pin is active (output)	
constant false	Tristated	The pin is inactive (input, hi-Z state	e)
string	Net name	Name of the net providing the driving value	all of the following is true: • not the value matches ^(.* .*)\$ • [invalid reference/nets][the value]
string	Invalid net placeholder	A placeholder for a net that has been deleted or renamed (and always has the logical value false)	the value matches ^net_← deleted:.*\$

Sample read command (note that :gpio_pin is a URL template argument and needs to be replaced before trying):

 \Rightarrow (possible variant)

"Sample value"

Sample (possible variant) write command (note that :gpio_pin is a URL template argument and needs to be replaced before trying):

2.28.1 Net name

```
(possibly) string relay/pins/S/mode_driver/

Name of the net providing the driving value
```

The value is subject to the following constraints: all of the following is true:

- not the value matches ^(|.*|.*)\$
- [invalid reference ../nets][the value]

Sample write command (note that :gpio_pin is a URL template argument and needs to be replaced before trying):

2.28.2 Invalid net placeholder

(possibly) string	relay/pins/S/mode_driver/
A placeholder for	a net that has been deleted or renamed (and always has the logical value false)

The value is subject to the following constraints: the value matches ^net_deleted:.*\$

Sample write command (note that :gpio_pin is a URL template argument and needs to be replaced before trying):

2.29 GPIO pin: Mode driver locked

sum (boolean)	relay/pins/S/mode_driver_locked/	
Flag indicating if the pin's mode configuration is fixed		

Retrieving the value is denied if not administrative user

This sum does not support direct modification if agent identifier is not equal to relay.

This sum can assume the following values:

constant true	Locked	The pin's mode configuration is fixed
constant false	Variable	The pin's mode configuration can be changed

Sample read command (note that :gpio_pin is a URL template argument and needs to be replaced before trying):

⇒ (possible variant)

true

Sample (possible variant) write command (note that :gpio_pin is a URL template argument and needs to be replaced before trying):

2.30 GPIO pin: Level driver

sum (variant)	relay/pins/S/level_driver/	
Configured sig	Configured signal driving the pin's output state	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can change as if by itself or indirectly because of other actions.

This sum can assume the following values:

constant true	High	The pin is driven high if active or in enabled if tristated	its pull-up resistor is
constant false	Low	The pin is driven low if active or i disabled if tristated	ts pull-up resistor is
string	Net name	Name of the net providing the driving value	all of the following is true: • not the value matches ^(.* .*)\$ • [invalid reference/nets][the value]
string	Invalid net placeholder	A placeholder for a net that has been deleted or renamed (and always has the logical value false)	the value matches ^net_← deleted:.*\$

Sample read command (note that :gpio_pin is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftrightarrow restapi/relay/pins/:gpio_pin/level_driver/"
```

 \Rightarrow (possible variant)

"Sample value"

Sample (possible variant) write command (note that :gpio_pin is a URL template argument and needs to be replaced before trying):

2.30.1 Net name

(possibly) string	relay/pins/S/level_driver/
Name of the net providing the driving value	

The value is subject to the following constraints: all of the following is true:

- not the value matches $^{\wedge}(|.*|.*)$ \$
- [invalid reference ../nets][the value]

Sample write command (note that :gpio_pin is a URL template argument and needs to be replaced before trying):

2.30.2 Invalid net placeholder

(possibly) string	relay/pins/S/level_driver/
A placeholder for a net that has been deleted or renamed (and always has the logical value false)	

The value is subject to the following constraints: the value matches ^net_deleted:.*\$

Sample write command (note that :gpio_pin is a URL template argument and needs to be replaced before trying):

2.31 GPIO pin: Level driver locked

```
sum (boolean) relay/pins/S/level_driver_locked/
Flag indicating if the pin's output configuration is fixed
```

Retrieving the value is denied if not administrative user

This sum does not support direct modification if agent identifier is not equal to relay.

This sum can assume the following values:

constant true	Locked	The pin's output configuration is fixed
constant false	Variable	The pin's output configuration can be changed


 \Rightarrow (possible variant)

false

Sample (possible variant) write command (note that :gpio_pin is a URL template argument and needs to be replaced before trying):

2.32 Nets

```
map relay/nets/
Nets controlling the GPIO pins
```



This map represents a value in persistent storage.

This map contains Net elements.

Sample read command:

2.32 Nets 35

```
},
 "nets_2":{
 "value":true,
 "tracking":null,
 "name": "Sample value of net nets_2 of name",
 "expression": "Sample value of net nets_2 of expression, if any"
 },
 "nets_4":{
 "value":false,
 "tracking": "Sample value of net nets_4 of tracking",
 "name": "Sample value of net nets_4 of name",
 "expression": "Sample value of net nets_4 of expression, if any"
 },
 "nets_3":{
 "value":true,
 "tracking": "Sample value of net nets_3 of tracking",
 "name": "Sample value of net nets_3 of name",
 "expression":null
 },
 "nets_1":{
 "value":false,
 "tracking": "Sample value of net nets_1 of tracking",
 "name": "Sample value of net nets_1 of name",
 "expression":null
}
Sample write command:
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
"https://192.168.0.100/restapi/relay/nets/"
Sample net creation command:
cur1\
--digest\
-u admin:1234\
-X PUT\
```

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"value\":true,\"tracking\":\"Sample value of net nets_2 of \( \to \)
\to tracking\",\"name\":\"Sample value of net nets_2 of name\",\"expression \( \to \)
\to \":\"Sample value of net nets_2 of expression, if any\"}"\
"https://192.168.0.100/restapi/relay/nets/nets_2/"
```

2.32.1 Net

object	relay/nets/S/	
Object	Object representing a state of a signal	

This object contains the following items:

name	Name
expression	Expression, if any
tracking	Tracking
value	Value

Sample read command (note that :net is a URL template argument and needs to be replaced before trying):

Sample write command (note that :net is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"value\":false,\"tracking\":\"Sample value of tracking\",\"name \( \to \) \":\"Sample value of name\",\"expression\":\"Sample value of expression, if \( \to \) any\"}"\
"https://192.168.0.100/restapi/relay/nets/:net/"
```

Sample deletion command (note that :net is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X DELETE -H "Accept: application/json" "https \leftrightarrow ://192.168.0.100/restapi/relay/nets/:net/"
```

See also Net: Name

See also Net: Expression, if any

See also Net: Tracking

See also Net: Value

2.33 Net: Name

string	relay/nets/S/name/	
User-vi	User-visible net name	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Sample read command (note that :net is a URL template argument and needs to be replaced before trying):

Sample write command (note that :net is a URL template argument and needs to be replaced before trying):

2.34 Net: Expression, if any

sum (optional string)	relay/nets/S/expression/	
Expression governing the net's value, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Variable	The net value can be modified arbitrarily
string	Expression	Expression governing the net's value

Sample read command (note that :net is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :net is a URL template argument and needs to be replaced before trying):

2.34.1 Expression

(possibly) string	ly) string relay/nets/S/expression/		
Expression gover	Expression governing the net's value		

Sample write command (note that :net is a URL template argument and needs to be replaced before trying):

2.35 Net: Tracking

sum (optional enumerated string)	relay/nets/S/tracking/
Method of reporting the net's value	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	None	Net value is not updated	
constant "pull"	Pull	Net value is updated periodically	
constant "push"	Push	Net value is reported when changed	

Sample read command (note that :net is a URL template argument and needs to be replaced before trying):

"Sample value"

Sample (possible variant) write command (note that :net is a URL template argument and needs to be replaced before trying):

2.36 Net: Value

sum (boolean)	relay/nets/S/value/
Current net value	

Retrieving the value is denied if any of the following is true:

- not administrative user
- all of the following is true:
 - expression, if any

not tracking

Changing the value is denied if not administrative user

Using the sum as a field for indexing into the grandparent collection is denied

This sum does not support direct modification if all of the following is true:

- · expression, if any
- · agent identifier is not equal to relay

This sum can assume the following values:

constant true	High	The net value is high	
constant false	Low	The net value is low	

Sample read command (note that :net is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :net is a URL template argument and needs to be replaced before trying):

2.37 Enable measurement-driven outlet control

sum (boolean) relay/fuses_enabled/

Allow use of measurement results to conditionally switch off outlets, enabling safety shutdown and correct power loss operation

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum is expected to be visible to advanced users only.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command:

Sample (possible variant) write command:

2.38 Minimum relay voltage, if any

sum (optional number)	relay/min_relay_voltage/		
Minimum relay voltage below which it cannot drive outlets and they must be considered off, if any			

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum is expected to be visible to advanced users only.

This sum can assume the following values:

constant null	Disable relay undervoltage handling	Ignore relay undervoltage. This is unsafe!	
number	Minimum relay voltage	Minimum relay voltage below which it cannot drive outlets and they must be considered off	the value is greater than 0

Sample read command:

Sample (possible variant) write command:

2.38.1 Minimum relay voltage

```
(possibly) number relay/min_relay_voltage/

Minimum relay voltage below which it cannot drive outlets and they must be considered off
```

The value is subject to the following constraints: the value is greater than 0

Sample write command:

2.39 Measurement-driven relatch timeout, if any

sum (optional number)	relay/fuse_relatch/	
Time to hold outlets off after switching them off due to measurement limits being hit, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Latch OFF	Switch outlets off until the user takes action	
number	Measurement-driven relatch timeout	Time to hold outlets off after switching them off due to	the value is greater than 0
		measurement limits being hit	

Sample read command:

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "null" "https://192.168.0.100/restapi/ \leftrightarrow relay/fuse_relatch/"
```

2.39.1 Measurement-driven relatch timeout

```
(possibly) number relay/fuse_relatch/

Time to hold outlets off after switching them off due to measurement limits being hit
```

The value is subject to the following constraints: the value is greater than 0

Sample write command:

2.40 Keypad state

sum (boolean)	relay/keypad_enabled/	
Flag indicating whether keypad is enabled or disabled		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command:

Sample (possible variant) write command:

2.41 LCD all-caps filter

```
sum (boolean) relay/all_caps/
Flag enabling all-caps display of text
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	All CAPS	All LCD strings are displayed in capital letters
constant false	Standard mode	LCD strings are displayed as configured without capi-
		talization

Sample read command:

Sample (possible variant) write command:

2.42 Beep sequence

```
string relay/beep_sequence/
Signal sequence for beeper activation
```

The value is subject to the following constraints: the value matches ^[01. _-]*\$

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

Sample read command:

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "\"Sample value\"" "https \leftrightarrow ://192.168.0.100/restapi/relay/beep_sequence/"
```

2.43 Backlight sequence

```
string relay/backlight_sequence/
Signal sequence for backlight blinking
```

The value is subject to the following constraints: the value matches ^[01. _-]*\$

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

Sample read command:

Sample write command:

2.44 LCD column count

```
number relay/lcd_columns/
Number of LCD columns
```

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- the value is greater or equal to 0

This number does not support direct modification.

This number represents a value in persistent storage.

Sample read command:

2.45 LCD row count

```
number relay/lcd_rows/
Number of LCD rows
```

The value is subject to the following constraints: all of the following is true:

2.46 User LCD lines 45

- · the value is an integer
- the value is greater or equal to 0

This number does not support direct modification.

This number represents a value in persistent storage.

Sample read command:

2.46 User LCD lines

```
array relay/user_lines/
Array of strings to override LCD lines with, from top to bottom
```

The value is subject to the following constraints: length of the value is equal to lcd row count

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This array contains User LCD line, if any elements.

Sample read command:

Sample write command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/relay/user_lines/"
```

Sample user lcd line, if any creation command:

See also User LCD lines: User LCD line, if any

2.47 User LCD lines: User LCD line, if any

sum (optional string)	relay/user_lines/N/
The line to override th	e corresponding line of the LCD output with, if any

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum can assume the following values:

constant null	No user LCD line	Do not override the corresponding line of the ordinary LCD output
string	User LCD line	The line to override the corresponding line of the LCD output with

Sample read command (note that :user_lcd_line__if_any is a URL template argument and needs to be replaced before trying):

 \Rightarrow (possible variant)

Sample (possible variant) write command (note that :user_lcd_line__if_any is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :user_lcd_line__if_any is a URL template argument and needs to be replaced before trying):

2.47.1 User LCD line

```
(possibly) string relay/user_lines/N/
The line to override the corresponding line of the LCD output with
```

Sample write command (note that :user_lcd_line__if_any is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :user_lcd_line__if_any is a URL template argument and needs to be replaced before trying):

[&]quot;Sample value"

2.48 User message force display timeout, if any

sum (optional number)	relay/user_message_force_timeout/
Time during which the user script LCD message always overrides ordinary LCD output, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

С	onstant null	Always force user message	The user message always overrides ordinary LCD output	
n	umber	User message force display timeout	Time during which the user script LCD message always overrides ordinary LCD output	the value is greater or equal to 0

Sample read command:

Sample (possible variant) write command:

2.48.1 User message force display timeout

```
(possibly) number relay/user_message_force_timeout/
Time during which the user script LCD message always overrides ordinary LCD output
```

The value is subject to the following constraints: the value is greater or equal to 0

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept ↔ : application/json" --data-binary "5" "https://192.168.0.100/restapi/relay/ ↔ user_message_force_timeout/"
```

2.49 User message display timeout, if any

sum (optional number)	relay/user_message_timeout/
Time after which the use	er script LCD message is replaced by ordinary LCD output even if nothing else happens,
if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Show user message indefi- nitely	The user message stays on LCD until ordinary LCD output changes	
number	User message display time- out	Time after which the user script LCD message is replaced by ordinary LCD output even if nothing else happens	

Sample read command:

Sample (possible variant) write command:

2.49.1 User message display timeout

```
(possibly) number relay/user_message_timeout/

Time after which the user script LCD message is replaced by ordinary LCD output even if nothing else happens
```

The value is subject to the following constraints: the value is greater or equal to 0


Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "2" "https://192.168.0.100/restapi/relay/ \leftrightarrow user_message_timeout/"
```

2.50 Notifications

2.50 Notifications 49

```
object relay/notifications/
Relay-state-related notifications
```



This object does not support direct modification.


This object contains the following items:

events	Events	
parameter_kinds	Parameter kinds	

Sample read command:

2.50.1 Events

map	relay/notifications/events/	
Event	Event templates	



This map does not support direct modification.

This map contains **Event** elements.

Sample read command:

Creating elements in this collection is not supported.

See also Events: Event

See also Notifications: Parameter kinds

2.51 Message template: Message template element

sum (variant)	relay/notifications/events/S/message_template/N/	
Element of hur	Element of human-readable message template	

This sum does not support direct modification.

This sum can assume the following values:

string	String	Fixed string	
number	Parameter	Index of message parameter to insert	event parameters[the value]

Sample read command (note that :event and :message_template_element are URL template arguments and need to be replaced before trying):

2.51.1 String

(possibly) string	sibly) string relay/notifications/events/S/message_template/N/	
Fixed string		

2.51.2 Parameter

(possibly) number	relay/notifications/events/S/message_template/N/
Index of message parameter to insert	

The value is subject to the following constraints: event parameters[the value]

2.52 Event parameter: Fixed value

s	um (variant)	relay/notifications/events/S/parameters/N/fixed_value/
Fixed parameter value for this particular event		

This sum does not support direct modification.

This sum can assume the following values:

constant null	Null	Null
constant true	True	True
constant false	False	False
string	String	This string
number	Number	This number

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

2.52.1 String

(possibly) string	relay/notifications/events/S/parameters/N/fixed_value/
This string	

2.52.2 Number

(possibly) number	relay/notifications/events/S/parameters/N/fixed_value/
This number	

2.53 Event parameter: Fixed value flag

sum (boolean)	relay/notifications/events/S/parameters/N/has_fixed_value/
Flag indicating that the parameter's value for this event is fixed	

This sum does not support direct modification.

This sum can assume the following values:

constant true	Fixed	The value is fixed
constant false	Variable	The value is variable

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

2.54 Event parameter: Identifier

string	relay/notifications/events/S/parameters/N/id/
Parameter identifier	

The value is subject to the following constraints: parameter kinds


This string does not support direct modification.

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

2.55 Events: Event 53

2.55 Events: Event

object	relay/notifications/events/S/
Event template	



This object contains the following items:

message_template	Message template
parameters	Event parameters
severity	Severity

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←
   → restapi/relay/notifications/events/:event/"
\Rightarrow
"severity":2,
"message_template":[
 "Sample value of message template of message template element #1",
 10,
 5
],
"parameters":[
  "fixed_value":10,
  "has_fixed_value":false,
  "id": "Sample value of event parameters of event parameter #1 of identifier"
  "fixed_value":8,
  "has_fixed_value":true,
  "id": "Sample value of event parameters of event parameter #2 of identifier"
 },
```

```
"fixed_value":false,
   "has_fixed_value":true,
   "id":"Sample value of event parameters of event parameter #3 of identifier"
},
{
   "fixed_value":false,
   "has_fixed_value":false,
   "id":"Sample value of event parameters of event parameter #4 of identifier"
},
{
   "fixed_value":false,
   "has_fixed_value":false,
   "has_fixed_value":false,
   "id":"Sample value of event parameters of event parameter #5 of identifier"
}
```

Sample write command (note that :event is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/relay/notifications/events/:event/"
```

2.55.1 Message template

```
array relay/notifications/events/S/message_template/
Template for human-readable message generation
```

This array does not support direct modification.

This array contains Message template element elements.

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

Creating elements in this collection is not supported.


See also Message template: Message template element

2.55.2 Event parameters

2.55 Events: Event 55

array relay/notifications/events/S/parameters/

Additional data associated with the event



This array does not support direct modification.

This array contains **Event parameter** elements.

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←

→ restapi/relay/notifications/events/:event/parameters/"

\Rightarrow
[
 "fixed_value":null,
 "has_fixed_value":false,
 "id": "Sample value of event parameter #1 of identifier"
},
 "fixed_value":false,
 "has_fixed_value":false,
 "id": "Sample value of event parameter #2 of identifier"
},
 "fixed_value":false,
 "has_fixed_value":true,
 "id": "Sample value of event parameter #3 of identifier"
},
 "fixed_value":false,
 "has_fixed_value":false,
 "id": "Sample value of event parameter #4 of identifier"
},
 "fixed_value":null,
 "has_fixed_value":true,
 "id": "Sample value of event parameter #5 of identifier"
]
```

Creating elements in this collection is not supported.

2.55.2.1 Event parameter

2.55 Events: Event 57

object	relay/notifications/events/S/parameters/N/	
Propert	Properties of a parameter associated with the event	

This object contains the following items:

fixed_value	Fixed value
has_fixed_value	Fixed value flag
id	Identifier

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

Sample write command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"fixed_value\":false,\"has_fixed_value\":true,\"id\":\"Sample \( \to \)
\to value of identifier\"}"\
"https://192.168.0.100/restapi/relay/notifications/events/:event/parameters/: \( \to \)
\to event_parameter/"
```

See also Event parameter: Fixed value

See also Event parameter: Fixed value flag

See also Event parameter: Identifier

2.55.3 Severity

sum (enumerated number)	relay/notifications/events/S/severity/
Severity rating assigned to the event	

This sum does not support direct modification.

This sum can assume the following values:

constant 1	Emergency	Treat the event as an emergency
constant 2	Alert	Treat the event as an alert
constant 3	Critical	Treat the event as critical
constant 4	Error	Treat the event as an error
constant 5	Warning	Treat the event as a warning
constant 6	Notice	Treat the event as a notice
constant 7	Informational	Treat the event as informational
constant 8	Debug	Treat the event as debugging-related

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftrightarrow restapi/relay/notifications/events/:event/severity/"
```

 \Rightarrow (possible variant)

6

2.56 Notifications: Parameter kinds

object	ct relay/notifications/parameter_kinds/			
Kinds o	Kinds of event parameters			

This object does not correspond to an actual resource.

This object contains the following items:

locked	Lock state
outlet	Outlet
physical_state	Physical state
state	Configured state
transient_state	Transient state

2.56.1 Lock state

sum (boolean)	relay/notifications/parameter_kinds/locked/
Indicates whether the outlet state is locked from keypad	

This sum can assume the following values:

constant true	Locked	The outlet state cannot be changed
constant false	Unlocked	The outlet state can be changed

Sample read command:

```
\Rightarrow (possible variant)
```

t rue

Sample (possible variant) write command:

2.56.2 Outlet

```
        number
        relay/notifications/parameter_kinds/outlet/

        Outlet index
```

The value is subject to the following constraints: outlets[the value]

Sample read command:

Sample write command:

2.56.3 Physical state

sum (boolean)	relay/notifications/parameter_kinds/physical_state/
Current actual state of the outlet	

This sum can assume the following values:

constant true	On	The outlet is powered
constant false	Off	The outlet is not powered

Sample read command:

Sample (possible variant) write command:

2.56.4 Configured state

```
sum (boolean) relay/notifications/parameter_kinds/state/
Saved configured state of the outlet
```

This sum can assume the following values:

constant true	On	The outlet is powered
constant false	Off	The outlet is not powered

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/relay/notifications/parameter_kinds/state/"
```

\Rightarrow (possible variant)

false

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "true" "https://192.168.0.100/restapi/ \hookleftarrow: relay/notifications/parameter_kinds/state/"
```

2.56.5 Transient state

sum (boolean) relay/notifications/parameter_kinds/transient_state/	
Current expecte	ed state of the outlet

This sum can assume the following values:

constant true	On	The outlet is powered
constant false	Off	The outlet is not powered

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/relay/notifications/parameter_kinds/transient_state/"
```


\Rightarrow (possible variant)

false

Sample (possible variant) write command:

3 Authentication server object

object	auth/		
Object	Object representing the authentication server configuration		



This object contains the following items:

users	Users list
cookie_timeout	Cookie timeout
notifications	Notifications


Sample read command:

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "..." "https://192.168.0.100/restapi/auth \leftrightarrow \leftrightarrow /"
```

3.1 Users list

array	auth/users/	
List of	List of user accounts	



Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This array represents a value in persistent storage.

This array represents an unordered set (order of its elements doesn't matter, and each value should not be supplied more than once).

This array contains User account elements.

Sample read command:

3.1 Users list 63


Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "..." "https://192.168.0.100/restapi/auth \leftrightarrow /users/"
```

Sample user account creation command:

3.1.1 User account

object	auth/users/N/	
User ac	User account configuration	



Removing the object from its parent collection is denied if administrative user

This object contains the following items:

name	Username
password	Password
is_allowed	User allowed
is_admin	Administrative user
outlet_access	Outlet access levels

Sample read command (note that :user_account is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←
   → restapi/auth/users/:user_account/"
\Rightarrow
{
 "password": "Sample value of password",
"is_admin":false,
 "name": "Sample value of username",
 "is_allowed":true,
 "outlet_access":[
 false,
 true,
 true,
 true,
 true,
 true
 1
```

Sample write command (note that :user_account is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :user_account is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X DELETE -H "Accept: application/json" "https \leftrightarrow ://192.168.0.100/restapi/auth/users/:user_account/"
```

See also User account: Username

See also User account: Password

See also User account: User allowed

See also User account: Administrative user

See also User account: Outlet access levels

3.2 User account: Username

string	auth/users/N/name/
Username	

The value is subject to the following constraints: all of the following is true:

- the value matches ^[a-zA-Z0-9]*\$
- · name members of all values of users list are distinct

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Write operations must supply the current value of password if administrative user

Sample read command (note that :user_account is a URL template argument and needs to be replaced before trying):

Sample write command (note that :user_account is a URL template argument and needs to be replaced before trying):

3.3 User account: Password

```
string auth/users/N/password/
Password
```

The value is subject to the following constraints: the value matches $[-\sim]$ *\$

Retrieving the value is denied if any of the following is true:

- · not administrative user
- administrative user
- hide user passwords

Using the string as a field for indexing into the grandparent collection is denied

This string represents a value in persistent storage.

This string should be displayed in a secure manner.

Write operations must supply the current value of the value if administrative user

Sample read command (note that :user_account is a URL template argument and needs to be replaced before trying):

Sample write command (note that :user_account is a URL template argument and needs to be replaced before trying):

3.4 User account: User allowed

sum (boolean)	auth/users/N/is_allowed/
Flag indicating whether user is allowed or denied	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum does not support direct modification if administrative user.

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Allowed	The user is allowed to log in
constant false	Denied	The user is denied login

Sample read command (note that :user_account is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :user_account is a URL template argument and needs to be replaced before trying):

3.5 User account: Administrative user

sum (boolean)	auth/users/N/is_admin/		
Flag indicating whether the user is an administrator			

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum does not support direct modification.

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Administrator	The user is an administrator
constant false	Regular user	The user is a regular user

Sample read command (note that :user_account is a URL template argument and needs to be replaced before trying):

3.6 User account: Outlet access levels

```
array auth/users/N/outlet_access/
Access levels per outlet
```

The value is subject to the following constraints: length of the value is equal to length of outlets

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This array does not support direct modification if administrative user.

This array represents a value in persistent storage.

This array contains Outlet access elements.

Sample read command (note that :user_account is a URL template argument and needs to be replaced before trying):

Sample write command (note that :user_account is a URL template argument and needs to be replaced before trying):

Sample outlet access creation command (note that :user_account is a URL template argument and needs to be replaced before trying):

3.6.1 Outlet access

sum (boolean)	auth/users/N/outlet_access/N/
Access level for outlet by index	

The value is subject to the following constraints: outlets[index of the value]

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum does not support direct modification if administrative user.

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Full	Outlet state can be manipulated by the user
constant false	None	Outlet state cannot be neither seen nor manipulated by the user

Sample read command (note that :user_account and :outlet_access are URL template arguments and need to be replaced before trying):

Sample (possible variant) write command (note that :user_account and :outlet_access are URL template arguments and need to be replaced before trying):

Sample deletion command (note that :user_account and :outlet_access are URL template arguments and need to be replaced before trying):

3.8 Notifications 69

3.7 Cookie timeout

```
number | auth/cookie_timeout/
The amount of time for which a cookie is valid
```

The value is subject to the following constraints: the value is greater than 0

This number represents a value in persistent storage.


Sample read command:

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow: application/json" --data-binary "5" "https://192.168.0.100/restapi/auth/ \leftrightarrow: cookie_timeout/"
```

3.8 Notifications

```
object auth/notifications/
Authentication-related notifications
```



This object does not support direct modification.


This object contains the following items:

events	Events
parameter_kinds	Parameter kinds

Sample read command:

3.8.1 **Events**

map	auth/notifications/events/	
Event	Event templates	



This map does not support direct modification.

This map contains **Event** elements.

Sample read command:

Creating elements in this collection is not supported.

See also Events: Event

See also Notifications: Parameter kinds

3.9 Message template: Message template element

sum (variant)	auth/notifications/events/S/message_template/N/	
Element of hur	Element of human-readable message template	

This sum does not support direct modification.

This sum can assume the following values:

string	String	Fixed string	
number Parameter Index of message parameter to insert even		event parameters[the value]	

Sample read command (note that :event and :message_template_element are URL template arguments and need to be replaced before trying):

3.9.1 String

(possibly) string	auth/notifications/events/S/message_template/N/	
Fixed string		

3.9.2 Parameter

(possibly) number	auth/notifications/events/S/message_template/N/		
Index of message p	Index of message parameter to insert		

The value is subject to the following constraints: event parameters[the value]

3.10 Event parameter: Fixed value

sum (variant)	auth/notifications/events/S/parameters/N/fixed_value/	
Fixed paramete	Fixed parameter value for this particular event	

This sum does not support direct modification.

This sum can assume the following values:

constant null	Null	Null
constant true	True	True
constant false	False	False
string	String	This string
number	Number	This number

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

3.10.1 String

(possibly) string auth/notifications/events/S/parameters/N/fixed_value/	
This string	

3.10.2 Number

(possibly) number	auth/notifications/events/S/parameters/N/fixed_value/
This number	

3.11 Event parameter: Fixed value flag

sum (boolean)	auth/notifications/events/S/parameters/N/has_fixed_value/
Flag indicating that the parameter's value for this event is fixed	

This sum does not support direct modification.

This sum can assume the following values:

constant true	Fixed	The value is fixed
constant false	Variable	The value is variable

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

3.12 Event parameter: Identifier

```
string auth/notifications/events/S/parameters/N/id/
Parameter identifier
```

The value is subject to the following constraints: parameter kinds


This string does not support direct modification.

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

3.13 Events: Event

```
object auth/notifications/events/S/

Event template
```



This object contains the following items:

message_template	Message template
parameters	Event parameters
severity	Severity

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

Sample write command (note that :event is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/auth/notifications/events/:event/"
```

3.13.1 Message template

3.13 Events: Event 75

array auth/notifications/events/S/message_template/

Template for human-readable message generation

This array does not support direct modification.

This array contains Message template element elements.


Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

Creating elements in this collection is not supported.

See also Message template: Message template element

3.13.2 Event parameters

array auth/notifications/events/S/parameters/
Additional data associated with the event



This array does not support direct modification.

This array contains **Event parameter** elements.

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

Creating elements in this collection is not supported.

3.13.2.1 Event parameter

object	auth/notifications/events/S/parameters/N/	
Propert	Properties of a parameter associated with the event	

This object contains the following items:

fixed_value	Fixed value
has_fixed_value	Fixed value flag
id	Identifier

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

Sample write command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"fixed_value\":false,\"has_fixed_value\":false,\"id\":\"Sample \( \to \)
\to value of identifier\"}"\
"https://192.168.0.100/restapi/auth/notifications/events/:event/parameters/: \( \to \)
\to event_parameter/"
```

See also Event parameter: Fixed value

See also Event parameter: Fixed value flag

See also Event parameter: Identifier

3.13.3 Severity

sum (enumerated number) auth/notifications/events/S/severity/		
Severity rating assigned to the event		

This sum does not support direct modification.

This sum can assume the following values:

constant 1	Emergency	Treat the event as an emergency
constant 2	Alert	Treat the event as an alert
constant 3	Critical	Treat the event as critical
constant 4	Error	Treat the event as an error
constant 5	Warning	Treat the event as a warning
constant 6	Notice	Treat the event as a notice
constant 7	Informational	Treat the event as informational
constant 8	Debug	Treat the event as debugging-related

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

 $\Rightarrow \text{(possible variant)}$

5

3.14 Notifications: Parameter kinds

object	auth/notifications/parameter_kinds/		
Kinds o	Kinds of event parameters		

This object does not correspond to an actual resource.

This object contains the following items:

auth_allowed	Authentication allowed
auth_ip	IP address
auth_login	Username
auth_method	Method
auth_reason	Reason
user_state	User state

3.14.1 Authentication allowed

sum (boolean)	auth/notifications/parameter_kinds/auth_allowed/		
Authentication decision result			

This sum can assume the following values:

constant true	Allowed	The user is allowed to log in
constant false	Denied	The user is denied to log in

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/auth/notifications/parameter_kinds/auth_allowed/"
```

\Rightarrow (possible variant)

false

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "true" "https://192.168.0.100/restapi/ \hookrightarrow auth/notifications/parameter_kinds/auth_allowed/"
```

3.14.2 IP address

string	auth/notifications/parameter_kinds/auth_ip/	
The IP	The IP address of the user	

Sample read command:

Sample write command:

3.14.3 Username

```
string | auth/notifications/parameter_kinds/auth_login/
The name of the user
```

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/auth/notifications/parameter_kinds/auth_login/"
```

```
⇒
"Sample value"
```

Sample write command:

3.14.4 Method

```
string auth/notifications/parameter_kinds/auth_method/
The authentication method
```

Sample read command:

Sample write command:

3.14.5 Reason

```
string auth/notifications/parameter_kinds/auth_reason/
The reason for authentication decision
```

Sample read command:

Sample write command:

3.14.6 User state

sum (variant)	auth/notifications/parameter_kinds/user_state/	
The state of the user		

This sum can assume the following values:

constant true	Existing	The user exists
constant false	Deleted	The user has been deleted
constant "new"	New	The user has been created

Sample read command:

 $\Rightarrow \text{(possible variant)}$

true

Sample (possible variant) write command:

4 Configuration server object

```
object | config/
Object representing configuration server
```



This object contains the following items:

	Г
links	Links list
plots	Plots list
meters	Meters list
contact	Primary unit contact
contacts	Related contacts
location	Unit location
oid	Model OID
version	Version number
hardware_id	Hardware ID
serial	Serial number
outlet_label	Outlet label
brand_company_name	Brand company name
brand_name	Brand name
brand_url	Brand URL
brand_manual_url	Brand manual URL
brand_faq_url	Brand FAQ URL
brand_product_info_url	Brand product information URL
support_email	Support email
register_url	Registration URL
support_url	Support URL
update_url	Update URL
custom_brand_company_name	Custom brand company name, if any
custom_brand_name	Custom brand name, if any

	0 1 1 110 1
custom_brand_url	Custom brand URL, if any
custom_brand_logo	Custom brand logo URL, if any
custom_brand_logo_width	Custom brand logo width, if any
custom_brand_logo_height	Custom brand logo height, if any
custom_support_email	Custom support email, if any
custom_register_url	Custom registration URL, if any
custom_support_url	Custom support URL, if any
custom_update_url	Custom update URL, if any
custom_help_url	Custom help URL, if any
registration_status	Registration status
refresh_enabled	Enable page refresh
refresh_delay_minutes	Page refresh delay
image_format	Preferred image format
hostname	Unit hostname
timezone	Time zone
http_ports	HTTP ports
https_ports	HTTPS ports
https_cert	HTTPS certificate settings
ssh_enabled	SSH enabled
ssh_port	SSH port number
ssh_authorized_keys	SSH authorized keys
ntp_server_enabled	NTP server enabled
ntp_peers	NTP peers
syslog_minimal_severity	Syslog threshold severity
syslog_ip_address	Syslog server address, if any
allow_jsonrpc	Allow JSONRPC
allow_restapi	Allow REST-like API
allow_restapi_origins	Allowed REST-like API client origins
relax_nonhtml_methods	Relax non-HTML method CSRF checks
relax_nonhtml_content_types	Relax non-HTML content type CSRF checks
allow_plaintext_logins	Allow plaintext logins
name_always_visible	Relay name visibility
hide_passwords	Hide user passwords
hide_wifi_key	Hide WiFi key
lockout_delay_minutes	Security lockout duration
protect_firmware	Protect firmware
protect_admin	Protect admin login
protect_network	Protect network settings
protect_private_config	Protect private settings
protect_restore	Protect from restore
protect_maintenance	Protect from maintenance
protect_notification	Protect notification settings
upgrade_notify_beep	Beep on upgrade
upgrade_notify_blink	Blink on upgrade
known_quantities	Known quantities
known_quantities	Known timezones
known_protection_bits	Known protection bits
relay_ports	Relay ports


4.1 Links list

Sample read command:

Sample write command:

4.1 Links list

```
array config/links/
List of user-defined links to display in the web UI
```



Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This array represents a value in persistent storage.

This array contains Link elements.

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftrightarrow restapi/config/links/"
```

 \Rightarrow

```
"href": "Sample value of link #1 of uri",
 "description": "Sample value of link #1 of description"
 "href": "Sample value of link #2 of uri",
 "description": "Sample value of link #2 of description"
},
 "href": "Sample value of link #3 of uri",
 "description": "Sample value of link #3 of description"
},
 "href": "Sample value of link #4 of uri",
 "description": "Sample value of link #4 of description"
},
 "href": "Sample value of link #5 of uri",
 "description": "Sample value of link #5 of description"
},
 "href": "Sample value of link #6 of uri",
 "description": "Sample value of link #6 of description"
]
```

Sample write command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/config/links/"
```

Sample link creation command:

See also Links list: Link

4.2 Links list: Link

object	config/links/N/
User-defined link	

Retrieving the value is denied if not administrative user

This object represents a value in persistent storage.

This object contains the following items:

4.2 Links list: Link 85

href	URI
description	Description

Sample read command (note that :link is a URL template argument and needs to be replaced before trying):

Sample write command (note that :link is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :link is a URL template argument and needs to be replaced before trying):

4.2.1 URI

```
string config/links/N/href/
The target URI of the link
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Sample read command (note that :link is a URL template argument and needs to be replaced before trying):

Sample write command (note that :link is a URL template argument and needs to be replaced before trying):

4.2.2 Description

string config/links/N/description/
The textual representation of the link

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.


Sample read command (note that :link is a URL template argument and needs to be replaced before trying):

Sample write command (note that :link is a URL template argument and needs to be replaced before trying):

4.3 Plots list

```
array config/plots/
List of plots to display in the web UI
```

4.3 Plots list 87



Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This array represents a value in persistent storage.

This array contains Plot elements.

Sample read command:

Sample write command:


```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "..." "https://192.168.0.100/restapi/ \hookleftarrow \hookrightarrow config/plots/"
```

Sample plot creation command:

4.3.1 Plot

object config/plots/N/

Configuration of plot for measured values



This object contains the following items:

title	Title
display	Display
width	Width
height	Height
x1	X1 axis settings
x2	X2 axis settings
y1	Y1 axis settings
y2	Y2 axis settings
data	Plot lines

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

 \Rightarrow

. . .

4.5 Plot: Display 89

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X DELETE -H "Accept: application/json" "https \leftrightarrow ://192.168.0.100/restapi/config/plots/:plot/"
```

See also Plot: Title

See also Plot: Display

See also Plot: Width

See also Plot: Height

See also Plot: X1 axis settings

See also Plot: X2 axis settings

See also Plot: Y1 axis settings

See also Plot: Y2 axis settings

See also Plot: Plot lines

4.4 Plot: Title

```
string config/plots/N/title/
The title of the plot
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.5 Plot: Display

sum (boolean)	config/plots/N/display/
Indicates whether the plot should be displayed	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Shown	The plot is shown
constant false	Hidden	The plot is hidden

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow: application/json" --data-binary "true" "https://192.168.0.100/restapi/ \leftrightarrow config/plots/:plot/display/"
```

4.6 Plot: Width

true

number	config/plots/N/width/	
The width	The width of the plot	

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- the value is greater than 0

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/config/plots/:plot/width/"
```

⇒ 9

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.7 Plot: Height

```
number config/plots/N/height/
The height of the plot
```

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater than 0

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.8 Plot: X1 axis settings

```
object config/plots/N/x1/
Configuration for X1 axis
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This object represents a value in persistent storage.

This object contains the following items:

min	Minimum, if any
max	Maximum, if any
softmin	Soft minimum, if any
softmax	Soft maximum, if any
tics	Major tick interval, if any
mtics	Minor ticks per major tick, if any

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"softmin\":3,\"softmax\":null,\"max\":null,\"tics\":8,\"mtics\": \( \to \) null,\"min\":null}"\
"https://192.168.0.100/restapi/config/plots/:plot/x1/"
```

4.8.1 Minimum, if any

sum (optional number)	config/plots/N/x1/min/
Minimum value to display on the axis, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Automatic	The maximum value is derived from data and the soft
		maximum
number	Minimum	Minimum value to display on the axis

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.8.1.1 Minimum

(possibly) number	config/plots/N/x1/min/
Minimum value to display on the axis	

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.8.2 Maximum, if any

sum (optional number)	config/plots/N/x1/max/	
Maximum value to display on the axis, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Automatic	The minimum value is derived from data and the soft	
		minimum	
number	Maximum	Maximum value to display on the axis	

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.8.2.1 Maximum

```
(possibly) number | config/plots/N/x1/max/

Maximum value to display on the axis
```

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.8.3 Soft minimum, if any

sum (optional number)	config/plots/N/x1/softmin/	
Minimum value to display on the axis unless values exist below it, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	None	No soft maximum defined
number	Soft minimum	Minimum value to display on the axis unless values exist below it

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.8.3.1 Soft minimum

(possibly) number	config/plots/N/x1/softmin/	
Minimum value to display on the axis unless values exist below it		

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.8.4 Soft maximum, if any

sum (optional number)	nal number) config/plots/N/x1/softmax/	
Maximum value to display on the axis unless values exist above it, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	None	No soft minimum defined	
number	Soft maximum	Maximum value to display on the axis unless values	
		exist above it	

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "2" "https://192.168.0.100/restapi/config \leftrightarrow /plots/:plot/x1/softmax/"
```

4.8.4.1 Soft maximum

```
(possibly) number | config/plots/N/x1/softmax/

Maximum value to display on the axis unless values exist above it
```

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept ↔ : application/json" --data-binary "1" "https://192.168.0.100/restapi/config ↔
```

```
→ /plots/:plot/x1/softmax/"
```

4.8.5 Major tick interval, if any

sum (optional number)	config/plots/N/x1/tics/	
The interval, in value units, between major ticks of the axis, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Automatic	The tick interval is derived from data and size	
number	Major tick interval	The interval, in value units, between major ticks of the	
		axis	

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

 \Rightarrow (possible variant)

null

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "9" "https://192.168.0.100/restapi/config \leftrightarrow /plots/:plot/x1/tics/"
```

4.8.5.1 Major tick interval

```
(possibly) number config/plots/N/x1/tics/
The interval, in value units, between major ticks of the axis
```

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "2" "https://192.168.0.100/restapi/config \leftrightarrow /plots/:plot/x1/tics/"
```

4.8.6 Minor ticks per major tick, if any

sum (optional number)	config/plots/N/x1/mtics/	
The number of minor ticks between two major ticks, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	None	There are no minor ticks	
number	Minor ticks per major tick	The number of minor ticks be-	all of the following is true:
		tween two major ticks	 the value is an integer the value is greater or equal to 0

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/config/plots/:plot/x1/mtics/"
```

 \Rightarrow (possible variant)

null

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.8.6.1 Minor ticks per major tick

(possibly) number	config/plots/N/x1/mtics/	
The number of minor ticks between two major ticks		

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- the value is greater or equal to 0

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "6" "https://192.168.0.100/restapi/config \leftrightarrow /plots/:plot/x1/mtics/"
```

4.9 Plot: X2 axis settings

```
object config/plots/N/x2/
Configuration for X2 axis
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This object represents a value in persistent storage.

This object contains the following items:

min	Minimum, if any
max	Maximum, if any
softmin	Soft minimum, if any
softmax	Soft maximum, if any
tics	Major tick interval, if any
mtics	Minor ticks per major tick, if any

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.9.1 Minimum, if any

sum (optional number)	config/plots/N/x2/min/
Minimum value to display on the axis, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Automatic	The maximum value is derived from data and the soft
		maximum
number	Minimum	Minimum value to display on the axis

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.9.1.1 Minimum

(possibly) number	config/plots/N/x2/min/
Minimum value to display on the axis	

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "1" "https://192.168.0.100/restapi/config \leftrightarrow /plots/:plot/x2/min/"
```

4.9.2 Maximum, if any

sum (optional number)	config/plots/N/x2/max/
Maximum value to display on the axis, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Automatic	The minimum value is derived from data and the soft
		minimum
number	Maximum	Maximum value to display on the axis

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "null" "https://192.168.0.100/restapi/ \hookleftarrow \hookrightarrow config/plots/:plot/x2/max/"
```

4.9.2.1 Maximum

```
(possibly) number | config/plots/N/x2/max/

Maximum value to display on the axis
```

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "2" "https://192.168.0.100/restapi/config \leftrightarrow /plots/:plot/x2/max/"
```

4.9.3 Soft minimum, if any

sum (optional number)	config/plots/N/x2/softmin/
Minimum value to display on the axis unless values exist below it, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	None	No soft maximum defined
number	Soft minimum	Minimum value to display on the axis unless values exist below it

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.9.3.1 Soft minimum

(possibly) number	config/plots/N/x2/softmin/
Minimum value to display on the axis unless values exist below it	

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.9.4 Soft maximum, if any

sum (optional number)	config/plots/N/x2/softmax/
Maximum value to display on the axis unless values exist above it, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	None	No soft minimum defined
number	Soft maximum	Maximum value to display on the axis unless values exist above it

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "3" "https://192.168.0.100/restapi/config \leftrightarrow /plots/:plot/x2/softmax/"
```

4.9.4.1 Soft maximum

```
(possibly) number | config/plots/N/x2/softmax/

Maximum value to display on the axis unless values exist above it
```

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept ↔ : application/json" --data-binary "9" "https://192.168.0.100/restapi/config ↔
```

```
→ /plots/:plot/x2/softmax/"
```

4.9.5 Major tick interval, if any

sum (optional number)	config/plots/N/x2/tics/
The interval, in value units, between major ticks of the axis, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Automatic	The tick interval is derived from data and size
number	Major tick interval	The interval, in value units, between major ticks of the
		axis

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

 \Rightarrow (possible variant)

null

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.9.5.1 Major tick interval

```
(possibly) number config/plots/N/x2/tics/
The interval, in value units, between major ticks of the axis
```

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "9" "https://192.168.0.100/restapi/config \leftrightarrow /plots/:plot/x2/tics/"
```

4.9.6 Minor ticks per major tick, if any

sum (optional number)	config/plots/N/x2/mtics/	
The number of minor ticks between two major ticks, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	None	There are no minor ticks	
number	Minor ticks per major tick	The number of minor ticks be-	all of the following is true:
		tween two major ticks	 the value is an integer the value is greater or equal to 0

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftrightarrow restapi/config/plots/:plot/x2/mtics/"
```

 \Rightarrow (possible variant)

null

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.9.6.1 Minor ticks per major tick

(possibly) number	config/plots/N/x2/mtics/	
The number of minor ticks between two major ticks		

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- the value is greater or equal to 0

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "7" "https://192.168.0.100/restapi/config \leftrightarrow /plots/:plot/x2/mtics/"
```

4.10 Plot: Y1 axis settings

```
object config/plots/N/y1/
Configuration for Y1 axis
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This object represents a value in persistent storage.

This object contains the following items:

min	Minimum, if any	
max	Maximum, if any	
softmin	Soft minimum, if any	
softmax	Soft maximum, if any	
tics	Major tick interval, if any	
mtics	Minor ticks per major tick, if any	

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.10.1 Minimum, if any

sum (optional number)	config/plots/N/y1/min/	
Minimum value to display on the axis, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Automatic	The maximum value is derived from data and the soft
		maximum
number	Minimum	Minimum value to display on the axis

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "9" "https://192.168.0.100/restapi/config \leftarrow \leftrightarrow /plots/:plot/y1/min/"
```

4.10.1.1 Minimum

(possibly) number	config/plots/N/y1/min/		
Minimum value to display on the axis			

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.10.2 Maximum, if any

sum (optional number)	config/plots/N/y1/max/	
Maximum value to display on the axis, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

co	nstant null	Automatic	The minimum value is derived from data and the soft
			minimum
nu	mber	Maximum	Maximum value to display on the axis

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

null

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "null" "https://192.168.0.100/restapi/ \hookleftarrow \hookrightarrow config/plots/:plot/y1/max/"
```

4.10.2.1 Maximum

```
(possibly) number | config/plots/N/y1/max/

Maximum value to display on the axis
```

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "6" "https://192.168.0.100/restapi/config \leftrightarrow /plots/:plot/y1/max/"
```

4.10.3 Soft minimum, if any

sum (optional number)	config/plots/N/y1/softmin/	
Minimum value to display on the axis unless values exist below it, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	None	No soft maximum defined
number	Soft minimum	Minimum value to display on the axis unless values exist below it

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.10.3.1 Soft minimum

(possibly) number	config/plots/N/y1/softmin/
Minimum value to display on the axis unless values exist below it	

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "3" "https://192.168.0.100/restapi/config \leftrightarrow /plots/:plot/y1/softmin/"
```

4.10.4 Soft maximum, if any

sum (optional number)	config/plots/N/y1/softmax/
Maximum value to display on the axis unless values exist above it, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	None	No soft minimum defined
number	Soft maximum	Maximum value to display on the axis unless values
		exist above it

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.10.4.1 Soft maximum

```
(possibly) number | config/plots/N/y1/softmax/

Maximum value to display on the axis unless values exist above it
```

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept ↔ : application/json" --data-binary "7" "https://192.168.0.100/restapi/config ↔
```

```
→ /plots/:plot/y1/softmax/"
```

4.10.5 Major tick interval, if any

sum (optional number)	config/plots/N/y1/tics/	
The interval, in value units, between major ticks of the axis, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Automatic	The tick interval is derived from data and size
number	Major tick interval	The interval, in value units, between major ticks of the
		axis

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

 \Rightarrow (possible variant)

null

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow: application/json" --data-binary "5" "https://192.168.0.100/restapi/config \leftrightarrow /plots/:plot/y1/tics/"
```

4.10.5.1 Major tick interval

```
(possibly) number config/plots/N/y1/tics/
The interval, in value units, between major ticks of the axis
```

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "5" "https://192.168.0.100/restapi/config \leftrightarrow /plots/:plot/y1/tics/"
```

4.10.6 Minor ticks per major tick, if any

sum (optional number)	onal number) config/plots/N/y1/mtics/	
The number of minor ticks between two major ticks, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	None	There are no minor ticks	
number	Minor ticks per major tick	The number of minor ticks be-	all of the following is true:
		tween two major ticks	 the value is an integer the value is greater or equal to 0

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.10.6.1 Minor ticks per major tick

(possibly) number	config/plots/N/y1/mtics/	
The number of mine	The number of minor ticks between two major ticks	

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- the value is greater or equal to 0

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "2" "https://192.168.0.100/restapi/config \leftrightarrow /plots/:plot/y1/mtics/"
```

4.11 Plot: Y2 axis settings

```
object config/plots/N/y2/
Configuration for Y2 axis
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This object represents a value in persistent storage.

This object contains the following items:

min	Minimum, if any
max	Maximum, if any
softmin	Soft minimum, if any
softmax	Soft maximum, if any
tics	Major tick interval, if any
mtics	Minor ticks per major tick, if any
mtics	Minor ticks per major tick, if any

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"softmin\":null,\"softmax\":null,\"max\":null,\"tics\":6,\"mtics \( \to \) \":2,\"min\":null}"\
"https://192.168.0.100/restapi/config/plots/:plot/y2/"
```

4.11.1 Minimum, if any

sum (optional number)	config/plots/N/y2/min/
Minimum value to display on the axis, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Automatic	The maximum value is derived from data and the soft
		maximum
number	Minimum	Minimum value to display on the axis

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftrightarrow restapi/config/plots/:plot/y2/min/"
```

 \Rightarrow (possible variant)

null

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.11.1.1 Minimum

(possibly) number	config/plots/N/y2/min/	
Minimum value to display on the axis		

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.11.2 Maximum, if any

sum (optional number)	config/plots/N/y2/max/	
Maximum value to display on the axis, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Automatic	The minimum value is derived from data and the soft minimum	
number	Maximum	Maximum value to display on the axis	

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "null" "https://192.168.0.100/restapi/ \leftrightarrow config/plots/:plot/y2/max/"
```

4.11.2.1 Maximum

(possibly) number	config/plots/N/y2/max/
Maximum value to display on the axis	

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "1" "https://192.168.0.100/restapi/config \leftrightarrow /plots/:plot/y2/max/"
```

4.11.3 Soft minimum, if any

sum (optional number)	config/plots/N/y2/softmin/	
Minimum value to display on the axis unless values exist below it, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

null

constant null	None	No soft maximum defined	
number	Soft minimum	Minimum value to display on the axis unless values exist below it	

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.11.3.1 Soft minimum

```
(possibly) number config/plots/N/y2/softmin/
Minimum value to display on the axis unless values exist below it
```

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.11.4 Soft maximum, if any

sum (optional number)	config/plots/N/y2/softmax/		
Maximum value to display on the axis unless values exist above it, if any			

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	None	No soft minimum defined	
number	Soft maximum	Maximum value to display on the axis unless values exist above it	

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.11.4.1 Soft maximum

(possibly) number config/plots/N/y2/softmax/		
Maximum value to display on the axis unless values exist above it		

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.11.5 Major tick interval, if any

sum (optional number)	config/plots/N/y2/tics/	
The interval, in value units, between major ticks of the axis, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Automatic The tick interval is derived from data and size	
number	Major tick interval The interval, in value units, between major ticks o	
		axis

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

 \Rightarrow (possible variant)

null

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "2" "https://192.168.0.100/restapi/config \leftrightarrow /plots/:plot/y2/tics/"
```

4.11.5.1 Major tick interval

```
(possibly) number config/plots/N/y2/tics/
The interval, in value units, between major ticks of the axis
```

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.11.6 Minor ticks per major tick, if any

sum (optional number)	config/plots/N/y2/mtics/	
The number of minor ticks between two major ticks, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	None	There are no minor ticks	
number	Minor ticks per major tick	The number of minor ticks be-	all of the following is true:
		tween two major ticks	 the value is an integer the value is greater or equal to 0

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.11.6.1 Minor ticks per major tick

```
(possibly) number | config/plots/N/y2/mtics/
The number of minor ticks between two major ticks
```

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater or equal to 0

Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

4.12 Plot line configuration: Style

object	config/plots/N/data/N/style/
Style of the plot line	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This object represents a value in persistent storage.

This object contains the following items:

style	Line style
type	Line type
color	Line color
width	Line width
size	Marker size
axes	Base axes
marker	Marker type

Sample read command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

Sample write command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"type\":\"Sample value of line type\",\"style\":\"Sample value \
\to of line style\",\"marker\":\"Sample value of marker type\",\"color\":\" \
\to Sample value of line color\",\"axes\":\"Sample value of base axes\",\"size \
\to \":9,\"width\":6}"\
"https://192.168.0.100/restapi/config/plots/:plot/data/:plot_line_configuration/ \to \to style/"
```

4.12.1 Line style

```
string config/plots/N/data/N/style/style/
The style of the line
```

The value is subject to the following constraints: plot styles[the value]

This string represents a value in persistent storage.

Sample read command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

Sample write command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

4.12.2 Line type

```
string config/plots/N/data/N/style/type/
The type of the line
```

The value is subject to the following constraints: line types[the value]

This string represents a value in persistent storage.

Sample read command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

Sample write command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

4.12.3 Line color

string config/plots/N/data/N/style/color/
The color of the line

The value is subject to the following constraints: the value matches ^[0-9A-F]{6}\$

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Sample read command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

Sample write command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

4.12.4 Line width

```
number config/plots/N/data/N/style/width/
The width of the line
```

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater or equal to 0

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/config/plots/:plot/data/:plot_line_configuration/style/width/"
```

 \Rightarrow

7

Sample write command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

4.12.5 Marker size

number	config/plots/N/data/N/style/size/	
The size of the markers		

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- the value is greater or equal to 0

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

Sample write command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "5" "https://192.168.0.100/restapi/config \leftrightarrow /plots/:plot/data/:plot_line_configuration/style/size/"
```

4.12.6 Base axes

```
string config/plots/N/data/N/style/axes/

The axes on which the line should be plotted. Units of lines plotted on the same axes must match
```

The value is subject to the following constraints: axes[the value]

This string represents a value in persistent storage.

Sample read command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

Sample write command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

4.12.7 Marker type

```
string config/plots/N/data/N/style/marker/
The type of the marker
```

The value is subject to the following constraints: marker types[the value]

This string represents a value in persistent storage.


Sample read command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

Sample write command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

4.13 Plot: Plot lines

array	config/plots/N/data/	
Config	Configurations of values to plot	

4.13 Plot: Plot lines 121



This array contains Plot line configuration elements.

Sample read command (note that :plot is a URL template argument and needs to be replaced before trying):


Sample write command (note that :plot is a URL template argument and needs to be replaced before trying):

Sample plot line configuration creation command (note that :plot is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/config/plots/:plot/data/"
```

4.13.1 Plot line configuration

object	config/plots/N/data/N/	
Propert	Properties of a plot line	



This object contains the following items:

ds	Data source
style	Style
title	Title

Sample read command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

4.13 Plot: Plot lines 123

Sample write command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/config/plots/:plot/data/:plot_line_configuration/"
```

Sample deletion command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

4.13.1.1 Data source

```
string config/plots/N/data/N/ds/
Identifier of the data source to use
```

The value is subject to the following constraints: measured values[the value]

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Sample read command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

Sample write command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow: application/json" --data-binary "\"Sample value\"" "https \leftrightarrow://192.168.0.100/restapi/config/plots/:plot/data/:plot_line_configuration/ \leftrightarrow ds/"
```

See also Plot line configuration: Style

4.13.1.2 Title

string	config/plots/N/data/N/title/	
The title	The title of the plot line	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.


Sample read command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

Sample write command (note that :plot and :plot_line_configuration are URL template arguments and need to be replaced before trying):

4.14 Meters list

array	config/meters/
List of meters to display in the web UI	

4.14 Meters list 125



Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This array represents a value in persistent storage.

This array contains Meter configuration elements.

Sample read command:

Sample meter configuration creation command:

4.14.1 Meter configuration

object	config/meters/N/
Configuration of meter for a measured value	

Meter configuration		
title:Title		
display:Display		
data:Data source		
width:Width		
height:Height		
scale:Display scale		
decimals:Decimals		
color:Arrow color		
min_value:Minimum value		
sectors:Meter sectors	•	Meter sectors
	-	[element]:Sector configuration

This object contains the following items:

title	Title
display	Display
data	Data source
width	Width
height	Height
scale	Display scale
decimals	Decimals
color	Arrow color
min_value	Minimum value
sectors	Meter sectors

Sample read command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

Sample write command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/config/meters/:meter_configuration/"
```

Sample deletion command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X DELETE -H "Accept: application/json" "https \leftrightarrow ://192.168.0.100/restapi/config/meters/:meter_configuration/"
```

See also Meter configuration: Title

See also Meter configuration: Display

See also Meter configuration: Data source

See also Meter configuration: Width

See also Meter configuration: Height

See also Meter configuration: Display scale

See also Meter configuration: Decimals

See also Meter configuration: Arrow color

See also Meter configuration: Minimum value

See also Meter configuration: Meter sectors

4.15 Meter configuration: Title

string	config/meters/N/title/
The title of the meter	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Sample read command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/config/meters/:meter_configuration/title/"
```

 \Rightarrow

```
"Sample value"
```

Sample write command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

4.16 Meter configuration: Display

sum (boolean)	config/meters/N/display/	
Indicates whether the meter should be displayed		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Shown	The meter is shown
constant false	Hidden	The meter is hidden

Sample read command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow : application/json" --data-binary "true" "https://192.168.0.100/restapi/ \hookleftarrow \hookrightarrow config/meters/:meter_configuration/display/"
```

4.17 Meter configuration: Data source

string	config/meters/N/data/	
Identifie	Identifier of the data source to use	

The value is subject to the following constraints: measured values[the value]

This string represents a value in persistent storage.

Sample read command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

Sample write command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow : application/json" --data-binary "\"Sample value\"" "https \hookleftarrow ://192.168.0.100/restapi/config/meters/:meter_configuration/data/"
```

4.18 Meter configuration: Width

number	config/meters/N/width/	
The widtl	The width of the meter	

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- the value is greater than 0

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

Sample write command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

4.19 Meter configuration: Height

number	config/meters/N/height/
The height of the meter	

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- the value is greater than 0

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

Sample write command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow: application/json" --data-binary "9" "https://192.168.0.100/restapi/config \leftrightarrow /meters/:meter_configuration/height/"
```

4.20 Meter configuration: Display scale

```
string config/meters/N/scale/
The scale function to use for display
```

The value is subject to the following constraints: plot scales[the value]

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Sample read command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/config/meters/:meter_configuration/scale/"
```

 \Rightarrow

```
"Sample value"
```

Sample write command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

4.21 Meter configuration: Decimals

number	r config/meters/N/decimals/	
Number of decimal places to show in displayed value		

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- · the value is greater or equal to 0

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

Sample write command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow: application/json" --data-binary "5" "https://192.168.0.100/restapi/config \leftrightarrow /meters/:meter_configuration/decimals/"
```

4.22 Meter configuration: Arrow color

```
string config/meters/N/color/
The color of the meter arrow
```

The value is subject to the following constraints: the value matches ^[0-9A-F]{6}\$

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Sample read command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

Sample write command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

4.23 Meter configuration: Minimum value

```
number config/meters/N/min_value/
The minimum value to be displayed on the meter
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user


This number represents a value in persistent storage.

Sample read command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

Sample write command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

4.24 Meter configuration: Meter sectors

array	config/meters/N/sectors/	
Configuration of meter sectors		



Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This array represents a value in persistent storage.

This array contains Sector configuration elements.

Sample read command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←
   → restapi/config/meters/:meter_configuration/sectors/"
\Rightarrow
[
 "value":1,
 "name": "Sample value of sector configuration #1 of name",
 "color": "Sample value of sector configuration #1 of color"
},
 "value":5,
 "name": "Sample value of sector configuration #2 of name",
 "color": "Sample value of sector configuration #2 of color"
},
{
 "value":2,
 "name": "Sample value of sector configuration #3 of name",
 "color": "Sample value of sector configuration #3 of color"
},
 "value":1,
 "name": "Sample value of sector configuration #4 of name",
 "color": "Sample value of sector configuration #4 of color"
},
 "value":1,
 "name": "Sample value of sector configuration #5 of name",
 "color": "Sample value of sector configuration #5 of color"
},
```

```
{
  "value":5,
  "name":"Sample value of sector configuration #6 of name",
  "color":"Sample value of sector configuration #6 of color"
},
{
  "value":5,
  "name":"Sample value of sector configuration #7 of name",
  "color":"Sample value of sector configuration #7 of color"
}
```

Sample write command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

Sample sector configuration creation command (note that :meter_configuration is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"value\":8,\"name\":\"Sample value of name\",\"color\":\"Sample \( \to \)
\to value of color\"}"\
"https://192.168.0.100/restapi/config/meters/:meter_configuration/sectors/"
```

4.24.1 Sector configuration

```
object config/meters/N/sectors/N/
Configuration of a meter sector
```

This object contains the following items:

name	Name	
value	Maximum value	
color	Color	

Sample read command (note that :meter_configuration and :sector_configuration are URL template arguments and need to be replaced before trying):

Sample write command (note that :meter_configuration and :sector_configuration are URL template arguments and need to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"value\":5,\"name\":\"Sample value of name\",\"color\":\"Sample \( \to \)
\to value of color\"}"\
"https://192.168.0.100/restapi/config/meters/:meter_configuration/sectors/: \( \to \) sector_configuration/"
```

Sample deletion command (note that :meter_configuration and :sector_configuration are URL template arguments and need to be replaced before trying):

4.24.1.1 Name

string	config/meters/N/sectors/N/name/	
The name of the sector		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Sample read command (note that :meter_configuration and :sector_configuration are URL template arguments and need to be replaced before trying):

Sample write command (note that :meter_configuration and :sector_configuration are URL template arguments and need to be replaced before trying):

4.24.1.2 Maximum value

number	er config/meters/N/sectors/N/value/	
The maximum value for the sector		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command (note that :meter_configuration and :sector_configuration are URL template arguments and need to be replaced before trying):

Sample write command (note that :meter_configuration and :sector_configuration are URL template arguments and need to be replaced before trying):

4.24.1.3 Color

```
string config/meters/N/sectors/N/color/
The color of the sector
```

The value is subject to the following constraints: the value matches ^[0-9A-F]{6}\$

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Sample read command (note that :meter_configuration and :sector_configuration are URL template arguments and need to be replaced before trying):

Sample write command (note that :meter_configuration and :sector_configuration are URL template arguments and need to be replaced before trying):

4.25 Primary unit contact

4.26 Related contacts 137

string | config/contact/

The person or entity responsible for this unit and information on how to contact them

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.


Changes to this string do not take effect immediately.

→ ://192.168.0.100/restapi/config/contact/"

Sample read command:

4.26 Related contacts

```
map config/contacts/
Contacts related to the unit in different ways
```



Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This map represents a value in persistent storage.

This map contains Contact elements.

Sample read command:

Sample write command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/config/contacts/"
```

Sample contact creation command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"phone\":null,\"fax\":null,\"name\":\"Sample value of contact \( \to \) related_contacts_7 of name\",\"email\":null}"\
"https://192.168.0.100/restapi/config/contacts/related_contacts_7/"
```

4.26.1 Contact

4.27 Contact: Name 139

object	config/contacts/S/
Contact properties	

The value is subject to the following constraints: not index of the value matches (|\$.*)

This object represents a value in persistent storage.

This object contains the following items:

name	Name	
email	Email, if any	
phone	Phone number, if any	
fax	Fax number, if any	

Sample read command (note that :contact is a URL template argument and needs to be replaced before trying):

Sample write command (note that :contact is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"phone\":null,\"fax\":\"Sample value of fax number, if any\",\" \( \to \) name\":\"Sample value of name\",\"email\":null}"\
"https://192.168.0.100/restapi/config/contacts/:contact/"
```

Sample deletion command (note that :contact is a URL template argument and needs to be replaced before trying):

See also Contact: Name

See also Contact: Email, if any

See also Contact: Phone number, if any

See also Contact: Fax number, if any

4.27 Contact: Name

string	config/contacts/S/name/
Contact name	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Sample read command (note that :contact is a URL template argument and needs to be replaced before trying):

Sample write command (note that :contact is a URL template argument and needs to be replaced before trying):

4.28 Contact: Email, if any

```
sum (optional string) | config/contacts/S/email/
Contact email address, if any
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	None	No email address stored	
string	Email	Contact email address	the value is not equal to ""

Sample read command (note that :contact is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :contact is a URL template argument and needs to be replaced before trying):

4.28.1 Email

```
(possibly) string | config/contacts/S/email/
Contact email address
```

The value is subject to the following constraints: the value is not equal to ""

Sample write command (note that :contact is a URL template argument and needs to be replaced before trying):

4.29 Contact: Phone number, if any

sum (optional string)	config/contacts/S/phone/
Contact phone number, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	None	No phone number stored	I
string	Phone number	Contact phone number	the value is not equal to ""

Sample read command (note that :contact is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/config/contacts/:contact/phone/"
```

 \Rightarrow (possible variant)

"Sample value"

Sample (possible variant) write command (note that :contact is a URL template argument and needs to be replaced before trying):

4.29.1 Phone number

```
(possibly) string config/contacts/S/phone/
Contact phone number
```

The value is subject to the following constraints: the value is not equal to ""

Sample write command (note that :contact is a URL template argument and needs to be replaced before trying):

4.30 Contact: Fax number, if any

```
sum (optional string) config/contacts/S/fax/
Contact fax number, if any
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	None	No fax number stored	
string	Fax number	Contact fax number	the value is not equal to ""

Sample read command (note that :contact is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :contact is a URL template argument and needs to be replaced before trying):

4.30.1 Fax number

(possibly) string	config/contacts/S/fax/
Contact fax number	

The value is subject to the following constraints: the value is not equal to ""

4.32 Model OID 143

Sample write command (note that :contact is a URL template argument and needs to be replaced before trying):

4.31 Unit location

```
string config/location/
The physical location of this unit (e.g. '1st floor, rack 9')
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Changes to this string do not take effect immediately.

Sample read command:

Sample write command:

4.32 Model OID

string	config/oid/	
Object	Object identifier of unit model (should be registered under dliRegistration OID)	

Retrieving the value is denied if not administrative user

This string does not support direct modification.

This string represents a value in persistent storage.

Sample read command:

4.33 Version number

string	config/version/
Version number of frontend software	

This string does not support direct modification.

This string represents a value in persistent storage.

Sample read command:

4.34 Hardware ID

string	config/hardware_id/
Identifier of unit hardware model	

Retrieving the value is denied if not administrative user

This string does not support direct modification.

This string represents a value in persistent storage.

Sample read command:

4.35 Serial number

string	config/serial/	
Unit's s	Unit's serial number	

4.38 Brand name 145

This string does not support direct modification.

This string represents a value in persistent storage.

Sample read command:

4.36 Outlet label

```
string config/outlet_label/
User-visible label for an outlet controlled by a relay
```

This string does not support direct modification.

This string represents a value in persistent storage.

Sample read command:

4.37 Brand company name

```
string config/brand_company_name/
The name of the company which produced the device
```

Retrieving the value is denied if not administrative user

This string does not support direct modification.

This string represents a value in persistent storage.

Sample read command:

4.38 Brand name

string config/brand_name/

Default brand name, unless overridden

Retrieving the value is denied if not administrative user

This string does not support direct modification.

This string represents a value in persistent storage.

Sample read command:

4.39 Brand URL

```
string config/brand_url/
Default brand URL, unless overridden
```

Retrieving the value is denied if not administrative user

This string does not support direct modification.

This string represents a value in persistent storage.

Sample read command:

4.40 Brand manual URL

string	config/brand_manual_url/	
Brand	Brand product manual URL	

Retrieving the value is denied if not administrative user

This string does not support direct modification.

This string represents a value in persistent storage.

Sample read command:

4.43 Support email 147

4.41 Brand FAQ URL

```
string config/brand_faq_url/
Brand product FAQ URL
```

Retrieving the value is denied if not administrative user

This string does not support direct modification.

This string represents a value in persistent storage.

Sample read command:

4.42 Brand product information URL

```
string config/brand_product_info_url/

Brand product information URL
```

Retrieving the value is denied if not administrative user

This string does not support direct modification.

This string represents a value in persistent storage.

Sample read command:

4.43 Support email

string config/support_email/
Product support email

Retrieving the value is denied if not administrative user

This string does not support direct modification.

This string represents a value in persistent storage.

Sample read command:

4.44 Registration URL

```
string config/register_url/

Default registration URL, unless overridden
```

Retrieving the value is denied if not administrative user

This string does not support direct modification.

This string represents a value in persistent storage.

Sample read command:

4.45 Support URL

string	ring config/support_url/	
Default	Default support URL, unless overridden	

Retrieving the value is denied if not administrative user

This string does not support direct modification.

This string represents a value in persistent storage.

Sample read command:

4.46 Update URL

string	config/update_url/
Default update URL, unless overridden	

Retrieving the value is denied if not administrative user

This string does not support direct modification.

This string represents a value in persistent storage.

Sample read command:

4.47 Custom brand company name, if any

sum (optional string)	config/custom_brand_company_name/	
User-visible brand con	User-visible brand company name, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Default	Use default brand company name	
string	Custom brand company name	User-visible brand company name	the value is not equal to ""

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/config/custom_brand_company_name/"
```

 \Rightarrow (possible variant)

null

Sample (possible variant) write command:

4.47.1 Custom brand company name

```
(possibly) string config/custom_brand_company_name/
User-visible brand company name
```

The value is subject to the following constraints: the value is not equal to ""

Sample write command:

4.48 Custom brand name, if any

```
sum (optional string) config/custom_brand_name/
User-visible product brand name, if any
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Default	Use default product brand name	
string	Custom brand name	User-visible product brand name	the value is not equal to ""

Sample read command:

Sample (possible variant) write command:

4.48.1 Custom brand name

(possibly) string	config/custom_brand_name/	
User-visible product brand name		

The value is subject to the following constraints: the value is not equal to ""

Sample write command:

4.49 Custom brand URL, if any

```
sum (optional string) | config/custom_brand_url/
User-visible brand URL, if any
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Default	Use default brand URL	
string	Custom brand URL	User-visible brand URL	the value is not equal to ""

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/config/custom_brand_url/"
```

\Rightarrow (possible variant)

Sample (possible variant) write command:

4.49.1 Custom brand URL

```
(possibly) string | config/custom_brand_url/
User-visible brand URL
```

[&]quot;Sample value"

The value is subject to the following constraints: the value is not equal to ""

Sample write command:

4.50 Custom brand logo URL, if any

```
sum (optional string) config/custom_brand_logo/
User-visible brand logo URL, if any
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Default	Use default brand logo	
string	Custom brand logo URL	User-visible brand logo URL	the value is not equal to ""

Sample read command:

Sample (possible variant) write command:

4.50.1 Custom brand logo URL

```
(possibly) string | config/custom_brand_logo/
User-visible brand logo URL
```

The value is subject to the following constraints: the value is not equal to ""

Sample write command:

4.51 Custom brand logo width, if any

sum (optional number)	onal number) config/custom_brand_logo_width/	
User-visible brand logo width, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Default	Use default brand logo width
number	Custom brand logo width	User-visible brand logo width

Sample read command:

Sample (possible variant) write command:

4.51.1 Custom brand logo width

```
(possibly) number | config/custom_brand_logo_width/
User-visible brand logo width
```

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "3" "https://192.168.0.100/restapi/config \leftrightarrow /custom_brand_logo_width/"
```

4.52 Custom brand logo height, if any

```
sum (optional number) | config/custom_brand_logo_height/
User-visible brand logo height, if any
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Default	Use default brand logo height
number	Custom brand logo height	User-visible brand logo height

Sample read command:

\Rightarrow (possible variant)

null

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "2" "https://192.168.0.100/restapi/config \leftrightarrow /custom_brand_logo_height/"
```

4.52.1 Custom brand logo height

(possibly) number	config/custom_brand_logo_height/
User-visible brand logo height	

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "7" "https://192.168.0.100/restapi/config \leftrightarrow /custom_brand_logo_height/"
```

4.53 Custom support email, if any

sum (optional string)	n (optional string) config/custom_support_email/	
User-visible product support email, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Default	Use default support email	
string	Custom support email	User-visible product support email	the value is not equal to ""

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/config/custom_support_email/"
```

 \Rightarrow (possible variant)

null

Sample (possible variant) write command:

4.53.1 Custom support email

```
(possibly) string | config/custom_support_email/
User-visible product support email
```

The value is subject to the following constraints: the value is not equal to ""

Sample write command:

4.54 Custom registration URL, if any

```
sum (optional string) config/custom_register_url/
User-visible registration URL, if any
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	III Default Use default registration URL		
string	Custom registration URL	User-visible registration URL	the value is not equal to ""

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/config/custom_register_url/"
```

 \Rightarrow (possible variant)

```
"Sample value"
```

Sample (possible variant) write command:

4.54.1 Custom registration URL

```
(possibly) string | config/custom_register_url/
User-visible registration URL
```

The value is subject to the following constraints: the value is not equal to ""

Sample write command:

4.55 Custom support URL, if any

```
sum (optional string) | config/custom_support_url/
User-visible support URL, if any
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Default	Use default support URL	
string	Custom support URL	User-visible support URL	the value is not equal to ""

Sample read command:

Sample (possible variant) write command:

4.55.1 Custom support URL

(possibly) string	config/custom_support_url/
User-visible support URL	

The value is subject to the following constraints: the value is not equal to ""

Sample write command:

4.56 Custom update URL, if any

```
sum (optional string) config/custom_update_url/
User-visible update URL, if any
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Default	Use default update URL	
string	Custom update URL	User-visible update URL	the value is not equal to ""

Sample read command:

Sample (possible variant) write command:

4.56.1 Custom update URL

```
(possibly) string config/custom_update_url/
User-visible update URL
```

The value is subject to the following constraints: the value is not equal to ""

Sample write command:

4.57 Custom help URL, if any

```
sum (optional string) config/custom_help_url/
User-visible help URL, if any
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Internal help	Use the internal embedded help system	
string	Custom help URL	User-visible help URL	the value is not equal to ""

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/config/custom_help_url/"
```

⇒ (possible variant)

"Sample value"

Sample (possible variant) write command:

4.57.1 Custom help URL

```
(possibly) string | config/custom_help_url/
User-visible help URL
```

The value is subject to the following constraints: the value is not equal to ""

Sample write command:

4.58 Registration status

sum (boolean)	config/registration_status/
Status of the unit registration	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Defined	The user has either registered the unit, or refused to	
		do so	
constant false	Undefined	The user hasn't decided on registering the unit and needs to be reminded	

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/config/registration_status/"
```

 \Rightarrow (possible variant)

false

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "true" "https://192.168.0.100/restapi/ \hookleftarrow \hookrightarrow config/registration_status/"
```

4.59 Enable page refresh

sum (boolean)	config/refresh_enabled/
Periodically refresh web UI status page	

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/config/refresh_enabled/"
```

```
\Rightarrow (possible variant)
```

t rue

Sample (possible variant) write command:

4.60 Page refresh delay

```
number config/refresh_delay_minutes/
Status page refresh delay, if refresh is enabled
```

The value is subject to the following constraints: the value is greater than 0

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command:

Sample write command:

4.61 Preferred image format

```
string config/image_format/

Default image format for plots and meters
```

The value is subject to the following constraints: image formats[the value]

This string represents a value in persistent storage.

4.63 Time zone 161

Sample write command:

4.62 Unit hostname

```
string config/hostname/

Host name of the unit (sent by DHCP client, redirected to on network configuration changes when next IP address is unknown)
```

The value is subject to the following constraints: the value matches (([a-zA-Z0-9]|[a-zA-Z0-9]|[a-zA-Z0-9-]*[a-zA-Z0-9-]*[a-zA-Z0-9-]*[a-zA-Z0-9-]*[a-zA-Z0-9-]*[a-zA-z0-9-]*[a-za-z0-9-]

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Changes to this string do not take effect immediately.

Sample read command:

Sample write command:

4.63 Time zone

```
    string
    config/timezone/


    System time zone
```

The value is subject to the following constraints: known timezones[the value]

This string represents a value in persistent storage.

4.64 HTTP ports

```
array config/http_ports/
HTTP port bindings
```



Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This array represents a value in persistent storage.

This array represents an unordered set (order of its elements doesn't matter, and each value should not be supplied more than once).

Changes to this array do not take effect immediately.

This array contains Port binding elements.

Sample write command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/config/http_ports/"
```

Sample port binding creation command:

See also HTTP ports: Port binding

4.65 HTTP ports: Port binding

```
object config/http_ports/N/
Address and port to bind service to
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- not administrative user
- protect network settings

This object represents a value in persistent storage.

Changes to this object do not take effect immediately.

This object contains the following items:

address	Address
port	Port

Sample read command (note that :port_binding is a URL template argument and needs to be replaced before trying):

Sample write command (note that :port_binding is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :port_binding is a URL template argument and needs to be replaced before trying):

4.65.1 Address

```
string config/http_ports/N/address/
Address to listen on
```

The value is subject to the following constraints: the value matches (([0-9]|[1-9][0-9]|1[0-9]|2]|2[0-4][0-9]|25[0-5]).)(3)([0-9]|[1-9][0-9]|1[0-9]|2|2[0-4][0-9]|25[0-5])

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Changes to this string do not take effect immediately.

Sample read command (note that :port_binding is a URL template argument and needs to be replaced before trying):

4.66 HTTPS ports 165

Sample write command (note that :port_binding is a URL template argument and needs to be replaced before trying):

4.65.2 Port

```
number | config/http_ports/N/port/
Port number to bind to
```

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- · the value is greater than 0
- the value is less than 65535

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This number represents a value in persistent storage.


Changes to this number do not take effect immediately.

Sample read command (note that :port_binding is a URL template argument and needs to be replaced before trying):

Sample write command (note that :port_binding is a URL template argument and needs to be replaced before trying):

4.66 HTTPS ports

```
array config/https_ports/
HTTPS port bindings
```



Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This array represents a value in persistent storage.

This array represents an unordered set (order of its elements doesn't matter, and each value should not be supplied more than once).

Changes to this array do not take effect immediately.

This array contains Port binding elements.

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \( \infty \) restapi/config/https_ports/"

\Rightarrow [
{
    "port":5,
    "address":"Sample value of port binding #1 of address"
},
{
    "port":3,
    "address":"Sample value of port binding #2 of address"
},
{
    "port":10,
    "address":"Sample value of port binding #3 of address"
}
```

Sample write command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/config/https_ports/"
```

Sample port binding creation command:

See also HTTPS ports: Port binding

4.67 HTTPS ports: Port binding

```
object config/https_ports/N/
Address and port to bind service to
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This object represents a value in persistent storage.

Changes to this object do not take effect immediately.

This object contains the following items:

address	Address
port	Port

Sample read command (note that :port_binding is a URL template argument and needs to be replaced before trying):

Sample write command (note that :port_binding is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :port_binding is a URL template argument and needs to be replaced before trying):

4.67.1 Address

```
string config/https_ports/N/address/
Address to listen on
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Changes to this string do not take effect immediately.

Sample read command (note that :port_binding is a URL template argument and needs to be replaced before trying):

Sample write command (note that :port_binding is a URL template argument and needs to be replaced before trying):

4.67.2 Port

```
number | config/https_ports/N/port/
Port number to bind to
```

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater than 0
- the value is less than 65535

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This number represents a value in persistent storage.


Changes to this number do not take effect immediately.

Sample read command (note that :port_binding is a URL template argument and needs to be replaced before trying):

Sample write command (note that :port_binding is a URL template argument and needs to be replaced before trying):

4.68 HTTPS certificate settings

```
object config/https_cert/
HTTPS certificate configuration
```



This object contains the following items:

bits	Bits
domains	Domain names override, if any
addresses	Addresses override, if any
automatic_renewal	Automatic renewal
renewal_method	Certificate renewal method
renewal_data	Data
csr	HTTPS certificate signing request
cert	HTTPS certificate chain
key	HTTPS certificate key
renew_cert	Renew certificate
generate_key	Generate key
known_renewal_methods	Renewal methods
distinguished_name	Distinguished name
known_dn_oids	Known DN OIDs
string_mask	String mask

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/config/https_cert/"
```

 \Rightarrow

. . .

Sample write command:

4.68.1 Bits

```
number config/https_cert/bits/
Size of new private keys
```

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- the value is greater than 0

Sample read command:


Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "6" "https://192.168.0.100/restapi/config \leftrightarrow /https_cert/bits/"
```

4.68.2 Domain names override, if any

```
sum (optional array) | config/https_cert/domains/

Explicit domain name list to certify for when enrolling certificate, if any
```



This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Use hostname	Certify for the current hostname when enrolling certifi-
		cate
array	Domain names override	Explicit domain name list to certify for when enrolling
		certificate


Sample read command:

Sample (possible variant) write command:

See also Domain names override, if any: Domain names override

4.68.3 Addresses override, if any

sum (optional array)	config/https_cert/addresses/	
Explicit list of addresses to certify for when enrolling certificate, if any		



This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Use all known addresses	Certify for all current addresses when enrolling certificate automatically
array	Addresses override	Explicit list of addresses to certify for when enrolling certificate

Sample read command:

Sample (possible variant) write command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "[\"Sample value of ipv4 address #1\",\"Sample value of ipv4 \
\to address #2\",\"Sample value of ipv4 address #3\"]"\
"https://192.168.0.100/restapi/config/https_cert/addresses/"
```

See also Addresses override, if any: Addresses override

4.68.4 Automatic renewal

sum (boolean) config/https_cert/automatic_renewal/		
Automatic renewal of certificate at or near expiry		

This sum represents a value in persistent storage.

This sum can assume the following values:

	constant true	Enabled	The feature is enabled
Ī	constant false	Disabled	The feature is disabled

Sample read command:

→ : application/json" --data-binary "true" "https://192.168.0.100/restapi/ ←

4.68.5 Certificate renewal method

```
string config/https_cert/renewal_method/

Method to use when renewing the certificate
```

The value is subject to the following constraints: renewal methods[the value]

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

→ config/https_cert/automatic_renewal/"

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command:

See also HTTPS certificate settings: Data

4.68.6 HTTPS certificate signing request

string | config/https cert/csr/

The certificate signing request you need to sign in order to obtain an HTTPS certificate for the unit, to be honored by an external entity (read may fail if key generation is in progress)

Retrieving the value is denied if not administrative user

This string does not support direct modification.

This string can change as if by itself or indirectly because of other actions.

Changes to this string cannot be tracked.

Sample read command:

4.68.7 HTTPS certificate chain

```
string config/https_cert/cert/
```

HTTPS certificate chain presented by the unit to clients (read may fail if renewal is in progress)

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

Using the string as a field for indexing into the grandparent collection is denied

→ ://192.168.0.100/restapi/config/https_cert/cert/"

This string represents a value in persistent storage.

This string can change as if by itself or indirectly because of other actions.

Changes to this string cannot be tracked.

Changes to this string may have an effect besides setting value.

Changes to this string do not take effect immediately.

4.68.8 HTTPS certificate key

string config/https_cert/key/

The key used by the HTTPS certificate presented by the unit; certificate will be renewed as a side effect of writing; writing actual data is not recommended, please use the certificate request signing path instead

Retrieving the value is denied

Changing the value is denied if not administrative user

Using the string as a field for indexing into the grandparent collection is denied

This string represents a value in persistent storage.

This string can change as if by itself or indirectly because of other actions.

Changes to this string cannot be tracked.

Changes to this string may have an effect besides setting value.

Changes to this string do not take effect immediately.

This string should be displayed in a secure manner.

Representation of the resource cannot be obtained. Attempts to do so will succeed but return JSON '{"\$ref":""}' which means "the value of this resource".

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow: application/json" --data-binary "\"Sample value\"" "https \leftrightarrow: //192.168.0.100/restapi/config/https_cert/key/"
```

4.68.9 Renew certificate

```
call | config/https_cert/renew_cert/
```

Initiate attempt to renew the certificate using the selected method

Performing the function call is denied if any of the following is true:

- · not administrative user
- · protect network settings

The call has no arguments (supply empty tuple).

The call returns no results (expect an empty tuple).

Sample invocation:

4.68.10 Generate key

call | config/https_cert/generate_key/

Initiate generation of a new private key; certificate renewal will be attempted as a side effect; if that fails, the key is unchanged

Performing the function call is denied if any of the following is true:

- · not administrative user
- · protect network settings


The call has no arguments (supply empty tuple).

The call returns no results (expect an empty tuple).

Sample invocation:

4.68.11 Renewal methods

map	config/https_cert/known_renewal_methods/	
Know	Known renewal methods	



Retrieving the value is denied if not administrative user

This map does not support direct modification.


This map contains Renewal method elements.

Creating elements in this collection is not supported.

See also Renewal methods: Renewal method

4.68.12 Distinguished name

map	config/https_cert/distinguished_name/
New certificate distinguished name elements	



Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This map represents a value in persistent storage.

This map contains Values elements.

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/config/https_cert/distinguished_name/"
```

 \Rightarrow

. . .

Sample write command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/config/https_cert/distinguished_name/"
```

Sample values creation command:

See also Distinguished name: Values

See also HTTPS certificate settings: Known DN OIDs

4.68.13 String mask

sum (enumerated string)	config/https_cert/string_mask/
The set of string types to use for new certificates	

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant "default"	OpenSSL default	PrintableString, T61String and BMPString
constant "pkix"	PKIX	PrintableString and BMPString
constant "utf8only"	UTF-8 strings only	UTF8String
constant "nombstr"	No multibyte strings	PrintableString and T61String

4.69 Domain names override, if any: Domain names override

```
(possibly) array config/https_cert/domains/

Explicit domain name list to certify for when enrolling certificate
```

This array contains Hostname elements.

Sample write command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "[\"Sample value of hostname #1\",\"Sample value of hostname \(\to\)
\(\to\) #2\",\"Sample value of hostname #3\",\"Sample value of hostname #4\",\" \(\to\)
\(\to\) Sample value of hostname #5\",\"Sample value of hostname #6\",\"Sample \(\to\)
\(\to\) value of hostname #7\"]"\
\"https://192.168.0.100/restapi/config/https_cert/domains/"
```

Sample hostname creation command:

4.69.1 Hostname

```
string config/https_cert/domains/N/
Hostname to certify for
```

The value is subject to the following constraints: the value matches (([a-zA-Z0-9][a-zA-Z0-9][a-zA-Z0-9-]*[a-zA-Z0-9-]*[a-zA-Z0-9])))

This string represents a value in persistent storage.

Sample read command (note that :hostname is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/config/https_cert/domains/:hostname/"
```

```
⇒
"Sample value"
```

Sample write command (note that :hostname is a URL template argument and needs to be replaced before trying):

4.70 Addresses override, if any: Addresses override

```
(possibly) array config/https_cert/addresses/
Explicit list of addresses to certify for when enrolling certificate
```

This array contains IPv4 address elements.

Sample write command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/config/https_cert/addresses/"
```

Sample ipv4 address creation command:

4.70.1 IPv4 address

```
string config/https_cert/addresses/N/
IPv4 address to certify for, in dotted quad notation
```

This string represents a value in persistent storage.

Sample read command (note that :ipv4_address is a URL template argument and needs to be replaced before trying):

Sample write command (note that :ipv4_address is a URL template argument and needs to be replaced before trying):

4.71 HTTPS certificate settings: Data

```
map | config/https_cert/renewal_data/
Renewal-method-specific data
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This map represents a value in persistent storage.

This map contains Data item elements.

Sample read command:

Sample write command:

Sample data item creation command:

4.71.1 Data item

```
string config/https_cert/renewal_data/S/

Item of renewal-method-specific data
```

The value is subject to the following constraints: the value matches renewal methods[certificate renewal method].data_items[index of the value].regexp

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

Using the string as a field for indexing into the grandparent collection is denied if any of the following is true:

- · not administrative user
- · all of the following is true:
 - index of the value is not equal to ""
 - renewal methods[certificate renewal method].data items[index of the value].secret

This string represents a value in persistent storage.

This string should be displayed in a secure manner if all of the following is true:

- index of the value is not equal to ""
- renewal methods[certificate renewal method].data_items[index of the value].secret

Sample read command (note that :data_item is a URL template argument and needs to be replaced before trying):

Sample write command (note that :data_item is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :data_item is a URL template argument and needs to be replaced before trying):

4.72 Supported data items: Data item properties

object	config/https_cert/known_renewal_methods/S/data_items/S/
Properties of data item	

This object contains the following items:

name	Name
regexp	Regular expression
secret	Secret

Sample read command (note that :renewal_method and :data_item_properties are URL template arguments and need to be replaced before trying):

Sample write command (note that :renewal_method and :data_item_properties are URL template arguments and need to be replaced before trying):

4.72.1 Name

```
string config/https_cert/known_renewal_methods/S/data_items/S/name/

Data item name
```

Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :renewal_method and :data_item_properties are URL template arguments and need to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/config/https_cert/known_renewal_methods/:renewal_method/data_items \leftarrow \hookrightarrow /:data_item_properties/name/"
```

```
⇒
"Sample value"
```

4.72.2 Regular expression

```
string config/https_cert/known_renewal_methods/S/data_items/S/regexp/

Regular expression which the data item must match
```

Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :renewal_method and :data_item_properties are URL template arguments and need to be replaced before trying):

4.72.3 Secret

sum (boolean)	config/https_cert/known_renewal_methods/S/data_items/S/secret/
Flag indicating whether the data item can contain private information	

Retrieving the value is denied if not administrative user

This sum does not support direct modification.

This sum can assume the following values:


constant true	Secret	The data item can contain private information
constant false	Not secret	The data item contains only public information

Sample read command (note that :renewal_method and :data_item_properties are URL template arguments and need to be replaced before trying):

4.73 Renewal methods: Renewal method

```
object config/https_cert/known_renewal_methods/S/

Method of certificate renewal
```



Retrieving the value is denied if not administrative user

This object contains the following items:


data_items	Supported data items
name	Name

Sample read command (note that :renewal_method is a URL template argument and needs to be replaced before trying):

Sample write command (note that :renewal_method is a URL template argument and needs to be replaced before trying):

4.73.1 Supported data items

```
map config/https_cert/known_renewal_methods/S/data_items/
Properties of supported data items
```



Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map contains Data item properties elements.

Sample read command (note that :renewal_method is a URL template argument and needs to be replaced before trying):

Creating elements in this collection is not supported.

See also Supported data items: Data item properties

4.73.2 Name

string	config/https_cert/known_renewal_methods/S/name/	
Renewal method name		

Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :renewal_method is a URL template argument and needs to be replaced before trying):

4.74 Distinguished name: Values

```
array config/https_cert/distinguished_name/S/
Distinguished name element value set
```

The value is subject to the following constraints: any of the following is true:

- known dn oids[index of the value]
- index of the value matches ^012{1,}

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This array represents a value in persistent storage.

This array contains Value elements.

Sample read command (note that :values is a URL template argument and needs to be replaced before trying):

Sample write command (note that :values is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow : application/json" --data-binary "[\"Sample value of value #1\"]" "https \hookleftarrow ://192.168.0.100/restapi/config/https_cert/distinguished_name/:values/"
```

Sample value creation command (note that :values is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :values is a URL template argument and needs to be replaced before trying):

4.74.1 Value

```
string config/https_cert/distinguished_name/S/N/
Distinguished name element value
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :values and :value are URL template arguments and need to be replaced before trying):

Sample write command (note that :values and :value are URL template arguments and need to be replaced before trying):

Sample deletion command (note that :values and :value are URL template arguments and need to be replaced before trying):

4.75 HTTPS certificate settings: Known DN OIDs

```
map config/https_cert/known_dn_oids/
Known distinguished name element object identifiers
```

Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map contains OID elements.

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/config/https_cert/known_dn_oids/"
```

```
{
    "known_dn_oids_6":"Sample value of oid known_dn_oids_6",
    "known_dn_oids_9":"Sample value of oid known_dn_oids_9",
    "known_dn_oids_7":"Sample value of oid known_dn_oids_7",
    "known_dn_oids_4":"Sample value of oid known_dn_oids_4",
    "known_dn_oids_8":"Sample value of oid known_dn_oids_8",
    "known_dn_oids_1":"Sample value of oid known_dn_oids_1",
    "known_dn_oids_5":"Sample value of oid known_dn_oids_5",
    "known_dn_oids_2":"Sample value of oid known_dn_oids_2",
    "known_dn_oids_3":"Sample value of oid known_dn_oids_3",
}
```

Creating elements in this collection is not supported.

4.75.1 OID

```
string config/https_cert/known_dn_oids/S/
Object identifier value
```

Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :oid is a URL template argument and needs to be replaced before trying):

4.76 SSH enabled

```
sum (boolean) | config/ssh_enabled/
Whether the SSH server should be enabled
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This sum represents a value in persistent storage.

Changes to this sum do not take effect immediately.

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command:

 \hookrightarrow : application/json" --data-binary "true" "https://192.168.0.100/restapi/ \hookleftarrow

4.77 SSH port number

→ config/ssh_enabled/"

```
number | config/ssh_port/
Port number of the SSH server
```

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- the value is greater than 0
- the value is less than 65535

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This number represents a value in persistent storage.

Changes to this number do not take effect immediately.


Sample read command:

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "2" "https://192.168.0.100/restapi/config \leftrightarrow /ssh_port/"
```

4.78 SSH authorized keys

```
array config/ssh_authorized_keys/
List of public keys allowed to log in
```



Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This array represents a value in persistent storage.

Changes to this array do not take effect immediately.

This array contains SSH authorized key elements.

Sample read command:

Sample write command:

Sample ssh authorized key creation command:

See also SSH authorized keys: SSH authorized key

4.79 SSH authorized keys: SSH authorized key

```
object config/ssh_authorized_keys/N/
Public key allowed to log in
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This object represents a value in persistent storage.

Changes to this object do not take effect immediately.

This object contains the following items:

data	Data
options	Options
comment	Comment

Sample read command (note that :ssh_authorized_key is a URL template argument and needs to be replaced before trying):

Sample write command (note that :ssh_authorized_key is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"comment\":\"Sample value of comment\",\"options\":\"Sample \( \to \)
\to value of options\",\"data\":\"Sample value of data\"}"\
"https://192.168.0.100/restapi/config/ssh_authorized_keys/:ssh_authorized_key/"
```

Sample deletion command (note that :ssh_authorized_key is a URL template argument and needs to be replaced before trying):

4.79.1 Data

```
string config/ssh_authorized_keys/N/data/
Public key data
```

The value is subject to the following constraints: the value matches (([0-9])+([0-9]

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Changes to this string do not take effect immediately.

Sample read command (note that :ssh_authorized_key is a URL template argument and needs to be replaced before trying):

Sample write command (note that :ssh_authorized_key is a URL template argument and needs to be replaced before trying):

4.79.2 Options

```
string config/ssh_authorized_keys/N/options/
Public key options
```

The value is subject to the following constraints: the value matches $([^{\land}]+|^{"}]^{*})*$

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

4.80 NTP server enabled 195

This string represents a value in persistent storage.

Changes to this string do not take effect immediately.

Sample read command (note that :ssh_authorized_key is a URL template argument and needs to be replaced before trying):

Sample write command (note that :ssh_authorized_key is a URL template argument and needs to be replaced before trying):

4.79.3 Comment

```
string config/ssh_authorized_keys/N/comment/
Public key comment
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This string represents a value in persistent storage.

Changes to this string do not take effect immediately.

Sample read command (note that :ssh_authorized_key is a URL template argument and needs to be replaced before trying):

Sample write command (note that :ssh_authorized_key is a URL template argument and needs to be replaced before trying):

4.80 NTP server enabled

sum (boolean)	config/ntp_server_enabled/
Whether the device should act as NTP server	

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This sum represents a value in persistent storage.

Changes to this sum do not take effect immediately.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/config/ntp_server_enabled/"
```

 \Rightarrow (possible variant)

false

Sample (possible variant) write command:

4.81 NTP peers

```
array config/ntp_peers/
List of NTP servers to get time information from
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This array represents a value in persistent storage.

Changes to this array do not take effect immediately.

This array contains NTP peer elements.

Sample read command:

Sample write command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/config/ntp_peers/"
```

Sample ntp peer creation command:

See also NTP peers: NTP peer

4.82 NTP peers: NTP peer

```
    sum (string)
    config/ntp_peers/N/

    NTP server to get time information from
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This sum represents a value in persistent storage.

Changes to this sum do not take effect immediately.

string	Hostname	Hostname	the value matches ^(([a-zA-Z0-9] [a-zA-Z0-
			9][a-zA-Z0-9-]∗[a-zA-Z0-9]).)∗([A-Za-z]([A-←
			Za-z0-9-]*[A-Za-z0-9])? [A-Za-z0-9][A-Za-z0-
			9-]*[A-Za-z]([A-Za-z0-9-]*[A-Za-z0-9])?)\$
string	IPv4 address	IPv4 address in dotted quad notation	the value matches ^(([0-9] [1-9][0-9] 1[0-9]{2} 2[0-4][0-9] 25[0-5]).){3}([0-9] [1-9][0-9] 1[0-9]{2} 2[0-4][0-9] 25[0-5])\$

Sample read command (note that :ntp_peer is a URL template argument and needs to be replaced before trying):

 \Rightarrow (possible variant)

"Sample value"

Sample (possible variant) write command (note that :ntp_peer is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :ntp_peer is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X DELETE -H "Accept: application/json" "https \leftarrow ://192.168.0.100/restapi/config/ntp_peers/:ntp_peer/"
```

4.82.1 Hostname

(possibly) string	config/ntp_peers/N/
Hostname	

The value is subject to the following constraints: the value matches (([a-zA-Z0-9]|[a-zA-Z0-9]|[a-zA-Z0-9-]*[a-zA-Z0-9-]*[a-zA-Z0-9-]*[a-zA-Z0-9-]*[a-zA-Z0-9-]*[a-zA-z0-9-]*[a-za-z0-9-]

Sample write command (note that :ntp_peer is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :ntp_peer is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X DELETE -H "Accept: application/json" "https \leftrightarrow ://192.168.0.100/restapi/config/ntp_peers/:ntp_peer/"
```

4.82.2 IPv4 address

```
(possibly) string config/ntp_peers/N/
IPv4 address in dotted quad notation
```

Sample write command (note that :ntp_peer is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :ntp_peer is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X DELETE -H "Accept: application/json" "https \leftarrow ://192.168.0.100/restapi/config/ntp_peers/:ntp_peer/"
```

4.83 Syslog threshold severity

sum (enumerated number)	config/syslog_minimal_severity/
Threshold severity for system messages, below which they are not logged	

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- not administrative user
- · protect network settings

This sum represents a value in persistent storage.

Changes to this sum do not take effect immediately.

This sum can assume the following values:

constant 1	Emergency	Log when unit becomes unstable or unusable	
constant 2	Alert	Log conditions requiring immediate action	
constant 3	Critical	Log critical conditions	
constant 4	Error	Log error conditions	
constant 5	Warning	Log warning conditions	
constant 6	Notice	Log normal but significant conditions	
constant 7	Informational	Log informational messages	
constant 8	Debug	Log tracing and debugging messages	

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/config/syslog_minimal_severity/"
```

```
\Rightarrow (possible variant)
```

10

Sample (possible variant) write command:

4.84 Syslog server address, if any

sum (optional string)	config/syslog_ip_address/
Host name or IPv4 ad	dress of the syslog server to forward log messages to, if any

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This sum represents a value in persistent storage.

Changes to this sum do not take effect immediately.

This sum can assume the following values:

constant null	Syslog server disabled	System log messages are not forwarded to a server	
string	Hostname	Hostname	the value matches ^(([a-zA-Z0-9] [a-zA-Z0-9]][a-zA-Z0-9-]*[a-zA-Z0-9]].)*([A-Za-z]([A-Za-z0-9-]*[A-Za-z0-9]]?[A-Za-z0-9]]A-← Za-z0-9-]*[A-Za-z0-9])?)\$
string	IPv4 address	IPv4 address in dotted quad notation	the value matches ^(([0-9] [1-9][0-9] 1[0-9]{2} 2[0-4][0-9] 25[0-5]).){3}([0-9] [1-9][0-9] 1[0-9]{2} 2[0-4][0-9] 25[0-5])\$

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftrightarrow restapi/config/syslog_ip_address/"
```

\Rightarrow (possible variant)

null

Sample (possible variant) write command:

4.85 Allow JSONRPC 201

4.84.1 Hostname

(possibly) string	config/syslog_ip_address/
Hostname	

The value is subject to the following constraints: the value matches (([a-zA-Z0-9]|[a-zA-Z0-9]|[a-zA-Z0-9-]*[a-zA-Z0-9-]*[a-zA-Z0-9-]*[a-zA-Z0-9-]*[a-zA-z0-9-]*[a-za-z0-9-]

Sample write command:

4.84.2 IPv4 address

```
(possibly) string config/syslog_ip_address/
IPv4 address in dotted quad notation
```

The value is subject to the following constraints: the value matches $(([0-9]|[1-9][0-9]|1[0-9][2]|2[0-4][0-9]|25[0-5]).){3}([0-9]|[1-9][0-9]|2[0-4][0-9]|25[0-5])$ \$

Sample write command:

4.85 Allow JSONRPC

sum (boolean)	config/allow_jsonrpc/
Enable HTTP cl	ients to perform JSON-RPC requests

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This sum represents a value in persistent storage.

CC	onstant true	Enabled	The feature is enabled
CC	onstant false	Disabled	The feature is disabled

Sample read command:

4.86 Allow REST-like API

⇔ config/allow_jsonrpc/"

```
sum (boolean) | config/allow_restapi/
Enable HTTP clients to perform REST-like API requests
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command:

curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftarrow : application/json" --data-binary "false" "https://192.168.0.100/restapi/ \leftarrow

```
4.87 Allowed REST-like API client origins
```

→ config/allow_restapi/"

```
array config/allow_restapi_origins/
List of origins permitted to access the REST-like API
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This array represents a value in persistent storage.

This array contains Allowed REST-like API client origin elements.

Sample read command:

Sample write command:

Sample allowed rest-like api client origin creation command:

4.87.1 Allowed REST-like API client origin

```
string config/allow_restapi_origins/N/
Origin permitted to access the REST-like API
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :allowed_rest_like_api_client_origin is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←
   → restapi/config/allow_restapi_origins/:allowed_rest_like_api_client_origin/"
\Rightarrow
"Sample value"
```

Sample write command (note that :allowed_rest_like_api_client_origin is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept ←
    \hookrightarrow : application/json" --data-binary "\"Sample value\"" "https \hookleftarrow
    \hookrightarrow ://192.168.0.100/restapi/config/allow_restapi_origins/: \hookleftarrow
    → allowed_rest_like_api_client_origin/"
```

Sample deletion command (note that :allowed rest like api client origin is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X DELETE -H "Accept: application/json" "https ←
    \hookrightarrow ://192.168.0.100/restapi/config/allow_restapi\_origins/: \hookleftarrow
    → allowed_rest_like_api_client_origin/"
```

4.88 Relax non-HTML method CSRF checks

sum (boolean)	config/relax_nonhtml_methods/
Enable HTTP clients to perform PUT/PATCH/DELETE API requests without a CSRF protection header (currently	
cannot be sent via an HTML form)	

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This sum represents a value in persistent storage.

constant true	Enabled	The feature is enabled		
constant false	Disabled	The feature is disabled	DI I FPCR5 Object Model Reference	2018042071000477

Sample read command:

4.89 Relax non-HTML content type CSRF checks

→ config/relax_nonhtml_methods/"

```
sum (boolean) config/relax_nonhtml_content_types/

Enable HTTP clients to perform API requests with e.g. application/json or application/json-rpc without a CSRF protection header (currently cannot be sent via an HTML form)
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command:

4.90 Allow plaintext logins

→ config/relax_nonhtml_content_types/"

sum (boolean)	config/allow_plaintext_logins/
Allow HTTP clients to authenticate using Basic authentication or plaintext login form	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/config/allow_plaintext_logins/"
```

 \Rightarrow (possible variant)

false

Sample (possible variant) write command:

4.91 Relay name visibility

sum (boolean)	config/name_always_visible/
Flag enabling vi	sibility of relay name

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Everywhere	Relay name visible everywhere, including the login
		page
constant false	Authorized users only	Relay name visible only on pages which require autho-
		rization

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/config/name_always_visible/"
```

 \Rightarrow (possible variant)

4.93 Hide WiFi key 207

false

Sample (possible variant) write command:

4.92 Hide user passwords

sum (boolean)	config/hide_passwords/
Whether user passwords should be hidden	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Hide	Do not display user passwords in web UI	
constant false	Show	Display user passwords in web UI	

Sample read command:

 \Rightarrow (possible variant)

false

Sample (possible variant) write command:

4.93 Hide WiFi key

sum (boolean)	config/hide_wifi_key/
Whether the WiFi key should be hidden	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

constant true	Hide	Do not display WiFi key in web UI
constant false	Show	Display WiFi key in web UI

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow
    → restapi/config/hide_wifi_key/"
\Rightarrow (possible variant)
false
Sample (possible variant) write command:
```

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftarrow
   ↔ : application/json" --data-binary "false" "https://192.168.0.100/restapi/ ↔
   → config/hide_wifi_key/"
```

4.94 Security lockout duration

number	config/lockout_delay_minutes/
Time during which, after several unsuccessful logins, subsequent logins are denied	

The value is subject to the following constraints: the value is greater or equal to 0

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←
   → restapi/config/lockout_delay_minutes/"
\Rightarrow
9
```

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept ←
   \hookrightarrow: application/json" --data-binary "10" "https://192.168.0.100/restapi/ \hookleftarrow
   → config/lockout_delay_minutes/"
```

4.95 Protect firmware

sum (boolean)	config/protect_firmware/
Protect firmware from being overwritten	

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · the value

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Protected	Associated object cannot be changed
constant false	Not protected	Associated object can be changed

Sample read command:

false

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "false" "https://192.168.0.100/restapi/ \hookleftarrow \hookrightarrow config/protect_firmware/"
```

4.96 Protect admin login

```
sum (boolean) | config/protect_admin/
Protect admin settings from being modified
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · the value

This sum represents a value in persistent storage.

constant true	Protected	Associated object cannot be changed
constant false	Not protected	Associated object can be changed

Sample read command:

4.97 Protect network settings

→ config/protect_admin/"

```
sum (boolean) config/protect_network/

Protect network settings from being modified
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- the value

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Protected	Associated object cannot be changed
constant false	Not protected	Associated object can be changed

Sample read command:

4.98 Protect private settings

→ config/protect_network/"

4.99 Protect from restore 211

sum (boolean)	config/protect_private_config/
Protect private configuration settings from being stored in backups	

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · the value

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Protected	Associated object cannot be changed
constant false	Not protected	Associated object can be changed

Sample read command:

Sample (possible variant) write command:

4.99 Protect from restore

```
sum (boolean) | config/protect_restore/
Protect settings from being restored from backups
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · the value

This sum represents a value in persistent storage.

constant true	Protected	Associated object cannot be changed
constant false	Not protected	Associated object can be changed

Sample read command:

Sample (possible variant) write command:

4.100 Protect from maintenance

sum (boolean)) config/protect_maintenance/	
Disable remote maintenance support		

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- not administrative user
- the value

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Protected	Associated object cannot be changed
constant false	Not protected	Associated object can be changed

Sample read command:

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "false" "https://192.168.0.100/restapi/ \hookleftarrow \hookrightarrow config/protect_maintenance/"
```

4.101 Protect notification settings

sum (variant)	rariant) config/protect_notification/	
Protect notification settings from being modified		

Changing the value is denied if the value

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Protected	Associated object cannot be changed, and its security- related parameters cannot be read
constant false	Not protected	Associated object can be changed, and its security-related parameters can be read
constant "sender"	Protect sender configuration	Associated object cannot be changed, and its security- related parameters cannot be read; properties not re- lated to sender configuration can still be read and changed

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/config/protect_notification/"
```

 \Rightarrow (possible variant)

true

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "true" "https://192.168.0.100/restapi/ \hookleftarrow \hookrightarrow config/protect_notification/"
```

4.102 Beep on upgrade

sum (boolean)	config/upgrade_notify_beep/
Indicate firmware upgrade progress by beeping	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command:

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow : application/json" --data-binary "true" "https://192.168.0.100/restapi/ \hookrightarrow config/upgrade_notify_beep/"
```

4.103 Blink on upgrade

sum (boolean)	config/upgrade_notify_blink/
Indicate firmware upgrade progress by blinking	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/config/upgrade_notify_blink/"
```


\Rightarrow (possible variant)

false

Sample (possible variant) write command:

4.104 Known quantities

map	config/known_quantities/	
Map o	Map of known physical quantities	



This map does not support direct modification.

This map represents a value in persistent storage.


This map contains Quantity elements.

Sample read command:

Creating elements in this collection is not supported.

4.104.1 Quantity

object	config/known_quantities/S/	
Physica	Physical quantity	



This object contains the following items:

name	Name
preferred_unit	Preferred unit, if any
units	Known units

Sample read command (note that :quantity is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←
   → restapi/config/known_quantities/:quantity/"
\Rightarrow
 "preferred_unit":null,
 "name": "Sample value of name",
 "units":{
 "known_units_3":{
  "offset":10,
  "internal":true,
  "name": "Sample value of known units of unit known_units_3 of name",
  "scale":2
 },
 "known_units_5":{
  "offset":5,
  "internal":false,
  "name": "Sample value of known units of unit known_units_5 of name",
  "scale":9
 },
 "known_units_2":{
  "offset":8,
  "internal":true,
  "name": "Sample value of known units of unit known_units_2 of name",
  "scale":1
 },
 "known_units_4":{
  "offset":2,
  "internal":true,
  "name": "Sample value of known units of unit known_units_4 of name",
```

```
"scale":5
},
"known_units_1":{
  "offset":10,
  "internal":true,
  "name":"Sample value of known units of unit known_units_1 of name",
  "scale":6
}
}
}
```

Sample write command (note that :quantity is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/config/known_quantities/:quantity/"
```

See also Quantity: Name

See also Quantity: Preferred unit, if any

See also Quantity: Known units

4.105 Quantity: Name

```
string config/known_quantities/S/name/
Quantity name
```

This string does not support direct modification.

This string represents a value in persistent storage.

Sample read command (note that :quantity is a URL template argument and needs to be replaced before trying):

4.106 Quantity: Preferred unit, if any

```
sum (optional string) | config/known_quantities/S/preferred_unit/

Default UI unit for quantity, if any
```

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Standard unit	UI shows quantity in SI unit	S
string	Preferred unit	Default UI unit for quantity	known units[the value]

Sample read command (note that :quantity is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :quantity is a URL template argument and needs to be replaced before trying):

4.106.1 Preferred unit

```
(possibly) string | config/known_quantities/S/preferred_unit/

Default UI unit for quantity
```

The value is subject to the following constraints: known units[the value]


Sample write command (note that :quantity is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow: application/json" --data-binary "\"Sample value\"" "https \leftrightarrow://192.168.0.100/restapi/config/known_quantities/:quantity/preferred_unit/"
```

4.107 Quantity: Known units

```
map | config/known_quantities/S/units/

Map of known units for quantity
```



Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This map represents a value in persistent storage.

This map contains Unit elements.

Sample read command (note that :quantity is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←
    \hookrightarrow \verb|restapi/config/known_quantities/:quantity/units/"|
\Rightarrow
 "known_units_3":{
 "offset":6,
 "internal":false,
 "name": "Sample value of unit known_units_3 of name",
 "scale":7
 },
 "known_units_1":{
 "offset":3,
 "internal": false,
 "name": "Sample value of unit known_units_1 of name",
 "scale":5
 },
 "known_units_4":{
 "offset":6,
 "internal":false,
 "name": "Sample value of unit known_units_4 of name",
 "scale":8
 },
 "known_units_2":{
```

```
"offset":7,
"internal":false,
"name":"Sample value of unit known_units_2 of name",
"scale":5
}
}
```

Sample write command (note that :quantity is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/config/known_quantities/:quantity/units/"
```

Sample unit creation command (note that :quantity is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"offset\":4,\"internal\":false,\"name\":\"Sample value of unit \( \to \) known_units_6 of name\",\"scale\":6}"\
"https://192.168.0.100/restapi/config/known_quantities/:quantity/units/ \( \to \) known_units_6/"
```

4.107.1 Unit

object	t config/known_quantities/S/units/S/	
Unit of p	Unit of physical quantity	

Changing the value is denied if not administrative user

This object does not support direct modification if internal.

This object represents a value in persistent storage.

This object contains the following items:

internal	Internal
name	Name
offset	Offset
scale	Scaling factor

Sample read command (note that :quantity and :unit are URL template arguments and need to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/config/known_quantities/:quantity/units/:unit/"
```

```
⇒
{
  "offset":5,
  "internal":false,
  "name":"Sample value of name",
  "scale":2
}
```

Sample write command (note that :quantity and :unit are URL template arguments and need to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"offset\":3,\"internal\":false,\"name\":\"Sample value of name \( \to \\ \",\"scale\":1}\"\
"https://192.168.0.100/restapi/config/known_quantities/:quantity/units/:unit/"
```

Sample deletion command (note that :quantity and :unit are URL template arguments and need to be replaced before trying):

```
curl --digest -u admin:1234 -X DELETE -H "Accept: application/json" "https ↔ ://192.168.0.100/restapi/config/known_quantities/:quantity/units/:unit/"
```

4.107.1.1 Internal

sum (boolean)	config/known_quantities/S/units/S/internal/	
Flag indicating whether this measurement unit is internal		

This sum does not support direct modification.

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Internal	This unit is internal and cannot be modified
constant false	User	This unit is user-supplied and can be modified

Sample read command (note that :quantity and :unit are URL template arguments and need to be replaced before trying):

4.107.1.2 Name

string	config/known_quantities/S/units/S/name/
Unit name	

This string does not support direct modification if internal.

This string represents a value in persistent storage.

Sample read command (note that :quantity and :unit are URL template arguments and need to be replaced before trying):

Sample write command (note that :quantity and :unit are URL template arguments and need to be replaced before trying):

4.107.1.3 Offset

```
number config/known_quantities/S/units/S/offset/
Offset for conversion from standard SI unit
```

Changing the value is denied if not administrative user

This number does not support direct modification if internal.

This number represents a value in persistent storage.

Sample read command (note that :quantity and :unit are URL template arguments and need to be replaced before trying):

Sample write command (note that :quantity and :unit are URL template arguments and need to be replaced before trying):

4.107.1.4 Scaling factor

number	config/known_quantities/S/units/S/scale/
Scaling factor for conversion from standard SI unit	

4.108 Known timezones 223

Changing the value is denied if not administrative user

This number does not support direct modification if internal.

This number represents a value in persistent storage.

Sample read command (note that :quantity and :unit are URL template arguments and need to be replaced before trying):

Sample write command (note that :quantity and :unit are URL template arguments and need to be replaced before trying):

4.108 Known timezones

```
map | config/known_timezones/
Map of known time zones
```

Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map represents a value in persistent storage.

This map contains Timezone elements.

Sample read command:

Creating elements in this collection is not supported.

4.108.1 Timezone

string config/known_timezones/S/
Time zone name

Retrieving the value is denied if not administrative user

This string does not support direct modification.


This string represents a value in persistent storage.

Sample read command (note that :timezone is a URL template argument and needs to be replaced before trying):

4.109 Known protection bits

```
map config/known_protection_bits/

Map of known protection bits
```



Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map contains Protection bit elements.

Sample read command:

Creating elements in this collection is not supported.

4.109.1 Protection bit

object	config/known_protection_bits/S/	
Protecti	Protection bit properties	

Retrieving the value is denied if not administrative user

This object contains the following items:

name	Name
status	Protection status

Sample read command (note that :protection_bit is a URL template argument and needs to be replaced before trying):

Sample write command (note that :protection_bit is a URL template argument and needs to be replaced before trying):

See also Protection bit: Name

See also Protection bit: Protection status

4.110 Protection bit: Name

```
string config/known_protection_bits/S/name/
Protection bit name
```

This string does not support direct modification.

Sample read command (note that :protection_bit is a URL template argument and needs to be replaced before trying):

4.111 Protection bit: Protection status

sum (variant)	config/known_protection_bits/S/status/
Status of protection	

Retrieving the value is denied if not administrative user

This sum does not support direct modification.

This sum can change as if by itself or indirectly because of other actions.

Changes to this sum cannot be tracked.

This sum can assume the following values:

constant true	Enabled	Protection is enabled and effective
constant false	Disabled	Protection is disabled
string	Ineffective	Protection is enabled, but not effective for the following
		reason

Sample read command (note that :protection_bit is a URL template argument and needs to be replaced before trying):

 \Rightarrow (possible variant)

true

4.111.1 Ineffective

(possibly) string	config/known_protection_bits/S/status/
Protection is enabled, but not effective for the following reason	

4.112 Relay ports

array	config/relay_ports/	
List of	List of devices to which relay modules are connected	

This array does not support direct modification.

This array represents a value in persistent storage.

This array is expected to be visible to advanced users only.

This array contains Relay port elements.

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ 

→ restapi/config/relay_ports/"

⇒

[
"Sample value of relay port #1",
"Sample value of relay port #2",
"Sample value of relay port #3",
"Sample value of relay port #4",
"Sample value of relay port #5",
"Sample value of relay port #6",
"Sample value of relay port #7",
"Sample value of relay port #8",
"Sample value of relay port #8",
"Sample value of relay port #8",
"Sample value of relay port #9"
]
```

Creating elements in this collection is not supported.

4.112.1 Relay port

```
string config/relay_ports/N/
Filename of a relay module device
```

This string does not support direct modification.


This string represents a value in persistent storage.

This string is expected to be visible to advanced users only.

Sample read command (note that :relay_port is a URL template argument and needs to be replaced before trying):

5 Network configuration data

```
object network/
Data related to network state and configuration
```



Retrieving the value is denied if not administrative user

This object contains the following items:

wired	Wired network data
wireless	Wireless network data
same_subnet_only	Same subnet restriction
known_protocols	Known protocols
interface_order	Interface priority order
notifications	Notifications


Sample read command:

Sample write command:

5.1 Wired network data

5.1 Wired network data 229

```
object network/wired/
Data related to wired network state and configuration
```



Retrieving the value is denied if not administrative user

This object contains the following items:

mac_address	MAC address
online	Online
protocol	IP address assignment protocol
ip_address	IP address
netmask	Network mask
gateway	Default gateway IP address, if any
dns_servers	DNS servers
serve_dns	DNS server

Sample read command:

```
"Sample value of dns servers of dns server #3",

"Sample value of dns servers of dns server #4",

"Sample value of dns servers of dns server #5",

"Sample value of dns servers of dns server #6",

"Sample value of dns servers of dns server #7"

],

"mac_address": "Sample value of mac address",

"gateway": "Sample value of default gateway ip address, if any"
```

Sample write command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/network/wired/"
```

5.1.1 MAC address

```
string network/wired/mac_address/
MAC address to use for this interface
```

The value is subject to the following constraints: the value matches ^([0-9A-Fa-f]{2}:){5}[0-9A-Fa-f]{2}\$

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Changes to this string do not take effect immediately.

Sample read command:

Sample write command:

5.1.2 Online

sum (boolean)	network/wired/online/
Flag indicating t	he interface online status

5.1 Wired network data 231

Retrieving the value is denied if not administrative user

This sum does not support direct modification.

This sum can change as if by itself or indirectly because of other actions.

This sum can assume the following values:

constant true	Online	The interface is online
constant false	Offline	The interface is offline

Sample read command:

5.1.3 IP address assignment protocol

string	network/wired/protocol/	
Method	Method for obtaining an IP address for this interface	

The value is subject to the following constraints: known protocols[the value]

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Changes to this string do not take effect immediately.

Sample read command:

 \hookrightarrow : application/json" --data-binary "\"Sample value\"" "https \hookleftarrow

→ ://192.168.0.100/restapi/network/wired/protocol/"

```
5.1.4 IP address
```

```
string
        network/wired/ip address/
IP address to use for this interface
```

5]).){3}([0-9]|[1-9][0-9]|1[0-9]{2}|2[0-4][0-9]|25[0-5])\$

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string does not support direct modification if ip address assignment protocol is not equal to static.

This string represents a value in persistent storage.

This string can change as if by itself or indirectly because of other actions.

Changes to this string do not take effect immediately.

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←
   → restapi/network/wired/ip_address/"
\Rightarrow
"Sample value"
```

```
Sample write command:
```

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept ←
   → : application/json" --data-binary "\"Sample value\"" "https ←

→ ://192.168.0.100/restapi/network/wired/ip_address/"
```

5.1.5 Network mask

```
network/wired/netmask/
string
Network mask to use for this interface
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string does not support direct modification if ip address assignment protocol is not equal to static.

This string represents a value in persistent storage.

This string can change as if by itself or indirectly because of other actions.

Changes to this string do not take effect immediately.

Sample read command:

See also Wired network data: Default gateway IP address, if any

See also Wired network data: DNS servers

5.1.6 DNS server

sum (boolean)	network/wired/serve_dns/
Respond to DNS queries	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

Changes to this sum do not take effect immediately.

This sum can assume the following values:

Ì	constant true	Enabled	The feature is enabled
	constant false	Disabled	The feature is disabled

Sample read command:

Sample (possible variant) write command:

5.2 Wired network data: Default gateway IP address, if any

sum (optional string)	network/wired/gateway/
The IP address to send packets which are not targeted to local networks, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum does not support direct modification if ip address assignment protocol is not equal to static.

This sum represents a value in persistent storage.

This sum can change as if by itself or indirectly because of other actions.

Changes to this sum do not take effect immediately.

This sum can assume the following values:

constant null	No default gateway	Packets with nonlocal destination	on are dropped
string	Default gateway IP address	The IP address to send packets which are not targeted to local networks	the value matches ^(([0-9] [1-9][0-9] 1[0-9]{2} 2[0-4][0-9] 25[0-5]).){3}([0-9] [1-9][0-9] 1[0-9]{2} 2[0-4][0-9] 25[0-5])\$

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftrightarrow restapi/network/wired/gateway/"
```

\Rightarrow (possible variant)

"Sample value"

Sample (possible variant) write command:

5.2.1 Default gateway IP address

```
(possibly) string network/wired/gateway/
The IP address to send packets which are not targeted to local networks
```

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow: application/json" --data-binary "\"Sample value\"" "https \leftrightarrow: //192.168.0.100/restapi/network/wired/gateway/"
```

5.3 Wired network data: DNS servers

```
array network/wired/dns_servers/
List of DNS server IP addresses
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This array does not support direct modification if ip address assignment protocol is not equal to static.

This array represents a value in persistent storage.

This array can change as if by itself or indirectly because of other actions.

Changes to this array do not take effect immediately.

This array contains DNS server elements.

Sample read command:

Sample write command:

Sample dns server creation command:

5.3.1 DNS server

```
string network/wired/dns_servers/N/
DNS server IP address
```

The value is subject to the following constraints: the value matches (([0-9]|[1-9][0-9]|1[0-9][2]|2[0-4][0-9]|25[0-5]).)(3)([0-9]|[1-9][0-9]|1[0-9][2]|2[0-4][0-9]|25[0-5])

Sample read command (note that :dns_server is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/network/wired/dns_servers/:dns_server/"
```


```
⇒
"Sample value"
```

Sample write command (note that :dns_server is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :dns_server is a URL template argument and needs to be replaced before trying):

5.4 Wireless network data

object	network/wireless/	
Data re	Data related to wireless network state and configuration	



Retrieving the value is denied if not administrative user

This object contains the following items:

enabled	Enable wireless module
online	Online
mac_address	MAC address
protocol	IP address assignment protocol
ip_address	IP address
netmask	Network mask
gateway	Default gateway IP address, if any
dns_servers	DNS servers
serve_dns	DNS server
mode	Mode
known_modes	Known modes
ssid	SSID
channel	Wireless channel
known_channels	Known channels
encryption	Encryption
known_encryptions	Known encryptions
key	Key
wac_supported	Wireless Accessory Configuration supported
wac_enabled	Wireless Accessory Configuration enabled

Sample read command:

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "..." "https://192.168.0.100/restapi/ \leftrightarrow network/wireless/"
```

5.4.1 Enable wireless module

sum (boolean)	network/wireless/enabled/
Flag indicating whether the wireless module is enabled	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

Changes to this sum do not take effect immediately.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command:

Sample (possible variant) write command:

5.4.2 Online

true

sum (boolean)	network/wireless/online/
Flag indicating the interface online status	

Retrieving the value is denied if not administrative user

This sum does not support direct modification.

This sum can change as if by itself or indirectly because of other actions.

This sum can assume the following values:

constant true	Online	The interface is online
constant false	Offline	The interface is offline

Sample read command:

5.4.3 MAC address

false

string	network/wireless/mac_address/	
MAC a	MAC address to use for this interface	

The value is subject to the following constraints: the value matches ^([0-9A-Fa-f]{2}:){5}[0-9A-Fa-f]{2}\$

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

5.4 Wireless network data 239

This string represents a value in persistent storage.

Changes to this string do not take effect immediately.

Sample read command:

5.4.4 IP address assignment protocol

```
string network/wireless/protocol/

Method for obtaining an IP address for this interface
```

The value is subject to the following constraints: known protocols[the value]

→ ://192.168.0.100/restapi/network/wireless/mac_address/"

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Changes to this string do not take effect immediately.

Sample read command:

Sample write command.

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow : application/json" --data-binary "\"Sample value\"" "https \hookleftarrow ://192.168.0.100/restapi/network/wireless/protocol/"
```

5.4.5 IP address

```
string network/wireless/ip_address/
IP address to use for this interface
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string does not support direct modification if ip address assignment protocol is not equal to static.

This string represents a value in persistent storage.

This string can change as if by itself or indirectly because of other actions.

→ ://192.168.0.100/restapi/network/wireless/ip_address/"

Changes to this string do not take effect immediately.

Sample read command:

5.4.6 Network mask

```
string network/wireless/netmask/
Network mask to use for this interface
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string does not support direct modification if ip address assignment protocol is not equal to static.

This string represents a value in persistent storage.

This string can change as if by itself or indirectly because of other actions.

Changes to this string do not take effect immediately.

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/network/wireless/netmask/"
```

 \Rightarrow

5.4 Wireless network data 241

```
"Sample value"
```

Sample write command:

See also Wireless network data: Default gateway IP address, if any

See also Wireless network data: DNS servers

5.4.7 DNS server

sum (boolean)	sum (boolean) network/wireless/serve_dns/	
Respond to DNS queries		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

Changes to this sum do not take effect immediately.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command:

\Rightarrow (possible variant)

false

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "true" "https://192.168.0.100/restapi/ \hookleftarrow network/wireless/serve_dns/"
```

5.4.8 Mode

```
string network/wireless/mode/
Wireless module mode
```

The value is subject to the following constraints: known modes[the value]

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Changes to this string do not take effect immediately.

Sample read command:

See also Wireless network data: Known modes

5.4.9 SSID

```
string network/wireless/ssid/
SSID (wireless network name) to use
```

The value is subject to the following constraints: length of the value is less or equal to 32

→ ://192.168.0.100/restapi/network/wireless/ssid/"

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Changes to this string do not take effect immediately.

Sample read command:

5.4.10 Wireless channel

5.4 Wireless network data 243

string network/wireless/channel/
Wireless channel to use

The value is subject to the following constraints: known channels[the value]

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Changes to this string do not take effect immediately.

Sample read command:

See also Wireless network data: Known channels

5.4.11 Encryption

string	network/wireless/encryption/	
Wireles	Wireless encryption to use	

The value is subject to the following constraints: known encryptions[the value]

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Changes to this string do not take effect immediately.

Sample read command:

Sample write command:

See also Wireless network data: Known encryptions

5.4.12 Key

```
string network/wireless/key/
Encryption key
```

The value is subject to the following constraints: any of the following is true:

- all of the following is true:
 - length of the value is greater or equal to 8
 - length of the value is less or equal to 63
- · encryption is equal to none

Retrieving the value is denied if any of the following is true:

- · not administrative user
- · hide wifi key

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Changes to this string do not take effect immediately.

This string should be displayed in a secure manner.

Sample read command:

5.4.13 Wireless Accessory Configuration supported

→ ://192.168.0.100/restapi/network/wireless/key/"

5.4 Wireless network data 245

sum (boolean)	network/wireless/wac_supported/	
Flag indicating	Flag indicating device support for Wireless Accessory Configuration	

Retrieving the value is denied if not administrative user

This sum does not support direct modification.

This sum can assume the following values:

constant true	Supported	The device supports WAC
constant false	Not supported	The device does not support WAC

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftrightarrow restapi/network/wireless/wac_supported/"
```

 \Rightarrow (possible variant)

false

5.4.14 Wireless Accessory Configuration enabled

sum (boolean) network/wireless/wac_enabled/		
Flag indicating whether Wireless Accessory Configuration is currently active (any manual changes automatically		
disable it)		

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · not wireless accessory configuration supported

This sum can change as if by itself or indirectly because of other actions.

Changes to this sum cannot be tracked.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/network/wireless/wac_enabled/"
```

⇒ (possible variant)

true

Sample (possible variant) write command:

5.5 Wireless network data: Default gateway IP address, if any

sum (optional string)	network/wireless/gateway/
The IP address to send packets which are not targeted to local networks, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum does not support direct modification if ip address assignment protocol is not equal to static.

This sum represents a value in persistent storage.

This sum can change as if by itself or indirectly because of other actions.

Changes to this sum do not take effect immediately.

This sum can assume the following values:

constant null	No default gateway	Packets with nonlocal destination	on are dropped
string	Default gateway IP address	The IP address to send packets which are not targeted to local networks	the value matches ^(([0-9] [1-9][0-9] 1[0-9]{2} 2[0-4][0-9] 25[0-5]).){3}([0-9] [1-9][0-9] 1[0-9]{2} 2[0-4][0-9] 25[0-5])\$

Sample read command:

\Rightarrow (possible variant)

null

Sample (possible variant) write command:

5.5.1 Default gateway IP address

(possibly) string	network/wireless/gateway/		
The IP address to	o send packets which are not targeted to local networks		

Sample write command:

5.6 Wireless network data: DNS servers

```
array network/wireless/dns_servers/
List of DNS server IP addresses
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This array does not support direct modification if ip address assignment protocol is not equal to static.

This array represents a value in persistent storage.

This array can change as if by itself or indirectly because of other actions.

Changes to this array do not take effect immediately.

This array contains DNS server elements.

Sample read command:

Sample write command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "[\"Sample value of dns server #1\",\"Sample value of dns server \(
\to \display \text{2\",\"Sample value of dns server #3\",\"Sample value of dns server #4\"]"\
"https://192.168.0.100/restapi/network/wireless/dns_servers/"
```

Sample dns server creation command:

5.6.1 DNS server

```
string network/wireless/dns_servers/N/
DNS server IP address
```

Sample read command (note that :dns_server is a URL template argument and needs to be replaced before trying):

Sample write command (note that :dns_server is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :dns_server is a URL template argument and needs to be replaced before trying):

5.7 Wireless network data: Known modes

```
map network/wireless/known_modes/
Known wireless modes
```

Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map contains Mode elements.

Sample read command:

Creating elements in this collection is not supported.

5.7.1 Mode

```
string network/wireless/known_modes/S/
Name of wireless mode
```

Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :mode is a URL template argument and needs to be replaced before trying):

5.8 Wireless network data: Known channels

```
map network/wireless/known_channels/
Known wireless channels
```

Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map contains Channel elements.

Sample read command:

Creating elements in this collection is not supported.

5.8.1 Channel

string	network/wireless/known_channels/S/
Name of wireless channel	

Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :channel is a URL template argument and needs to be replaced before trying):

5.9 Wireless network data: Known encryptions

```
map network/wireless/known_encryptions/
Known wireless encryptions
```

Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map contains **Encryption** elements.

Sample read command:

Creating elements in this collection is not supported.

5.9.1 Encryption

```
string network/wireless/known_encryptions/S/
Name of wireless encryption
```

Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :encryption is a URL template argument and needs to be replaced before trying):

5.10 Same subnet restriction

sum (boolean)	network/same_subnet_only/	
Reject incoming	Reject incoming connections from networks other than local subnets	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

Changes to this sum do not take effect immediately.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command:

true

Sample (possible variant) write command:

5.11 Known protocols

```
map network/known_protocols/
Known IP address assignment protocols
```

Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map contains Protocol elements.

Sample read command:

Creating elements in this collection is not supported.

5.11.1 Protocol

```
string network/known_protocols/S/
Name of IP address assignment protocol
```

Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :protocol is a URL template argument and needs to be replaced before trying):

5.12 Interface priority order

```
array network/interface_order/
The order of preference in which interfaces will be used
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This array contains Interface order element elements.

Sample read command:

Sample write command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/network/interface_order/"
```

5.13 Notifications 253

Sample interface order element creation command:

```
curl --digest -u admin:1234 -H "Content-type: application/json" -H "Accept: \longleftrightarrow application/json" --data-binary "\"Sample value\"" "https://192.168.0.100/ \longleftrightarrow restapi/network/interface_order/"
```

5.12.1 Interface order element

sum (enumerated string)	network/interface_order/N/
Element of the interface preference order	

This sum can assume the following values:

constant "wired"	Wired	Wired network interface
constant "wireless"	Wireless	Wireless network interface

Sample read command (note that :interface_order_element is a URL template argument and needs to be replaced before trying):


Sample (possible variant) write command (note that :interface_order_element is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :interface_order_element is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X DELETE -H "Accept: application/json" "https \leftrightarrow ://192.168.0.100/restapi/network/interface_order/:interface_order_element/"
```

5.13 Notifications

object	network/notifications/
Network interface status notifications	



This object does not support direct modification.


This object contains the following items:

events	Events
parameter_kinds	Parameter kinds

Sample read command:

5.13.1 Events

map	network/notifications/events/	
Event	Event templates	



This map does not support direct modification.

This map contains **Event** elements.

Sample read command:

Creating elements in this collection is not supported.

See also Events: Event

See also Notifications: Parameter kinds

5.14 Message template: Message template element

sum (variant)	network/notifications/events/S/message_template/N/
Element of human-readable message template	

This sum does not support direct modification.

This sum can assume the following values:

string	String	Fixed string	
number	Parameter	Index of message parameter to insert	event parameters[the value]

Sample read command (note that :event and :message_template_element are URL template arguments and need to be replaced before trying):

5.14.1 String

(possibly) string	network/notifications/events/S/message_template/N/
Fixed string	

5.14.2 Parameter

(possibly) number	network/notifications/events/S/message_template/N/
Index of message parameter to insert	

The value is subject to the following constraints: event parameters[the value]

5.15 Event parameter: Fixed value

sum (variant)	network/notifications/events/S/parameters/N/fixed_value/	
Fixed paramet	Fixed parameter value for this particular event	

This sum does not support direct modification.

This sum can assume the following values:

constant null	Null	Null
constant true	True	True
constant false	False	False
string	String	This string
number	Number	This number

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

5.15.1 String

(possibly) string	network/notifications/events/S/parameters/N/fixed_value/
This string	

5.15.2 Number

(possibly) number	network/notifications/events/S/parameters/N/fixed_value/
This number	

5.16 Event parameter: Fixed value flag

sum (boolean)	network/notifications/events/S/parameters/N/has_fixed_value/		
Flag indicating that the parameter's value for this event is fixed			

This sum does not support direct modification.

This sum can assume the following values:

constant true	Fixed	The value is fixed	
constant false	Variable	The value is variable	

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

5.17 Event parameter: Identifier

```
string network/notifications/events/S/parameters/N/id/
Parameter identifier
```

The value is subject to the following constraints: parameter kinds


This string does not support direct modification.

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

5.18 Events: Event

```
object network/notifications/events/S/

Event template
```



This object contains the following items:

message_template	Message template
parameters	Event parameters
severity	Severity

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

Sample write command (note that :event is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/network/notifications/events/:event/"
```

5.18.1 Message template

5.18 Events: Event 259

```
array network/notifications/events/S/message_template/

Template for human-readable message generation
```

This array does not support direct modification.

This array contains Message template element elements.


Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

Creating elements in this collection is not supported.

See also Message template: Message template element

5.18.2 Event parameters

```
array network/notifications/events/S/parameters/
Additional data associated with the event
```



This array does not support direct modification.

This array contains **Event parameter** elements.

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

Creating elements in this collection is not supported.

5.18.2.1 Event parameter

object	network/notifications/events/S/parameters/N/	
Properties of a parameter associated with the event		

This object contains the following items:

fixed_value	Fixed value
has_fixed_value	Fixed value flag
id	Identifier

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

Sample write command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
```

See also Event parameter: Fixed value

See also Event parameter: Fixed value flag

See also Event parameter: Identifier

5.18.3 Severity

sum (enumerated number)	network/notifications/events/S/severity/
Severity rating assigned to the event	

This sum does not support direct modification.

This sum can assume the following values:

constant 1	Emergency	Treat the event as an emergency
constant 2	Alert	Treat the event as an alert
constant 3	Critical	Treat the event as critical
constant 4	Error	Treat the event as an error
constant 5	Warning	Treat the event as a warning
constant 6	Notice	Treat the event as a notice
constant 7	Informational	Treat the event as informational
constant 8	Debug	Treat the event as debugging-related

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

5.19 Notifications: Parameter kinds

object	bject network/notifications/parameter_kinds/	
Kinds o	Kinds of event parameters	

This object does not correspond to an actual resource.

This object contains the following items:

network_device	Device name
network_link←	Device index
_id	
network_up	Status

5.19.1 Device name

string	network/notifications/parameter_kinds/network_device/	
Low-lev	Low-level network interface name	

Sample read command:

Sample write command:

5.19.2 Device index

number	nber network/notifications/parameter_kinds/network_link_id/	
Low-leve	Low-level network interface index	

The value is subject to the following constraints: the value is an integer

Sample read command:

Sample write command:

5.19.3 Status

sum (boolean)	sum (boolean) network/notifications/parameter_kinds/network_up/	
Network interfac	Network interface status	

This sum can assume the following values:

constant true	Up	The network interface is connected
constant false	Down	The network interface is disconnected

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftrightarrow restapi/network/notifications/parameter_kinds/network_up/"
```


\Rightarrow (possible variant)

false

Sample (possible variant) write command:

6 Event notification server object

object	object notification/	
Object i	representing the event notification server configuration	



This object contains the following items:

sinks	Sinks
rules	Rules
known_sink_types	Sink types
sink_data_item_groups	Sink data item groups


Sample read command:

Sample write command:

6.1 Sinks

6.1 Sinks 265

```
array notification/sinks/
Sink array
```



Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This array represents a value in persistent storage.

This array contains Sink elements.

Sample read command:


Sample write command:

Sample sink creation command:

```
curl\
--digest\
-u admin:1234\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"type\":\"Sample value of type\",\"name\":\"Sample value of name \( \to \) \",\"data\":\"\sample value of data of data item data_2\",\" \( \to \) \data_1\":\"Sample value of data of data item data_1\"}\"\"https://192.168.0.100/restapi/notification/sinks/"
```

6.1.1 Sink

object	notification/sinks/N/	
Event s	Event sink	



Retrieving the value is denied if not administrative user

This object represents a value in persistent storage.

This object contains the following items:

data	Data
name	Name
test	Test
type	Type

6.2 Sink: Data 267

Sample read command (note that :sink is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←
   → restapi/notification/sinks/:sink/"
\Rightarrow
"type": "Sample value of type",
"name": "Sample value of name",
"data":{
 "data_9": "Sample value of data of data item data_9",
 "data_7":"Sample value of data of data item data_7",
 "data_2": "Sample value of data of data item data_2",
 "data_8": "Sample value of data of data item data_8",
 "data_5": "Sample value of data of data item data_5",
 "data_3": "Sample value of data of data item data_3",
 "data_4": "Sample value of data of data item data_4",
 "data_1": "Sample value of data of data item data_1"
 "data_6": "Sample value of data of data item data_6"
}
```

Sample write command (note that :sink is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/notification/sinks/:sink/"
```

Sample deletion command (note that :sink is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X DELETE -H "Accept: application/json" "https \leftrightarrow ://192.168.0.100/restapi/notification/sinks/:sink/"
```

See also Sink: Data

See also Sink: Name

See also Sink: Test

See also Sink: Type

6.2 Sink: Data

```
map notification/sinks/N/data/
Sink-type-specific data
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

· not administrative user

protect notification settings

This map represents a value in persistent storage.

This map contains Data item elements.

Sample read command (note that :sink is a URL template argument and needs to be replaced before trying):

Sample write command (note that :sink is a URL template argument and needs to be replaced before trying):

Sample data item creation command (note that :sink is a URL template argument and needs to be replaced before trying):

6.2.1 Data item

```
string notification/sinks/N/data/S/

Item of sink-type-specific data
```

The value is subject to the following constraints: the value matches sink types[type].data_items[index of the value].regexp

Retrieving the value is denied if any of the following is true:

not administrative user

6.3 Sink: Name 269

- · all of the following is true:
 - index of the value is not equal to ""
 - sink data item groups[sink types[type].data_items[index of the value].group].unreadable

Changing the value is denied if any of the following is true:

- · not administrative user
- · all of the following is true:
 - index of the value is not equal to ""
 - sink data item groups[sink types[type].data_items[index of the value].group].immutable

Using the string as a field for indexing into the grandparent collection is denied if any of the following is true:

- · not administrative user
- · all of the following is true:
 - index of the value is not equal to ""
 - sink data item groups[sink types[type].data_items[index of the value].group].secret

This string represents a value in persistent storage.

This string should be displayed in a secure manner if all of the following is true:

- · index of the value is not equal to ""
- sink data item groups[sink types[type].data_items[index of the value].group].secret

Sample read command (note that :sink and :data_item are URL template arguments and need to be replaced before trying):

Sample write command (note that :sink and :data_item are URL template arguments and need to be replaced before trying):

Sample deletion command (note that :sink and :data_item are URL template arguments and need to be replaced before trying):

```
curl --digest -u admin:1234 -X DELETE -H "Accept: application/json" "https \leftrightarrow ://192.168.0.100/restapi/notification/sinks/:sink/data/:data_item/"
```

6.3 Sink: Name

```
string notification/sinks/N/name/
Sink name (can be shared between sinks)
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect notification settings

This string represents a value in persistent storage.

Sample read command (note that :sink is a URL template argument and needs to be replaced before trying):

Sample write command (note that :sink is a URL template argument and needs to be replaced before trying):

6.4 Sink: Test

```
call notification/sinks/N/test/
Send a test notification using this sink
```

Performing the function call is denied if not administrative user

The call has no arguments (supply empty tuple).

The call returns no results (expect an empty tuple).

Sample invocation (note that :sink is a URL template argument and needs to be replaced before trying):

6.5 Sink: Type

6.6 Rules 271

```
string notification/sinks/N/type/
Sink type
```

The value is subject to the following constraints: sink types[the value]

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect notification settings


This string represents a value in persistent storage.

Sample read command (note that :sink is a URL template argument and needs to be replaced before trying):

Sample write command (note that :sink is a URL template argument and needs to be replaced before trying):

6.6 Rules

```
array notification/rules/
Event processing rule list
```



Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect notification settings

This array represents a value in persistent storage.

This array contains Rule elements.

Sample read command:

Sample write command:

6.7 Rules: Rule 273

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/notification/rules/"
```

Sample rule creation command:

See also Rules: Rule

6.7 Rules: Rule

object	notification/rules/N/	
Event processing rule		

Retrieving the value is denied if not administrative user

This object represents a value in persistent storage.

This object contains the following items:

condition	Rule condition
action	Rule action

Sample read command (note that :rule is a URL template argument and needs to be replaced before trying):

Sample write command (note that :rule is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :rule is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X DELETE -H "Accept: application/json" "https \leftrightarrow ://192.168.0.100/restapi/notification/rules/:rule/"
```

6.7.1 Rule condition

```
string notification/rules/N/condition/

Lua expression to evaluate for events to be matched
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect notification settings

This string represents a value in persistent storage.

Sample read command (note that :rule is a URL template argument and needs to be replaced before trying):

Sample write command (note that :rule is a URL template argument and needs to be replaced before trying):

6.7.2 Rule action

```
string notification/rules/N/action/
Lua code to evaluate for matching events
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect notification settings

This string represents a value in persistent storage.


Sample read command (note that :rule is a URL template argument and needs to be replaced before trying):

6.8 Sink types 275

Sample write command (note that :rule is a URL template argument and needs to be replaced before trying):

6.8 Sink types

```
map notification/known_sink_types/
Known sink types
```



Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map contains Sink type elements.

Sample read command:

Creating elements in this collection is not supported.

6.8.1 Sink type

```
object notification/known_sink_types/S/

Type of sink
```

```
Sink type

data_items:Supported data items
name:Name

Supported data items
[element]:Data item properties
```

Retrieving the value is denied if not administrative user

This object contains the following items:

data_items	Supported data items
name	Name

Sample read command (note that :sink_type is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←

→ restapi/notification/known_sink_types/:sink_type/"

\Rightarrow
"name": "Sample value of name",
"data_items":{
 "supported_data_items_1":{
  "group": "Sample value of data item group",
  "name": "Sample value of name",
  "regexp": "Sample value of regular expression"
 },
 "supported_data_items_2":{
  "group": "Sample value of data item group",
  "name": "Sample value of name",
  "regexp": "Sample value of regular expression"
}
}
```

Sample write command (note that :sink_type is a URL template argument and needs to be replaced before trying):


```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/notification/known_sink_types/:sink_type/"
```

See also Sink type: Supported data items

See also Sink type: Name

6.9 Sink type: Supported data items

map	notification/known_sink_types/S/data_items/	
Prope	Properties of supported data items	



Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map contains Data item properties elements.

Sample read command (note that :sink_type is a URL template argument and needs to be replaced before trying):

Creating elements in this collection is not supported.

6.9.1 Data item properties

object	notification/known_sink_types/S/data_items/S/
Properties of data item	

This object contains the following items:

name	Name
group	Data item group
regexp	Regular expression

Sample read command (note that :sink_type and :data_item_properties are URL template arguments and need to be replaced before trying):

Sample write command (note that :sink_type and :data_item_properties are URL template arguments and need to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"group\":\"Sample value of data item group\",\"name\":\"Sample \\
\to value of name\",\"regexp\":\"Sample value of regular expression\"}"\
"https://192.168.0.100/restapi/notification/known_sink_types/:sink_type/ \\
\to data_items/:data_item_properties/"
```

6.9.1.1 Name

```
string notification/known_sink_types/S/data_items/S/name/

Data item name
```

Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :sink_type and :data_item_properties are URL template arguments and need to be replaced before trying):

6.9.1.2 Data item group

```
string notification/known_sink_types/S/data_items/S/group/
The group of data items to which this one belongs
```

The value is subject to the following constraints: sink data item groups[the value]

Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :sink_type and :data_item_properties are URL template arguments and need to be replaced before trying):

6.9.1.3 Regular expression

```
string notification/known_sink_types/S/data_items/S/regexp/

Regular expression which the data item must match
```

Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :sink_type and :data_item_properties are URL template arguments and need to be replaced before trying):

6.10 Sink type: Name

```
string notification/known_sink_types/S/name/
Sink type name
```


Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :sink_type is a URL template argument and needs to be replaced before trying):

6.11 Sink data item groups

map	notification/sink_data_item_groups/	
Prope	Properties of groups of sink data items	



Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map contains Sink data item group elements.

Sample read command:

Creating elements in this collection is not supported.

See also Sink data item groups: Sink data item group

6.12 Sink data item groups: Sink data item group

object	object notification/sink_data_item_groups/S/	
Propert	Properties of a group of sink data items	

Retrieving the value is denied if not administrative user

This object contains the following items:

immutable	Immutable
name	Name
secret	Secret
unreadable	Unreadable

Sample read command (note that :sink_data_item_group is a URL template argument and needs to be replaced before trying):

Sample write command (note that :sink_data_item_group is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"immutable\":false,\"unreadable\":true,\"name\":\"Sample value \( \to \)
\( \to \) of name\",\"secret\":true\"\
"https://192.168.0.100/restapi/notification/sink_data_item_groups/: \( \to \) \( \to \) sink_data_item_group/"
```

6.12.1 Immutable

sum (boolean)	notification/sink_data_item_groups/S/immutable/
Flag indicating whether the data item is not permitted to be changed	

Retrieving the value is denied if not administrative user

This sum does not support direct modification.

This sum can assume the following values:

constant true	Immutable	The data item is not permitted to be changed
constant false	Not immutable	The data item can be changed

Sample read command (note that :sink_data_item_group is a URL template argument and needs to be replaced before trying):

6.12.2 Name

string	notification/sink_data_item_groups/S/name/	
Data ite	Data item group name	

Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :sink_data_item_group is a URL template argument and needs to be replaced before trying):

6.12.3 Secret

sum (boolean)	notification/sink_data_item_groups/S/secret/
Flag indicating whether the data item can contain private information	

Retrieving the value is denied if not administrative user

This sum does not support direct modification.

This sum can assume the following values:

constant true	Secret	The data item can contain private information
constant false	Not secret	The data item contains only public information

Sample read command (note that :sink_data_item_group is a URL template argument and needs to be replaced before trying):

true

6.12.4 Unreadable

sum (boolean)	notification/sink_data_item_groups/S/unreadable/
Flag indicating whether the data item is not permitted to be read	

Retrieving the value is denied if not administrative user

This sum does not support direct modification.

This sum can assume the following values:


constant true	Unreadable	The data item is not permitted to be read
constant false	Not unreadable	The data item can be read

Sample read command (note that :sink_data_item_group is a URL template argument and needs to be replaced before trying):

7 Autoping server object

object	autoping/
Object representing the autoping server state and configuration	

7.1 Enabled 285



This object contains the following items:

enabled	Enabled
items	Items
ping_interval	Ping interval
ping_timeout	Ping timeout
post_reboot_delay	Post-reboot delay
max_reboot_count	Default maximum total reboot count, if any
pings_before_enabling	Pings before enabling
resume_without_retrial	Resume without retrial
handle_failures_immediately	Handle failures immediately
reset_statistics	Reset statistics
notifications	Notifications
max_consecutive_reboot_count	Default maximum consecutive reboot count, if any

Sample read command:

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "..." "https://192.168.0.100/restapi/ \leftrightarrow autoping/"
```

7.1 Enabled

sum (boolean)	autoping/enabled/
Autoping global enable status	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/autoping/enabled/"
```


\Rightarrow (possible variant)

false

Sample (possible variant) write command:

7.2 Items

array	autoping/items/
Autopii	ng item list



Retrieving the value is denied if not administrative user

7.2 Items 287

Changing the value is denied if not administrative user

This array represents a value in persistent storage.

This array contains Autoping item data elements.

Sample read command:

Sample write command:


Sample autoping item data creation command:

```
curl --digest -u admin:1234 -H "Content-type: application/json" -H "Accept: \leftrightarrow application/json" --data-binary "..." "https://192.168.0.100/restapi/ \leftrightarrow autoping/items/"
```

7.2.1 Autoping item data

```
object autoping/items/N/

Data related to autoping item state and configuration
```



Retrieving the value is denied if not administrative user

This object contains the following items:

enabled	Enabled status
addresses	Address list
outlets	Controlled outlets
script	Script command, if any
enable	Request item state change
status	Autoping item status
pings_before_enabling	Pings remaining to enable, if any
recently_failed	Recently failed
resumption_trial	In resumption trial

Sample read command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

Sample write command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

See also Autoping item data: Enabled status

See also Autoping item data: Address list

See also Autoping item data: Controlled outlets

See also Autoping item data: Script command, if any

See also Autoping item data: Request item state change

See also Autoping item data: Autoping item status

See also Autoping item data: Pings remaining to enable, if any

See also Autoping item data: Recently failed

See also Autoping item data: In resumption trial

7.3 Autoping item data: Enabled status

sum (boolean) autoping/items/N/enabled/		autoping/items/N/enabled/
Whether this item is enabled (can be triggered)		

Retrieving the value is denied if not administrative user

This sum does not support direct modification.

This sum represents a value in persistent storage.

This sum can change as if by itself or indirectly because of other actions.

This sum can assume the following values:

constant true	Enabled	The feature is enabled	
constant false	Disabled	The feature is disabled	

Sample read command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/autoping/items/:autoping_item_data/enabled/"
```

⇒ (possible variant)

true

7.4 Autoping item data: Address list

```
array autoping/items/N/addresses/
List of addresses to ping
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This array represents a value in persistent storage.

This array represents an unordered set (order of its elements doesn't matter, and each value should not be supplied more than once).

This array contains Address elements.

Sample read command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

Sample write command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

Sample address creation command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

7.4.1 Address

```
string autoping/items/N/addresses/N/
URL to ping (default schema is icmp)
```

The value is subject to the following constraints: address list are distinct

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Sample read command (note that :autoping_item_data and :address are URL template arguments and need to be replaced before trying):

Sample write command (note that :autoping_item_data and :address are URL template arguments and need to be replaced before trying):

Sample deletion command (note that :autoping_item_data and :address are URL template arguments and need to be replaced before trying):

7.5 Autoping item data: Controlled outlets

```
array autoping/items/N/outlets/
List of outlets to perform specified action on
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This array represents a value in persistent storage.

This array represents an unordered set (order of its elements doesn't matter, and each value should not be supplied more than once).

This array contains Outlet index elements.

Sample read command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

```
[
4
1
```

Sample write command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

Sample outlet index creation command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

7.5.1 Outlet index

```
number | autoping/items/N/outlets/N/
Index of outlet to perform action on
```

The value is subject to the following constraints: all of the following is true:

- outlets[the value]
- · controlled outlets are distinct

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command (note that :autoping_item_data and :outlet_index are URL template arguments and need to be replaced before trying):

Sample write command (note that :autoping_item_data and :outlet_index are URL template arguments and need to be replaced before trying):

Sample deletion command (note that :autoping_item_data and :outlet_index are URL template arguments and need to be replaced before trying):

7.6 Autoping item data: Script command, if any

sum (string)	autoping/items/N/script/
Action to perform on selected outlets on failure, or cycle them if empty	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

string	Script command	Action to perform on selected outlets on failure	all of the following is true: • not the value matches ^(.* .*)\$ • user functions[the value]
string	Invalid action placeholder	A placeholder for a failure action that has been deleted or renamed (has no effect other than logging a warning)	the value matches ^autoping_← deleted:.*\$
constant ""	Cycle outlets	Selected outlets are to be cycled o	on failure

Sample read command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

7.6.1 Script command

(possibly) string	autoping/items/N/script/
Action to perform on selected outlets on failure	

The value is subject to the following constraints: all of the following is true:

- not the value matches ^(|.*|.*)\$
- user functions[the value]

Sample write command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

7.6.2 Invalid action placeholder

```
(possibly) string autoping/items/N/script/

A placeholder for a failure action that has been deleted or renamed (has no effect other than logging a warning)
```

The value is subject to the following constraints: the value matches ^autoping deleted:.*\$

Sample write command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

7.7 Autoping item data: Request item state change

```
call autoping/items/N/enable/
```

Request the item to enter enabled or disabled status. Disabled status is entered immediately. If the item is disabled, enabling it is not immediate (takes a trial period).

Performing the function call is denied if not administrative user

The call accepts the following arguments:

1. Enabled or Disabled

The call returns no results (expect an empty tuple).

Sample invocation (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

7.7.1 Desired item state

```
sum (boolean) autoping/items/N/enable/arguments: 1/
The state you request the item to switch to
```

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

7.8 Target states: Target state

object	autoping/items/N/status/hosts/N/	
State of	State of a target subjected to ping	

This object contains the following items:

address	Address
state	State
success_count	Success count
failure_count	Failure count
queue_size	Queue size

Sample read command (note that :autoping_item_data and :target_state are URL template arguments and need to be replaced before trying):

Sample write command (note that :autoping_item_data and :target_state are URL template arguments and need to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"state\":true,\"success_count\":8,\"address\":\"Sample value of \( \to \) address\",\"failure_count\":1,\"queue_size\":4}"\
"https://192.168.0.100/restapi/autoping/items/:autoping_item_data/status/hosts/: \( \to \) target_state/"
```

7.8.1 Address

string	autoping/items/N/status/hosts/N/address/	
Address that is being checked (default schema is icmp)		

The value is subject to the following constraints: address members of all values of target states are distinct

This string does not support direct modification.

This string can change as if by itself or indirectly because of other actions.

Changes to this string cannot be tracked.

Sample read command (note that :autoping_item_data and :target_state are URL template arguments and need to be replaced before trying):

7.8.2 State

sum (optional boolean)	autoping/items/N/status/hosts/N/state/
Target perceived state	

Retrieving the value is denied if not administrative user

This sum does not support direct modification.

This sum can change as if by itself or indirectly because of other actions.

Changes to this sum cannot be tracked.

This sum can assume the following values:

constant true	Online	The target is responding to ping requests
constant false	Offline	The target is not responding to ping requests
constant null	Unknown	Not enough information about target state

Sample read command (note that :autoping_item_data and :target_state are URL template arguments and need to be replaced before trying):

7.8.3 Success count

number	autoping/items/N/status/hosts/N/success_count/	
Number of times this target has responded to a ping request in time		

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- the value is greater or equal to 0

Retrieving the value is denied if not administrative user

This number does not support direct modification.

This number can change as if by itself or indirectly because of other actions.

Changes to this number cannot be tracked.

Sample read command (note that :autoping_item_data and :target_state are URL template arguments and need to be replaced before trying):

7.8.4 Failure count

```
number | autoping/items/N/status/hosts/N/failure_count/

Number of times this target has failed to respond to a ping request in time
```

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater or equal to 0

Retrieving the value is denied if not administrative user

This number does not support direct modification.

This number can change as if by itself or indirectly because of other actions.

Changes to this number cannot be tracked.

Sample read command (note that :autoping_item_data and :target_state are URL template arguments and need to be replaced before trying):

7.8.5 Queue size

number | autoping/items/N/status/hosts/N/queue size/

Number of ping requests to which no replies have yet been received (0 if the parent ping item is not enabled)

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- the value is greater or equal to 0

Retrieving the value is denied if not administrative user

This number does not support direct modification.


This number can change as if by itself or indirectly because of other actions.

Changes to this number cannot be tracked.

Sample read command (note that :autoping_item_data and :target_state are URL template arguments and need to be replaced before trying):

7.9 Autoping item data: Autoping item status

```
object | autoping/items/N/status/
Information on monitored target status and reboots
```



Retrieving the value is denied if not administrative user

This object contains the following items:


hosts	Target states
reboots	Reboot count

Sample read command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

Sample write command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

7.9.1 Target states

array	autoping/items/N/status/hosts/	
State	States of targets associated with this item	



Retrieving the value is denied if not administrative user

This array does not support direct modification.

This array can change as if by itself or indirectly because of other actions.

Changes to this array cannot be tracked.

This array represents an unordered set (order of its elements doesn't matter, and each value should not be supplied more than once).

This array contains Target state elements.

Sample read command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←

→ restapi/autoping/items/:autoping_item_data/status/hosts/"

 "state":false,
 "success_count":3,
 "address": "Sample value of target state #1 of address",
 "failure_count":3,
 "queue_size":9
 },
 {
 "state":false,
 "success_count":4,
 "address": "Sample value of target state #2 of address",
 "failure_count":3,
 "queue_size":9
 },
 {
 "state":false,
 "success_count":3,
 "address": "Sample value of target state #3 of address",
 "failure_count":2,
 "queue_size":8
 },
 "state":null,
 "success_count":9,
 "address": "Sample value of target state #4 of address",
 "failure_count":3,
 "queue_size":5
 },
 {
 "state":false,
 "success_count":3,
 "address": "Sample value of target state #5 of address",
 "failure_count":8,
 "queue_size":2
 },
 "state":true,
 "success_count":3,
 "address": "Sample value of target state #6 of address",
 "failure_count":1,
 "queue_size":3
 },
 {
```

```
"state":null,
"success_count":10,
"address":"Sample value of target state #7 of address",
"failure_count":6,
"queue_size":6
}
```

Creating elements in this collection is not supported.

See also Target states: Target state

7.9.2 Reboot count

number | autoping/items/N/status/reboots/
Number of times this item's action has been triggered

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- the value is greater or equal to 0

This number does not support direct modification.

This number can change as if by itself or indirectly because of other actions.

Changes to this number cannot be tracked.

Sample read command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

7.10 Autoping item data: Pings remaining to enable, if any

```
sum (optional number) autoping/items/N/pings_before_enabling/
Estimate of number of successful ping replies remaining to enable the item, if any
```

Retrieving the value is denied if not administrative user

This sum does not support direct modification.

This sum can change as if by itself or indirectly because of other actions.

This sum can assume the following values:

constant null	Trial period over	Item is no longer in the trial state or disabled)	ate (it is either enabled
number	Pings remaining to enable	Estimate of successful ping replies remaining to enable the item (replies from targets which have already reached the enable threshold do not count)	 all of the following is true: the value is an integer the value is greater or equal to 0

Sample read command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

7.10.1 Pings remaining to enable

(possibly) number autoping/items/N/pings_before_enabling/	
Estimate of successful ping replies remaining to enable the item (replies from targets which have already reached	
the enable threshold do not count)	

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater or equal to 0

7.11 Autoping item data: Recently failed

sum (boolean)	autoping/items/N/recently_failed/
Flag indicating whether this item has recently failed	

Retrieving the value is denied if not administrative user

This sum does not support direct modification.

This sum represents a value in persistent storage.

This sum can change as if by itself or indirectly because of other actions.

Changes to this sum cannot be tracked.

This sum can assume the following values:

constant true	Recently failed	The item has failed recently, and a new failure would	
		be counted as consecutive	
constant false	Normal operation	The item is in normal operational state DLI EPCRS object Model Reference: 20180	420T190047Z

7.13 Ping interval 303

Sample read command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

7.12 Autoping item data: In resumption trial

sum (boolean)	autoping/items/N/resumption_trial/
Flag indicating whether this item is being tried after service restoration	

Retrieving the value is denied if not administrative user

This sum does not support direct modification.

This sum represents a value in persistent storage.

This sum can change as if by itself or indirectly because of other actions.

This sum can assume the following values:

constant true	In resumption trial	Item is being tried after service restoration (failures don't cause it to trigger until the required amount of requests succeed)
constant false	Normal operation	The item is in normal operational state, and may be triggered by failures

Sample read command (note that :autoping_item_data is a URL template argument and needs to be replaced before trying):

7.13 Ping interval

number	autoping/ping_interval/
Interval between consecutive pings to the same address	

The value is subject to the following constraints: the value is greater than 0

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

```
Sample read command:
```

Sample write command:

7.14 Ping timeout

```
number | autoping/ping_timeout/
Absence of response this long means the ping has timed out
```

The value is subject to the following constraints: the value is greater than 0

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command:

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "9" "https://192.168.0.100/restapi/ \hookrightarrow autoping/ping_timeout/"
```

7.15 Post-reboot delay

```
number | autoping/post_reboot_delay/

Time to wait after triggering the autoping action before pinging again
```

The value is subject to the following constraints: the value is greater than 0

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command:

Sample write command:

7.16 Default maximum total reboot count, if any

```
sum (number) autoping/max_reboot_count/

Default maximum total number of times to perform the autoping action on an entry before giving up, if any
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

number	Maximum total reboot count	Maximum total number of times to perform the autoping action on an entry before giv- ing up (counter does not get reset if response is received)	 all of the following is true: the value is an integer the value is greater than 0
constant 0	Retry indefinitely	Perform the autoping action indemany reboot attempts yielded no	-

Sample read command:

Sample (possible variant) write command:

7.16.1 Maximum total reboot count

(possibly) number | autoping/max_reboot_count/

Maximum total number of times to perform the autoping action on an entry before giving up (counter does not get reset if response is received)

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- the value is greater than 0

Sample write command:

7.17 Pings before enabling

```
number | autoping/pings_before_enabling/
Minimum number of successful ping responses before enabling an autoping entry
```

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater or equal to 0

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command:

Sample write command:

7.18 Resume without retrial

sum (boolean) | autoping/resume_without_retrial/

Activate enabled entries when service is restored without waiting for a certain number of successful ping responses

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/autoping/resume_without_retrial/"
```

⇒ (possible variant)

false

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "true" "https://192.168.0.100/restapi/ \hookleftarrow autoping/resume_without_retrial/"
```

7.19 Handle failures immediately

```
sum (boolean) | autoping/handle_failures_immediately/
```

Detect and act upon explicit failures (e.g. TCP port closed response, HTTP 500, etc.) immediately instead of waiting for timeout

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/autoping/handle_failures_immediately/"
```

```
\Rightarrow (possible variant)
```

false

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow : application/json" --data-binary "true" "https://192.168.0.100/restapi/ \hookleftarrow autoping/handle_failures_immediately/"
```

7.20 Reset statistics

```
call autoping/reset_statistics/
Clear the statistics (item success, failure and reboot counters)
```

Performing the function call is denied if not administrative user

The call has no arguments (supply empty tuple).


The call returns no results (expect an empty tuple).

Sample invocation:

7.21 Notifications

object	autoping/notifications/
Autoping status notifications	

7.21 Notifications 309



This object does not support direct modification.


This object contains the following items:

events	Events
parameter_kinds	Parameter kinds

Sample read command:

7.21.1 Events

map	autoping/notifications/events/
Event templates	



This map does not support direct modification.

This map contains **Event** elements.

Sample read command:

Creating elements in this collection is not supported.

See also Events: Event

7.21.2 Parameter kinds

object	autoping/notifications/parameter_kinds/	
Kinds o	Kinds of event parameters	

This object does not correspond to an actual resource.

This object contains the following items:

ping_address	Address
ping_item_addrs	Item addresses
ping_item_consecutive_failure_count	Consecutive failure count
ping_item_max_consecutive_failure_count	Maximum consecutive failure count, if any
ping_item_max_total_failure_count	Maximum total failure count, if any
ping_item_name	Item name
ping_item_pings_before_enabling	Pings before enabling
ping_item_script_name	Item script name

ping_item_state	Item state
ping_item_total_failure_count	Total failure count
ping_ping_time	Ping time
ping_ping_timeout	Ping timeout
ping_state	Ping state

See also Parameter kinds: Address

See also Parameter kinds: Item addresses

See also Parameter kinds: Consecutive failure count

See also Parameter kinds: Maximum consecutive failure count, if any

See also Parameter kinds: Maximum total failure count, if any

See also Parameter kinds: Item name

See also Parameter kinds: Pings before enabling

See also Parameter kinds: Item script name

See also Parameter kinds: Item state

See also Parameter kinds: Total failure count

See also Parameter kinds: Ping time

See also Parameter kinds: Ping timeout

See also Parameter kinds: Ping state

7.22 Message template: Message template element

sum (variant)	autoping/notifications/events/S/message_template/N/		
Element of hur	Element of human-readable message template		

This sum does not support direct modification.

This sum can assume the following values:

string	String	Fixed string	
number	Parameter	Index of message parameter to insert	event parameters[the value]

Sample read command (note that :event and :message_template_element are URL template arguments and need to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftrightarrow restapi/autoping/notifications/events/:event/message_template/: \leftrightarrow message_template_element/"
```

 \Rightarrow (possible variant)

7

7.22.1 String

(possibly) string autoping/notifications/events/S/message_template/N/	
Fixed string	

7.22.2 Parameter

(possibly) number autoping/notifications/events/S/message_template/N/		
Index of message parameter to insert		

The value is subject to the following constraints: event parameters[the value]

7.23 Event parameter: Fixed value

sum (variant)	autoping/notifications/events/S/parameters/N/fixed_value/	
Fixed parameter value for this particular event		

This sum does not support direct modification.

This sum can assume the following values:

constant null	Null	Null
constant true	True	True
constant false	False	False
string	String	This string
number	Number	This number

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftrightarrow restapi/autoping/notifications/events/:event/parameters/:event_parameter/ \leftrightarrow fixed_value/"
```

 \Rightarrow (possible variant)

false

7.23.1 String

(possibly) string	autoping/notifications/events/S/parameters/N/fixed_value/
This string	

7.26 Events: Event 313

7.23.2 Number

(possibly) number	autoping/notifications/events/S/parameters/N/fixed_value/
This number	

7.24 Event parameter: Fixed value flag

sum (boolean)	autoping/notifications/events/S/parameters/N/has_fixed_value/	
Flag indicating that the parameter's value for this event is fixed		

This sum does not support direct modification.

This sum can assume the following values:

constant true	Fixed	The value is fixed
constant false	Variable	The value is variable

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

7.25 Event parameter: Identifier

string autoping/notifications/events/S/parameters/N/id/				
Parame	Parameter identifier			

The value is subject to the following constraints: parameter kinds


This string does not support direct modification.

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

7.26 Events: Event

```
object autoping/notifications/events/S/

Event template
```



This object contains the following items:

message_template	Message template	
parameters	Event parameters	
severity	Severity	

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←
   → restapi/autoping/notifications/events/:event/"
\Rightarrow
"severity":4,
"message_template":[
 "Sample value of message template of message template element #2",
 2,
 "Sample value of message template of message template element #5",
 "Sample value of message template of message template element #7",
 "Sample value of message template of message template element \$8",
 5
],
"parameters":[
  "fixed_value":1,
  "has_fixed_value":false,
  "id": "Sample value of event parameters of event parameter #1 of identifier"
 },
 {
```

7.26 Events: Event 315

```
"fixed_value":true,
   "has_fixed_value":true,
   "id":"Sample value of event parameters of event parameter #2 of identifier"
   }
]
```

Sample write command (note that :event is a URL template argument and needs to be replaced before trying):

7.26.1 Message template

```
array autoping/notifications/events/S/message_template/
Template for human-readable message generation
```

This array does not support direct modification.

This array contains Message template element elements.


Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

Creating elements in this collection is not supported.

See also Message template: Message template element

7.26.2 Event parameters

```
array autoping/notifications/events/S/parameters/
Additional data associated with the event
```



This array does not support direct modification.

This array contains Event parameter elements.

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

Creating elements in this collection is not supported.

7.26.2.1 Event parameter

object autoping/notifications/events/S/parameters/N/		
Properties of a parameter associated with the event		

This object contains the following items:

fixed_value	Fixed value	
has_fixed_value	Fixed value flag	
id	Identifier	

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

```
"id":"Sample value of identifier"
}
```

Sample write command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

See also Event parameter: Fixed value

See also Event parameter: Fixed value flag

See also Event parameter: Identifier

7.26.3 Severity

sum (enumerated number)	autoping/notifications/events/S/severity/	
Severity rating assigned to the event		

This sum does not support direct modification.

This sum can assume the following values:

constant 1	Emergency	Treat the event as an emergency
constant 2	Alert	Treat the event as an alert
constant 3	Critical	Treat the event as critical
constant 4	Error	Treat the event as an error
constant 5	Warning	Treat the event as a warning
constant 6	Notice	Treat the event as a notice
constant 7	Informational	Treat the event as informational
constant 8	Debug	Treat the event as debugging-related

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

7.27 Parameter kinds: Address

```
string autoping/notifications/parameter_kinds/ping_address/
Address of ping target
```

Sample read command:

7.28 Parameter kinds: Item addresses

```
string autoping/notifications/parameter_kinds/ping_item_addrs/
Comma-separated list of addresses belonging to this item
```

Sample read command:

7.29 Parameter kinds: Consecutive failure count

```
number autoping/notifications/parameter_kinds/ping_item_consecutive_failure_count/

Number of times the item has failed consecutively
```

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater or equal to 0

Sample read command:

7.30 Parameter kinds: Maximum consecutive failure count, if any

S	sum (optional number)	autoping/notifications/parameter_kinds/ping_item_max_consecutive_failure_count/		
١	Number of consecutive failures after which the item becomes disabled, if any			

This sum can assume the following values:

constant null	Retry indefinitely	The action will be performed regardless of the number	
		of consecutive failures	
number	Maximum consecutive failure	Number of consecutive fail-	all of the following is true:
	count	ures after which the item be- comes disabled	 the value is an integer the value is greater or equal to 0

Sample read command:

Sample (possible variant) write command:

7.30.1 Maximum consecutive failure count

```
(possibly) number | autoping/notifications/parameter_kinds/ping_item_max_consecutive_failure_count/

Number of consecutive failures after which the item becomes disabled
```

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- · the value is greater or equal to 0

Sample write command:

7.31 Parameter kinds: Maximum total failure count, if any

sum (optional number)	autoping/notifications/parameter_kinds/ping_item_max_total_failure_count/	
Number of total failures	Number of total failures after which the item becomes disabled, if any	

This sum can assume the following values:

constant null	Retry indefinitely	The action will be performed re- of total failures	gardless of the number
number	Maximum total failure count	Number of total failures after which the item becomes disabled	all of the following is true: • the value is an integer • the value is greater or equal to 0

Sample read command:

Sample (possible variant) write command:

7.31.1 Maximum total failure count

```
(possibly) number | autoping/notifications/parameter_kinds/ping_item_max_total_failure_count/

Number of total failures after which the item becomes disabled
```

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater or equal to 0

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftarrow
    \hookrightarrow : application/json" --data-binary "10" "https://192.168.0.100/restapi/ \hookleftarrow
    \hookrightarrow \verb"autoping/notifications/parameter_kinds/ping_item_max_total_failure_count/"
```

7.32 Parameter kinds: Item name

```
autoping/notifications/parameter_kinds/ping_item_name/
Name of the autoping item
```

```
Sample read command:
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←
    → restapi/autoping/notifications/parameter_kinds/ping_item_name/"
"Sample value"
Sample write command:
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept ←
    \hookrightarrow : application/json" --data-binary "\"Sample value\"" "https \hookleftarrow
    \hookrightarrow ://192.168.0.100/restapi/autoping/notifications/parameter_kinds/ \hookleftarrow
    → ping_item_name/"
```

7.33 Parameter kinds: Pings before enabling

```
number
          autoping/notifications/parameter_kinds/ping_item_pings_before_enabling/
Number of successful pings left to enable the autoping item
```

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater or equal to 0

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←
   → restapi/autoping/notifications/parameter_kinds/ ←
   → ping_item_pings_before_enabling/"
9
```

Sample write command:

7.34 Parameter kinds: Item script name

```
string autoping/notifications/parameter_kinds/ping_item_script_name/

Name of the scripting function associated with the autoping item
```

Sample read command:

7.35 Parameter kinds: Item state

→ ping_item_script_name/"

sum (variant)	autoping/notifications/parameter_kinds/ping_item_state/	
State of the au	State of the autoping item	

This sum can assume the following values:

constant true	Enabled	The autoping item is enabled
constant false	Disabled	The autoping item is disabled
constant "enabling"	Enabling	The autoping item is in trial state

Sample read command:

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "false" "https://192.168.0.100/restapi/ \hookleftarrow \hookrightarrow autoping/notifications/parameter_kinds/ping_item_state/"
```

7.36 Parameter kinds: Total failure count

number | autoping/notifications/parameter_kinds/ping_item_total_failure_count/

Total number of times the item has failed

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater or equal to 0

Sample read command:

Sample write command:

7.37 Parameter kinds: Ping time

```
number | autoping/notifications/parameter_kinds/ping_ping_time/

The time it took to arrive at this ping state
```

The value is subject to the following constraints: the value is greater or equal to 0

Sample read command:

Sample write command:

7.38 Parameter kinds: Ping timeout

number autoping/notifications/parameter_kinds/ping_ping_timeout/

The time after which the ping is considered unsuccessful if no response seen

The value is subject to the following constraints: the value is greater than 0

```
Sample read command:
```

Sample write command:

7.39 Parameter kinds: Ping state

sum (variant)	autoping/notifications/parameter_kinds/ping_state/	
State of the tar	State of the target ping request	

This sum can assume the following values:

constant true	Reachable	The target has responded to the ping
constant false	Unreachable	The ping has timed out
constant "sent"	Sent	The ping has been sent but no response yet seen, and timeout not reached

Sample read command:

true

Sample (possible variant) write command:

7.40 Default maximum consecutive reboot count, if any

sum (number) autoping/max_consecutive_reboot_count/

Default maximum consecutive number of times to perform the autoping action on an entry before giving up, if any

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

number	Maximum consecutive reboot count	Maximum consecutive number of times to perform the autoping action on an entry before giving up (counter gets reset if response is received)	all of the following is true:the value is an integerthe value is greater than 0
constant 0	Retry indefinitely	Perform the autoping action in how many consecutive reboot a sponse	-

Sample read command:

Sample (possible variant) write command:

7.40.1 Maximum consecutive reboot count

```
(possibly) number | autoping/max_consecutive_reboot_count/

Maximum consecutive number of times to perform the autoping action on an entry before giving up (counter gets reset if response is received)
```


The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater than 0

Sample write command:

8 Scripting server object

object	script/
Object i	representing the scripting server state and configuration



This object contains the following items:

source	User script source
user_functions	User functions
boot_handler	Script to start at boot, if any
threads	Thread map
start	Start a script thread
stop	Stop a script thread
traced	Script tracing
step_delay	Script step delay
step_time_limit	Script step time limit
notifications	Notifications
snippets	Script snippets
user_function_ui_order	User function UI order

Sample read command:

8.2 User functions 327

8.1 User script source

```
string script/source/
Source of the user script from which user functions are extracted
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Sample read command:

8.2 User functions

```
map | script/user_functions/
Mapping of user function names to their signatures
```

Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map can change as if by itself or indirectly because of other actions.

Changes to this map cannot be tracked.

This map contains User script function signature elements.

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow
    → restapi/script/user_functions/"
\Rightarrow
"user_functions_6":"Sample value of user script function signature \leftarrow
    → user_functions_6",
"user_functions_7":"Sample value of user script function signature \leftarrow
    \hookrightarrow user_functions_7",
"user_functions_4":"Sample value of user script function signature ←
    → user_functions_4",
"user_functions_1":"Sample value of user script function signature ←
    → user_functions_1",
"user_functions_5":"Sample value of user script function signature \leftarrow
    → user_functions_5",
"user_functions_10":"Sample value of user script function signature \hookleftarrow
    → user_functions_10",
"user_functions_8":"Sample value of user script function signature \ \hookleftarrow
    → user_functions_8",
"user_functions_2":"Sample value of user script function signature \ensuremath{\leftarrow}

    user_functions_2",

"user_functions_3":"Sample value of user script function signature \leftarrow

    user_functions_3",

"user_functions_9":"Sample value of user script function signature \leftarrow
    → user_functions_9"
```

Creating elements in this collection is not supported.

8.2.1 User script function signature

```
string | script/user_functions/S/
Indicates that the map key is a user script function, and provides a signature which may serve as a hint as to the function content
```

The value is subject to the following constraints: not index of the value matches (|.*|.*)\$

Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :user_script_function_signature is a URL template argument and needs to be replaced before trying):

8.3 Script to start at boot, if any

8.4 Thread map 329

sum (string)	script/boot_handler/	
User scripting	User scripting function to run at cold boot, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can change as if by itself or indirectly because of other actions.

This sum can assume the following values:

ĺ	string	Script to start at boot	User scripting function to run at cold boot	user functions[the value]
	constant ""	None	Don't run any scripting function at cold boo	t

Sample read command:

\Rightarrow (possible variant)

Sample (possible variant) write command:

8.3.1 Script to start at boot

```
(possibly) string | script/boot_handler/
User scripting function to run at cold boot
```


The value is subject to the following constraints: user functions[the value]

Sample write command:

8.4 Thread map

map	script/threads/	
Мар о	Map of user scripting threads	

[&]quot;Sample value"



Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map can change as if by itself or indirectly because of other actions.

Changes to this map cannot be tracked.

This map contains Scripting thread elements.

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←
   → restapi/script/threads/"
 "thread_map_5":{
 "label": "Sample value of scripting thread thread_map_5 of label"
 "thread_map_3":{
 "label": "Sample value of scripting thread thread_map_3 of label"
 },
 "thread_map_1":{
 "label": "Sample value of scripting thread thread_map_1 of label"
 },
 "thread_map_4":{
 "label": "Sample value of scripting thread thread_map_4 of label"
 "thread_map_6":{
 "label": "Sample value of scripting thread thread_map_6 of label"
 },
 "thread_map_2":{
 "label": "Sample value of scripting thread thread_map_2 of label"
```

Creating elements in this collection is not supported.

See also Thread map: Scripting thread

8.5 Thread map: Scripting thread

```
object script/threads/S/
User scripting thread status
```

This object contains the following items:

```
label Label
```

Sample read command (note that :scripting_thread is a URL template argument and needs to be replaced before trying):

Sample write command (note that :scripting_thread is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "{\"label\":\"Sample value of label\"}" " \leftrightarrow https://192.168.0.100/restapi/script/threads/:scripting_thread/"
```

8.5.1 Label

```
string script/threads/S/label/
User thread label
```

Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :scripting_thread is a URL template argument and needs to be replaced before trying):

8.6 Start a script thread

```
call script/start/
Start a user scripting thread
```

Performing the function call is denied if not administrative user

The call accepts the following arguments:

1. object "Code source"

The call returns the following results:

1. string

Sample invocation:

8.6.1 Code source

object	script/start/arguments: 1/
Source of the code to run	

This object does not correspond to an actual resource.

This object contains the following items:

user_function	User function, if any
source	User code, if any
displayed_source	Displayed source code, if any

See also Code source: User function, if any

See also Code source: User code, if any

See also Code source: Displayed source code, if any

8.6.2 Resulting thread ID

string	script/start/results: 1/
Identifier of the started thread	

The value is subject to the following constraints: [invalid reference ../../threads][the value]

This string does not correspond to an actual resource.

8.7 Code source: User function, if any

sum (optional string)	script/start/arguments: 1/user_function/
Name of user function to run, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	No user function is run	The source of code is not a user function	
string	User function	Name of user function to run	user functions[the value]

8.7.1 User function

(possibly) string	ing script/start/arguments: 1/user_function/	
Name of user function to run		

The value is subject to the following constraints: user functions[the value]

This string does not correspond to an actual resource.

8.8 Code source: User code, if any

sum (optional string)	script/start/arguments: 1/source/	
Explicit code to run as user script (if user_function is not set or is an existing user script function), if any		

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	User function invocation	The user_function is invoked with no arguments	
string	User code	code Explicit code to run as user script (if user_function	
		not set or is an existing user script function)	

8.8.1 User code

	(possibly) string script/start/arguments: 1/source/	
Explicit code to run as user script (if user_function is not set or is an existing user script function)		

This string does not correspond to an actual resource.

8.9 Code source: Displayed source code, if any

sum (optional string) script/start/arguments: 1/displayed_source/	
Source code describing thread overview (doesn't have to be valid code), if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	Use default	Display source, or user_function name	
string	Displayed source code	ved source code Source code describing thread overview (doesn't have	
		to be valid code)	

8.9.1 Displayed source code

(possibly) string	script/start/arguments: 1/displayed_source/
Source code describing thread overview (doesn't have to be valid code)	

This string does not correspond to an actual resource.

8.10 Stop a script thread

call	script/stop/	
Stop	Stop a user scripting thread, or all user scripting threads	

Performing the function call is denied if not administrative user

The call accepts the following arguments:

1. Thread ID or All threads

The call returns no results (expect an empty tuple).

Sample invocation:

See also Stop a script thread: Thread(s) to stop

8.11 Stop a script thread: Thread(s) to stop

sum (string)	script/stop/arguments: 1/	
Identifier of th	Identifier of the thread to stop, or "all" to stop all threads	

This sum does not correspond to an actual resource.

This sum can assume the following values:

string	Thread ID	Identifier of the thread to stop	thread map[the value]
constant "all"	All threads	Stop all threads	

8.11.1 Thread ID

(possibly) string	script/stop/arguments: 1/	
Identifier of the thread to stop		

The value is subject to the following constraints: thread map[the value]

This string does not correspond to an actual resource.

8.12 Script tracing

sum (boolean)	script/traced/		
Perform step-by	Perform step-by-step logging of script operation		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \longleftrightarrow restapi/script/traced/"
```

 \Rightarrow (possible variant)

true

Sample (possible variant) write command:

8.13 Script step delay

number | script/step_delay/

Delay after executing legacy scripting functions

The value is subject to the following constraints: the value is greater than 0

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command:

Sample write command:

8.14 Script step time limit

```
number | script/step_time_limit/

Maximum amount of time a scripting thread is allowed to run uninterrupted
```

The value is subject to the following constraints: the value is greater than 0

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command:


Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow: application/json" --data-binary "8" "https://192.168.0.100/restapi/script \leftrightarrow /step_time_limit/"
```

8.15 Notifications

8.15 Notifications 337

```
object script/notifications/
Scripting server notifications
```



This object does not support direct modification.

This object contains the following items:

events	Events
parameter_kinds	Parameter kinds


Sample read command:

 \Rightarrow

• •

8.15.1 Events

map	script/notifications/events/	
Event	Event templates	



This map does not support direct modification.

This map contains **Event** elements.

Sample read command:

Creating elements in this collection is not supported.

See also Events: Event

8.15.2 Parameter kinds

object	script/notifications/parameter_kinds/	
Kinds o	Kinds of event parameters	

This object does not correspond to an actual resource.

This object contains the following items:

thread_error	Thread error
thread_id	Thread ID
thread_name	Thread name
thread_origin	Thread origin, if any
thread_start_reason	Thread start reason, if any
thread_state	Thread state
thread_stop_reason	Thread stop reason

See also Parameter kinds: Thread error

See also Parameter kinds: Thread ID

See also Parameter kinds: Thread name

See also Parameter kinds: Thread origin, if any

See also Parameter kinds: Thread start reason, if any

See also Parameter kinds: Thread state

See also Parameter kinds: Thread stop reason

8.16 Message template: Message template element

sum (variant)	script/notifications/events/S/message_template/N/
Element of human-readable message template	

This sum does not support direct modification.

This sum can assume the following values:

string	String	Fixed string	
number	Parameter	Index of message parameter to insert	event parameters[the value]

Sample read command (note that :event and :message_template_element are URL template arguments and need to be replaced before trying):

8.16.1 String

(possibly) string	script/notifications/events/S/message_template/N/
Fixed string	

8.16.2 Parameter

(possibly) number	script/notifications/events/S/message_template/N/
Index of message parameter to insert	

The value is subject to the following constraints: event parameters[the value]

8.17 Event parameter: Fixed value

sum (variant)	script/notifications/events/S/parameters/N/fixed_value/
Fixed parameter value for this particular event	

This sum does not support direct modification.

This sum can assume the following values:

constant null	Null	Null
constant true	True	True
constant false	False	False
string	String	This string
number	Number	This number

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

8.17.1 String

(possibly) string	script/notifications/events/S/parameters/N/fixed_value/
This string	

8.17.2 Number

(possibly) number	script/notifications/events/S/parameters/N/fixed_value/
This number	

8.18 Event parameter: Fixed value flag

sum (boolean)	script/notifications/events/S/parameters/N/has_fixed_value/
Flag indicating that the parameter's value for this event is fixed	

This sum does not support direct modification.

This sum can assume the following values:

constant true	Fixed	The value is fixed
constant false	Variable	The value is variable

8.20 Events: Event 341

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

8.19 Event parameter: Identifier

string	script/notifications/events/S/parameters/N/id/
Parameter identifier	


The value is subject to the following constraints: parameter kinds

This string does not support direct modification.

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

8.20 Events: Event

object	script/notifications/events/S/	
Event template		



This object contains the following items:

message_template	Message template
parameters	Event parameters
severity	Severity

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

Sample write command (note that :event is a URL template argument and needs to be replaced before trying):

8.20.1 Message template

8.20 Events: Event 343

```
array script/notifications/events/S/message_template/
Template for human-readable message generation
```

This array does not support direct modification.

This array contains Message template element elements.


Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

Creating elements in this collection is not supported.

See also Message template: Message template element

8.20.2 Event parameters

array	script/notifications/events/S/parameters/
Additional data associated with the event	



This array does not support direct modification.

This array contains **Event parameter** elements.

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow

→ restapi/script/notifications/events/:event/parameters/"

\Rightarrow
 "fixed_value":null,
 "has_fixed_value":true,
 "id": "Sample value of event parameter #1 of identifier"
},
 "fixed_value":5,
 "has_fixed_value":false,
 "id": "Sample value of event parameter #2 of identifier"
},
 "fixed_value": "Sample value of event parameter #3 of fixed value",
 "has_fixed_value":false,
 "id": "Sample value of event parameter #3 of identifier"
},
 "fixed_value": "Sample value of event parameter #4 of fixed value",
 "has_fixed_value":true,
 "id": "Sample value of event parameter #4 of identifier"
 "fixed_value":false,
 "has_fixed_value":false,
 "id": "Sample value of event parameter #5 of identifier"
1
```

Creating elements in this collection is not supported.

8.20.2.1 Event parameter

object	script/notifications/events/S/parameters/N/	
Propert	Properties of a parameter associated with the event	

This object contains the following items:

fixed_value	Fixed value
has_fixed_value	Fixed value flag
id	Identifier

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

 \Rightarrow

```
{
  "fixed_value":"Sample value of fixed value",
  "has_fixed_value":true,
  "id":"Sample value of identifier"
}
```

Sample write command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"fixed_value\":null,\"has_fixed_value\":false,\"id\":\"Sample \( \to \)
\to value of identifier\"}"\
"https://192.168.0.100/restapi/script/notifications/events/:event/parameters/: \( \to \)
\to event_parameter/"
```

See also Event parameter: Fixed value

See also Event parameter: Fixed value flag

See also Event parameter: Identifier

8.20.3 Severity

sum (enumerated number)	script/notifications/events/S/severity/
Severity rating assigned to the event	

This sum does not support direct modification.

This sum can assume the following values:

constant 1	Emergency	Treat the event as an emergency
constant 2	Alert	Treat the event as an alert
constant 3	Critical	Treat the event as critical
constant 4	Error	Treat the event as an error
constant 5	Warning	Treat the event as a warning
constant 6	Notice	Treat the event as a notice
constant 7	Informational	Treat the event as informational
constant 8	Debug	Treat the event as debugging-related

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

8.21 Parameter kinds: Thread error

string script/notifications/parameter_kinds/thread_error/

Thread execution error description

Sample read command:

Sample write command:

8.22 Parameter kinds: Thread ID

```
string script/notifications/parameter_kinds/thread_id/
Thread identifier
```

Sample read command:

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow: application/json" --data-binary "\"Sample value\"" "https \leftrightarrow://192.168.0.100/restapi/script/notifications/parameter_kinds/thread_id/"
```

8.23 Parameter kinds: Thread name

```
string script/notifications/parameter_kinds/thread_name/
Thread human-readable name
```

Sample read command:

 \Rightarrow

```
"Sample value"
```

Sample write command:

8.24 Parameter kinds: Thread origin, if any

sum (optional string)	script/notifications/parameter_kinds/thread_origin/
Origin of the thread, if any	

This sum can assume the following values:

constant null	Unknown origin	Origin of this thread is not known
string	Thread origin	Origin of the thread

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/script/notifications/parameter_kinds/thread_origin/"
```

\Rightarrow (possible variant)

null

Sample (possible variant) write command:

8.24.1 Thread origin

```
(possibly) string | script/notifications/parameter_kinds/thread_origin/
Origin of the thread
```

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "\"Sample value\"" "https \leftrightarrow ://192.168.0.100/restapi/script/notifications/parameter_kinds/thread_origin \leftrightarrow \leftrightarrow /"
```

8.25 Parameter kinds: Thread start reason, if any

```
sum (optional string) | script/notifications/parameter_kinds/thread_start_reason/

Reason of the thread start, if any
```

This sum can assume the following values:

constant null	Unknown start reason	Reason of the thread start is not known
string Thread start reason		Reason of the thread start

Sample read command:

\Rightarrow (possible variant)

Sample (possible variant) write command:

8.25.1 Thread start reason

(possibly) string script/notifications/parameter_kinds/thread_start_reason/	
Reason of the thread start	

Sample write command:

8.26 Parameter kinds: Thread state

sum (boolean) script/notifications/parameter_kinds/thread_state/	
Thread execution state	

This sum can assume the following values:

constant true	Running	The thread is running
constant false	Stopped	The thread is stopped

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/script/notifications/parameter_kinds/thread_state/"
```

\Rightarrow (possible variant)

true

[&]quot;Sample value"

Sample (possible variant) write command:

8.27 Parameter kinds: Thread stop reason

```
string script/notifications/parameter_kinds/thread_stop_reason/
Reason of the thread stop
```


curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←

Sample read command:

8.28 Script snippets

→ thread_stop_reason/"

```
map | script/snippets/
Fragments of Lua code provided initially as samples or saved for later use
```



Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This map represents a value in persistent storage.

Changes to this map cannot be tracked.

This map contains Script snippet elements.

Sample read command:

Sample write command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/script/snippets/"
```

Sample script snippet creation command:

See also Script snippets: Script snippet

8.29 Script snippets: Script snippet

```
object script/snippets/S/
User script snippet
```

This object contains the following items:

```
source Snippet source
```

Sample read command (note that :script_snippet is a URL template argument and needs to be replaced before trying):

Sample write command (note that :script_snippet is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :script_snippet is a URL template argument and needs to be replaced before trying):

8.29.1 Snippet source

```
string script/snippets/S/source/
Source of the snippet
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Changes to this string cannot be tracked.

Sample read command (note that :script_snippet is a URL template argument and needs to be replaced before trying):

Sample write command (note that :script_snippet is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow: application/json" --data-binary "\"Sample value\"" "https \leftrightarrow: //192.168.0.100/restapi/script/snippets/:script_snippet/source/"
```

8.30 User function UI order

```
array script/user_function_ui_order/
Preferred order of user functions when displayed to user
```

Retrieving the value is denied if not administrative user

This array does not support direct modification.

This array can change as if by itself or indirectly because of other actions.

Changes to this array cannot be tracked.

This array contains User script function name for index elements.

Sample read command:

Creating elements in this collection is not supported.

8.30.1 User script function name for index

```
string script/user_function_ui_order/N/
Indicates that the preferred location of this user function in a list is the index in the array; may specify a nonexistent function
```

Retrieving the value is denied if not administrative user


This string does not support direct modification.

Sample read command (note that :user_script_function_name_for_index is a URL template argument and needs to be replaced before trying):

9 SNMP server object

9 SNMP server object 353

```
object snmp/
Object representing SNMP server configuration
```



This object contains the following items:

enabled	Allow SNMP
engine_id	Engine ID
oid_subtrees	OID subtrees
users	Users
community_mappings	Community mappings
known_auth_methods	Known authentication methods
known_priv_methods	Known privacy methods

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftrightarrow restapi/snmp/"
```

 \Rightarrow

. . .

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "..." "https://192.168.0.100/restapi/snmp \leftrightarrow \leftrightarrow /"
```

9.1 Allow SNMP

```
sum (boolean) snmp/enabled/
Enable SNMP server operation
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/snmp/enabled/"
```

 \Rightarrow (possible variant)

true

Sample (possible variant) write command:

9.2 Engine ID

```
string snmp/engine_id/
The engine ID, in hexadecimal, to which all user authentication and privacy keys are localized
```

The value is subject to the following constraints: the value matches ([0-9A-F]{2})*

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

9.3 OID subtrees 355

- · not administrative user
- · protect network settings


This string represents a value in persistent storage.

 \hookrightarrow ://192.168.0.100/restapi/snmp/engine_id/"

```
Sample read command:
```

9.3 OID subtrees

```
map snmp/oid_subtrees/
OID subtrees exposed by SNMP server
```



Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This map represents a value in persistent storage.

This map contains OID subtree elements.

Sample read command:

Sample write command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/snmp/oid_subtrees/"
```

Sample oid subtree creation command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/snmp/oid_subtrees/oid_subtrees_4/"
```

See also OID subtrees: OID subtree

9.4 OID subtrees: OID subtree

object	snmp/oid_subtrees/S/	
Propert	erties of an OID subtree	

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This object represents a value in persistent storage.

This object contains the following items:

title	Title	
root	Root mask	
read_security_level	Read security level	5 Object Model Reference: 20180420T190047Z
write_security_level	Write security level	•

Sample read command (note that :oid_subtree is a URL template argument and needs to be replaced before trying):

Sample write command (note that :oid_subtree is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :oid_subtree is a URL template argument and needs to be replaced before trying):

9.4.1 Title

```
string snmp/oid_subtrees/S/title/
The title of this subtree
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This string represents a value in persistent storage.

Sample read command (note that :oid_subtree is a URL template argument and needs to be replaced before trying):

```
"Sample value"
```

Sample write command (note that :oid_subtree is a URL template argument and needs to be replaced before trying):

9.4.2 Root mask

```
string | snmp/oid_subtrees/S/root/
```

The root OID mask of this subtree (for all but the first two arcs, '*' can be used for "don't care" parts, and inclusive ranges can be specified like '1,2,4-7')

The value is subject to the following constraints: the value matches (0|1|(01|2)(.(*|(0|[1-9][0-9]*)(-(0|[1-9][0-9]*)(-(0|[1-9][0-9]*))?)))))

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :oid_subtree is a URL template argument and needs to be replaced before trying):

Sample write command (note that :oid_subtree is a URL template argument and needs to be replaced before trying):

9.4.3 Read security level

```
sum (enumerated string) snmp/oid_subtrees/S/read_security_level/
Required security level for reading from this subtree
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant "deny"	Forbidden	Nobody can read from this OID subtree
constant "priv"	Authenticated and encrypted	SNMPv3 authentication and encryption must be used to read from this OID subtree
constant "auth"	Authenticated	SNMPv3 authentication must be used to read from this OID subtree (encryption is optional)
constant "noauth"	Minimal	Any protocol, including SNMPv1 and SNMPv2c, can be used to read from this OID subtree (authentication and encryption are optional)

Sample read command (note that :oid_subtree is a URL template argument and needs to be replaced before trying):

"Sample value"

Sample (possible variant) write command (note that :oid_subtree is a URL template argument and needs to be replaced before trying):

9.4.4 Write security level

sum (enumerated string)	snmp/oid_subtrees/S/write_security_level/
Required security level for writing to this subtree	

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant "deny"	Forbidden	Nobody can write to this OID subtree
constant "priv"	Authenticated and encrypted	SNMPv3 authentication and encryption must be used to write to this OID subtree
constant "auth"	Authenticated	SNMPv3 authentication must be used to write to this OID subtree (encryption is optional)
constant "noauth"	Minimal	Any protocol, including SNMPv1 and SNMPv2c, can be used to write to this OID subtree (authentication and encryption are optional)

Sample read command (note that :oid_subtree is a URL template argument and needs to be replaced before trying):


```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/snmp/oid_subtrees/:oid_subtree/write_security_level/"
```

 \Rightarrow (possible variant)

Sample (possible variant) write command (note that :oid_subtree is a URL template argument and needs to be replaced before trying):

9.5 Users

map	snmp/users/
SNMP user accounts	



[&]quot;Sample value"

9.5 Users 361

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This map represents a value in persistent storage.

This map contains User elements.

Sample read command:

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "..." "https://192.168.0.100/restapi/snmp \leftrightarrow /users/"
```

Sample user creation command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/snmp/users/users_1/"
```

9.5.1 User

```
object snmp/users/S/
Properties of an SNMP user
```

User		
is_allowed:User allowed	1	
auth_method:Authentication method]	
has_auth_password:Authentication password configured		
auth_password:Authentication password		
priv_method:Privacy method		
has_priv_password:Privacy password configured		
priv_password:Privacy password		
subtree_access:Subtree access levels	 	Subtree access levels
	-	[element]:Subtree access

The value is subject to the following constraints: index of the value matches ^[a-zA-Z0-9]*\$

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This object represents a value in persistent storage.

This object contains the following items:

is_allowed	User allowed
auth_method	Authentication method
has_auth_password	Authentication password configured
auth_password	Authentication password
priv_method	Privacy method
has_priv_password	Privacy password configured
priv_password	Privacy password
subtree_access	Subtree access levels

Sample read command (note that :user is a URL template argument and needs to be replaced before trying):

9.6 User: User allowed 363

Sample write command (note that :user is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/snmp/users/:user/"
```

Sample deletion command (note that :user is a URL template argument and needs to be replaced before trying):

See also User: User allowed

See also User: Authentication method

See also User: Authentication password configured

See also User: Authentication password

See also User: Privacy method

See also User: Privacy password configured

See also User: Privacy password

See also User: Subtree access levels

9.6 User: User allowed

```
sum (boolean) snmp/users/S/is_allowed/
Flag indicating whether user is allowed or denied
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

· not administrative user

· protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Allowed	The user is allowed to log in
constant false	Denied	The user is denied login

Sample read command (note that :user is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :user is a URL template argument and needs to be replaced before trying):

9.7 User: Authentication method

```
string snmp/users/S/auth_method/
User authentication method
```

The value is subject to the following constraints: known authentication methods[the value]

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- not administrative user
- protect network settings

This string represents a value in persistent storage.

Sample read command (note that :user is a URL template argument and needs to be replaced before trying):

Sample write command (note that :user is a URL template argument and needs to be replaced before trying):

9.8 User: Authentication password configured

sum (boolean) snmp/users/S/has auth password/

Flag indicating if the authentication password has been configured for the user (cleared if engine ID or authentication method changes)

Retrieving the value is denied if not administrative user

This sum does not support direct modification.

This sum can change as if by itself or indirectly because of other actions.

Changes to this sum cannot be tracked.

This sum can assume the following values:

constant true	Configured	The authentication password has been configured
constant false	Not configured	The authentication password hasn't been configured,
		the user won't be able to log in

Sample read command (note that :user is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/snmp/users/:user/has_auth_password/"
```

 \Rightarrow (possible variant)

true

9.9 User: Authentication password

string	snmp/users/S/auth pass	sword/
--------	------------------------	--------

User authentication password (cannot be read as it is stored localized to the engine ID), empty if not set

The value is subject to the following constraints: any of the following is true:

- the value is equal to ""
- length of the value is greater or equal to 8

Retrieving the value is denied

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

Using the string as a field for indexing into the grandparent collection is denied

This string represents a value in persistent storage.

This string can change as if by itself or indirectly because of other actions.

This string should be displayed in a secure manner.

Representation of the resource cannot be obtained. Attempts to do so will succeed but return JSON '{"\$ref":""}' which means "the value of this resource".

Sample write command (note that :user is a URL template argument and needs to be replaced before trying):

9.10 User: Privacy method

```
string snmp/users/S/priv_method/
User privacy method
```

The value is subject to the following constraints: known privacy methods[the value]

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :user is a URL template argument and needs to be replaced before trying):

Sample write command (note that :user is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "\"Sample value\"" "https \leftrightarrow ://192.168.0.100/restapi/snmp/users/:user/priv_method/"
```

9.11 User: Privacy password configured

```
sum (boolean) snmp/users/S/has_priv_password/
Flag indicating if the privacy password has been configured for the user (cleared if engine ID or authentication or privacy method changes)
```

Retrieving the value is denied if not administrative user

This sum does not support direct modification.

This sum can change as if by itself or indirectly because of other actions.

Changes to this sum cannot be tracked.

This sum can assume the following values:

constant true	Configured	The privacy password has been configured
constant false	Not configured	The privacy password hasn't been configured, the user won't be able to log in

Sample read command (note that :user is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftrightarrow restapi/snmp/users/:user/has_priv_password/"
```

 \Rightarrow (possible variant)

false

9.12 User: Privacy password

string	snmp/users/S/priv_password/	
User	User privacy password (cannot be read as it is stored localized to the engine ID), empty if not set	

The value is subject to the following constraints: any of the following is true:

- the value is equal to ""
- length of the value is greater or equal to 8

Retrieving the value is denied

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

Using the string as a field for indexing into the grandparent collection is denied

This string represents a value in persistent storage.

This string can change as if by itself or indirectly because of other actions.

This string should be displayed in a secure manner.

Representation of the resource cannot be obtained. Attempts to do so will succeed but return JSON '{"\$ref":""}' which means "the value of this resource".

Sample write command (note that :user is a URL template argument and needs to be replaced before trying):

9.13 User: Subtree access levels

```
map snmp/users/S/subtree_access/
OID subtree access levels
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This map represents a value in persistent storage.

This map contains Subtree access elements.

Sample read command (note that :user is a URL template argument and needs to be replaced before trying):

Sample write command (note that :user is a URL template argument and needs to be replaced before trying):

Sample subtree access creation command (note that :user is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "\"Sample value of subtree access subtree_access_levels_5\""\
"https://192.168.0.100/restapi/snmp/users/:user/subtree_access/ \(\therefore\) subtree_access_levels_5/"
```

9.13.1 Subtree access

sum (optional variant)	snmp/users/S/subtree_access/S/
OID subtree access level	

The value is subject to the following constraints: oid subtrees[index of the value]

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Full	OIDs can be read and written by the user
constant "readonly"	Read-only	OIDs can only be read, not written, by the user
constant false	None	OIDs can neither be read nor written by the user
constant null	Default	No access rule present (permissions are determined by parent OID access levels, or denied)

Sample read command (note that :user and :subtree_access are URL template arguments and need to be replaced before trying):

 \Rightarrow (possible variant)


true

Sample (possible variant) write command (note that :user and :subtree_access are URL template arguments and need to be replaced before trying):

Sample deletion command (note that :user and :subtree_access are URL template arguments and need to be replaced before trying):

9.14 Community mappings

array	snmp/community_mappings/	
Mappir	Mappings of SNMP v1/v2c communities to user names	



Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This array represents a value in persistent storage.

This array contains Community mapping elements.

Sample read command:

Sample write command:

Sample community mapping creation command:

See also Community mappings: Community mapping

9.15 Community mappings: Community mapping

object	snmp/community_mappings/N/	
Propert	Properties of a community mapping	

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This object represents a value in persistent storage.

This object contains the following items:

community	Community
user	User
ip_address	IP address
netmask	Network mask

Sample read command (note that :community_mapping is a URL template argument and needs to be replaced before trying):

Sample write command (note that :community_mapping is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :community_mapping is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X DELETE -H "Accept: application/json" "https ↔ ://192.168.0.100/restapi/snmp/community_mappings/:community_mapping/"
```

9.15.1 Community

```
string snmp/community_mappings/N/community/
The community identifier
```

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :community_mapping is a URL template argument and needs to be replaced before trying):

Sample write command (note that :community_mapping is a URL template argument and needs to be replaced before trying):

9.15.2 User

```
string snmp/community_mappings/N/user/
The user identifier
```

The value is subject to the following constraints: users[the value]

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :community_mapping is a URL template argument and needs to be replaced before trying):

Sample write command (note that :community_mapping is a URL template argument and needs to be replaced before trying):

9.15.3 IP address

```
string snmp/community_mappings/N/ip_address/
IP address allowed to connect
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This string represents a value in persistent storage.

Sample read command (note that :community_mapping is a URL template argument and needs to be replaced before trying):

Sample write command (note that :community_mapping is a URL template argument and needs to be replaced before trying):

9.15.4 Network mask

string	snmp/community_mappings/N/netmask/
- Networ	k mask allowed to connect
	DI LEDODE OLI

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :community_mapping is a URL template argument and needs to be replaced before trying):

Sample write command (note that :community_mapping is a URL template argument and needs to be replaced before trying):

9.16 Known authentication methods

```
map snmp/known_auth_methods/
Map of known authentication methods
```

Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map represents a value in persistent storage.

This map contains Authentication method elements.

Sample read command:

Creating elements in this collection is not supported.

9.16.1 Authentication method

string	snmp/known_auth_methods/S/	
Authen	Authentication method name	

Retrieving the value is denied if not administrative user

This string does not support direct modification.

This string represents a value in persistent storage.

Sample read command (note that :authentication_method is a URL template argument and needs to be replaced before trying):

9.17 Known privacy methods

map	snmp/known_priv_methods/	
Map o	Map of known privacy methods	

Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map represents a value in persistent storage.

This map contains Privacy method elements.

Sample read command:

10 UPnP server object 377

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←

→ restapi/snmp/known_priv_methods/"

\Rightarrow
 "known_privacy_methods_8":"Sample value of privacy method \leftarrow

→ known_privacy_methods_8",

 "known_privacy_methods_5":"Sample value of privacy method \ \hookleftarrow
    \hookrightarrow known_privacy_methods_5",
 "known_privacy_methods_1":"Sample value of privacy method \leftarrow
    → known_privacy_methods_1",
 "known_privacy_methods_7":"Sample value of privacy method ←

→ known_privacy_methods_7",

 "known_privacy_methods_3":"Sample value of privacy method \leftarrow

→ known_privacy_methods_3",

 "known_privacy_methods_2":"Sample value of privacy method \leftarrow

→ known_privacy_methods_2",
 "known_privacy_methods_6":"Sample value of privacy method \begin{tabular}{l} \hookleftarrow \end{tabular}

→ known_privacy_methods_6",
 "known_privacy_methods_9":"Sample value of privacy method \leftarrow
    "known_privacy_methods_4":"Sample value of privacy method \leftarrow

→ known_privacy_methods_4"
```

Creating elements in this collection is not supported.

9.17.1 Privacy method

string	snmp/known_priv_methods/S/	
Privacy	Privacy method name	

Retrieving the value is denied if not administrative user


This string does not support direct modification.

This string represents a value in persistent storage.

Sample read command (note that :privacy_method is a URL template argument and needs to be replaced before trying):

10 UPnP server object

object upnp/	
Object representing the UPnP server configuration	



This object contains the following items:

enabled	Enabled
outlets	Outlet UPnP configuration settings
profiles	UPnP device profiles
notifications	Notifications

Sample read command:

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "..." "https://192.168.0.100/restapi/upnp \leftrightarrow /"
```

10.1 Enabled

sum (boolean)	upnp/enabled/
UPnP enable status	

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/upnp/enabled/"
```

 \Rightarrow (possible variant)


true

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow : application/json" --data-binary "false" "https://192.168.0.100/restapi/ \hookrightarrow upnp/enabled/"
```

10.2 Outlet UPnP configuration settings

```
array upnp/outlets/
Properties related to exposing outlets via UPnP
```



The value is subject to the following constraints: length of the value is equal to length of outlets

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This array represents a value in persistent storage.

This array contains Outlet UPnP configuration elements.

Sample read command:

Sample write command:

Sample outlet upnp configuration creation command:

```
curl\
--digest\
-u admin:1234\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"exposed\":true,\"profile\":\"Sample value of profile\",\"id \( \to \) \":\"Sample value of identifier\",\"alternate_name\":null}"\
"https://192.168.0.100/restapi/upnp/outlets/"
```

10.2.1 Outlet UPnP configuration

object	upnp/outlets/N/	
Propert	Properties related to exposing the outlet via UPnP	

The value is subject to the following constraints: outlets[index of the value]

This object contains the following items:

alternate_name	Alternate name, if any
exposed	Exposed
id	Identifier
profile	Profile

Sample read command (note that :outlet_upnp_configuration is a URL template argument and needs to be replaced before trying):

Sample write command (note that :outlet_upnp_configuration is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"exposed\":false,\"profile\":\"Sample value of profile\",\"id \( \to \) \":\"Sample value of identifier\",\"alternate_name\":\"Sample value of \( \to \) \\
\to alternate name, if any\"}"\
"https://192.168.0.100/restapi/upnp/outlets/:outlet_upnp_configuration/"
```

Sample deletion command (note that :outlet_upnp_configuration is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X DELETE -H "Accept: application/json" "https \leftrightarrow ://192.168.0.100/restapi/upnp/outlets/:outlet_upnp_configuration/"
```

See also Outlet UPnP configuration: Alternate name, if any

See also Outlet UPnP configuration: Exposed

See also Outlet UPnP configuration: Identifier

See also Outlet UPnP configuration: Profile

10.3 Outlet UPnP configuration: Alternate name, if any

```
sum (optional string) upnp/outlets/N/alternate_name/

Alternate name for the same outlet to be used instead of the configured name, if any
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Configured outlet name	Use the outlet's configured name
string	Alternate name	Alternate name for the same outlet to be used instead
		of the configured name

Sample read command (note that :outlet_upnp_configuration is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :outlet_upnp_configuration is a URL template argument and needs to be replaced before trying):

10.3.1 Alternate name

(possibly) string	upnp/outlets/N/alternate_name/
Alternate name for the same outlet to be used instead of the configured name	

Sample write command (note that :outlet_upnp_configuration is a URL template argument and needs to be replaced before trying):

10.4 Outlet UPnP configuration: Exposed

sum (boolean)	upnp/outlets/N/exposed/
Outlet is exposed via UPnP	

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Enabled	The feature is enabled	
constant false	Disabled	The feature is disabled	

Sample read command (note that :outlet_upnp_configuration is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :outlet_upnp_configuration is a URL template argument and needs to be replaced before trying):

10.5 Outlet UPnP configuration: Identifier

string	upnp/outlets/N/id/
Outlet device identifier seed	

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :outlet_upnp_configuration is a URL template argument and needs to be replaced before trying):

Sample write command (note that :outlet_upnp_configuration is a URL template argument and needs to be replaced before trying):

10.6 Outlet UPnP configuration: Profile

string	upnp/outlets/N/profile/
Outlet device profile	

The value is subject to the following constraints: upnp device profiles[the value]

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings


This string represents a value in persistent storage.

Sample read command (note that :outlet_upnp_configuration is a URL template argument and needs to be replaced before trying):

Sample write command (note that :outlet_upnp_configuration is a URL template argument and needs to be replaced before trying):

10.7 UPnP device profiles

```
map upnp/profiles/
Map of UPnP device exposure settings
```



Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This map represents a value in persistent storage.

This map contains UPnP device profile elements.

Sample read command:


Sample write command:

Sample upnp device profile creation command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "..." "https://192.168.0.100/restapi/upnp \leftrightarrow /profiles/upnp_device_profiles_2/"
```

10.7.1 UPnP device profile

object upnp/profiles/S/
UPnP device exposure settings



This object contains the following items:

actions	Action map
device_type	Device type
device_version	Device version
device_xmlns	Device namespace
manufacturer	Manufacturer
model	Model
model_number	Model number
nid	Namespace identifier
service_control_url	Service control URL
service_event_sub_url	Service event subscription URL
service_id	Service ID
service_scpd_url	Service SCPD URL
service_type	Service type
service_version	Service version
service_xmlns	Service namespace
state_variables	State variables
types	Variable types
uuid_prefix	UUID prefix

Sample read command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

Sample write command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

Sample deletion command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X DELETE -H "Accept: application/json" "https ↔ ://192.168.0.100/restapi/upnp/profiles/:upnp_device_profile/"
```

See also UPnP device profile: Action map

See also UPnP device profile: Device type

See also UPnP device profile: Device version

See also UPnP device profile: Device namespace

See also UPnP device profile: Manufacturer

See also UPnP device profile: Model

See also UPnP device profile: Model number

See also UPnP device profile: Namespace identifier

See also UPnP device profile: Service control URL

See also UPnP device profile: Service event subscription URL

See also UPnP device profile: Service ID

See also UPnP device profile: Service SCPD URL

See also UPnP device profile: Service type

See also UPnP device profile: Service version

See also UPnP device profile: Service namespace

See also UPnP device profile: State variables

See also UPnP device profile: Variable types

See also UPnP device profile: UUID prefix

10.8 Arguments: Argument

object	upnp/profiles/S/actions/S/arguments/N/	
Action in	Action input or output argument properties	

This object contains the following items:

is_output	Output/return value flag
name	Argument name
state_id	Related state variable identifier, if any
type	Argument type

Sample read command (note that :upnp_device_profile, :action and :argument are URL template arguments and need to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \( \to \) restapi/upnp/profiles/:upnp_device_profile/actions/:action/arguments/: \( \to \) argument/"

\( \to \) argument/"

\( \to \) argument type",

"is_output":false,

"name":"Sample value of argument name",

"state_id":null
}
```

Sample write command (note that :upnp_device_profile, :action and :argument are URL template arguments and need to be replaced before trying):

Sample deletion command (note that :upnp_device_profile, :action and :argument are URL template arguments and need to be replaced before trying):

10.8.1 Output/return value flag

sum (boolean)	upnp/profiles/S/actions/S/arguments/N/is_output/
Flag indicating that the argument is output/return instead of input	

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Output/return	The argument is output, and also the return value if it's
		the first output argument
constant false	Input	The argument is input

Sample read command (note that :upnp_device_profile, :action and :argument are URL template arguments and need to be replaced before trying):

Sample (possible variant) write command (note that :upnp_device_profile, :action and :argument are URL template arguments and need to be replaced before trying):

10.8.2 Argument name

string	upnp/profiles/S/actions/S/arguments/N/name/
The name of the argument as seen by clients	

The value is subject to the following constraints: the value matches ^[a-zA-Z_][a-zA-Z_0-9]*\$

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile, :action and :argument are URL template arguments and need to be replaced before trying):

Sample write command (note that :upnp_device_profile, :action and :argument are URL template arguments and need to be replaced before trying):

10.8.3 Related state variable identifier, if any

sum (optional string)	upnp/profiles/S/actions/S/arguments/N/state_id/
The identifier of the state variable to which the argument is related, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	No related state variable	The argument isn't related to a state variable	
string	Related state variable identifier	The identifier of the state variable to which the argument is re-	state variables[the value]
		lated	

Sample read command (note that :upnp_device_profile, :action and :argument are URL template arguments and need to be replaced before trying):

Sample (possible variant) write command (note that :upnp_device_profile, :action and :argument are URL template arguments and need to be replaced before trying):

10.8.3.1 Related state variable identifier

(possibly) string	upnp/profiles/S/actions/S/arguments/N/state_id/
The identifier of the state variable to which the argument is related	

The value is subject to the following constraints: state variables[the value]

Sample write command (note that :upnp_device_profile, :action and :argument are URL template arguments and need to be replaced before trying):

10.8.4 Argument type

```
string upnp/profiles/S/actions/S/arguments/N/type/
The type of the argument
```

The value is subject to the following constraints: variable types[the value]

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings


This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile, :action and :argument are URL template arguments and need to be replaced before trying):

Sample write command (note that :upnp_device_profile, :action and :argument are URL template arguments and need to be replaced before trying):

10.9 UPnP device profile: Action map

```
map upnp/profiles/S/actions/
Map of actions that can be performed on the outlet
```



Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This map represents a value in persistent storage.

This map contains Action elements.


Sample read command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

Sample write command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

Sample action creation command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

10.9.1 Action

```
object upnp/profiles/S/actions/S/
Action properties
```



The value is subject to the following constraints: index of the value matches ^[a-zA-Z][a-zA-Z 0-9]*\$

This object contains the following items:

arguments	Arguments
code	Code

Sample read command (note that :upnp_device_profile and :action are URL template arguments and need to be replaced before trying):


Sample write command (note that :upnp_device_profile and :action are URL template arguments and need to be replaced before trying):

Sample deletion command (note that :upnp_device_profile and :action are URL template arguments and need to be replaced before trying):

```
curl --digest -u admin:1234 -X DELETE -H "Accept: application/json" "https \leftrightarrow ://192.168.0.100/restapi/upnp/profiles/:upnp_device_profile/actions/:action \leftrightarrow ://
```

10.9.1.1 Arguments

```
array upnp/profiles/S/actions/S/arguments/
Action input and output arguments
```



Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This array represents a value in persistent storage.

This array contains Argument elements.

Sample read command (note that :upnp_device_profile and :action are URL template arguments and need to be replaced before trying):

Sample write command (note that :upnp_device_profile and :action are URL template arguments and need to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/upnp/profiles/:upnp_device_profile/actions/:action \(\lefta\)
\(\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\til\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\te
```

Sample argument creation command (note that :upnp_device_profile and :action are URL template arguments and need to be replaced before trying):

See also Arguments: Argument

10.9.1.2 Code

```
string upnp/profiles/S/actions/S/code/
Code of Lua function to perform the action
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile and :action are URL template arguments and need to be replaced before trying):

Sample write command (note that :upnp_device_profile and :action are URL template arguments and need to be replaced before trying):

10.10 UPnP device profile: Device type

```
string upnp/profiles/S/device_type/
Device type identifier
```

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

Sample write command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

10.11 UPnP device profile: Device version

```
string upnp/profiles/S/device_version/

Device version string
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/upnp/profiles/:upnp_device_profile/device_version/"
```

 \Rightarrow

```
"Sample value"
```

Sample write command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

10.12 UPnP device profile: Device namespace

```
string upnp/profiles/S/device_xmlns/
Device description XML namespace
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

Sample write command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

10.13 UPnP device profile: Manufacturer

string	upnp/profiles/S/manufacturer/
Manufacturer name	

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

Sample write command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

10.14 UPnP device profile: Model

```
string upnp/profiles/S/model/
Model name
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

Sample write command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

10.15 UPnP device profile: Model number

```
string upnp/profiles/S/model_number/
Model number string
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

Sample write command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

10.16 UPnP device profile: Namespace identifier

```
string upnp/profiles/S/nid/
URN namespace identifier
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftrightarrow restapi/upnp/profiles/:upnp_device_profile/nid/"
```

 \Rightarrow

```
"Sample value"
```

Sample write command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

10.17 UPnP device profile: Service control URL

```
string upnp/profiles/S/service_control_url/
URL to send service control requests to
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

Sample write command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

10.18 UPnP device profile: Service event subscription URL

```
string upnp/profiles/S/service_event_sub_url/
URL to send service subscription management requests to
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

Sample write command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

10.19 UPnP device profile: Service ID

```
string upnp/profiles/S/service_id/
Service identifier
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

Sample write command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

10.20 UPnP device profile: Service SCPD URL

```
string upnp/profiles/S/service_scpd_url/
Service control protocol document URL
```

Changing the value is denied if any of the following is true:

- not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

Sample write command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

10.21 UPnP device profile: Service type

```
string upnp/profiles/S/service_type/
Service type identifier
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

```
⇒
"Sample value"
```

Sample write command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

10.22 UPnP device profile: Service version

```
string upnp/profiles/S/service_version/
Service version string
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

Sample write command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

10.23 UPnP device profile: Service namespace

```
string upnp/profiles/S/service_xmlns/
Service description XML namespace
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings


This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

Sample write command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

10.24 UPnP device profile: State variables

```
map upnp/profiles/S/state_variables/
Map of state variable bindings
```



Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This map represents a value in persistent storage.

This map contains State variable binding elements.

Sample read command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←
    → restapi/upnp/profiles/:upnp_device_profile/state_variables/"
\Rightarrow
 "state_variables_2":{
 "default_value":"Sample value of state variable binding state_variables_2 of \leftarrow
     → default variable name",
 "events_enabled":false,
 "name":"Sample value of state variable binding state_variables_2 of outlet \,\hookleftarrow\,
     → property name",
 "type":"Sample value of state variable binding state_variables_2 of variable \,\hookleftarrow

→ type"

},
 "state_variables_1":{
 "default_value": "Sample value of state variable binding state_variables_1 of ←
     → default variable name",
 "events_enabled":false,
 "name":"Sample value of state variable binding state_variables_1 of outlet ↔
     → property name",
 "type": "Sample value of state variable binding state_variables_1 of variable \leftarrow

→ type"

 }
}
```

Sample write command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/upnp/profiles/:upnp_device_profile/state_variables \(\rightarrow\)
```

Sample state variable binding creation command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

10.24.1 State variable binding

```
object upnp/profiles/S/state_variables/S/
Properties of a state variable binding
```

The value is subject to the following constraints: index of the value matches ^[a-zA-Z_][a-zA-Z_0-9]*\$

This object contains the following items:

default_value	Default variable name
events_enabled	Events
name	Outlet property name
type	Variable type

Sample read command (note that :upnp_device_profile and :state_variable_binding are URL template arguments and need to be replaced before trying):

Sample write command (note that :upnp_device_profile and :state_variable_binding are URL template arguments and need to be replaced before trying):

Sample deletion command (note that :upnp_device_profile and :state_variable_binding are URL template arguments and need to be replaced before trying):

10.24.1.1 Default variable name

string	upnp/profiles/S/state_variables/S/default_value/	
The string-encoded default value of the state variable		

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile and :state_variable_binding are URL template arguments and need to be replaced before trying):

Sample write command (note that :upnp_device_profile and :state_variable_binding are URL template arguments and need to be replaced before trying):

10.24.1.2 Events

sum (boolean)	upnp/profiles/S/state_variables/S/events_enabled/	
Send events on property change		

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command (note that :upnp_device_profile and :state_variable_binding are URL template arguments and need to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/upnp/profiles/:upnp_device_profile/state_variables/: ←
```

Sample (possible variant) write command (note that :upnp_device_profile and :state_variable_binding are URL template arguments and need to be replaced before trying):

10.24.1.3 Outlet property name

```
string upnp/profiles/S/state_variables/S/name/
The outlet property to which the variable is bound
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile and :state_variable_binding are URL template arguments and need to be replaced before trying):

Sample write command (note that :upnp_device_profile and :state_variable_binding are URL template arguments and need to be replaced before trying):

10.24.1.4 Variable type

```
string upnp/profiles/S/state_variables/S/type/
The type of the variable
```

The value is subject to the following constraints: variable types[the value]

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings


This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile and :state_variable_binding are URL template arguments and need to be replaced before trying):

Sample write command (note that :upnp_device_profile and :state_variable_binding are URL template arguments and need to be replaced before trying):

10.25 UPnP device profile: Variable types

```
map upnp/profiles/S/types/
Map of supported variable types
```



Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This map represents a value in persistent storage.

This map contains Variable type elements.

Sample read command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

Sample write command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/upnp/profiles/:upnp_device_profile/types/"
```

Sample variable type creation command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"decode\":\"Sample value of variable type variable_types_1 of \( \rightarrow \) decoding function\",\"encode\":\"Sample value of variable type \( \rightarrow \) variable_types_1 of encoding function\"}"\
"https://192.168.0.100/restapi/upnp/profiles/:upnp_device_profile/types/ \( \rightarrow \) variable_types_1/"
```

10.25.1 Variable type

```
object upnp/profiles/S/types/S/
Variable type properties
```

The value is subject to the following constraints: index of the value matches ^[a-zA-Z_][a-zA-Z_0-9]*\$

This object contains the following items:

decode	Decoding function
encode	Encoding function

Sample read command (note that :upnp_device_profile and :variable_type are URL template arguments and need to be replaced before trying):

Sample write command (note that :upnp_device_profile and :variable_type are URL template arguments and need to be replaced before trying):

Sample deletion command (note that :upnp_device_profile and :variable_type are URL template arguments and need to be replaced before trying):

10.25.1.1 Decoding function

```
string upnp/profiles/S/types/S/decode/
Code of Lua function to decode and validate the value's string representation
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile and :variable_type are URL template arguments and need to be replaced before trying):

Sample write command (note that :upnp_device_profile and :variable_type are URL template arguments and need to be replaced before trying):

10.25.1.2 Encoding function

string	upnp/profiles/S/types/S/encode/
Code of Lua function to check and encode the value to string representation	

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile and :variable_type are URL template arguments and need to be replaced before trying):

Sample write command (note that :upnp_device_profile and :variable_type are URL template arguments and need to be replaced before trying):

10.26 UPnP device profile: UUID prefix

```
string upnp/profiles/S/uuid_prefix/
Outlet device identifier prefix
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

· not administrative user

· protect network settings


This string represents a value in persistent storage.

Sample read command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

Sample write command (note that :upnp_device_profile is a URL template argument and needs to be replaced before trying):

10.27 Notifications

```
object upnp/notifications/
UPnP-related notifications
```



This object does not support direct modification.

This object contains the following items:


10.27 Notifications 415

events	Events
parameter_kinds	Parameter kinds

Sample read command:

10.27.1 Events

map	upnp/notifications/events/	
Event	Event templates	



This map does not support direct modification.

This map contains **Event** elements.

Sample read command:

Creating elements in this collection is not supported.

See also Events: Event

10.27.2 Parameter kinds

object	ct upnp/notifications/parameter_kinds/		
Kinds o	Kinds of event parameters		

This object does not correspond to an actual resource.

This object is empty.

10.28 Message template: Message template element

sum (variant)	upnp/notifications/events/S/message_template/N/	
Element of human-readable message template		

This sum does not support direct modification.

This sum can assume the following values:

string	String	Fixed string	
number	Parameter	Index of message parameter to insert	event parameters[the value]

Sample read command (note that :event and :message_template_element are URL template arguments and need to be replaced before trying):

10.28.1 String

(possibly) string	upnp/notifications/events/S/message_template/N/
Fixed string	

10.28.2 Parameter

(possibly) number	upnp/notifications/events/S/message_template/N/
Index of message parameter to insert	

The value is subject to the following constraints: event parameters[the value]

10.29 Event parameter: Fixed value

sum (variant)	upnp/notifications/events/S/parameters/N/fixed_value/		
Fixed paramete	Fixed parameter value for this particular event		

This sum does not support direct modification.

This sum can assume the following values:

constant null	Null	Null
constant true	True	True
constant false	False	False
string	String	This string
number	Number	This number

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

10.29.1 String

(possibly) string	upnp/notifications/events/S/parameters/N/fixed_value/
This string	

10.29.2 Number

(possibly) number	upnp/notifications/events/S/parameters/N/fixed_value/
This number	

10.30 Event parameter: Fixed value flag

sum (boolean)	upnp/notifications/events/S/parameters/N/has_fixed_value/	
Flag indicating	Flag indicating that the parameter's value for this event is fixed	

This sum does not support direct modification.

This sum can assume the following values:

constant true	Fixed	The value is fixed
constant false	Variable	The value is variable

Sample read command (note that :event and :event_parameter are URL template arguments and need to be re-

placed before trying):

10.31 Event parameter: Identifier

string	upnp/notifications/events/S/parameters/N/id/		
Parame	Parameter identifier		

The value is subject to the following constraints: parameter kinds


This string does not support direct modification.

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

10.32 Events: Event

object	ect upnp/notifications/events/S/		
Event to	Event template		

10.32 Events: Event 419



This object contains the following items:

message_template	Message template
parameters	Event parameters
severity	Severity

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

Sample write command (note that :event is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/upnp/notifications/events/:event/"
```

10.32.1 Message template

array	upnp/notifications/events/S/message_template/
Template for human-readable message generation	

This array does not support direct modification.

This array contains Message template element elements.


Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

Creating elements in this collection is not supported.

See also Message template: Message template element

10.32.2 Event parameters

```
array upnp/notifications/events/S/parameters/
Additional data associated with the event
```



This array does not support direct modification.

This array contains **Event parameter** elements.

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

10.32 Events: Event 421

```
"id": "Sample value of event parameter #1 of identifier"
},
"fixed_value":null,
"has_fixed_value":true,
"id": "Sample value of event parameter #2 of identifier"
},
"fixed_value":null,
"has_fixed_value":true,
"id": "Sample value of event parameter #3 of identifier"
},
"fixed_value":null,
"has_fixed_value":false,
"id": "Sample value of event parameter #4 of identifier"
},
"fixed_value":6,
"has_fixed_value":false,
"id": "Sample value of event parameter #5 of identifier"
```

Creating elements in this collection is not supported.

10.32.2.1 Event parameter

object	upnp/notifications/events/S/parameters/N/	
Propert	Properties of a parameter associated with the event	

This object contains the following items:

fixed_value	Fixed value
has_fixed_value	Fixed value flag
id	Identifier

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

Sample write command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
```

See also Event parameter: Fixed value

See also Event parameter: Fixed value flag

See also Event parameter: Identifier

10.32.3 Severity

sum (enumerated number)	upnp/notifications/events/S/severity/
Severity rating assigned to the event	

This sum does not support direct modification.

This sum can assume the following values:


constant 1	Emergency	Treat the event as an emergency
constant 2	Alert	Treat the event as an alert
constant 3	Critical	Treat the event as critical
constant 4	Error	Treat the event as an error
constant 5	Warning	Treat the event as a warning
constant 6	Notice	Treat the event as a notice
constant 7	Informational	Treat the event as informational
constant 8	Debug	Treat the event as debugging-related

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

11 MQTT client object

object	mqtt/	
Object representing the MQTT client configuration		

11 MQTT client object 423



This object contains the following items:

enabled	Enabled
outlets	Outlet MQTT configuration settings
broker_address	MQTT broker address
use_ssl	Use SSL
username	Username
password	Password
topic_root	Topic root
lwt_topic	Last Will and Testament topic
lwt_payload	Last Will and Testament payload
lwt_qos	Last Will and Testament QoS
notifications	Notifications
broker_port	MQTT broker port, if any

Sample read command:

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "..." "https://192.168.0.100/restapi/mqtt \leftrightarrow \leftrightarrow /"
```

11.1 Enabled

sum (boolean)	mqtt/enabled/
MQTT client enable status	

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled


Sample read command:

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "true" "https://192.168.0.100/restapi/ \leftrightarrow mqtt/enabled/"
```

11.2 Outlet MQTT configuration settings

```
array mqtt/outlets/
Properties related to exposing outlets via MQTT
```



The value is subject to the following constraints: length of the value is equal to length of outlets

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This array represents a value in persistent storage.

This array contains Outlet MQTT configuration elements.

Sample read command:

Sample write command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/mqtt/outlets/"
```

Sample outlet mqtt configuration creation command:

```
curl\
--digest\
-u admin:1234\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"topic_subtree\":\"Sample value of topic subtree, if any\",\" \( \topic_subtree\":\"sample value of topic
```

11.2.1 Outlet MQTT configuration

object	mqtt/outlets/N/
Properties related to exposing the outlet via MQTT	

The value is subject to the following constraints: outlets[index of the value]

This object contains the following items:

allow_read	Allow read
allow_write	Allow write
qos	State subscription and report QoS
topic_subtree	Topic subtree, if any

Sample read command (note that :outlet_mqtt_configuration is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \( \topic_\) restapi/mqtt/outlets/:outlet_mqtt_configuration/"

\( \topic_\) subtree":null,

"allow_read":false,

"allow_write":true,

"qos":5
}
```

Sample write command (note that :outlet_mqtt_configuration is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"topic_subtree\":null,\"allow_read\":true,\"allow_write\":false \( \topic_subtree\) \\ \"qos\":2}"\
"https://192.168.0.100/restapi/mqtt/outlets/:outlet_mqtt_configuration/"
```

Sample deletion command (note that :outlet_mqtt_configuration is a URL template argument and needs to be replaced before trying):

See also Outlet MQTT configuration: Allow read

See also Outlet MQTT configuration: Allow write

See also Outlet MQTT configuration: State subscription and report QoS

See also Outlet MQTT configuration: Topic subtree, if any

11.3 Outlet MQTT configuration: Allow read

sum (boolean)	mqtt/outlets/N/allow_read/
Outlet state is broadcasted via MQTT	

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command (note that :outlet_mqtt_configuration is a URL template argument and needs to be replaced before trying):

 \Rightarrow (possible variant)

false

Sample (possible variant) write command (note that :outlet_mqtt_configuration is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "false" "https://192.168.0.100/restapi/ \leftrightarrow : mqtt/outlets/:outlet_mqtt_configuration/allow_read/"
```

11.4 Outlet MQTT configuration: Allow write

sum (boolean)	mqtt/outlets/N/allow_write/
Outlet state can be changed via MQTT	

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Enabled	The feature is enabled
constant false	Disabled	The feature is disabled

Sample read command (note that :outlet_mqtt_configuration is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :outlet_mqtt_configuration is a URL template argument and needs to be replaced before trying):

11.5 Outlet MQTT configuration: State subscription and report QoS

sum (enumerated number)	mqtt/outlets/N/qos/	
Quality of service when subscribing to and broadcasting outlet state		

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- not administrative user
- · protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant 0	At most once	most once Message should be delivered at most once	
constant 1	At least once	Message should be delivered at least once	
constant 2 Exactly once Message should be delivered e		Message should be delivered exactly once	

Sample read command (note that :outlet_mqtt_configuration is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :outlet_mqtt_configuration is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow: application/json" --data-binary "7" "https://192.168.0.100/restapi/mqtt/ \leftrightarrow: outlets/:outlet_mqtt_configuration/qos/"
```

11.6 Outlet MQTT configuration: Topic subtree, if any

sum (optional string)	mqtt/outlets/N/topic_subtree/
MQTT topic subtree (relative to the topic root), if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Outlet index-based	Use 'outlets/'+the 0-based outlet index as topic subtree
string	Topic subtree	MQTT topic subtree (relative to the topic root)

Sample read command (note that :outlet_mqtt_configuration is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :outlet_mqtt_configuration is a URL template argument and needs to be replaced before trying):

11.6.1 Topic subtree

(possibly) string	mqtt/outlets/N/topic_subtree/
MQTT topic subtree (relative to the topic root)	

Sample write command (note that :outlet_mqtt_configuration is a URL template argument and needs to be replaced before trying):

11.7 MQTT broker address

```
sum (string) mqtt/broker_address/
Host name or IPv4 address of the MQTT broker to connect to
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

string	Hostname	Hostname	the value matches ^(([a-zA-Z0-9] [a-zA-Z0-9][a-zA-Z0-9]][a-zA-Z0-9-]*[a-zA-Z0-9]].)*([A-Za-z]([A-← Za-z0-9-]*[A-Za-z0-9]]? [A-Za-z0-9]]A-Za-z0-9-]*[A-Za-z0-9])?)\$
string	IPv4 address	IPv4 address in dotted quad notation	the value matches ^(([0-9] [1-9][0-9] 1[0-9]{2} 2[0-4][0-9] 25[0-5]).){3}([0-9] [1-9][0-9] 1[0-9][2] 2[0-4][0-9] 25[0-5])\$

Sample read command:

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "\"Sample value\"" "https \leftrightarrow ://192.168.0.100/restapi/mqtt/broker_address/"
```

11.7.1 Hostname

(possibly) string	mqtt/broker_address/
Hostname	

The value is subject to the following constraints: the value matches (([a-zA-Z0-9]|[a-zA-Z0-9]|[a-zA-Z0-9]*[a-zA-Z0-9])))*([A-Za-z]([A-Za-z0-9-]*[A-Za-z0-9])))

Sample write command:

11.7.2 IPv4 address

```
(possibly) string mqtt/broker_address/
IPv4 address in dotted quad notation
```

Sample write command:

11.8 Use SSL

```
sum (boolean) | mqtt/use_ssl/
Use SSL when connecting to the MQTT broker
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

CC	nstant true	Enabled	The feature is enabled	
CC	nstant false	Disabled	The feature is disabled	

11.10 Password 433

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←
    → restapi/mqtt/use_ssl/"
\Rightarrow (possible variant)
true
Sample (possible variant) write command:
```

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept ←
    \hookrightarrow: application/json" --data-binary "false" "https://192.168.0.100/restapi/ \hookleftarrow
   → mqtt/use_ssl/"
```

11.9 Username

```
mqtt/username/
string
Username to use when connecting to the MQTT broker
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This string represents a value in persistent storage.

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←
   → restapi/mqtt/username/"
"Sample value"
```

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept ←
   → : application/json" --data-binary "\"Sample value\"" "https ↔
   → ://192.168.0.100/restapi/mqtt/username/"
```

11.10 Password

```
mqtt/password/
string
Password to use when connecting to the MQTT broker
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- protect network settings

This string represents a value in persistent storage.

This string should be displayed in a secure manner.

Sample read command:

Sample write command:

11.11 Topic root

```
string mqtt/topic_root/
Topic root to use for all messages
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command:

11.12 Last Will and Testament topic

→ ://192.168.0.100/restapi/mqtt/topic_root/"

```
string mqtt/lwt topic/
```

Topic of the message for the broker to send if the unit goes offline unexpectedly (not relative to the topic root)

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command:

Sample write command:

11.13 Last Will and Testament payload

```
string mqtt/lwt_payload/
Payload of the message for the broker to send if the unit goes offline unexpectedly
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

→ ://192.168.0.100/restapi/mqtt/lwt_payload/"

- · not administrative user
- · protect network settings

This string represents a value in persistent storage.

Sample read command:

11.14 Last Will and Testament QoS

sum (enumerated number)	mqtt/lwt_qos/		
Quality of service for the message for the broker to send if the unit goes offline unexpectedly			

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- not administrative user
- protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant 0	At most once	at most once Message should be delivered at most once	
constant 1	At least once	Message should be delivered at least once	
constant 2 Exactly once Message should be delivered exactly once			

Sample read command:


Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "4" "https://192.168.0.100/restapi/mqtt/ \leftrightarrow \times \text{lwt_qos/"}
```

11.15 Notifications

object	mqtt/notifications/		
MQTT-r	MQTT-related notifications		

11.15 Notifications 437



This object does not support direct modification.


This object contains the following items:

events	Events
parameter_kinds	Parameter kinds

Sample read command:

11.15.1 Events

map	mqtt/notifications/events/		
Event	Event templates		



This map does not support direct modification.

This map contains **Event** elements.

Sample read command:

Creating elements in this collection is not supported.

See also Events: Event

See also Notifications: Parameter kinds

11.16 Message template: Message template element

sum (variant)	mqtt/notifications/events/S/message_template/N/	
Element of human-readable message template		

This sum does not support direct modification.

This sum can assume the following values:

string	String	Fixed string	
number	Parameter	Index of message parameter to insert	event parameters[the value]

Sample read command (note that :event and :message_template_element are URL template arguments and need to be replaced before trying):

11.16.1 String

(possibly) string	ng mqtt/notifications/events/S/message_template/N/	
Fixed string		

11.16.2 Parameter

(possibly) number	mqtt/notifications/events/S/message_template/N/		
Index of message parameter to insert			

The value is subject to the following constraints: event parameters[the value]

11.17 Event parameter: Fixed value

sum (variant) mqtt/notifications/events/S/parameters/N/fixed_value/		
Fixed parameter value for this particular event		

This sum does not support direct modification.

This sum can assume the following values:

constant null	Null	Null
constant true	True	True
constant false	False	False
string	String	This string
number	Number	This number

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

11.17.1 String

(possibly) string	mqtt/notifications/events/S/parameters/N/fixed_value/	
This string		

11.17.2 Number

(possibly) number mqtt/notifications/events/S/parameters/N/fixed_value/	
This number	

11.18 Event parameter: Fixed value flag

sum (boolean)	mqtt/notifications/events/S/parameters/N/has_fixed_value/	
Flag indicating that the parameter's value for this event is fixed		

This sum does not support direct modification.

This sum can assume the following values:

constant true	Fixed	The value is fixed
constant false	Variable	The value is variable

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

11.19 Event parameter: Identifier

string	mqtt/notifications/events/S/parameters/N/id/
Parameter identifier	

The value is subject to the following constraints: parameter kinds


This string does not support direct modification.

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

11.20 Events: Event 441

11.20 Events: Event

object	mqtt/notifications/events/S/	
Event to	Event template	



This object contains the following items:

message_template	Message template	
parameters	Event parameters	
severity	Severity	

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

Sample write command (note that :event is a URL template argument and needs to be replaced before trying):

11.20.1 Message template

```
array mqtt/notifications/events/S/message_template/
Template for human-readable message generation
```

This array does not support direct modification.

This array contains Message template element elements.


Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

Creating elements in this collection is not supported.

See also Message template: Message template element

11.20.2 Event parameters

array	mqtt/notifications/events/S/parameters/	
Additional data associated with the event		



11.20 Events: Event 443

This array does not support direct modification.

This array contains **Event parameter** elements.

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow
   → restapi/mqtt/notifications/events/:event/parameters/"
\Rightarrow
[
 "fixed_value":true,
 "has_fixed_value":true,
 "id": "Sample value of event parameter #1 of identifier"
 "fixed_value": "Sample value of event parameter #2 of fixed value",
 "has_fixed_value":false,
 "id": "Sample value of event parameter #2 of identifier"
},
 "fixed_value":null,
 "has_fixed_value":true,
 "id": "Sample value of event parameter #3 of identifier"
},
 "fixed_value":8,
 "has_fixed_value":true,
 "id": "Sample value of event parameter #4 of identifier"
 "fixed_value":7,
 "has_fixed_value":true,
 "id": "Sample value of event parameter #5 of identifier"
},
 "fixed_value":null,
 "has_fixed_value":false,
 "id": "Sample value of event parameter #6 of identifier"
```

Creating elements in this collection is not supported.

11.20.2.1 Event parameter

object	mqtt/notifications/events/S/parameters/N/		
Propert	Properties of a parameter associated with the event		

This object contains the following items:

fixed_value	Fixed value	
has_fixed_value	Fixed value flag	
id	Identifier	

Sample read command (note that :event and :event_parameter are URL template arguments and need to be re-

placed before trying):

Sample write command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"fixed_value\":\"Sample value of fixed value\",\"has_fixed_value \\
\to \\":false,\\"id\\":\"Sample value of identifier\\"}\\
"https://192.168.0.100/restapi/mqtt/notifications/events/:event/parameters/: \to \\
\to event_parameter/\"
```

See also Event parameter: Fixed value

See also Event parameter: Fixed value flag

See also Event parameter: Identifier

11.20.3 Severity

sum (enumerated number)	mqtt/notifications/events/S/severity/	
Severity rating assigned to the event		

This sum does not support direct modification.

This sum can assume the following values:

constant 1	Emergency	Treat the event as an emergency	
constant 2	Alert	Treat the event as an alert	
constant 3	Critical	Treat the event as critical	
constant 4	Error	Treat the event as an error	
constant 5	Warning	Treat the event as a warning	
constant 6	Notice	Treat the event as a notice	
constant 7	Informational	Treat the event as informational	
constant 8	Debug	Treat the event as debugging-related	

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

```
⇒ (possible variant)9
```

11.21 Notifications: Parameter kinds

object	mqtt/notifications/parameter_kinds/		
Kinds o	Kinds of event parameters		

This object does not correspond to an actual resource.

This object contains the following items:

connected	Connection status
-----------	-------------------

11.21.1 Connection status

sum (boolean)	mqtt/notifications/parameter_kinds/connected/	
Broker connection status		

This sum can assume the following values:

constant true	Connected	Broker connection successful
constant false	Failed to connect	Broker connection failed

Sample read command:

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "true" "https://192.168.0.100/restapi/ \hookrightarrow mqtt/notifications/parameter_kinds/connected/"
```

11.22 MQTT broker port, if any

```
sum (optional number) mqtt/broker_port/
Port of the MQTT broker to connect to, if any
```

Retrieving the value is denied if not administrative user

Changing the value is denied if any of the following is true:

- · not administrative user
- · protect network settings

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Use default port	Connect to port 1883 when SSL is not used, port 8883 if SSL is used	
number	MQTT broker port	Port of the MQTT broker to connect to	all of the following is true: • the value is an integer
			• the value is greater than 0
			the value is less than 65535

Sample read command:

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow : application/json" --data-binary "null" "https://192.168.0.100/restapi/ \hookrightarrow mqtt/broker_port/"
```

11.22.1 MQTT broker port

```
(possibly) number | mqtt/broker_port/
Port of the MQTT broker to connect to
```

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater than 0
- the value is less than 65535


Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "2" "https://192.168.0.100/restapi/mqtt/ \hookleftarrow \hookrightarrow broker_port/"
```

12 Meter server object

12 Meter server object 447

```
object meter/
Object representing the meter server state and configuration
```



Retrieving the value is denied if not administrative user

This object contains the following items:

values	Measured values
buses	Bus list
power_status	Power status
emergency_off_status	Emergency shutoff status
notifications	Notifications


Sample read command:

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow : application/json" --data-binary "..." "https://192.168.0.100/restapi/ \hookleftarrow \hookrightarrow meter/"
```

Measured values 12.1

```
meter/values/
map
Values measured by meters
```



This map contains Measured value elements.

-H "Content-type: application/json"\ -H "Accept: application/json"\

"https://192.168.0.100/restapi/meter/values/measured_values_3/"

```
Sample read command:
```

-X PUT\

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←


→ restapi/meter/values/"

Sample write command:
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept ←
    → : application/json" --data-binary "..." "https://192.168.0.100/restapi/ ←
    → meter/values/"
Sample measured value creation command:
curl\
--digest\
-u admin:1234\
```

12.1 Measured values 449

12.1.1 Measured value

object	meter/values/S/
Value m	neasured by meter



The value is subject to the following constraints: not index of the value matches (|.*|.*)\$

Removing the object from its parent collection is denied if not custom flag

This object contains the following items:

name	Value name
value	Value, if any
expression	Expression, if any
custom	Custom flag
in_calibration	Calibration flag
supports_calibration	Calibration support flag
quantity	Quantity
bus	Bus index, if any
internal	Internal
log_history	Log history
history_parameters	History log parameters
get_history	Get value history
clear_history	Clear value history
data_absence_alarm_level	Data absence alarm level, if any
data_absence_alarm_period	Data absence alarm period, if any

lowest_interval_alarm_level	Lowest interval alarm level, if any
lowest_interval_alarm_period	Lowest interval alarm period, if any
intervals	Value interval properties
commit_calibration	Commit calibration
history_subsample_count	History subsample count
history_time_step	History time step
insert_calibration_point	Insert calibration point

Sample read command (note that :measured_value is a URL template argument and needs to be replaced before trying):

Sample write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
\
"https://192.168.0.100/restapi/meter/values/:measured_value/"
```

Sample deletion command (note that :measured_value is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X DELETE -H "Accept: application/json" "https \leftrightarrow ://192.168.0.100/restapi/meter/values/:measured_value/"
```

See also Measured value: Value name

See also Measured value: Value, if any

See also Measured value: Expression, if any

See also Measured value: Custom flag

See also Measured value: Calibration flag

See also Measured value: Calibration support flag

See also Measured value: Quantity

See also Measured value: Bus index, if any

See also Measured value: Internal

See also Measured value: Log history

See also Measured value: History log parameters

See also Measured value: Get value history

See also Measured value: Clear value history

See also Measured value: Data absence alarm level, if any

See also Measured value: Data absence alarm period, if any

See also Measured value: Lowest interval alarm level, if any

See also Measured value: Lowest interval alarm period, if any

See also Measured value: Value interval properties

See also Measured value: Commit calibration

See also Measured value: History subsample count

See also Measured value: History time step

See also Measured value: Insert calibration point

12.2 Measured value: Value name

string	meter/values/S/name/	
Name	Name of the measured value	

This string does not support direct modification if not custom flag.

This string represents a value in persistent storage.

Sample read command (note that :measured_value is a URL template argument and needs to be replaced before trying):

Sample write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.3 Measured value: Value, if any

```
sum (variant) meter/values/S/value/
Current value measured by meter, if any
```

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum does not support direct modification if all of the following is true:

- · not custom flag
- · agent identifier is not equal to relay

This sum can change as if by itself or indirectly because of other actions.

Changes to this sum may have an effect besides setting value.

This sum can assume the following values:

number	Value	Current value measured by meter
constant false	No value	Indication that measurement is currently not being carried out

Sample read command (note that :measured_value is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.3.1 Value

```
(possibly) number | meter/values/S/value/
Current value measured by meter
```

Sample write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.4 Measured value: Expression, if any

sum (optional string)	meter/values/S/expression/	
Expression governing the value, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum does not support direct modification if not custom flag.

This sum represents a value in persistent storage.

This sum can change as if by itself or indirectly because of other actions.

This sum can assume the following values:

constant null	Variable	The value can be modified arbitrarily
string	Expression	Expression governing the value

Sample read command (note that :measured_value is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.4.1 Expression

```
(possibly) string meter/values/S/expression/
Expression governing the value
```

Sample write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.5 Measured value: Custom flag

```
sum (boolean) meter/values/S/custom/

Flag indicating whether the value is custom
```

Retrieving the value is denied if not administrative user

This sum does not support direct modification.

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Custom	The value is custom and can be modified freely
constant false	Built-in	The value is built-in and only the hardware can modify
		it

Sample read command (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.6 Measured value: Calibration flag

sum (boolean)	meter/values/S/in_calibration/	
Flag indicating whether the value is being calibrated		

The value is subject to the following constraints: any of the following is true:

- · calibration support flag
- · not the value

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum does not support direct modification if not calibration support flag.

This sum can change as if by itself or indirectly because of other actions if calibration support flag.

This sum can assume the following values:

constant true	Calibration	The value is being calibrated (it can be updated to match external reference)
constant false	Measurement	The value is being measured

Sample read command (note that :measured_value is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ← 

→ restapi/meter/values/:measured_value/in_calibration/"
```

 \Rightarrow (possible variant)

false

Sample (possible variant) write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.7 Measured value: Calibration support flag

sum (boolean)	meter/values/S/supports_calibration/	
Flag indicating whether calibrating the value is supported		

Retrieving the value is denied if not administrative user

This sum does not support direct modification.

This sum represents a value in persistent storage.

This sum can assume the following values:

ue, or it does
Je,

Sample read command (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.8 Measured value: Quantity

false

string	meter/values/S/quantity/	
Quantit	Quantity of the value	

The value is subject to the following constraints: known quantities[the value]

This string does not support direct modification if not custom flag.

This string represents a value in persistent storage.

Sample read command (note that :measured_value is a URL template argument and needs to be replaced before trying):

Sample write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.9 Measured value: Bus index, if any

sum (optional number)	meter/values/S/bus/
Index of bus being measured, if any	

This sum does not support direct modification if not custom flag.

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	Unspecified	The value is not related to a bu	IS
number	Bus index	Index of bus being measured	buses[the value]

Sample read command (note that :measured_value is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.9.1 Bus index

(possibly) number	meter/values/S/bus/	
Index of bus being I	Index of bus being measured	

The value is subject to the following constraints: buses[the value]

Sample write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.10 Measured value: Internal

sum (boolean)	meter/values/S/internal/
Flag indicating whether this value is internal	

This sum does not support direct modification if not custom flag.

This sum represents a value in persistent storage.

This sum can assume the following values:

constant true	Internal	The value is internal and should not matter to users
constant false	Visible	The value should be visible to users

Sample read command (note that :measured_value is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow : application/json" --data-binary "true" "https://192.168.0.100/restapi/ \hookrightarrow meter/values/:measured_value/internal/"
```

12.11 Measured value: Log history

sum (boolean)	meter/values/S/log_history/	
Flag indicating whether the value should be logged to the history		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.


constant tri	ue Enabled	The feature is enabled
constant fa	lse Disabled	The feature is disabled

Sample read command (note that :measured_value is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.12 Measured value: History log parameters

```
array meter/values/S/history_parameters/
Configuration of history logs sampling intervals and timespans
```



Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This array represents a value in persistent storage.

This array can change as if by itself or indirectly because of other actions.

This array contains History log elements.

Sample read command (note that :measured_value is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←

→ restapi/meter/values/:measured_value/history_parameters/"

[
[
 6,
 2
],
[
 4,
 9
],
[
 3,
 7
],
[
 4,
 2
],
Γ
 1.
 10
1
```

Sample write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

Sample history log creation command (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.12.1 History log

```
tuple meter/values/S/history_parameters/N/
History log settings
```

This tuple contains the following items:

1	Interval
2	Span

Sample read command (note that :measured_value and :history_log are URL template arguments and need to be replaced before trying):

Sample write command (note that :measured_value and :history_log are URL template arguments and need to be replaced before trying):

Sample deletion command (note that :measured_value and :history_log are URL template arguments and need to be replaced before trying):

12.12.1.1 Interval

```
number | meter/values/S/history_parameters/N/1/
```

Time interval between two consecutive history samples (changes will trigger history rebuilding and may cause adjustments to time span)

The value is subject to the following constraints: all of the following is true:

- the value is greater than 0
- the value modulo history time step is equal to 0

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

This number can change as if by itself or indirectly because of other actions.

Sample read command (note that :measured_value and :history_log are URL template arguments and need to be replaced before trying):

Sample write command (note that :measured_value and :history_log are URL template arguments and need to be replaced before trying):

12.12.1.2 Span

number	meter/values/S/history_parameters/N/2/		
Time spa	Time span covered by history fragment (changes will trigger history rebuilding)		

The value is subject to the following constraints: all of the following is true:

- the value is greater than 0
- · the value modulo interval is equal to 0

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

This number can change as if by itself or indirectly because of other actions.

Sample read command (note that :measured_value and :history_log are URL template arguments and need to be replaced before trying):

Sample write command (note that :measured_value and :history_log are URL template arguments and need to be replaced before trying):

12.13 Value history: Data point, if any

sum (variant)	meter/values/S/get_history/results: 1/3/N/	
Historical data	Historical data point, if any	

This sum does not correspond to an actual resource.

number	Data point	Historical data point, whose corresponding time is determined by array position
constant false	Missing data	Indication that data for the time determined by array position could not be found

12.13.1 Data point

(possibly) number	meter/values/S/get_history/results: 1/3/N/
Historical data point, whose corresponding time is determined by array position	

This number does not correspond to an actual resource.

12.14 Measured value: Get value history

call	meter/values/S/get_history/	
Get I	Get history of values over a specific time range	

Performing the function call is denied if not administrative user

The call accepts the following arguments:

- 1. number
- 2. number
- 3. number

The call returns the following results:

1. (number,number,array of "Data point or Missing data")

Sample invocation (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.14.1 Data start time

number	meter/values/S/get_history/arguments: 1/
Requested timestamp of the first data point to retrieve	

This number does not correspond to an actual resource.

12.14.2 Data end time

number	meter/values/S/get_history/arguments: 2/	
Requeste	Requested timestamp of the last data point to retrieve	

This number does not correspond to an actual resource.

12.14.3 Data time step


number	meter/values/S/get_history/arguments: 3/
Requested time step between succeeding data points	

The value is subject to the following constraints: the value is greater or equal to 0

This number does not correspond to an actual resource.

12.14.4 Value history record

tuple	meter/values/S/get_history/results: 1/
Historical measured values	



This tuple does not correspond to an actual resource.

This tuple contains the following items:

1	Data start time	
2	Data time step	
3	Value history	

12.14.4.1 Data start time

number | meter/values/S/get_history/results: 1/1/

Timestamp of the first retrieved historical data point (may differ from requested start timestamp)

This number does not correspond to an actual resource.

12.14.4.2 Data time step

number	meter/values/S/get_history/results: 1/2/
Time step between succeeding retrieved historical data points (may differ from requested time step)	

The value is subject to the following constraints: the value is greater or equal to 0

This number does not correspond to an actual resource.

12.14.4.3 Value history

array	meter/values/S/get_history/results: 1/3/	
Histori	Historical data points	

This array does not correspond to an actual resource.

This array contains Data point, if any elements.

See also Value history: Data point, if any

12.15 Measured value: Clear value history

```
call meter/values/S/clear_history/
Clear the complete history of values, and reset value to zero
```

Performing the function call is denied if not administrative user

The call has no arguments (supply empty tuple).

The call returns no results (expect an empty tuple).

Sample invocation (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.16 Measured value: Data absence alarm level, if any

sum (optional number)	meter/values/S/data_absence_alarm_level/
Alarm level for absence of data, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	None	No alarm is generated on absence of data
number	Data absence alarm level	Alarm level for absence of data

Sample read command (note that :measured_value is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.16.1 Data absence alarm level

```
(possibly) number | meter/values/S/data_absence_alarm_level/
Alarm level for absence of data
```

Sample write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow: application/json" --data-binary "4" "https://192.168.0.100/restapi/meter/ \leftrightarrow values/:measured_value/data_absence_alarm_level/"
```

12.17 Measured value: Data absence alarm period, if any

sum (optional number)	meter/values/S/data_absence_alarm_period/
The time interval after which data absence alarm events should be repeated, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	None	The data absence alarm event is generated only once on data loss and is not repeated	
number	Data absence alarm period	The time interval after which data absence alarm events should be repeated	the value is greater than 0

Sample read command (note that :measured_value is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.17.1 Data absence alarm period

(possibly) number	nber meter/values/S/data_absence_alarm_period/	
The time interval af	The time interval after which data absence alarm events should be repeated	

The value is subject to the following constraints: the value is greater than 0

Sample write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.18 Measured value: Lowest interval alarm level, if any

sum (optional number)	meter/values/S/lowest_interval_alarm_level/	
Alarm level for the lowest value interval, if any		

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

This sum can assume the following values:

constant null	None	No alarm is generated for the lowest value interval	Ī
number	Lowest interval alarm level	Alarm level for the lowest value interval	1

Sample read command (note that :measured_value is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow : application/json" --data-binary "null" "https://192.168.0.100/restapi/ \hookrightarrow meter/values/:measured_value/lowest_interval_alarm_level/"
```

12.18.1 Lowest interval alarm level

(possibly) number	meter/values/S/lowest_interval_alarm_level/	
Alarm level for the le	owest value interval	

Sample write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "1" "https://192.168.0.100/restapi/meter/ \leftrightarrow values/:measured_value/lowest_interval_alarm_level/"
```

12.19 Measured value: Lowest interval alarm period, if any

sum (optional number)	meter/values/S/lowest_interval_alarm_period/
The time interval after w	hich lowest interval alarm events should be repeated, if any

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

constant null	None	The alarm event is generated only once at lowest interval entry and is not repeated while the value is in the	
		interval	
number	Lowest interval alarm period	The time interval after which lowest	the value is greater than 0
		interval alarm events should be re-	
		peated	

Sample read command (note that :measured_value is a URL template argument and needs to be replaced before trying):

Sample (possible variant) write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.19.1 Lowest interval alarm period

(possibly) number	meter/values/S/lowest_interval_alarm_period/
The time interval af	ter which lowest interval alarm events should be repeated

The value is subject to the following constraints: the value is greater than 0

Sample write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "6" "https://192.168.0.100/restapi/meter/ \leftrightarrow values/:measured_value/lowest_interval_alarm_period/"
```

12.20 Interval configuration: Alarm level, if any

sum (optional number)	meter/values/S/intervals/N/alarm_level/
The level of importance assigned to this interval, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

constant null	None	No alarm is generated for this value interval
number	Alarm level	The level of importance assigned to this interval

Sample read command (note that :measured_value and :interval_configuration are URL template arguments and need to be replaced before trying):

null

Sample (possible variant) write command (note that :measured_value and :interval_configuration are URL template arguments and need to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "9" "https://192.168.0.100/restapi/meter/ \leftrightarrow values/:measured_value/intervals/:interval_configuration/alarm_level/"
```

12.20.1 Alarm level

(possibly) number	meter/values/S/intervals/N/alarm_level/	
The level of importance assigned to this interval		

Sample write command (note that :measured_value and :interval_configuration are URL template arguments and need to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "8" "https://192.168.0.100/restapi/meter/ \leftrightarrow values/:measured_value/intervals/:interval_configuration/alarm_level/"
```

12.21 Interval configuration: Alarm period, if any

sum (optional number)	meter/values/S/intervals/N/alarm_period/
The time interval after which alarm events should be repeated, if any	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum represents a value in persistent storage.

constant null	None	The alarm event is generated only once at interval entry and is not repeated while the value is in the interval	
number	Alarm period	The time interval after which alarm events should be repeated	the value is greater than 0

Sample read command (note that :measured_value and :interval_configuration are URL template arguments and need to be replaced before trying):

Sample (possible variant) write command (note that :measured_value and :interval_configuration are URL template arguments and need to be replaced before trying):

12.21.1 Alarm period


```
(possibly) number | meter/values/S/intervals/N/alarm_period/
The time interval after which alarm events should be repeated
```

The value is subject to the following constraints: the value is greater than 0

Sample write command (note that :measured_value and :interval_configuration are URL template arguments and need to be replaced before trying):

12.22 Measured value: Value interval properties

array	meter/values/S/intervals/
Properties defining intervals of the value and their alarm levels	



This array contains Interval configuration elements.

Sample read command (note that :measured_value is a URL template argument and needs to be replaced before trying):

Sample write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "[{\"lower_bound_top\":9,\"alarm_level\":9,\"lower_bound_bottom \( \to \) \\":1,\"alarm_period\":1},{\"lower_bound_top\":1,\"alarm_level\":5,\" \( \to \) \\ lower_bound_bottom\":6,\"alarm_period\":7}]"\
"https://192.168.0.100/restapi/meter/values/:measured_value/intervals/"
```

Sample interval configuration creation command (note that :measured_value is a URL template argument and needs to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"lower_bound_top\":8,\"alarm_level\":null,\"lower_bound_bottom \( \to \\ \":8,\\"alarm_period\\":2}\\\
"https://192.168.0.100/restapi/meter/values/:measured_value/intervals/"
```

12.22.1 Interval configuration

object	meter/values/S/intervals/N/
Configuration of a value interval	

This object contains the following items:

lower_bound_bottom	Lower bound bottom	
lower_bound_top	Lower bound top	
alarm_level	Alarm level, if any	
alarm_period	Alarm period, if any	

Sample read command (note that :measured_value and :interval_configuration are URL template arguments and need to be replaced before trying):

Sample write command (note that :measured_value and :interval_configuration are URL template arguments and need to be replaced before trying):

Sample deletion command (note that :measured_value and :interval_configuration are URL template arguments and need to be replaced before trying):

```
curl --digest -u admin:1234 -X DELETE -H "Accept: application/json" "https \leftrightarrow ://192.168.0.100/restapi/meter/values/:measured_value/intervals/: \leftrightarrow interval_configuration/"
```

12.22.1.1 Lower bound bottom

number	meter/values/S/intervals/N/lower_bound_bottom/
The bottom of the lower bound of this interval; value must be lower to be considered outside this interval	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command (note that :measured_value and :interval_configuration are URL template arguments and need to be replaced before trying):

Sample write command (note that :measured_value and :interval_configuration are URL template arguments and need to be replaced before trying):

12.22.1.2 Lower bound top

number	meter/values/S/intervals/N/lower_bound_top/
The top of the lower bound of this interval; value must be higher to be considered inside this interval	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command (note that :measured_value and :interval_configuration are URL template arguments and need to be replaced before trying):

Sample write command (note that :measured_value and :interval_configuration are URL template arguments and need to be replaced before trying):

See also Interval configuration: Alarm level, if any

See also Interval configuration: Alarm period, if any

12.23 Measured value: Commit calibration

```
call meter/values/S/commit_calibration/
Save calibration data to persistent storage
```

Performing the function call is denied if any of the following is true:

- · not administrative user
- · not ../in_calibration

The call has no arguments (supply empty tuple).

The call returns no results (expect an empty tuple).

Sample invocation (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.24 Measured value: History subsample count

```
number | meter/values/S/history_subsample_count/
Number of measurements per history sample
```

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater or equal to 0

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command (note that :measured_value is a URL template argument and needs to be replaced before trying):

Sample write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.25 Measured value: History time step

number | meter/values/S/history_time_step/

Minimal amount of time between saved history samples (changes will trigger history rebuilding and may cause adjustments to history_parameters)

The value is subject to the following constraints: the value is greater than 0

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command (note that :measured_value is a URL template argument and needs to be replaced before trying):

Sample write command (note that :measured_value is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "2" "https://192.168.0.100/restapi/meter/ \leftrightarrow values/:measured_value/history_time_step/"
```

12.26 Measured value: Insert calibration point

```
call meter/values/S/insert_calibration_point/

Specify custom calibration point, possibly overriding measurements
```

Performing the function call is denied if any of the following is true:

- · not administrative user
- · not ../in_calibration

The call accepts the following arguments:

- 1. Standard, Identity or Current
- 2. number
- 3. number
- 4. number
- 5. number

The call returns no results (expect an empty tuple).

Sample invocation (note that :measured_value is a URL template argument and needs to be replaced before trying):

12.26.1 Kind

sum (enumerated string)	meter/values/S/insert_calibration_point/arguments: 1/
Kind of calibration point	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant "standard"	Standard	The point supplies the calibrated value
constant "identity"	Identity	Assume the calibration function is the identity in point
constant "current"	Current	Assume the calibration function keeps current value in point

12.26.2 Value

number	meter/values/S/insert_calibration_point/arguments: 2/	
Calibrate	Calibrated value	

This number does not correspond to an actual resource.

12.26.3 Weight

number	meter/values/S/insert_calibration_point/arguments: 3/	
Weight of	Weight of the calibration point	

The value is subject to the following constraints: the value is greater or equal to 0

This number does not correspond to an actual resource.

12.26.4 Derivative

number	meter/values/S/insert_calibration_point/arguments: 4/
Derivative value in the calibration point	

This number does not correspond to an actual resource.

12.26.5 Derivative weight


number	meter/values/S/insert_calibration_point/arguments: 5/
Weight of derivative value in the calibration point	

The value is subject to the following constraints: the value is greater or equal to 0

This number does not correspond to an actual resource.

12.27 Bus list

array	meter/buses/
Attributes for buses	



This array does not support direct modification.

This array contains Bus attributes elements.

Sample read command:

```
"power_status":false,
 "name": "Sample value of bus attributes #2 of name",
 "power_factor_percent":9
},
{
 "power_status":false,
 "name": "Sample value of bus attributes #3 of name",
 "power_factor_percent":9
},
 "power_status":false,
 "name": "Sample value of bus attributes #4 of name",
 "power_factor_percent":3
},
{
 "power_status":true,
 "name": "Sample value of bus attributes #5 of name",
 "power_factor_percent":5
]
```

Creating elements in this collection is not supported.

See also Bus list: Bus attributes

12.28 Bus list: Bus attributes

object	meter/buses/N/	
Attribute	Attributes for a bus	

The value is subject to the following constraints: buses[index of the value]

This object contains the following items:

name	Name
power_status	Power status
power_factor_percent	Power factor

Sample read command (note that :bus_attributes is a URL template argument and needs to be replaced before trying):

Sample write command (note that :bus_attributes is a URL template argument and needs to be replaced before trying):

12.28.1 Name

string	meter/buses/N/name/	
User-vi	User-visible name of this bus	

Changing the value is denied if not administrative user

This string represents a value in persistent storage.

Sample read command (note that :bus_attributes is a URL template argument and needs to be replaced before trying):

Sample write command (note that :bus_attributes is a URL template argument and needs to be replaced before trying):

12.28.2 Power status

sum (boolean)	meter/buses/N/power_status/
Status of bus power	

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This sum does not support direct modification.

This sum can change as if by itself or indirectly because of other actions.

This sum can assume the following values:

constant true	On	Bus is powered
constant false	Off	Bus is not powered

12.29 Power status 481

Sample read command (note that :bus_attributes is a URL template argument and needs to be replaced before trying):

12.28.3 Power factor

```
number | meter/buses/N/power_factor_percent/
Power factor for this bus
```

The value is subject to the following constraints: all of the following is true:

- the value is greater or equal to 0
- the value is less or equal to 100

Retrieving the value is denied if not administrative user

Changing the value is denied if not administrative user

This number represents a value in persistent storage.

Sample read command (note that :bus_attributes is a URL template argument and needs to be replaced before trying):

Sample write command (note that :bus_attributes is a URL template argument and needs to be replaced before trying):

12.29 Power status

```
    sum (boolean)
    meter/power_status/

    Status of unit power
```

Retrieving the value is denied if not administrative user

This sum does not support direct modification.

This sum can change as if by itself or indirectly because of other actions.

This sum can assume the following values:

constant true	Mains	Unit is powered from at least one bus, outlets can be driven
constant false	Battery	Unit is powered from the battery only, outlets cannot be driven, unit shutdown expected

Sample read command:

12.30 Emergency shutoff status

sum (optional boolean)	meter/emergency_off_status/
Status of emergency shutoff	

Retrieving the value is denied if not administrative user

This sum does not support direct modification.

This sum can change as if by itself or indirectly because of other actions.

This sum can assume the following values:


constant true	Active	Emergency shutoff active, all outlets off
constant false	Inactive	Emergency shutoff inactive, normal outlet operation
constant null	Unknown	Emergency shutoff is in an unknown state, probably due to power failure, all outlets likely off

Sample read command:

12.31 Notifications

object	meter/notifications/
Meter status notifications	

12.31 Notifications 483



This object does not support direct modification.


This object contains the following items:

events	Events
parameter_kinds	Parameter kinds

Sample read command:

12.31.1 Events

map	meter/notifications/events/	
Event	Event templates	



This map does not support direct modification.

This map contains **Event** elements.

Sample read command:

Creating elements in this collection is not supported.

See also Events: Event

12.31.2 Parameter kinds

object	meter/notifications/parameter_kinds/	
Kinds o	Kinds of event parameters	

This object does not correspond to an actual resource.

This object contains the following items:

bus_index	Bus index
bus_name	Bus name
bus_powered	Bus power status
emergency_off	Emergency shutoff status
powered	Power status
value_alarm_duration	Value alarm duration
value_alarm_level	Value alarm level
value_alarm_repeated	Value alarm repeat count, if any

value_id	Value identifier
value_name	Value name

See also Parameter kinds: Bus index

See also Parameter kinds: Bus name

See also Parameter kinds: Bus power status

See also Parameter kinds: Emergency shutoff status

See also Parameter kinds: Power status

See also Parameter kinds: Value alarm duration

See also Parameter kinds: Value alarm level

See also Parameter kinds: Value alarm repeat count, if any

See also Parameter kinds: Value identifier

See also Parameter kinds: Value name

12.32 Message template: Message template element

sum (variant)	meter/notifications/events/S/message_template/N/	
Element of hur	Element of human-readable message template	

This sum does not support direct modification.

This sum can assume the following values:

string	String	Fixed string	
number	Parameter	Index of message parameter to insert	event parameters[the value]

Sample read command (note that :event and :message_template_element are URL template arguments and need to be replaced before trying):

12.32.1 String

(possibly) string	meter/notifications/events/S/message_template/N/
Fixed string	

12.32.2 Parameter

(possibly) number	meter/notifications/events/S/message_template/N/	
Index of message parameter to insert		

The value is subject to the following constraints: event parameters[the value]

12.33 Event parameter: Fixed value

sum (variant)	meter/notifications/events/S/parameters/N/fixed_value/	
Fixed parameter value for this particular event		

This sum does not support direct modification.

This sum can assume the following values:

constant null	Null	Null
constant true	True	True
constant false	False	False
string	String	This string
number	Number	This number

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

12.33.1 String

(possibly) string	y) string meter/notifications/events/S/parameters/N/fixed_value/	
This string		

12.33.2 Number

(possibly) number	meter/notifications/events/S/parameters/N/fixed_value/
This number	

12.34 Event parameter: Fixed value flag

12.36 Events: Event 487

sum (boolean)	meter/notifications/events/S/parameters/N/has_fixed_value/	
Flag indicating that the parameter's value for this event is fixed		

This sum does not support direct modification.

This sum can assume the following values:

constant true	Fixed	The value is fixed
constant false	Variable	The value is variable

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

12.35 Event parameter: Identifier

```
string meter/notifications/events/S/parameters/N/id/
Parameter identifier
```


The value is subject to the following constraints: parameter kinds

This string does not support direct modification.

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

12.36 Events: Event

object	meter/notifications/events/S/
Event template	



This object contains the following items:

message_template	Message template
parameters	Event parameters
severity	Severity

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←
   → restapi/meter/notifications/events/:event/"
\Rightarrow
"severity":3,
"message_template":[
 "Sample value of message template of message template element #1",
 "Sample value of message template of message template element #2"
1,
"parameters":[
  "fixed_value":true,
  "has_fixed_value":false,
  "id": "Sample value of event parameters of event parameter #1 of identifier"
 },
  "fixed value":null,
  "has_fixed_value":true,
  "id": "Sample value of event parameters of event parameter #2 of identifier"
  "fixed_value":true,
  "has_fixed_value":true,
  "id": "Sample value of event parameters of event parameter #3 of identifier"
 }
]
}
```

Sample write command (note that :event is a URL template argument and needs to be replaced before trying):

12.36 Events: Event 489

12.36.1 Message template

```
array meter/notifications/events/S/message_template/
Template for human-readable message generation
```

This array does not support direct modification.

This array contains Message template element elements.


Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

Creating elements in this collection is not supported.

See also Message template: Message template element

12.36.2 Event parameters

```
array meter/notifications/events/S/parameters/
Additional data associated with the event
```



This array does not support direct modification.

This array contains **Event parameter** elements.

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ ←
   → restapi/meter/notifications/events/:event/parameters/"
\Rightarrow
 "fixed_value":true,
 "has_fixed_value":false,
 "id": "Sample value of event parameter #1 of identifier"
 "fixed_value": "Sample value of event parameter #2 of fixed value",
 "has_fixed_value":false,
 "id": "Sample value of event parameter #2 of identifier"
},
 "fixed_value":true,
 "has_fixed_value":true,
 "id": "Sample value of event parameter #3 of identifier"
},
 "fixed_value":false,
 "has_fixed_value":false,
 "id": "Sample value of event parameter #4 of identifier"
 "fixed_value":true,
 "has_fixed_value":true,
 "id": "Sample value of event parameter #5 of identifier"
},
 "fixed_value": "Sample value of event parameter #6 of fixed value",
 "has_fixed_value":true,
 "id": "Sample value of event parameter #6 of identifier"
 "fixed_value":false,
 "has_fixed_value":false,
 "id": "Sample value of event parameter #7 of identifier"
1
```

Creating elements in this collection is not supported.

12.36.2.1 Event parameter

object	meter/notifications/events/S/parameters/N/	
Properties of a parameter associated with the event		

This object contains the following items:

fixed_value	Fixed value
-------------	-------------

12.36 Events: Event 491

has_fixed_value	Fixed value flag
id	Identifier

Sample read command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

Sample write command (note that :event and :event_parameter are URL template arguments and need to be replaced before trying):

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"fixed_value\":true,\"has_fixed_value\":true,\"id\":\"Sample \( \to \)
\to value of identifier\"}"\
"https://192.168.0.100/restapi/meter/notifications/events/:event/parameters/: \( \to \)
\to event_parameter/"
```

See also Event parameter: Fixed value

See also Event parameter: Fixed value flag

See also Event parameter: Identifier

12.36.3 Severity

sum (enumerated number)	meter/notifications/events/S/severity/	
Severity rating assigned to the	Severity rating assigned to the event	

This sum does not support direct modification.

This sum can assume the following values:

constant 1	Emergency	Treat the event as an emergency	
constant 2	Alert	Treat the event as an alert	
constant 3	Critical	Treat the event as critical	
constant 4	Error	Treat the event as an error	
constant 5	Warning	Treat the event as a warning	
constant 6	Notice	Treat the event as a notice	
constant 7	Informational	Treat the event as informational	
constant 8	Debug	Treat the event as debugging-related	

Sample read command (note that :event is a URL template argument and needs to be replaced before trying):

12.37 Parameter kinds: Bus index

```
number | meter/notifications/parameter_kinds/bus_index/
Index of the bus
```

Sample read command:

Sample write command:

12.38 Parameter kinds: Bus name

```
        number
        meter/notifications/parameter_kinds/bus_name/

        Name of the bus
```

Sample read command:

Sample write command:

12.39 Parameter kinds: Bus power status

sum (boolean)	meter/notifications/parameter_kinds/bus_powered/	
Status of bus po	Status of bus power	

This sum can assume the following values:

constant true	Powered	The bus is powered
constant false	Not powered	The bus is not powered

Sample read command:

\Rightarrow (possible variant)

false

Sample (possible variant) write command:

12.40 Parameter kinds: Emergency shutoff status

sum (boolean)	meter/notifications/parameter_kinds/emergency_off/	
Status of emerg	ency shutoff	

This sum can assume the following values:

constant true	Active	All outlets off
constant false	Inactive	Normal outlet operation

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/meter/notifications/parameter_kinds/emergency_off/"
```

\Rightarrow (possible variant)

false

Sample (possible variant) write command:

12.41 Parameter kinds: Power status

sum (boolean)	meter/notifications/parameter_kinds/powered/	
Status of unit po	Status of unit power	

This sum can assume the following values:

constant true	Mains	The unit is running on mains
constant false	Battery	The unit is running on battery

Sample read command:

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "false" "https://192.168.0.100/restapi/ \hookleftarrow \hookrightarrow meter/notifications/parameter_kinds/powered/"
```

12.42 Parameter kinds: Value alarm duration

```
number | meter/notifications/parameter_kinds/value_alarm_duration/

Amount of time the value has been at this alarm level
```

The value is subject to the following constraints: the value is greater or equal to 0

Sample read command:

Sample write command:

12.43 Parameter kinds: Value alarm level

number	meter/notifications/parameter_kinds/value_alarm_level/
Alarm level associated with the value	

Sample read command:

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "7" "https://192.168.0.100/restapi/meter/ \leftrightarrow notifications/parameter_kinds/value_alarm_level/"
```

12.44 Parameter kinds: Value alarm repeat count, if any

sum (optional number)	meter/notifications/parameter_kinds/value_alarm_repeated/
Number of consecutive times this alarm has been sent, if any	

This sum can assume the following values:

constant null	Initial alarm	The value has just entered the int	erval
number	Value alarm repeat count	Number of consecutive times	all of the following is true:
		this alarm has been sent	 the value is an integer the value is greater or equal to 0

Sample read command:

Sample (possible variant) write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "10" "https://192.168.0.100/restapi/meter \leftrightarrow /notifications/parameter_kinds/value_alarm_repeated/"
```

12.44.1 Value alarm repeat count

(possibly) number	meter/notifications/parameter_kinds/value_alarm_repeated/	
Number of consecutive times this alarm has been sent		

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- the value is greater or equal to 0

Sample write command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \leftrightarrow : application/json" --data-binary "10" "https://192.168.0.100/restapi/meter \leftrightarrow /notifications/parameter_kinds/value_alarm_repeated/"
```

12.45 Parameter kinds: Value identifier

```
string meter/notifications/parameter_kinds/value_id/
Identifier of the value
```

→ ://192.168.0.100/restapi/meter/notifications/parameter_kinds/value_id/"

12.46 Parameter kinds: Value name

```
string meter/notifications/parameter_kinds/value_name/

Name of the value
```


Sample read command:

```
curl --digest -u admin:1234 -X PUT -H "Content-type: application/json" -H "Accept \hookrightarrow: application/json" --data-binary "\"Sample value\"" "https \hookleftarrow://192.168.0.100/restapi/meter/notifications/parameter_kinds/value_name/"
```

13 Renderer object

13 Renderer object 497

```
object representing renderer capabilities and functions
```



This object contains the following items:

draw_message	Draw a message
draw_pie_meter	Draw a pie meter
draw_plot	Draw a plot
known_axes	Axes
known_image_formats	Image formats
known_line_types	Line types
known_marker_types	Marker types
known_plot_styles	Plot styles
known_scales	Plot scales

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftrightarrow restapi/renderer/"
```

 \Rightarrow

. . .

Sample write command:

13.1 Draw a message

```
call renderer/draw_message/
Generate an image with a message in its center
```

Performing the function call is denied if not administrative user

The call accepts the following arguments:

- 1. string
- 2. number
- 3. number
- 4. string

The call returns the following results:

- 1. string
- 2. string

Sample invocation:

13.1.1 Format

```
string renderer/draw_message/arguments: 1/
Image format
```

The value is subject to the following constraints: image formats[the value]

This string does not correspond to an actual resource.

13.1.2 Width

13.1 Draw a message 499

number	renderer/draw_message/arguments: 2/
The width of the image	

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater than 0

This number does not correspond to an actual resource.

13.1.3 Height

number	renderer/draw_message/arguments: 3/
The height of the image	

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater than 0

This number does not correspond to an actual resource.

13.1.4 Message

string	renderer/draw_message/arguments: 4/
Message text	

This string does not correspond to an actual resource.

13.1.5 Content type

string	renderer/draw_message/results: 1/
The content type of the generated image	

This string does not correspond to an actual resource.


13.1.6 Image data

string	renderer/draw_message/results: 2/
Generated image data	

This string does not correspond to an actual resource.

13.2 Draw a pie meter

call	renderer/draw_pie_meter/	
Generate a multi-sector meter image with an arrow indicating value		



Performing the function call is denied if not administrative user

The call accepts the following arguments:

- 1. string
- 2. number
- 3. number
- 4. object "Properties"
- 5. number
- 6. object "Value quantity and unit"

The call returns the following results:

- 1. string
- 2. string

Sample invocation:

13.2.1 Format

string	renderer/draw_pie_meter/arguments: 1/
Image format	

The value is subject to the following constraints: image formats[the value]

This string does not correspond to an actual resource.

13.2.2 Width

number	renderer/draw_pie_meter/arguments: 2/
The width of the image	

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater than 0

This number does not correspond to an actual resource.

13.2.3 Height

number	renderer/draw_pie_meter/arguments: 3/
The height of the image	


The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater than 0

This number does not correspond to an actual resource.

13.2.4 Properties

object	renderer/draw_pie_meter/arguments: 4/
Properties of the meter	



This object does not correspond to an actual resource.

This object contains the following items:

color	Arrow color
decimals	Decimals
min_value	Minimum value
scale	Display scale
sectors	Meter sectors

See also Properties: Arrow color

See also Properties: Decimals

See also Properties: Minimum value

See also Properties: Display scale

See also Properties: Meter sectors

13.2.5 Value

number	renderer/draw_pie_meter/arguments: 5/	
Meter val	Meter value to display	

This number does not correspond to an actual resource.

See also Draw a pie meter: Value quantity and unit

13.2.6 Content type

string	renderer/draw_pie_meter/results: 1/	
The co	The content type of the generated image	

This string does not correspond to an actual resource.

13.2.7 Image data

string	renderer/draw_pie_meter/results: 2/	
Genera	Generated image data	

This string does not correspond to an actual resource.

13.3 Properties: Arrow color

string	renderer/draw_pie_meter/arguments: 4/color/
The color of the meter arrow	

The value is subject to the following constraints: the value matches ^[0-9A-F]{6}\$

This string does not correspond to an actual resource.

13.4 Properties: Decimals

number	renderer/draw_pie_meter/arguments: 4/decimals/	
Number of	Number of decimal places to show in displayed value	

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater or equal to 0

This number does not correspond to an actual resource.

13.5 Properties: Minimum value

number	renderer/draw_pie_meter/arguments: 4/min_value/	
The mini	The minimum value to be displayed on the meter	

This number does not correspond to an actual resource.

13.6 Properties: Display scale


string	renderer/draw_pie_meter/arguments: 4/scale/	
The sca	The scale function to use for display	

The value is subject to the following constraints: plot scales[the value]

This string does not correspond to an actual resource.

13.7 Properties: Meter sectors

array	renderer/draw_pie_meter/arguments: 4/sectors/	
Param	Parameters of meter sectors	



This array does not correspond to an actual resource.

This array contains Sector parameters elements.

13.7.1 Sector parameters

object	renderer/draw_pie_meter/arguments: 4/sectors/N/	
Parame	Parameters of a meter sector	

This object does not correspond to an actual resource.

This object contains the following items:

name	Name
value	Maximum value
color	Color

13.7.1.1 Name

string	renderer/draw_pie_meter/arguments: 4/sectors/N/name/	
The na	The name of the sector	

This string does not correspond to an actual resource.

13.7.1.2 Maximum value

number	renderer/draw_pie_meter/arguments: 4/sectors/N/value/	
The maxi	The maximum value for the sector	

This number does not correspond to an actual resource.

13.7.1.3 Color

string	renderer/draw_pie_meter/arguments: 4/sectors/N/color/
The color of the sector	

The value is subject to the following constraints: the value matches ^[0-9A-F]{6}\$

This string does not correspond to an actual resource.

13.8 Draw a pie meter: Value quantity and unit

object	renderer/draw_pie_meter/arguments: 6/	
The qua	The quantity and unit for value	

This object does not correspond to an actual resource.

This object contains the following items:

quantity	Value quantity
unit	Value unit

13.8.1 Value quantity

string	renderer/draw_pie_meter/arguments: 6/quantity/
The quantity for value	

The value is subject to the following constraints: known quantities[the value]

This string does not correspond to an actual resource.

13.8.2 Value unit


string	renderer/draw_pie_meter/arguments: 6/unit/	
The un	The unit for value	

The value is subject to the following constraints: known quantities[value quantity].units[the value]

This string does not correspond to an actual resource.

13.9 Draw a plot

call	renderer/draw_plot/	
Gene	Generate an image with axes and data plotted on them	



Performing the function call is denied if not administrative user

13.9 Draw a plot 507

The call accepts the following arguments:

- 1. string
- 2. number
- 3. number
- 4. object "Properties"
- 5. array of "(string,array of "(number,None or Y)",object "Style",(object "X axis quantity and unit",object "Y axis quantity and unit"))"

The call returns the following results:

- 1. string
- 2. string

Sample invocation:

13.9.1 Format

string	renderer/draw_plot/arguments: 1/
Image format	

The value is subject to the following constraints: image formats[the value]

This string does not correspond to an actual resource.

13.9.2 Width

```
number renderer/draw_plot/arguments: 2/
The width of the image
```

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- the value is greater than 0

This number does not correspond to an actual resource.

13.9.3 Height

number	renderer/draw_plot/arguments: 3/	
The heigh	The height of the image	


The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater than 0

This number does not correspond to an actual resource.

13.9.4 Properties

object	renderer/draw_plot/arguments: 4/	
Propert	Properties of the plot	



This object does not correspond to an actual resource.

This object contains the following items:

13.9 Draw a plot 509

time_format	Custom time format, if any
x1	X1 axis settings
x2	X2 axis settings
y1	Y1 axis settings
y2	Y2 axis settings

See also Properties: Custom time format, if any

See also Properties: X1 axis settings


See also Properties: X2 axis settings

See also Properties: Y1 axis settings

See also Properties: Y2 axis settings

13.9.5 Lines

array	renderer/draw_plot/arguments: 5/
Plot data lines	



This array does not correspond to an actual resource.

This array contains Line elements.

See also Lines: Line

13.9.6 Content type

string	renderer/draw_plot/results: 1/	
The co	The content type of the generated image	

This string does not correspond to an actual resource.

13.9.7 Image data

string	renderer/draw_plot/results: 2/	
Genera	Generated image data	

This string does not correspond to an actual resource.

13.10 Properties: Custom time format, if any

sum (optional string)	renderer/draw_plot/arguments: 4/time_format/	
Custom format to display time in, if any		

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	Default	Use default time format
string	Custom time format	Custom format to display time in

13.10.1 Custom time format

(possibly) string	renderer/draw_plot/arguments: 4/time_format/
Custom format to display time in	

This string does not correspond to an actual resource.

13.11 Properties: X1 axis settings

object	renderer/draw_plot/arguments: 4/x1/	
Configu	Configuration for X1 axis	

This object does not correspond to an actual resource.

This object contains the following items:

min	Minimum, if any
max	Maximum, if any

softmin	Soft minimum, if any
softmax	Soft maximum, if any
tics	Major tick interval, if any
mtics	Minor ticks per major tick, if any

13.11.1 Minimum, if any

sum (optional number)	renderer/draw_plot/arguments: 4/x1/min/
Minimum value to display on the axis, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	Automatic	The maximum value is derived from data and the soft
		maximum
number	Minimum	Minimum value to display on the axis

13.11.1.1 Minimum

(possibly) number	renderer/draw_plot/arguments: 4/x1/min/	
Minimum value to display on the axis		

This number does not correspond to an actual resource.

13.11.2 Maximum, if any

sum (optional number)	renderer/draw_plot/arguments: 4/x1/max/	
Maximum value to display on the axis, if any		

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	Automatic	The minimum value is derived from data and the soft minimum
number	Maximum	Maximum value to display on the axis

13.11.2.1 Maximum

(possibly) number	renderer/draw_plot/arguments: 4/x1/max/	
Maximum value to display on the axis		

This number does not correspond to an actual resource.

13.11.3 Soft minimum, if any

sum (optional number)	renderer/draw_plot/arguments: 4/x1/softmin/
Minimum value to display on the axis unless values exist below it, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	None	No soft maximum defined
number	Soft minimum	Minimum value to display on the axis unless values
		exist below it

13.11.3.1 Soft minimum

(possibly) number	renderer/draw_plot/arguments: 4/x1/softmin/
Minimum value to display on the axis unless values exist below it	

This number does not correspond to an actual resource.

13.11.4 Soft maximum, if any

sum (optional number)	renderer/draw_plot/arguments: 4/x1/softmax/
Maximum value to display on the axis unless values exist above it, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	None	No soft minimum defined
number	Soft maximum	Maximum value to display on the axis unless values
		exist above it

13.11.4.1 Soft maximum

(possibly) number	renderer/draw_plot/arguments: 4/x1/softmax/
Maximum value to display on the axis unless values exist above it	

This number does not correspond to an actual resource.

13.11.5 Major tick interval, if any

sum (optional number)	renderer/draw_plot/arguments: 4/x1/tics/
The interval, in value units, between major ticks of the axis, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	Automatic	The tick interval is derived from data and size
number	Major tick interval	The interval, in value units, between major ticks of the
		axis

13.11.5.1 Major tick interval

(possibly) number	renderer/draw_plot/arguments: 4/x1/tics/	
The interval, in value units, between major ticks of the axis		

This number does not correspond to an actual resource.

13.11.6 Minor ticks per major tick, if any

sum (optional number)	renderer/draw_plot/arguments: 4/x1/mtics/
The number of minor ticks between two major ticks, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	None	There are no minor ticks	
number	Minor ticks per major tick	The number of minor ticks be-	all of the following is true:
		tween two major ticks	 the value is an integer the value is greater or equal to 0

13.11.6.1 Minor ticks per major tick

	(possibly) number	renderer/draw_plot/arguments: 4/x1/mtics/
The number of minor ticks between two major ticks		or ticks between two major ticks

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater or equal to 0

This number does not correspond to an actual resource.

13.12 Properties: X2 axis settings

object renderer/draw_plot/arguments: 4/x2/		
Configu	Configuration for X2 axis	

This object does not correspond to an actual resource.

This object contains the following items:

min	Minimum, if any
max	Maximum, if any
softmin	Soft minimum, if any
softmax	Soft maximum, if any
tics	Major tick interval, if any
mtics	Minor ticks per major tick, if any

13.12.1 Minimum, if any

sum (optional number)	renderer/draw_plot/arguments: 4/x2/min/
Minimum value to display on the axis, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	Automatic	The maximum value is derived from data and the soft
		maximum
number	Minimum	Minimum value to display on the axis

13.12.1.1 Minimum

(possibly) number	renderer/draw_plot/arguments: 4/x2/min/	
Minimum value to display on the axis		

This number does not correspond to an actual resource.

13.12.2 Maximum, if any

sum (optional number)	renderer/draw_plot/arguments: 4/x2/max/
Maximum value to display on the axis, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

	constant null	Automatic	The minimum value is derived from data and the soft minimum
Ī	number	Maximum	Maximum value to display on the axis

13.12.2.1 Maximum

(possibly) number	renderer/draw_plot/arguments: 4/x2/max/
Maximum value to display on the axis	

This number does not correspond to an actual resource.

13.12.3 Soft minimum, if any

sum (optional number)	renderer/draw_plot/arguments: 4/x2/softmin/		
Minimum value to display on the axis unless values exist below it, if any			

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	None	No soft maximum defined	
number	Soft minimum	Minimum value to display on the axis unless values	
		exist below it	

13.12.3.1 Soft minimum

(possibly) number	renderer/draw_plot/arguments: 4/x2/softmin/		
Minimum value to display on the axis unless values exist below it			

This number does not correspond to an actual resource.

13.12.4 Soft maximum, if any

sum (optional number)	renderer/draw_plot/arguments: 4/x2/softmax/	
Maximum value to display on the axis unless values exist above it, if any		

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	None	No soft minimum defined
number	Soft maximum	Maximum value to display on the axis unless values
		exist above it

13.12.4.1 Soft maximum

(possibly) number	renderer/draw_plot/arguments: 4/x2/softmax/	
Maximum value to display on the axis unless values exist above it		

This number does not correspond to an actual resource.

13.12.5 Major tick interval, if any

sum (optional number)	renderer/draw_plot/arguments: 4/x2/tics/	
The interval, in value units, between major ticks of the axis, if any		

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	Automatic	The tick interval is derived from data and size	
number	Major tick interval	The interval, in value units, between major ticks of the	
		axis	

13.12.5.1 Major tick interval

(possibly) number	renderer/draw_plot/arguments: 4/x2/tics/
The interval, in value units, between major ticks of the axis	

This number does not correspond to an actual resource.

13.12.6 Minor ticks per major tick, if any

sum (optional number)	renderer/draw_plot/arguments: 4/x2/mtics/
The number of minor ticks between two major ticks, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	None	There are no minor ticks	
number	Minor ticks per major tick	The number of minor ticks be-	all of the following is true:
		tween two major ticks	 the value is an integer the value is greater or equal to 0

13.12.6.1 Minor ticks per major tick

	(possibly) number	renderer/draw_plot/arguments: 4/x2/mtics/
The number of minor ticks between two major ticks		

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater or equal to 0

This number does not correspond to an actual resource.

13.13 Properties: Y1 axis settings

object	bject renderer/draw_plot/arguments: 4/y1/	
Configu	Configuration for Y1 axis	

This object does not correspond to an actual resource.

This object contains the following items:

min	Minimum, if any	
max	Maximum, if any	
softmin	Soft minimum, if any	
softmax	Soft maximum, if any	
tics	Major tick interval, if any	
mtics	Minor ticks per major tick, if any	

13.13.1 Minimum, if any

sum (optional number)	renderer/draw_plot/arguments: 4/y1/min/
Minimum value to display on the axis, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	Automatic	The maximum value is derived from data and the soft maximum
number	Minimum	Minimum value to display on the axis

13.13.1.1 Minimum

(possibly) number	renderer/draw_plot/arguments: 4/y1/min/	
Minimum value to display on the axis		

This number does not correspond to an actual resource.

13.13.2 Maximum, if any

sum (optional number)	renderer/draw_plot/arguments: 4/y1/max/
Maximum value to display on the axis, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	Automatic	The minimum value is derived from data and the soft minimum
number	Maximum	Maximum value to display on the axis

13.13.2.1 Maximum

(possibly) number	renderer/draw_plot/arguments: 4/y1/max/
Maximum value to display on the axis	

This number does not correspond to an actual resource.

13.13.3 Soft minimum, if any

	sum (optional number)	renderer/draw_plot/arguments: 4/y1/softmin/
Minimum value to display on the axis unless values exist below it, if any		

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	None	No soft maximum defined
number	Soft minimum	Minimum value to display on the axis unless values
		exist below it

13.13.3.1 Soft minimum

(possibly) number	renderer/draw_plot/arguments: 4/y1/softmin/
Minimum value to display on the axis unless values exist below it	

This number does not correspond to an actual resource.

13.13.4 Soft maximum, if any

sum (optional number)	renderer/draw_plot/arguments: 4/y1/softmax/
Maximum value to display on the axis unless values exist above it, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	None	No soft minimum defined
number	Soft maximum	Maximum value to display on the axis unless values
		exist above it

13.13.4.1 Soft maximum

(possibly) number	renderer/draw_plot/arguments: 4/y1/softmax/
Maximum value to display on the axis unless values exist above it	

This number does not correspond to an actual resource.

13.13.5 Major tick interval, if any

sum (optional number)	renderer/draw_plot/arguments: 4/y1/tics/
The interval, in value units, between major ticks of the axis, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	Automatic	The tick interval is derived from data and size
number	Major tick interval	The interval, in value units, between major ticks of the
		axis

13.13.5.1 Major tick interval

(possibly) number	renderer/draw_plot/arguments: 4/y1/tics/
The interval, in value units, between major ticks of the axis	

This number does not correspond to an actual resource.

13.13.6 Minor ticks per major tick, if any

sum (optional number)	renderer/draw_plot/arguments: 4/y1/mtics/
The number of minor ticks between two major ticks, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	None	There are no minor ticks	
number	Minor ticks per major tick	The number of minor ticks be-	all of the following is true:
		tween two major ticks	 the value is an integer the value is greater or equal to 0

13.13.6.1 Minor ticks per major tick

(possibly) number	renderer/draw_plot/arguments: 4/y1/mtics/
The number of minor ticks between two major ticks	

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- the value is greater or equal to 0

This number does not correspond to an actual resource.

13.14 Properties: Y2 axis settings

object	renderer/draw_plot/arguments: 4/y2/	
Configu	Configuration for Y2 axis	

This object does not correspond to an actual resource.

This object contains the following items:

min	Minimum, if any
max	Maximum, if any
softmin	Soft minimum, if any
softmax	Soft maximum, if any
tics	Major tick interval, if any
mtics	Minor ticks per major tick, if any

13.14.1 Minimum, if any

sum (optional number)	renderer/draw_plot/arguments: 4/y2/min/
Minimum value to display on the axis, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	Automatic	The maximum value is derived from data and the soft
		maximum
number	Minimum	Minimum value to display on the axis

13.14.1.1 Minimum

(possibly) number	renderer/draw_plot/arguments: 4/y2/min/
Minimum value to display on the axis	

This number does not correspond to an actual resource.

13.14.2 Maximum, if any

sum (optional number)	renderer/draw_plot/arguments: 4/y2/max/
Maximum value to display on the axis, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	Automatic	The minimum value is derived from data and the soft minimum
number	Maximum	Maximum value to display on the axis

13.14.2.1 Maximum

(possibly) number	renderer/draw_plot/arguments: 4/y2/max/
Maximum value to display on the axis	

This number does not correspond to an actual resource.

13.14.3 Soft minimum, if any

sum (optional number)	renderer/draw_plot/arguments: 4/y2/softmin/
Minimum value to display on the axis unless values exist below it, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	None	No soft maximum defined
number	Soft minimum	Minimum value to display on the axis unless values exist below it

13.14.3.1 Soft minimum

(possibly) number	renderer/draw_plot/arguments: 4/y2/softmin/
Minimum value to display on the axis unless values exist below it	

This number does not correspond to an actual resource.

13.14.4 Soft maximum, if any

sum (optional number)	renderer/draw_plot/arguments: 4/y2/softmax/
Maximum value to display on the axis unless values exist above it, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	None	No soft minimum defined
number	Soft maximum	Maximum value to display on the axis unless values
		exist above it

13.14.4.1 Soft maximum

(possibly) number	renderer/draw_plot/arguments: 4/y2/softmax/
Maximum value to display on the axis unless values exist above it	

This number does not correspond to an actual resource.

13.14.5 Major tick interval, if any

sum (optional number)	renderer/draw_plot/arguments: 4/y2/tics/
The interval, in value units, between major ticks of the axis, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	Automatic	The tick interval is derived from data and size
number	Major tick interval	The interval, in value units, between major ticks of the
		axis

13.14.5.1 Major tick interval

(possibly) number	renderer/draw_plot/arguments: 4/y2/tics/
The interval, in value units, between major ticks of the axis	

This number does not correspond to an actual resource.

13.14.6 Minor ticks per major tick, if any

sum (optional number)	renderer/draw_plot/arguments: 4/y2/mtics/
The number of minor ticks between two major ticks, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant null	None	There are no minor ticks	
number	Minor ticks per major tick	The number of minor ticks be-	all of the following is true:
		tween two major ticks	 the value is an integer the value is greater or equal to 0

13.14.6.1 Minor ticks per major tick

(possibly) number	umber renderer/draw_plot/arguments: 4/y2/mtics/	
The number of minor ticks between two major ticks		

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater or equal to 0

This number does not correspond to an actual resource.

13.15 Plot point: X

number	renderer/draw_plot/arguments: 5/N/2/N/1/	
X coordin	X coordinate to plot	

This number does not correspond to an actual resource.

13.16 Plot point: Y, if any

sum (variant)	renderer/draw_plot/arguments: 5/N/2/N/2/
Y coordinate to plot, if any	

This sum does not correspond to an actual resource.

This sum can assume the following values:

constant false	None	Data for this X position is absent
number	Υ	Y coordinate to plot

13.16.1 Y

(possibly) number	ly) number renderer/draw_plot/arguments: 5/N/2/N/2/	
Y coordinate to plot		

This number does not correspond to an actual resource.

13.17 Plotted quantities and units: X axis quantity and unit

object	renderer/draw_plot/arguments: 5/N/4/1/	
The qua	The quantity and unit for X axis	

This object does not correspond to an actual resource.

This object contains the following items:

quantity	X axis quantity
unit	X axis unit

13.17.1 X axis quantity

string	renderer/draw_plot/arguments: 5/N/4/1/quantity/	
The qu	The quantity for X axis	

The value is subject to the following constraints: known quantities[the value]

This string does not correspond to an actual resource.

13.17.2 X axis unit

string	renderer/draw_plot/arguments: 5/N/4/1/unit/
The unit for X axis	

The value is subject to the following constraints: known quantities[x axis quantity].units[the value]

This string does not correspond to an actual resource.

13.18 Plotted quantities and units: Y axis quantity and unit

object	renderer/draw_plot/arguments: 5/N/4/2/	
The qua	The quantity and unit for Y axis	

This object does not correspond to an actual resource.

This object contains the following items:

13.19 Lines: Line 525

quantity	Y axis quantity
unit	Y axis unit

13.18.1 Yaxis quantity

string	renderer/draw_plot/arguments: 5/N/4/2/quantity/	
The qu	The quantity for Y axis	

The value is subject to the following constraints: known quantities[the value]

This string does not correspond to an actual resource.

13.18.2 Y axis unit


string	renderer/draw_plot/arguments: 5/N/4/2/unit/
The unit for Y axis	

The value is subject to the following constraints: known quantities[y axis quantity].units[the value]

This string does not correspond to an actual resource.

13.19 Lines: Line

tuple	tuple renderer/draw_plot/arguments: 5/N/	
Plot da	Plot data line settings	



This tuple does not correspond to an actual resource.

This tuple contains the following items:

1	Title
2	Plot data
3	Style
4	Plotted quantities and units

13.19.1 Title


string	renderer/draw_plot/arguments: 5/N/1/	
Plot line title		

This string does not correspond to an actual resource.

13.19.2 Plot data

array	renderer/draw_plot/arguments: 5/N/2/	
Data to	Data to plot	

13.19 Lines: Line 527



This array does not correspond to an actual resource.

This array contains Plot point elements.

13.19.2.1 Plot point

tuple	renderer/draw_plot/arguments: 5/N/2/N/
Point to plot	

This tuple does not correspond to an actual resource.

This tuple contains the following items:

1	X
2	Y, if any

See also Plot point: X

See also Plot point: Y, if any

13.19.3 Style

object	ect renderer/draw_plot/arguments: 5/N/3/	
Style of the plot line		

This object does not correspond to an actual resource.

This object contains the following items:

style	Line style
type	Line type
color	Line color
width	Line width
size	Marker size
axes	Base axes
marker	Marker type

13.19.3.1 Line style

string	renderer/draw_plot/arguments: 5/N/3/style/	
The sty	The style of the line	

The value is subject to the following constraints: plot styles[the value]

This string does not correspond to an actual resource.

13.19.3.2 Line type

string	renderer/draw_plot/arguments: 5/N/3/type/
The type of the line	

The value is subject to the following constraints: line types[the value]

This string does not correspond to an actual resource.

13.19.3.3 Line color

string	renderer/draw_plot/arguments: 5/N/3/color/	
The col	The color of the line	

The value is subject to the following constraints: the value matches ^[0-9A-F]{6}\$

This string does not correspond to an actual resource.

13.19.3.4 Line width

number	renderer/draw_plot/arguments: 5/N/3/width/	
The width	The width of the line	

The value is subject to the following constraints: all of the following is true:

- the value is an integer
- the value is greater or equal to 0

This number does not correspond to an actual resource.

13.19 Lines: Line 529

13.19.3.5 Marker size

number	renderer/draw_plot/arguments: 5/N/3/size/	
The size	The size of the markers	

The value is subject to the following constraints: all of the following is true:

- · the value is an integer
- the value is greater or equal to 0

This number does not correspond to an actual resource.

13.19.3.6 Base axes

string	renderer/draw_plot/arguments: 5/N/3/axes/
The axes on which the line should be plotted. Units of lines plotted on the same axes must match	

The value is subject to the following constraints: axes[the value]

This string does not correspond to an actual resource.

13.19.3.7 Marker type

string	renderer/draw_plot/arguments: 5/N/3/marker/
The type of the marker	


The value is subject to the following constraints: marker types[the value]

This string does not correspond to an actual resource.

13.19.4 Plotted quantities and units

tuple	renderer/draw_plot/arguments: 5/N/4/	
Quanti	Quantities and units to be plotted	

13.20 Axes 531



This tuple does not correspond to an actual resource.

This tuple contains the following items:

1	X axis quantity and unit
2	Y axis quantity and unit

See also Plotted quantities and units: X axis quantity and unit

See also Plotted quantities and units: Y axis quantity and unit

13.20 Axes

map	renderer/known_axes/
Known axis combinations	

Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map contains Name elements.

Sample read command:

Creating elements in this collection is not supported.

13.20.1 Name

```
string renderer/known_axes/S/
Name of axis combination
```

Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :name is a URL template argument and needs to be replaced before trying):

13.21 Image formats

```
map renderer/known_image_formats/
Known image formats
```

Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map contains Name elements.

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/renderer/known_image_formats/"
```

13.22 Line types 533

```
{
   "image_formats_2":"Sample value of name image_formats_2",
   "image_formats_3":"Sample value of name image_formats_3",
   "image_formats_4":"Sample value of name image_formats_4",
   "image_formats_1":"Sample value of name image_formats_1",
   "image_formats_6":"Sample value of name image_formats_6",
   "image_formats_5":"Sample value of name image_formats_5"
}
```

Creating elements in this collection is not supported.

13.21.1 Name

```
string renderer/known_image_formats/S/

Name of image format
```

Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :name is a URL template argument and needs to be replaced before trying):

13.22 Line types

```
map renderer/known_line_types/
Known line types
```

Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map contains Name elements.

Sample read command:

Creating elements in this collection is not supported.

13.22.1 Name

```
string renderer/known_line_types/S/
Name of line type
```

Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :name is a URL template argument and needs to be replaced before trying):

13.23 Marker types

```
map renderer/known_marker_types/
Known marker types
```

Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map contains Name elements.

Sample read command:

Creating elements in this collection is not supported.

13.23.1 Name

string	renderer/known_marker_types/S/
Name of marker type	

Retrieving the value is denied if not administrative user

13.24 Plot styles 535

This string does not support direct modification.

Sample read command (note that :name is a URL template argument and needs to be replaced before trying):

13.24 Plot styles

```
map renderer/known_plot_styles/
Known plot styles
```

Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map contains Name elements.

Sample read command:

Creating elements in this collection is not supported.

13.24.1 Name

```
string renderer/known_plot_styles/S/

Name of plot style
```

Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :name is a URL template argument and needs to be replaced before trying):

13.25 Plot scales

14 Credentials 537

```
map renderer/known_scales/
Known plot scales
```

Retrieving the value is denied if not administrative user

This map does not support direct modification.

This map contains Name elements.

Sample read command:

Creating elements in this collection is not supported.

13.25.1 Name

```
string renderer/known_scales/S/
Name of plot scale
```

Retrieving the value is denied if not administrative user

This string does not support direct modification.

Sample read command (note that :name is a URL template argument and needs to be replaced before trying):

14 Credentials

object	cred/			
Security	Security attributes of agent performing request			

This object contains the following items:

name	Client username, if any
is_admin	Administrative user
outlet_access	Outlet access permissions
agent	Agent identifier
ip_address	Client IP address, if any

Sample read command:

Sample write command:

```
curl\
--digest\
-u admin:1234\
-X PUT\
-H "Content-type: application/json"\
-H "Accept: application/json"\
--data-binary "{\"ip_address\":\"Sample value of client ip address, if any\",\" \( \to \) is_admin\":true,\"name\":null,\"agent\":\"Sample value of agent identifier \( \to \) \",\"outlet_access\":[false,true,true,false,true]}"\
"https://192.168.0.100/restapi/cred/"
```

14.1 Client username, if any

sum (optional string)	cred/name/			
Username of the clien	Username of the client, as verified by the agent, if any			

This sum does not support direct modification.

This sum can assume the following values:

constant null	Username absent or unknown	Username could not be obtained
string	Client username	Username of the client, as verified by the agent

Sample read command:

14.1.1 Client username

(possibly) string	cred/name/	
Username of the client, as verified by the agent		

14.2 Administrative user

sum (boolean)	cred/is_admin/	
Flag indicating whether the user is an administrator		

This sum does not support direct modification.


This sum can assume the following values:

constant true	Administrator	The user is an administrator
constant false	Regular user	The user is a regular user

Sample read command:

14.3 Outlet access permissions

sum (variant)	cred/outlet_access/		
Access setting	Access settings for outlets		



The value is subject to the following constraints: any of the following is true:

- the value is equal to true
- · the value is equal to false
- length of the value is equal to length of outlets

This sum does not support direct modification.

This sum can assume the following values:

constant true	Full	State of all outlets can be manipulated by the user
constant false	None	Outlet states cannot be neither seen nor manipulated by the user
array	Outlet access levels	Access levels per outlet

Sample read command:

 \Rightarrow (possible variant)

false

See also Outlet access permissions: Outlet access levels

14.4 Outlet access permissions: Outlet access levels

(possibly) array	cred/outlet_access/	
Access levels per outlet		

This array contains Outlet access elements.

Creating elements in this collection is not supported.

14.4.1 Outlet access

sum (boolean)	cred/outlet_access/N/	
Access level for outlet by index		

The value is subject to the following constraints: outlets[index of the value]

This sum does not support direct modification.

This sum can assume the following values:

constant true	Full	Outlet state can be manipulated by the user	
constant false	None	Outlet state cannot be neither seen nor manipulated by the user	

Sample read command (note that :outlet_access is a URL template argument and needs to be replaced before trying):

14.5 Agent identifier

string	cred/agent/
Identifier of the agent performing request	

This string does not support direct modification.

Sample read command:

14.6 Client IP address, if any

```
sum (optional string) cred/ip_address/
IPv4 address of the client performing request, if any
```

This sum does not support direct modification.

This sum can assume the following values:

constant null	Client IP address absent or	The request is performed locally, or its origin is un-	
	unknown	known	
string	Client IP address	IPv4 address of the client per- forming request	the value matches ^(([0-9] [1-9][0-9] 1[0-9]{2} 2[0-4][0-9] 25[0-5]).){3}([0-9] [1-9][0-9] 1[0-9]{2} 2[0-4][0-9] 25[0-5])\$

Sample read command:

```
curl --digest -u admin:1234 -H "Accept: application/json" "https://192.168.0.100/ \leftarrow restapi/cred/ip_address/"
```

 \Rightarrow (possible variant)

null

14.6.1 Client IP address

(possibly) string	cred/ip_address/
IPv4 address of the	he client performing request

The value is subject to the following constraints: the value matches (([0-9]|[1-9][0-9]|1[0-9]|2)|2[0-4][0-9]|25[0-5]).)(3)([0-9]|[1-9][0-9]|2[0-4][0-9]|25[0-5])