

Muffler Delete




All potentiometers are Linear 100kOhm

Connectors




This board is intended to have the boost and main saturation circuits wired off-board using 3pdt footswitches

Clipping Diodes Mod



Selectable clipping modes using a switch, allowing the player to choose between a classic big muff sound, or a more "overdrivy" sound using LED clipping

Linear Power Booster



C15 and R21//R22 form an HPF The gain is given by Av = -R22/R23