

# Boom Height Controller – Diagnosing Hydraulic Delay

## Delay Too Low

Symptoms: oscillation, chasing ground.

Fix: increase hydraulicDelaySec.

## Delay Too High

Symptoms: sluggish, early response.

Fix: decrease hydraulicDelaySec slightly.